MITSUBISHI **ELECTRIC**

OPTIONAL DEFROS

MAC-646BH-E

SPLIT-TYPE AIR CONDITIONERS OUTDOOR UNIT DEFROST HEATER **INSTALLATION MANUAL**

BEFORE INSTALLATION

The defrost heater prevents freezing of outdoor unit base. The base may freeze when th The drain socket cannot be attached after fixing the defrost heater.


- Wear protective equipment such as gloves for your safety.
- Be careful not to cut your hands with the aluminum tape.
- Be careful not to wet electrical parts with water or snow during installation. Wet electric Do not install the outdoor unit directly on the ground. Install the outdoor unit on a rais

Components

1 Defrost heater	1	4	Self drilling screw	2	\bigcirc	Wiring diagram	1
② Aluminum tape	1	5	Cable clamp	1	8	Spec label	1
③ Heater support	1	6	Insulation	1			


PREPARING FOR INSTALLATION

- (1) Make sure to switch off the power supply or turn off the breaker.
- (2) Remove the top panel, front panel, service panel, motor support, and elect assy. (3) Remove the separator and the reactor.




INSTALLING THE HEATER


(1) Hold the left lower side of the heat exchanger, and slightly lift up the heat exchanger. (2) Insert the defrost heater ① under the heat exchanger, and align it with the groove on the base. After positioning the defrost heater ①, secure it to the base with the aluminum tape ②. In order to fix the defrost heater ① to the base, fix the heater support ③ to the base with 2 self drilling screws ④. (3) Put the heat exchanger back in place (refer to the figure below).




OST HEATER	Specif	JG79J553H01 ications	 THE FOLLOWING SHOULD ALWAYS BE OBSERVED FOR SA Be sure to read these safety precautions and instructions. Be sure to observe the warnings and cautions specified here as they include important item After reading this manual, be sure to store it for future reference. 		
-E	Rated Voltage	Electric Power	A WAR		
	230 V formed for a long time in very low temp	130 W berature, high humidity conditi	 Do not install the unit by yourself (user). Incomplete installation could cause fire, electric shock, or injury due to the unit falling, or leakage of water. Consult the dealer from whom you purchased the unit or a qualified installer. Earth the unit correctly. Do not connect the earth to a gas pipe, water pipe, lightning rod, or telephone earth. Defective earthing could cause electric shock. 		
			<u>Á</u> CAU		
ectrical parts could cause ma aised platform, such as on ra			 install an earth leakage breaker if necessary. (i.e. in places where there is moisture) Failure to install an earth leakage breaker may result in electric shock. 		



- Cut off the surplus part of the cable clamp (5).



- (3) Reinstall the front panel, top panel, and service panel.
- (4) Turn on the breaker, and perform test run to confirm that it works properly. Note: Do not install either drain socket which is provided with the outdoor unit or purchased separately.
 - Inside of the drain hose and/or drain socket may freeze if the drain socket is installed.



SAFETY

tems related to safety.

RNING (Could lead to death, serious injury, etc.)

Be sure to use the parts provided or specified parts for the installation work. Incomplete installation could cause fire, electric shock, or injury.

Spec name plate

Spec label (8)

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN