



CHILLERS AND HEAT PUMPS - Installation Maintenance Manual

**ANL
ANL H
ANL C**



Dear Customer,

Thank you for choosing an AERMEC product. This product is the result of many years of experience and in-depth engineering research, and it is built using top quality materials and advanced technologies.

Moreover, the CE mark guarantees that our appliances fully comply with the requirements of the European Machinery Directive in terms of safety. We constantly monitor the quality level of our products, and as a result AERMEC products are synonymous with Safety, Quality, and Reliability.

Product data may be subject to modifications deemed necessary for improving the product without the obligation to give prior notice.

Thank you again.
AERMEC S.p.A

AERMEC S.p.A. reserves the right at any moment to make any modifications considered necessary to improve our products and is not obliged to add these modifications to machines that have already been fabricated, delivered or are under construction.

SUMMARY

1. General warnings	6	9.6.2. On/Off Control(IA)	26
1.1. Preservation of the documentation	6	9.6.3. Remote Alarm (AE)	26
1.2. Warnings regarding safety and installation Standards.....	6	9.6.4. Remote Panel (TRA)	26
2. Selection and place of installation	7	9.6.5. Contact for thermostating domestic hot water DHW (TWS)	26
3. Positioning	7	9.6.6. Connection PR3 (ACCESSORY)	26
4. Internal hydraulic circuit	8	10. Control and commissioning	27
5. external hydraulic circuit ANL (not provided)	8	10.1. Preparation for commissioning.....	27
6. Loading the system	9	10.2. Machine commissioning	27
7. Emptying the system	9	10.3. Season changeover.....	27
8. Dimension tables and hydraulic fitting positions. 10		10.3.1. Season changeover from panel on machine.....	27
8.2.1. ANL 020 - 025 ° - °P/H - HP	10	10.3.2. Season changeover from PR3	27
8.2.2. ANL 030 - 040 ° - °P/H - HP	11	11. Functioning features	28
8.2.3. ANL 050 - 070 - 080 - 090 ° - °P/H - HP.....	12	11.1. Set Point in cooling mode.....	28
8.2.4. ANL 020 - 025 °A/HA	13	11.2. Set Point in heating mode	28
8.2.5. ANL 030 - 040 °A/HA	14	11.3. Compressor start-up delay	28
8.2.6. ANL 050 - 090 °A/HA	15	11.4. Circulation pump.....	28
8.2.7. ANL 100-150-200 ° - °P - °A / H - HP - HA.....	16	11.5. Fan speed control (dcpX accessory).....	28
8.2.8. ANL 020-025 C	17	11.6. Anti-freeze alarm.....	28
8.2.9. ANL 030-040 C	18	11.7. Water flow rate alarm.....	28
8.2.10. ANL 050-070-080-090 C	19	12. Maintenance	28
8.2.11. ANL 100-150-200 C	20	12.7.1. Hydraulic circuit.....	28
8.2.12. ANL 050-070-080-090 D HD	21	12.7.2. Electric circuit checks	28
8.2.13. ANL 100 - 150 - 200 D HD	22	12.7.3. Cooling circuit checks	28
9. Electric connections	23	12.7.4. Mechanical checks.....	28
9.1. Electric data in cooling mode.....	23	12.1. Extraordinary maintenance	29
9.2. Electric data in heating mode	24	12.1.1. Load procedure	29
9.3. Recommended electric cable sections	24	13. List of controls for guided procedure	30
9.3.1. Recommended cable lengths for max. length of 50 mt.....	24		
9.4. Electric Control Board	25		
9.5. Electric power connection.....	25		
9.6. Auxiliary connections under the responsibility of the user/installer.....	26		
9.6.1. Summer/Winter Remote Control (C/F).....	26		

ANL ANLH

SERIAL NUMBER

**CE DECLARATION
OF CONFORMITY**

We, the undersigned, hereby declare under our own responsibility that the assembly in question, defined as follows:

NAME ANLI
TYPE WATER/AIR chiller, heat pump
MODEL

To which this declaration refers, complies with the following harmonised standards:

CEI EN 60335-2-40 Safety standard regarding electrical heat pumps, air conditioners and dehumidifiers
CEI EN 61000-6-1 Immunity and electromagnetic emissions for residential environments
CEI EN 61000-6-3
CEI EN 61000-6-2 Immunity and electromagnetic emissions for industrial environments
CEI EN 61000-6-4
EN378 Refrigerating systems and heat pumps - Safety and environmental requirements
EN12735 Copper and copper alloys - Seamless, round copper tubes for air conditioning and refrigeration
UNI 12735 Seamless, round copper tubes for air conditioning and refrigeration
UNI 14276 Pressure equipment for cooling systems and heat pumps

Therefore complying with the essential requirements of the following directives:

- LVD Directive: 2006/95/CE
- Directive for electromagnetic compatibility 2004/108/CE
- Machinery Directive 98/37/CE
- PED Directive regarding pressurised devices 97/23/CE

The product, in agreement with Directive 97/23/CE, satisfies the Total quality Guarantee procedure (form H) with certificate n.06/270-QT3664 Rev.3 issued by the notified body n.1131 CEC via Pisacane 46 Legnano (MI) - Italy

Bevilacqua

15/01/2008

Marketing Manager
Signature



ANLC

SERIAL NUMBER

**CE DECLARATION
OF CONFORMITY**

We, the undersigned, hereby declare under our own responsibility that the assembly in question, defined as follows:

NAME **ANLC**
TYPE **MOTORCONDENSINGchiller**
MODEL

To which this declaration refers, complies with the following harmonised standards:

CEI EN 60335-2-40 Safety standard regarding electrical heat pumps, air conditioners and dehumidifiers
CEI EN 61000-6-1
CEI EN 61000-6-3 Immunity and electromagnetic emissions for residential environments
CEI EN 61000-6-2
CEI EN 61000-6-4 Immunity and electromagnetic emissions for industrial environments
EN378 Refrigerating systems and heat pumps - Safety and environmental requirements
EN12735 Copper and copper alloys - Seamless, round copper tubes for air conditioning and refrigeration
UNI 12735 Seamless, round copper tubes for air conditioning and refrigeration
UNI 14276 Pressure equipment for cooling systems and heat pumps

Therefore complying with the essential requirements of the following directives:

- LVD Directive: 2006/95/CE
- Directive for electromagnetic compatibility 2004/108/CE
- PED Directive regarding pressurised devices 97/23/CE

The product, in agreement with Directive 97/23/CE, satisfies the Total quality Guarantee procedure (form H) with certificate n.06/270-QT3664 Rev.3 issued by the notified body n.1131 CEC via Pisacane 46 Legnano (MI) - Italy


DECLARATION OF INCORPORATION

We, the undersigned, declare under our own responsibility, in compliance with paragraph 2, art. 4 of the Machinery Directive 98/37/CE, that start-up is prohibited before the machine in which it has been incorporated has been declared conform with the provisions of the Machinery Directive and/or all applicable Directives.

Bevilacqua

15/01/2008

Marketing Manager
Signature



1. GENERAL WARNINGS

Standards and Directives respected on designing and constructing the unit:

Safety:

Machinery Directive
98/37/CE

Low Voltage Directive
LVD 2006/95/CE

Electromagnetic compatibility Directive
EMC 89/336/EEC

Pressure Equipment Directive
PED 97/23/CE EN 378,
UNI EN 14276

Electric part:

EN 60204-1

Protection rating
IP24

Acoustic part:

ISO DIS 9614/2
(intensimetric method)

Certifications:

Eurovent
NF x ANLI 020H

Refrigerant GAS:

This unit contains fluoride gases with greenhouse effect covered by the Kyoto Protocol. Maintenance and disposal must only be performed by qualified staff.

R410A GWP=1900

AERMEC ANLs are constructed according to the recognised technical standards and safety regulations. They have been designed for air conditioning and the production of domestic hot water (DHW) and must be destined to this use compatibly with their performance features. Any contractual or extra-contractual liability of the Company is excluded for injury/damage to persons, animals or objects owing to installation, regulation and maintenance errors or improper use. All uses not expressly indicated in this manual are prohibited.

1.1. PRESERVATION OF THE DOCUMENTATION

The instructions along with all the related documentation must be given to the user of the system, who assumes the responsibility to conserve the instructions so that they are always at hand in case of need.

Read this sheet carefully; the execution of all works must be performed by qualified staff, according to Standards in force on this subject in different countries. (Ministerial Decree 329/2004).

The appliance must be installed in such a way as to enable maintenance and/or repairs to be carried out.

The appliance warranty does not cover the costs for ladder trucks, scaffolding,

or other elevation systems that may become necessary for carrying out servicing under warranty.

Do not modify or tamper with the chiller as dangerous situations can be created and the manufacturer will not be liable for any damage caused. The validity of the warranty shall be void in the event of failure to comply with the above-mentioned indications.

1.2. WARNINGS REGARDING SAFETY AND INSTALLATION STANDARDS

- The chiller must be installed by a qualified and suitably trained technician, in compliance with the national legislation in force in the country of destination (Ministerial Decree 329/2004).
AERMEC will not assume any responsibility for damage due to failure to follow these instructions.
- Before beginning any operation, READ THESE INSTRUCTIONS CAREFULLY AND CARRY OUT THE SAFETY CHECKS TO REDUCE ALL RISK OF DANGER TO A MINIMUM. All the staff involved must have thorough knowledge of the operations and any dangers that may arise at the moment in which the installation operations are carried out.



Danger!

The refrigerant circuit is under pressure. Moreover, very high temperatures can be reached. The appliance may only be opened by an SAT service technician or by a qualified technician.

Work on the cooling circuit may only be carried out by a qualified refrigeration technician.



R410A REFRIGERANT GAS


The cooler comes supplied with a sufficient quantity of R410A refrigerant gas. This refrigerant is chlorine-free and does not damage the ozone layer. R410A is not flammable. However, all maintenance operations must be carried out exclusively by a specialised technician using suitable protective equipment.



Danger of electrical discharge!

Before opening the heat pump, completely disconnect the appliance from the power mains.

FOR THE INSTALLER



2. SELECTION AND PLACE OF INSTALLATION

Before beginning installation consent with client and pay attention to the following recommendations:

- The support surface must be capable of supporting the unit weight.
- The safety differences between the unit and other appliances or structures must be scrupulously respected so that the inlet and outlet air from the fans is free to circulate.
- The unit must be installed by an enabled technician in compliance with the national legislation in force in the country of destination, respecting the minimum technical spaces in order to allow maintenance.

3. POSITIONING

Before handling the unit, verify the lifting capacity of the machines used, respecting the indications given on the packaging.

To handle the machine (ANL 020-090) on horizontal surfaces, use fork lift trucks or similar in the most appropriate man-

ner, paying attention to the distribution of the unit weight.


In the case of lifting (ANL 100-200), insert pipes into the holes supplied on the base (NOT SUPPLIED). The length of the pipes must be such to allow positioning of the lifting belts and relative safety pins.

Position the unit in the place indicated by the customer, placing a rubber covering between the base and the support (min. thickness 10 mm.) or alternatively anti-vibrating feet (ACCESSORIES).


For further information, refer to the dimensional tables

Fix the unit checking that it is level. Make sure that the hydraulic and electric part can be easily reached.


In case of installation in places where gusts of wind are frequent, fix the unit suitably using tie-rods. Envision the installation of the condensate drain tray in the versions where envisioned (as ACCESSORY).



ANL 020 - 025 - 030 - 040



ANL 050 - 080 - 090




ANL 100-150-200

1100

EXAMPLE OF HYDRAULIC CIRCUITS

the diagrams shown here are an example



version with pump only




fig 1




fig 2

version A
ANL 020÷040
WITH
FLOODED
EVAPORATOR

fig 3

version A A
ANL 100 - 150 - 200

KEY

- 1 Circulator/pump
- 2 Differential pressure switch/flow meter (ANL 020÷040A)
- 3 Safety valve
- 4 Expansion vessel
- 5 Water filter
- 6 Plate heat exchanger (inside the storage tank in ANL 020÷040A)
- 7 Vent valve
- 8 Storage
- 9 Electric resistance (ACCESSORY)

4. INTERNAL HYDRAULIC CIRCUIT

The internal hydraulic circuit of the ANL is made up according to the version:

Standard version

- Fitted water filter
- Differential pressure switch
- Plate heat exchanger
- Water inlet/outlet probes (SIW-SUW)

P version with pump (fig.1)

- Fitted water filter
- Discharge tube
- Safety valve
- Circulator/pump
- Differential pressure switch
- Plate heat exchanger
- Water inlet/outlet probes (SIW-SUW)
- Expansion vessel

"ANL °/H version A" (fig. 2/3)

(with storage tank and pumps)

Internally flooded in the evaporator for sizes from 020 to 040

Outside the storage tank for sizes from 050 to 200

- Water flow switch (for sizes 020-025-030-040)
- Differential pressure switch (for sizes from 050 to 200)
- Filter
- Circulator/Pump
- Storage tank
- Safety valve (calibrated 6 bar)
- Expansion vessel
- Manual air vent valve
- Water inlet/outlet probes (SIW- SUW)

"ANL C"

This version does not have a hydraulic circuit.

5. EXTERNAL HYDRAULIC CIRCUIT ANL (NOT PROVIDED)

The choice and the installation of components external to the ANL is up to the installer, who must operate according to the rules of good technical design and in compliance with the regulations in force in the country of destination (Ministerial Decree 329/2004). Before connecting the pipes make sure that they do not contain stones, sand, rust, sludge or foreign bodies that could damage the system. It is good practice to realise a unit by-pass to

be able to wash the pipes without having to disconnect the appliance. The connection pipes must be adequately supported so that its weight is not borne by the appliance.

It is recommended to install the following tools on the evaporator water circuit, whenever not envisioned in the version in your possession:

1. two manometers with suitable scale (in inlet and outlet).
2. Two anti-vibration joints (in inlet and in outlet).
3. Two cut-off valves (in normal input, in calibration valve output).
4. A flow meter (in inlet) or a differential pressure switch (inlet - outlet).
5. two thermometers (in inlet and in outlet).
6. Pump (if not supplied with the machine)
7. Expansion vessel (if not supplied with the machine)
8. Safety valve (if not supplied with the machine)
9. Storage tank (if not supplied with the machine)

It is necessary that the cooling unit water flow rate is in compliance with the values given in the performance tables. The system water content must be such to prevent functioning inefficiency of the cooling circuits.

An appropriate load/reintegration system must be prepared for the ANL A chillers, which is engaged on the return line along with a drain cock in the lower part of the system.

The systems loaded with anti-freeze or particular legal dispositions, make the use of water disconnectors mandatory. Supply/reintegration water details must be conditioned with appropriate treatment systems.

PH	6-8
Electric conductivity	less than 200 mV/cm (25°C)
Chloride ions	less than 50 ppm
Sulphuric acid ions	less than 50 ppm
Total iron	less than 0,3 ppm
Alkalinity M	less than 50 ppm
Total hardness	less than 50 ppm
Sulphur ions	none
ammonia ions	none
Silicone ions	less than 30 ppm

6. LOADING THE SYSTEM

- Before starting loading, check that the system drain cock is closed.
- Open all system vent valves and relative terminals.
- Open the system cut-off devices.
- Start filling by slowly opening the system water loading cock outside the appliance.
- When water starts to escape from the terminal vent valves, close them and continue loading until
- the value of 1.5 bar is read on the manometer.
-
- The system must be loaded at a pres-

- sure between 1 and 2 bar.
- It is recommended to repeat this operation after the appliance has functioned for a few hours and to periodically check the system pressure, reintegrating it
- if it falls below 1 bar.
- Check the hydraulic sealing of the joints.

7. EMPTYING THE SYSTEM

- Before beginning emptying, place the master switch at "OFF"


- Check that loading/water system reintegration cock is closed
- Open the drain cock outside the appliance and all system vent valves and relative terminals.

If anti-freeze is used by the unit, it must not be dumped as it is harmful to the environment. It should be collected and if possible reused.


If discharge takes place after functioning in heat pump mode, pay attention to the temperature of the water (also 50°).

8. DIMENSION TABLES AND HYDRAULIC FITTING POSITIONS

8.2.1. ANL 020 - 025 °- °P/H - HP




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT VT
				Gx	Gy	
020	°/H	°	75	174	325	9
020	°/H	P	77	177	326	9
025	°/H	°	75	174	325	9
025	°/H	P	77	177	326	9






Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.2. ANL 030 - 040 °P/H - HP




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT
				Gx	Gy	
030	°/H	°	86	183	336	9
030	°/H	P	91	180	327	9
040	°/H	°	86	183	336	9
040	°/H	P	91	180	327	9






Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.3. ANL 050 - 070 - 080 - 090 °-P/H - HP




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT VT
				Gx	Gy	
050	°/H	°	120	213	447	9
050	°/H	P	127	212	436	9
070	°/H	°	120	213	447	9
070	°/H	P	127	212	436	9
080	°/H	°	156	217	453	9
080	°/H	P	163	216	444	9
090	°/H	°	156	217	453	9
090	°/H	P	163	216	444	9




Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.4. ANL 020 - 025 °A/HA




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT VT
				Gx	Gy	
020	°/H	A	99	177	326	9
025	°/H	A	99	177	326	9






Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.5. ANL 030 - 040 °A/HA




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT VT
				Gx	Gy	
030	°/H	A	103	180	327	9
040	°/H	A	103	180	327	9




Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.6. ANL 050 - 090 °A - °Q/HA - HQ




ANL	MOD.	VERS.	WEIGHTS	BARYCENTRES		KIT VT
				Gx	Gy	
050	°/H	A	147	212	436	15
	°/H	Q	151	212	436	15
070	°/H	A	147	212	436	15
	°/H	Q	151	212	436	15
080	°/H	A	183	216	444	15
	°/H	Q	187	216	444	15
090	°/H	A	183	216	444	15
	°/H	Q	187	216	444	15




Mod.	A	B	C	D
VT 15	50	30	28,5	M10

8.2.7. ANL 100-150-200 ° - °P - °A - °Q / H - HP - HA - HQ







	VERS.	WEIGHTS	BARYCENTRES		KIT VT
			Gx	Gy	
ANL100	°	270	381	620	15
	P	288	382	659	15
	A	338	382	659	15
ANL100H	°	295	381	604	15
	P	313	381	640	15
	A	363	381	640	15
ANL150	°	293	383	650	15
	P	314	383	693	15
	A	364	383	693	15
ANL150H	°	322	382	630	15
	P	343	382	671	15
	A	393	382	671	15
ANL 200	°	329	383	600	15
	P	350	383	641	15
	A	400	383	641	15
ANL 200H	°	358	383	586	15
	P	379	383	626	15
	A	429	383	626	15







Mod.	A	B	C	D
VT 15	50	30	28,5	M10

8.2.8. ANL 020-025 C





Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.9. ANL 030-040 C










Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.10. ANL 050-070-080-090 C








Mod.	A	B	C	D
VT9	40	30	23	M8

8.2.11. ANL 100-150-200 C







Mod.	A	B	C	D
VT 15	50	30	28,5	M10

8.2.12. ANL 050-070-080-090 D HD - DA - HDA



Mod.		A	B	C	D
VT9	D-HD	40	30	23	M8
VT15	DA-HDA	50	30	28,5	M10

8.2.13. ANL 100 - 150 - 200 D HD



Mod.	A	B	C	D
VT 15	50	30	28,5	M10

9. ELECTRIC CONNECTIONS

The ANL chillers are completely wired at the factory and only require connection to the electrical mains, downstream from a unit switch, according to that envisioned by the Standards in force on this subject in the country of installation. It is also advised to check that:

- the electrical mains features are suitable for the absorption values indicated in the electrical data table (CHAPTER 7), also taking into consideration any other machines operating at the same time.
- The unit is only powered when installation has been completed (hydraulic and electric).
- Respect the connection indications of the phase, neutral and earth wires.
- The power supply line must have a relevant protection mounted upstream against short circuits and dispersions to earth, which isolates the system with respect to other utilities.
- The voltage must be within a tolerance of $\pm 10\%$ of the nominal power supply voltage of the machine (for unbalanced three-phase unit max 3% between the phases). Whenever these parameters are not respected, contact the electric



All the electrical operations must be carried out by STAFF IN POSSESSION OF THE NECESSARY QUALIFICATIONS BY LAW suitably trained and informed on the risks related to these operations.



The characteristics of the electrical lines and of the related components must be determined by STAFF QUALIFIED TO DESIGN ELECTRICAL SYSTEMS, in compliance with the international and national regulations of the place of installation of the unit and in compliance with the regulations in force at the moment of installation



For the installation requirements refer only to the electrical diagram supplied with the appliance. The electrical diagram along with the manuals must be kept in good condition and ALWAYS AVAILABLE FOR ANY FUTURE SERVICING ON THE UNIT.



IT IS mandatory to verify that the machine is watertight before making the electrical connections and it must only be powered up after the hydraulic and electrical works have been completed.

- energy public body. For electric connections, use the cables with double isolation according to the Standards in force on this subject in the different countries.
- The use of an omnipolar magnet circuit breaker switch is mandatory, in compliance with the IEC-EN Standards (contact opening at least 3 mm), with suitable cut-off power and differential protection on the basis of the electric data table shown below, installed as near as

- possible to the appliance.
- It is mandatory to make an effective earth connection. The manufacturer cannot be considered responsible for any damage caused by the lack of or ineffective appliance earth connection.
- For units with three-phase power supply, check the correct connection of the phases.

It is prohibited to use the water pipes to earth the appliance.

9.1. ELECTRIC DATA IN COOLING MODE

COOLING			020°	025°	030°	040°	050°	070°	080°	090°	100°	150°	200°	
Total input power	(°)	kW	1,84	2,00	2,46	3,25	4,03	4,88	6,33	6,63	8,4	10,0	13,7	
	A/P	kW	1,99	2,15	2,61	3,40	4,30	5,15	6,60	6,90	9,00	11,00	14,70	
	Q	kW	N.D.	N.D.	N.D.	N.D.	4,48	5,33	6,78	7,08	9,40	11,30	15,00	
Total input current (without circulation pump)	(°)	400V	A	3,7	4,2	4,70	6,2	8,7	9,7	12,2	12,8	16,7	18,8	25,7
		230V		9,4	10,0	13,0	16,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
	A/P	400V	A	4,7	5,2	5,70	7,2	10,7	11,7	14,2	14,8	17,90	20,80	27,70
Total input current (with circulation pump)		230V		10,4	11,0	14,0	17,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
	Q	400V		N.D.	N.D.	N.D.	N.D.	11,4	12,4	14,9	15,5	18,70	21,40	28,30
		400V	A	6	6	6,7	8,7	11,3	13,5	16,3	17,3	22	26	34
Maximum current (FLA) (without circulation pump)	(°)	230V	A	16,5	16,5	19,7	23,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
		400V		7	7	7,7	9,7	13,3	15,5	18,3	19,3	23,4	28,8	36,8
	A/P	230V	A	17,5	17,5	20,7	24,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Maximum current (FLA) (with circulation pump)		400V		N.D.	N.D.	N.D.	N.D.	14,0	16,2	19,0	20,0	24,8	29,5	37,5
	(°)	400V	A	26,5	32,5	35,7	48,7	65,3	75,3	102,3	96,3	76,0	87,0	117,0
		230V		59,5	62,5	83,7	98,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Peak current (LRA) (without circulation pump)	A/P	400V	A	27,5	33,5	36,7	49,7	67,3	77,3	104,3	98,3	77,4	89,8	119,8
		230V		60,5	63,5	84,7	99,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
	Q	400V		N.D.	N.D.	N.D.	N.D.	68,0	78,0	105,0	99,0	78,8	90,5	120,5

SAFETY AND CONTROL COMPONENTS ELECTRIC DATA

Fan magnet circuit breakers MTV1		A	2	2	2	2	2	2	2	2	2	2	2	2
Fan magnet circuit breakers MTV2		A	-	-	-	-	2	2	2	2	2	2	2	2
Compressors magnet circuit breakers MTC1	230V	A	16	16	20	25	18	21	25	25	-	-	-	-
Compressors magnet circuit breakers MTC1	400V	A	2,2	2,2	6	8	10	13	15	16	10/10	12,5/12,5	15/15	
High pressure pressure switch		bar	42	42	42	42	42	42	42	42	42	42	42	42
Low pressure pressure switch	cold	bar	2	2	2	2	2	2	2	2	2	2	2	2
Low pressure transducer	cold	bar	4	4	4	4	4	4	4	4	4	4	4	4
	CP	bar	2	2	2	2	2	2	2	2	2	2	2	2
High pressure transducer		bar	40	40	40	40	40	40	40	40	40	40	40	40

9.2. ELECTRIC DATA IN HEATING MODE

COOLING				020H	025H	030H	040H	050H	070H	080H	090H	100H	150H	200H
Total input power	(°)		kW	1,84	2,00	2,46	3,25	4,03	4,88	6,33	6,63	8,6	10,2	13,9
	A/P		kW	1,99	2,15	2,61	3,40	4,30	5,15	6,60	6,90	9,20	11,20	14,90
	Q		kW	-	-	-	-	4,48	5,33	6,78	7,08	9,60	11,50	15,20
HEATING														
Total input power	(°)		kW	1,91	2,12	2,62	3,18	4,30	4,90	6,30	6,85	8,6	10,1	13,3
	A/P		kW	2,06	2,27	2,77	3,33	4,57	5,17	6,57	7,12	9,20	11,10	14,30
	Q		kW	-	-	-	-	4,75	5,35	6,75	7,30	9,60	11,40	14,60
ELECTRICAL DATA														
Total input current when COLD (version without circulation pump)	(°)	400V-3	A	3,7	4,2	4,70	6,2	8,7	9,7	12,2	12,8	17,0	19,2	26,2
		230V-1		9,4	10,0	13,0	16,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Total input current when COLD (version with circulation pump)	A/P	400V-3	A	4,7	5,2	5,70	7,2	10,7	11,7	14,2	14,8	18,2	21,2	28,2
		230V-1		9,4	10,0	13,0	16,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
		Q	400V-3		N.D.	N.D.	N.D.	N.D.	11,4	12,4	14,9	15,5	19,0	21,8
Total input current when HOT (version without circulation pump)	(°)	400V-3	A	3,8	4,4	5,4	6,8	9,5	10,3	12,9	13,8	17,0	19,0	25,0
		230V-1		10,4	11,0	14,0	17,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Total input current when HOT (version with circulation pump)	A/P	400V-3	A	4,8	5,4	6,4	7,8	11,5	12,3	14,9	15,8	18,2	21,0	27,0
		230V-1		10,4	12,3	14,0	19,3	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
		Q	400V-3		N.D.	N.D.	N.D.	N.D.	12,2	13,0	15,6	16,5	19,0	21,6
Maximum current (FLA) (version without circulation pump)	(°)	400V-3	A	6	6	6,7	8,7	11,3	13,5	16,3	17,3	22,0	26,0	34,0
		230V-1		16,5	16,5	19,7	23,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Maximum current (FLA) (version with circulation pump)	A/P	400V-3	A	7	7	7,7	9,7	13,3	15,5	18,3	19,3	23,4	28,8	36,8
		230V-1		17,5	17,5	20,7	24,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
		Q	400V-3		N.D.	N.D.	N.D.	N.D.	14,0	16,2	19,0	20,0	24,8	29,5
Peak current (LRA) (version without circulation pump)	(°)	400V-3	A	26,5	32,5	35,70	48,7	65,3	75,3	102,3	96,3	76,0	87,0	117,0
		230V-1		59,5	62,5	83,70	98,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
Peak current (LRA) (version with circulation pump)	A/P	400V-3	A	27,5	33,5	36,70	49,7	67,3	77,3	104,3	98,3	77,4	89,8	119,8
		230V-1		60,5	63,5	84,7	99,7	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.	N.D.
		Q	400V-3		N.D.	N.D.	N.D.	N.D.	68,0	78,0	105,0	99,0	78,8	90,5
PEAK CURRENT (LRA)(VERSION WITH CIRCULATION PUMP)														
Fan magnet circuit breakers MTV1		A	2	2	2	2	2	2	2	2	2	2	2	2
Fan magnet circuit breakers MTV2		A	-	-	-	-	2	2	2	2	2	2	2	2
Compressors magnet circuit breakers MTC1/2		230V-1	A	16	16	20	25	-	-	-	-	-	-	-
		400V-3	A	2,2	2,2	6	8	10	13	15	16	10/10	12,5/12,5	15/15
High pressure pressure switch		bar	42	42	42	42	42	42	42	42	42	42	42	42
Low pressure pressure switch	Cold	bar	2	2	2	2	2	2	2	2	2	2	2	2
Low pressure transducer	Cold	bar	4	4	4	4	4	4	4	4	4	4	4	4
High pressure transducer		bar	40	40	40	40	40	40	40	40	40	40	40	40

9.3. RECOMMENDED ELECTRIC CABLE SECTION

The cable sections stated in the table are recommended for a maximum length of 50 m and placed in a cable trough.

For longer lengths or different cable laying, it is up to the PLANNER to

calculate the appropriate length of the cables as well as the connection to the earth wire and linking to connected cables:

- the length
- the type of cable
- the absorption of the unit and the physical location, and the ambient temperature.

NOTE:

Check the tightening of all power wire clamps on commissioning and after 30 days from start-up. Subsequently, check the tightening of all the power clamps every six months. Loose terminals can cause overheating of the cables and components.

9.3.1. Recommended cable lengths for max. length of 50 mt

			020	025	030	040	050	070	080	090	100	150	200
SEC A	230V-1	mm ²	4	4	6	6	-	-	-	-	-	-	-
	400V-3	mm ²	2,5	2,5	2,5	2,5	4	4	6	6	10	16	16
SEC B	230V-1	mm ²	0,5	0,5	0,5	0,5	-	-	-	-	-	-	-
	400V-3	mm ²	0,5	0,5	0,5	0,5	0,5	0,5	0,5	0,5	0,5	0,5	0,5
Earth	230V-1	mm ²	4	4	6	6	-	-	-	-	-	-	-
	400V-3	mm ²	2,5	2,5	2,5	2,5	4	4	6	6	10	16	16
IL	230V-1	A	25	25	25	32	-	-	-	-	-	-	-
	400V-3	A	16	16	16	16	16	16	25	25	25	45	45


SEC A Power supply

SEC B Remote control if present

Earth

IL Master switch

9.4. ELECTRIC CONTROL BOARD











The electric control board is situated inside the machine.

To access the electric control board and make the electric connections, in the sizes from 020 to 090 the upper and front panel must be removed, in sizes 100 - 200 act on the screw with ¼ of a turn and open the front panels.

9.5. ELECTRIC POWER CONNECTION

For the functional connection of the unit take the power supply cable at the electric control board inside the unit fig.1 and connect to the isolator clamps respecting the phase, the neutral and the earth both in the case of single-phase (230V~50Hz), and three-phase power supply (400V-3N~50Hz). fig.2



KEY

- 121 4-way connector
- 201 Magnet circuit breaker
- 202 Door-lock isolating switch
- 203 Contactor
- 204 Unipolar automatic switch
- 207 Pressure transducer
- 209 Moducontrol Board
- 210 Door-lock handle
- 211 Condenser
- 213 NTC probe
- 214 Pressing line gas probe
- 215 Board connection cable
- 216 Electric box
- 220 Contact
- 221 Screw feet
- 222 Terminal board kit for board
- 223 NTC probe 10K L=3000
- 226 Pressure switch transducer cable TAP
- 227 Pressure switch transducer cable TBP

9.6. AUXILIARY CONNECTIONS UNDER THE RESPONSIBILITY OF THE USER/INSTALLER

All clamps to which reference is made in the following explanations are part of the 11 POLE terminal board situated inside the electric control board and connected to the MODUCONTROL, see figure.

There are two types of connections, see wiring diagram at the bottom of the page:

9.6.1. Summer/Winter Remote Control (C/F)

To prepare a summer/winter switch-over device, connect the device contact to clamps 3 and 5 of the 11 POLE terminal board,

9.6.2. On/Off Control (IA)

To prepare a remote ON/OFF switch-over device, connect the device contact to clamps 4 and 5 of the 11 POLE terminal board,

9.6.3. Remote Alarm (AE)

If it should be necessary to view the machine block, in a remote point, due to functioning anomaly, it is possible via clamps 6 and 7 of the 11 POLE terminal board. Connect an acoustic or visual alarm signal device.

9.6.4. Remote Panel (TRA)


To prepare a summer/winter switch-over device, connect the device contact to clamps 8 and 9 of the 11 POLE terminal board,

9.6.5. Contact for thermostating domestic hot water DHW (TWS)


To prepare a stand-alone thermostating device, connect to clamps 10 and 11 of the 11 POLE terminal board.

9.6.6. Connection PR3 (ACCESSORY)

If you should have the PR3 accessory, always connect it to the 11 POLE terminal board as shown below. Remember that the maximum distance accepted is 150 mt. REMEMBER THAT THE PR3 AS WELL AS BEING CONNECTED MUST BE ENABLED see page 31



11 pole terminal board



10. CONTROL AND COMMISSIONING

10.1. PREPARATION FOR COMMISSIONING

Please note that, on request by the Aermec customer or the legitimate owner of the machine, the units in this series can be started up by the AERMEC After-Sales Service in your area (valid only on Italian territory). The start of operation must be scheduled in advance based on the timeframe for the completion of works for the system. Prior to the work to be carried out by the AERMEC After-Sales Service, all other works (electrical and hydraulic connections, loading and bleeding of air from the system) must have been completed.



Before starting the unit make sure that:

- All safety conditions have been respected
- The unit is correctly fixed to the support surface
- The minimum technical spaces have been respected;
- The hydraulic connections have been made respecting the inlet and outlet
- The hydraulic plant has been loaded and bled.
- The hydraulic circuit cocks are open
- The electric connections have been made correctly
- The voltage is within the tolerance of 10% of the unit nominal value
- The earth connection has been made correctly
- All electric and hydraulic connections have been tightened well.

10.2. MACHINE COMMISSIONING

Before starting the unit:



- Close the electric control board hatch.
- Position the appliance master switch at ON. (fig.3)
- Make sure that the auxiliary switch contact (IA) (see wiring diagram) is open (if used) and the LED (I) A display must be off fig 4.
- Press the ON key for 3 sec to switch the machine on.



10.3. SEASON CHANGEOVER

- For every season change, check that the functioning limits lie within the limits.
- Check that the compressor input current is lower than the maximum indicated in the technical data table.
- Check, that in models with three-phase power supply, that the compressor noise level is not abnormal. If this is the case, invert a phase.
- Make sure that the voltage value lies within the pre-fixed limits and that unbalance between the three phases (three-phase power supply) is not above 3%.

10.3.1. Season changeover from panel on machine


Access the USER SET list by touching the  key, insert the 000 password key (already displayed); just confirm by re-pressing the  key. The parameter affected is the 0

For further information refer to the USER manual

N	CODE	NAME	Min	Default	Max	Meaning
0	Sta	Season	0	0	1	0 functioning in cooling mode 1 functioning in heating mode

10.3.2. Season changeover from PR3

- Just act directly on the switch
The machine switches off automatically and switches back-on with the selected functioning mode



WARNING

Commissioning must be performed with standard settings. Only when the inspection has been completed can the functioning Set Point values be changed. Before start-up, power the unit for at least 12-24 hours positioning the protection magnet circuit breaker switch and the door lock isolating switch at ON fig. 3 and then switch the control panel fig. 04 off in order to allow heating of the compressor sump oil.



11. FUNCTIONING FEATURES

11.1. SET POINT IN COOLING MODE

(factory set) = 7°C, $\Delta t = 5^\circ\text{C}$.

11.2. SET POINT IN HEATING MODE

(factory set) = 45°C, $\Delta t = 5^\circ\text{C}$.

If the unit power supply is restored after a temporary interruption, the set mode will be kept in the memory.

11.3. COMPRESSOR START-UP DELAY

Two functions have been prepared to prevent compressor start-ups that are too close.

- Minimum time from last switch-off 180 seconds.
- Minimum time from last switch-on 300 seconds.

11.4. CIRCULATION PUMP

The circuit board envisions an output for pump management, which starts on commissioning and remains on for at least 150 seconds and controls the state of the probes.

After the first 40 seconds that the pump functions, when the water flow rate is in normal working conditions, the water flow rate alarm functions are activated (differential pressure switch or flow meter).

When the machine enters stand-by mode, the pump remains on for 30 sec and controls the flow meter or the pressure switch

11.5. FAN SPEED CONTROL (DCPX ACCESSORY)

To allow correct functioning of the unit at different external temperatures, the MODUCONTROL by reading the pressure via the pressure probe, controls the rotation speed of the fans, thus allowing to increase and/or decrease heat exchange, keeping the condensation or evaporation pressures more or less constant. The fan functions independently with respect to the compressor.

Remember that the DCPX is mandatory for the production of DHW

11.6. ANTI-FREEZE ALARM

The anti-freeze alarm is never active if the machine is off or in stand-by mode. In order to prevent breakage of the plate heat exchanger due to freezing of the water it contains, the MODUCONTROL blocks the compressor and ignition of the resistance (ACCESSORY) if the temperature detected by the probe positioned at the outlet of the heat exchanger and in inlet to the chiller is below +4°C.

THIS ANTI-FREEZE SET TEMPERATURE CAN ONLY BE VARIED BY AN AUTHORISED AFTER-SALES CENTRE AND ONLY AFTER HAVING CHECKED THAT THERE IS ANTI-FREEZE

SOLUTION IN THE WATER SYSTEM.

The intervention of this alarm determines compressor block and not pump block, which remains active along with the switch-on of the resistance if installed.

To restore normal functions the temperature of the outlet water must rise above +4°C.

Rearm is manual.

WHENEVER THIS ALARM INTERVENES, WE ADVISE YOU CALL THE NEAREST AFTER-SALES SERVICE IMMEDIATELY.

11.7. WATER FLOW RATE ALARM

The MODUCONTROL manages a water flow rate alarm controlled by the differential pressure switch installed in series on the machine.

This type of safety device intervenes after the first 40 seconds of pump functioning, if the water flow rate is not sufficient.

The intervention of this alarm determines compressor and pump block.



WARNING

Inspection, maintenance and eventual repair work must be carried out only by a legally qualified technician.



Lack of control/maintenance can cause damage to persons or things.



For appliances installed near to the sea, the maintenance intervals must be halved.

12. MAINTENANCE

All cleaning is prohibited until the unit has been disconnected from the electric power supply mains.

Make sure there is no voltage present before operating.

Periodic maintenance is fundamental to keep the unit perfectly efficient under a functional and energetic point of view.

It is therefore essential to carry out periodic yearly controls for the:

12.7.1. Hydraulic circuit

- Refilling of water circuit
- Cleaning the water filter
- Control of flow switch/pressure switch
- Bleed the air from the circuit.
- Verify that the water flow rate to the evaporator is constant.
- Verify the thermal insulation of the hydraulic piping.
- Check the percentage of glycol where necessary

12.7.2. Electric circuit checks

- Safety efficiency
- Electric supply pressure
- Electrical Input
- Connection tightness
- Verify the operation of the carter compressor resistance

12.7.3. Cooling circuit checks

- State of compressor
- Efficiency of the plate heat exchanger resistance if envisioned
- Work pressure
- Leak test for watertightness control of the cooling circuit
- Functioning of high and low pressure pressure switches
- Carry out the appropriate checks on the filter dryer to check efficiency

12.7.4. Mechanical checks

- Check the tightening of the screws the compressors and the electrical box, as well as the exterior panelling of the unit. Insufficient fastening can lead to undesired noise and

- vibrations
- Check the condition of the structure. If there are any oxidised parts, treat with paint suitable to eliminate or reduce oxidation.

12.1. EXTRAORDINARY MAINTENANCE

the ANLs are filled with R410A gas and are inspected at the factory. Under normal conditions they do not require Technical Assistance related to control of refrigerant gas. Through time gas leakage may be generated from the joints, causing refrigerant to escape and discharge the circuit, causing appliance malfunctioning. In these cases the leakage points are to be discovered, repaired and the Gas circuit is to be replenished, respecting the December 28 1993 n°549 law.

12.1.1. Load procedure

The load procedure is the following:

- Empty and dry the entire cooling circuit using a vacuum pump connected to the low and high pressure socket until 10 Pa is read on the vacuum meter. Wait a few minutes and check that this value does not rise above 50 Pa.
- Connect the refrigerant gas cylinder or a load cylinder to the socket on the low pressure line.
- Load the amount of refrigerant gas indicated on the appliance features plate.
- After a few hours of functioning, check that the liquid indicator indicates the dry circuit (dry-green). In the case of partial loss, the circuit must be emptied completely before being re-loaded.
- The R410A refrigerant must only be loaded in the liquid state.
- Functioning conditions that are different to the nominal conditions can give rise to values that are greatly different.
- The sealing test or the search for leaks must only be performed using R410A refrigerant gas, checking using a suitable leak detector.
- In the cooling circuit it is prohibited to use oxygen or acetylene or other inflammable or poisonous gases because they are a cause of explosions or intoxication. We recommend to envision a machine book (not supplied, but the user's responsibility), which allows to keep track of the interventions performed on the unit. In this way it will be easy to suitably organise the interventions making research and the prevention of any machine breakdowns easier.
- Use the date to record date, type of intervention made (routine maintenance, inspection or repairs), description of the intervention, measures actuated...
- IT IS forbidden to RELOAD the circuit with a refrigerant gas different to the one indicated. Using a different refrigerant gas can cause serious damage to the compressor.

We recommend to envision a machine book (not supplied, but the user's responsibility), which allows to keep track of the interventions performed on the unit. In this way it will be easy to suitably organise the interventions making research and the prevention of any machine breakdowns easier.

Use the date to record date, type of intervention made (routine maintenance, inspection or repairs), description of the intervention, measures actuated...

IT IS forbidden to RELOAD the circuit with a refrigerant gas different to the one indicated. Using a different refrigerant gas can cause serious damage to the compressor.

DISPOSAL

Envisions that disposal of the unit is carried out in conformity with the Standards in force in the different countries



13. LIST OF CONTROLS FOR THE GUIDED PROCEDURE

Some parameters in the moducontrol board must be set appropriately on the basis of the type of system in which the

unit is installed. These modifications, performed by the installer, are summarised and organised in the following guided procedures, with which to correctly set the unit circuit board parameters.



How to modify a parameter in the user menu:

To enter the **USER menu** press the key shown in (Fig.A). Once the key has been pressed the password must be inserted for access to the various menus. To access the user menu the password is **000** (which is the default displayed); to modify the value of the password use the arrow keys. Once the correct password has been inserted, press the key shown in (Fig.A). The display shows the index of the **USER** parameter and a string of three characters that identify it. The string re-

mains displayed for one second, after which it is replaced by the value relative to the parameter itself. To pass to the next parameter, use the arrow keys (Fig.B). To modify a parameter, just select it, press the key shown in (Fig.A), modify the value using the arrow keys shown in (Fig.B). To confirm the modification press the key shown in (Fig.A) again.



PASSWORD = 000





How to modify a parameter in the installer menu:

To enter the **INSTALLER menu**, press the key shown in (Fig.A). Once the key has been pressed the password must be inserted for access to the various menus. To access the user menu the **password is 030**. To modify the value of the password use the arrow keys. Once the correct password has been inserted, press the key shown in (Fig.A). The display shows the index of the **INSTALLER** parameter and a string of three characters that identify it. The string remains displayed for one

second, after which it is replaced by the value relative to the parameter itself. To pass to the next parameter, use the arrow keys (Fig.B). To modify a parameter, just select it, press the key shown in (Fig.A), modify the value using the arrow keys shown in (Fig.B). To confirm the modification press the key shown in (Fig.A) again.



PASSWORD = 030



(1) What type of system terminals are used in the heating circuit?

Reply	Operations to be performed
Is the unit a cooling only model	Go to question 2
Radiant panels (floor, etc....)	Set the parameter StC (index 3 USER menu) with the value of 35 °C
Fan coils or low temperature radiators	Set the parameter StC (index 3 USER menu) with the value of 45 °C (default value)
Other applications	Set the parameter StC (index 3 USER menu) with the value of 55 °C

(2) Is the remote panel accessory installed (PR3)?

Reply	Operations to be performed
Not installed	Go to question 3
Installed	<p>Set the parameter PAN (index 9 INSTALLER menu) with the appropriate value selecting from:</p> <p>Value (1):</p> <ul style="list-style-type: none">• Season control piloted from the circuit board• ON/OFF control enabled from PR3 <p>Value (2):</p> <ul style="list-style-type: none">• Season control enabled from PR3• ON/OFF control from panel on machine <p>Value (3):</p> <ul style="list-style-type: none">• Season control enabled from PR3• ON/OFF control enabled from PR3

(3) Is the production of DHW envisioned?

Reply	Operations to be performed
Not envisioned	Go to question 5
Envisioned	Set the parameter ASA (index A INSTALLER MENU) with the value (1)

(4) Is a 3-way diverter valve envisioned in the DHW production circuit?

Reply	Operations to be performed
Not envisioned	Go to question 5
Envisioned	Set the parameter AAS (index C INSTALLER menu) with the appropriate value (in seconds). This parameter indicates the stand-by time for inversion of the 3-way diverter valve on the DHW production system

(5) Is a room thermostat installed?

Reply	Operations to be performed
Not installed	No operation
Installed	<p>This parameter enables a digital clamp ID (indicated on the circuit board with the code TRA) to which a room thermostat must be connected, used to disable the compressors and the integrative resistances.</p> <p>Set the parameter trA (index D INSTALLER menu) with the appropriate value, selecting from:</p> <p>Value (1 or 2): Clamp ENABLED Value (0 or 3): Clamp DISABLED</p> <p>Remember that the OPEN state on the clamp represents:</p> <ul style="list-style-type: none">• the compressors and resistances block function if the parameter is set at 1• the compressors, pumps and resistances block function if the parameter is set at 2• represents the pump alarm (as in the previous software version), if the parameter is set at the value 3



For further information regarding operations that can be performed on the user and installer parameters, refer to the unit user manual.

ANOMALY	CAUSE	REMEDY
The chiller does not start-up	<ul style="list-style-type: none"> No electric voltage 	<ul style="list-style-type: none"> Check the presence of voltage Check the safety systems upstream from the appliance
	<ul style="list-style-type: none"> Master switch at OFF Remote switch at OFF (if present) Control panel at OFF Main switch at OFF Compressor magnet circuit breaker at OFF 	<ul style="list-style-type: none"> Position at ON
	<ul style="list-style-type: none"> Power supply voltage too low 	<ul style="list-style-type: none"> Check power supply line
	<ul style="list-style-type: none"> Remote control switch coil broken Circuit board broken Peak condenser broken Compressor broken 	<ul style="list-style-type: none"> Replace the component
Insufficient yield	<ul style="list-style-type: none"> No refrigerant Appliance dimensioning Functioning outside of operational limits 	<ul style="list-style-type: none"> Check
Noisy compressor	<ul style="list-style-type: none"> Liquid return to the compressor Inadequate fixing 	<ul style="list-style-type: none"> Check
Noise and vibrations	<ul style="list-style-type: none"> Phase inverted (in three-phase versions only) 	<ul style="list-style-type: none"> Invert a phase
	<ul style="list-style-type: none"> Contacts between metal bodies 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Weak rest Loose screws 	<ul style="list-style-type: none"> Restore Tighten the screws
The compressor stops due to intervention of the protections	<ul style="list-style-type: none"> Excessive flow pressure Low intake pressure Power supply voltage low Electric connections fastened badly Functioning outside of operational limits 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Pressure switch functions badly 	<ul style="list-style-type: none"> Replace the component
	<ul style="list-style-type: none"> Circuit breaker protection intervention 	<ul style="list-style-type: none"> Check power supply voltage Check electric isolation of the windings
High discharge pressure	<ul style="list-style-type: none"> High external air temperature High water input temperature 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Insufficient air flow Insufficient water flow 	<ul style="list-style-type: none"> Check fan functioning Check pump functioning
	<ul style="list-style-type: none"> Fan regulation anomalous functioning 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Air in the hydraulic system 	<ul style="list-style-type: none"> Bleed
	<ul style="list-style-type: none"> Excessive gas load 	<ul style="list-style-type: none"> Check
Low discharge pressure	<ul style="list-style-type: none"> Low external air temperature Low water input temperature 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Humidity in the cooling circuit 	<ul style="list-style-type: none"> Empty and restore the gas load
	<ul style="list-style-type: none"> Anomalous functioning of fan regulation (if envisioned) 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Air in the hydraulic system 	<ul style="list-style-type: none"> Bleed
	<ul style="list-style-type: none"> Insufficient gas load 	<ul style="list-style-type: none"> Check
High intake pressure	<ul style="list-style-type: none"> High external air temperature High water input temperature Thermostatic expansion valve too open or damaged 	<ul style="list-style-type: none"> Check
Low intake pressure	<ul style="list-style-type: none"> Low external air temperature Low water input temperature Thermostatic expansion valve damaged or blocked 	<ul style="list-style-type: none"> Check
	<ul style="list-style-type: none"> Water filter blocked Plate heat exchanger blocked 	
	<ul style="list-style-type: none"> Insufficient air flow 	<ul style="list-style-type: none"> Check fan functioning
	<ul style="list-style-type: none"> Insufficient water flow 	<ul style="list-style-type: none"> Check pump functioning

AERMEC
La prima per il clima

37040 Bevilacqua (VR) - Italy
Via Roma, 44 - Tel. (+39) 0442 633111
Telefax (+39) 0442 93730 - (+39) 0442 93566
www.aermec.com



carta riciclata
recycled paper
papier recyclé
recycled papier



The technical data given on the following documentation is not binding. Aermec reserves the right to make all the modifications deemed necessary for improving the product.