

**Sistema VMF**

**Scheda termostato espandibile per ventilconvettori**

**VMF system**

**Expandable thermostat board for fan coils**

**Systeme VMF**

**Platine thermostat extensible pour ventilo-convecteurs**

**VMF-System**

**Erweiterbare Thermostatplatine für Gebläsekonvektoren**

**Sistema VMF**

**Tarjeta del termostato expansible para fan coils**

# VMF-E1



**Congratulations on your purchase of this “VMF-E1” Aermec kit containing an EXPANDABLE THERMOSTAT BOARD FOR FAN COILS.**

**Made with top quality materials in strict compliance with safety regulations, “VMF-E1” will provide you with outstanding performance for a long time to come.**

---

## CONTENTS

Important information • Package	13
Description of the accessory	14
Summary of the control logics • Dimensions	17
Network settings • Installation	18
Electronic board connections	19
Dip-switch settings	20
Technical characteristics • Connections specifications • Compliance with EC Mark	21
Connections (examples)	53
Wiring diagrams	57
Wiring diagrams (connections)	61

**WARNING:** The VMF boards are designed to be applied to fan coils installed in indoor environments.

**WARNING:** Keep separate electrical connections from water connections. Water connections and drain should be on the side opposite of the electrical connections.

**WARNING:** the fan coil is connected to the power supply and water circuit. Operations performed by persons without the required technical skills can lead to personal injury to the operator or damage to the unit and surrounding objects.

**WARNING** Components sensitive to static electricity may be destroyed by voltages notably lower than those at the human perception threshold. These voltages form when you touch a component or electric contact of a unit, without first discharging accumulated static electricity from your body. The damage caused to the unit by an overvoltage is not immediately evident - it only appears after a certain period of operation.

 **STATIC ELECTRICITY ACCUMULATION**

Any person not connected in a conductive manner with the electronic potential of his surrounding environment can accumulate electrostatic charges.

 **STANDARD PROTECTION AGAINST ELECTROSTATIC CHARGES**

 **Earthing quality**

When working with units sensitive to electrostatic electricity, ensure that people, workplaces and unit casings are correctly earthed. This will prevent the formation of electrostatic charges.

 **Avoid direct contact**

Only touch the element exposed to electrostatic risk when absolutely essential (e.g. for maintenance). Touch the element without coming into contact with either the contact pins or the wire guides. If you follow this rule, the energy of the electrostatic charges cannot reach or damage the sensitive parts.

Before taking measurements on the unit, it is necessary to discharge all electrostatic charges from your body: to do this, just touch an earthed metal object. Only use earthed measuring instruments.

 **POWER WITH A SINGLE-PHASE VOLTAGE OF 230V ONLY**

Any other type of power supply could permanently damage the thermostat and fan coil.

### MALFUNCTIONING

**In case of malfunction, cut off power to the unit, then energise it again and restart the device. If the problem occurs again, call the local After-Sales Service immediately.**

### DO NOT TUG THE ELECTRIC CABLE

It is highly dangerous to pull, crush or tread on the electric cables, or to fix them with nails or drawing pins. A damaged power cable can cause short circuits and injure people.

---

## PACKAGE

The thermostats are shipped in standard cardboard box packaging.

## DESCRIPTION

### VMF - E1

#### EXPANDABLE ELECTRONIC THERMOSTAT BOARD KIT

The VMF-E1 accessory is an advanced electronic thermostat kit to be applied to the fan coils; it requires an interface inside the fan coil (VMF-E2; VMF-E2H), or on the wall (VMF-E4).

##### The VMF-E1 kit consists of:

- an E1-type thermostat board inserted in a protective box and easily applied to the side of the fan coil. This board has a protective fuse, a dip-switch for configuration, and connectors for connection with:
  - the power supply,
  - the earthing,
  - the valve control,
  - the fan motor control,
  - the ambient air temperature probe,
  - the water temperature probe,
  - the auxiliary water temperature probe,
  - the control panel (user interface),
  - the presence sensor,
  - the external contact,
  - the microswitch contact connected to the fan coil fin,
  - the central supervisor system serial (VMF-E5),
  - the fan coil network serial (TTL).

##### With the VMF-E1, you can manage:

- Three fan coil speeds in manual mode
- Continuous ventilation and thermostat control, by controlling the valves
- Automatic fan mode according to the load
- Season visualisation
- Visualisation of alarms and ventilation request
- Up to two ON/OFF 2- or 3-way valves
- The switch-on of an electric heater
- A germicidal lamp
- Plasmacluster filter
- An air temperature probe
- A water temperature probe, with minimum and maximum temperature and changeover functions
- An additional water probe (accessory) for controlling the second coil (4-pipe systems)
- Season change according to the water or air temperature (4-pipe systems)
- Input for "external contact". This is a digital input with the following logic: When open, the thermostat works normally; When closed, the fan coil is switched off.
- microswitch for fin contact
- Anti-freeze function

- Presence sensor
- Input for supervision serial. In networks made up of several fan coils subdivided into independent temperature areas, the VMF-E1 area regulator allows communication with a central system supervisor (VMF-E5)
- Communication with other thermostats, via a dedicated serial based on the TTL logic standards

### Description of the functions

#### • Operation in TTL network

The E1 thermostat is designed to communicate with other E0 and/or E1 and/or E18 type thermostats via a dedicated serial based on the TTL logic standards. This serial communication is essential for the exchange of information within small fan coil networks (up to 6) with a maximum network length of 30 metres. It was designed, in fact, for small areas where the fan coils (more than one) need to be controlled from a single control point.

More specifically, this network always contains a Master (to which a user interface VMF-E2, VMF-E2H, VMF-E4 is connected) which controls the operation of the Slaves connected to it, according to the settings made on its user interface.

The Master fan coil is fitted with an E0-type electronic board (VMF-E0, or fan coils fitted as standard with board E0), or an E1-type board (VMF-E1).

The Slave fan coil must be fitted with an E0-type electronic board (VMF-E0), or an E1-type board (VMF-E1).

All the fan coils of the TTL network must have the same type of configuration.

Example: all standard, all with purifiers (Plasmacluster and/or germicidal lamps), or all with an additional coil (electric or with water).

On the basis of the settings received from the network and the ambient conditions detected by the probes, the electronic board on each single Slave fan coil acts (independently from the other fan coils) to switch the ventilation on and off in order to create the conditions requested by the user for that specific room.

#### • Cooling operation

Cooling operation requires a water circuit with chiller.

#### • Heating operation

Heating operation requires a water circuit with boiler, heat pump or solar system.

#### • Changeover (seasonal change)

The thermostat automatically selects the operating mode (Heating/Cooling), if that mode is permitted (water probe and settings).

- **Normal band:** Heating at 39°C; Cooling at 17°C.

- **Reduced band:** Heating at 35°C; Cooling at 22°C.

- **Dead band:** can be selected at 5°C or

2°C.

#### Water side changeover

##### - Water temperature checks

Enabling of water side ventilation (only active with water temperature probe).

The thermostat identifies the ventilation enabling threshold in Heating mode (minimum controlled) and Cooling mode (maximum controlled); with the dip-switches it is possible to choose between two temperature bands.

#### Air side changeover

If the actual ambient temperature is lower than the set point by a value equal to the Dead Band, there is an automatic swap to Heating operation.

If the actual ambient temperature is higher than the set point by a value equal to the dead band, there is an automatic swap to Cooling operation.

In the fan coil networks, the values of the dead band are only those configured on the Master fan coil

#### • Pause due to power failure

After a power failure, the unit restarts with the settings that were active prior to the pause.

#### • Delayed start-up

The unit can begin ventilation some time after start-up - usually up to 2'40" (pre-heating function).

The delay is zero-set in units with an electric heater.

#### • **Anti-freeze protection**

Controls on OFF position. The fan coil can restart in heating mode (set point 12°C) if the ambient temperature falls below 7°C and the temperature of the water in the system is suitable.

In the fan coil networks, the Slave fan coils can activate the anti-freeze protection regardless of the settings on the Master fan coil.

If the anti-freeze protection is active on the Master fan coil, all the other Slave fan coils will also adopt a set point of 12°C, regardless of their ambient conditions.

#### • **Ambient temperature probe**

If the ambient temperature probe on the Slave fan coils is faulty, the temperature will be measured by the probe of the Master.

#### • **Ambient probe correction**

To obtain a better ambient temperature adjustment, the thermostat applies special algorithms to correct the ambient probe installed on the fan coil; the probe is in contact with the housing, and is therefore influenced by it.

The dynamic correction is a correction algorithm of the ambient probe which takes into account the particular operation status of the fan coil in any one moment. More precisely, there are two possible cases of dynamic correction:

- **Dynamic correction A:** in the case of systems without a valve (or with a downstream probe), the correction depends on the water and ambient temperatures.

- **Dynamic correction B:** in the case of systems with a valve and an upstream probe, the correction depends on the Valve and on the Water and Ambient temperatures. Unlike the previous correction, this one uses different time constants to calculate the appropriate correction (because the housing is influenced in a different way).

#### • **Water probe**

There is a water temperature probe in the heat exchanger of the unit.

The Slave fan coil can work without the water probe: if it is absent or faulty, the temperature will be measured by the Master probe alone. In this case, ventilation is always enabled on the Slave fan coil.

The water temperature probe can be positioned **downstream** or **upstream** from the shutoff valve, so also the dip-switches on the board must be set. The difference lies in the management of the ventilation of the fan coils with valve.

Setting the dip-switch as a **downstream**

**probe** of the valve, ventilation start-up (changeover) is dependent on the temperature of the air in the room.

Setting the dip-switch as an **upstream probe** of the valve, ventilation start-up is dependent on the temperature of the water in the system. With this setting, the pre-heating function is activated, and there is a ventilation start-up delay of between 0" and 2'40".

To position the bulb on the delivery pipe upstream of the valve, the standard water probe must be replaced with the VMF-SW probe accessory.

#### • **Ventilation**

3-speed ventilation can be controlled both manually and automatically.

- **Manual**, with the selector in position V1, V2 and V3. The fan is used with on-off cycles at the selected speed.

- **Automatic**, with the selector on AUTO. The fan speed is managed by the thermostat, on the basis of the ambient conditions and the fan coil configuration.

Thermostat settings:

- **3-level thermostat**, With the selector on AUTO. The fan maintains the speed relating to one of the three predetermined steps, depending on the difference between ambient temperature and set point. Once it has reached the set point, the fan will switch off.

- **Modulated output thermostat**, With the selector on AUTO. The fan makes cycles, alternating the speeds according to the difference between ambient temperature and set point. Once it has reached the set point, the fan will switch off. This setting is not compatible with continuous ventilation management.

#### • **Ventilation management**

Ventilation settings:

- **Continuous ventilation.** Ventilation is always active. The temperature is controlled by intercepting the flow of water to the fan coil. This function requires the presence of a water valve (accessory), and cannot be activated simultaneously with the "modulated output thermostat" option.

- **Thermostat-controlled ventilation.** Ventilation switches off when the set temperature is reached (set point).

#### • **Valve adjustment logics**

With the **Thermostat-controlled ventilation** or **Modulated output thermostat** setting, the valve is managed with the following logics:

- **Heating** - the valve is managed to exploit the stack effect of the fan coil, and to provide heat even with the fan switched off. These settings also reduce the number of valve openings and closings; with hot water circulating in the fan coil, a request from the thermostat will produce ventilation immediately.

- **Cooling** - to make the best use of the unit's cooling capacity and perform a more accurate check on the ambient temperature, the valve opening does not coincide with ventilation.

#### • **External contact**

The board offers the possibility of a connection with an external contact. With a closed external contact, the unit is configured as in the thermostat OFF position (except when the thermostat is in the Anti-freeze Protection position or when the ambient probe is absent or faulty). This contact can be used to manage inputs such as a remote ON-OFF controlled, a presence sensor, a window contact, a faulty circulation pump signal, etc.

In fan coil networks, only the external contact of the Master fan coil is enabled. If the master input is closed, all the slave fan coils of the network are switched off.

#### • **Microswitch contact**

The board offers the possibility of a connection with the Microswitch contact located on the delivery fins. With the fins closed, the fan coil is 100% OFF.

In fan coil networks, when the fin of the Master fan coil is closed, ventilation stops but the electronic thermostat board and the other fan coils in the network carry on working.

#### • **"Sleep" energy saving function**

Presence sensor to enable the "Sleep" function from an external contact (SP). The Sleep energy saving function involves varying the ambient set-point by 2 or 5 degrees (depending on the settings) when there are no people in the room.

In heating mode, the set point temperature is lowered.

In cooling mode, the set point temperature is raised.

To activate the Sleep function for energy savings, you must connect a presence sensor (with NO logic) to the SP contact.

The function is not active in Anti-freeze protection mode, or if the ambient probe is faulty.

In fan coil networks, only the presence sensor contact of the Master fan coil is enabled. The setting of the Master is sent to all the Slave fan coils in the network.

#### • **Emergency operation**

In the event of a faulty ambient probe, the electronic board can automatically detect the problem and enable an emergency program to avoid any inconvenience for the user, who is immediately informed of the fault (LED indicator lights).

#### • **Behaviour with a faulty water temperature probe**

Ventilation is always active.

The season change is made on the basis of the difference between the setting made and the actual ambient temperature.

If the actual ambient temperature exceeds the Heating set point by a value equal to the dead band, there is an automatic swap to Cooling operation.

If the actual ambient temperature falls below the Cooling set point by a value equal to the dead band, there is an automatic swap to Heating operation.

Heater switch-on and switch-off depends solely on the thermostat operation request.

In this case, a fixed correction of the ambient probe is envisaged, and is determined on the basis of the type of thermostat configured.

- **Behaviour with a faulty ambient temperature probe**

- **2-pipe system:**

With the selector in the OFF/Aux position, ventilation switched off and the valve is closed

With the selector in the AUTO, V1, V2, V3 position, the Heating mode is fixed and the valve is always open. The ventilation makes on-off cycles of variable duration depending on the position of the temperature selector.

- **4-pipe system:**

With the selector in the OFF/Aux position, ventilation switched off and the valve is closed

With the selector in the AUTO, V1, V2, V3 position, the Heating/Cooling mode is decided on the basis of the position of the temperature selector, activating the respective valve. The ventilation makes on-off cycles of variable duration depending on the position of the temperature selector.

- **Behaviour with a faulty ambient temperature probe on a Slave fan coil**

The board automatically assumes the reading of the ambient probe of the Master fan coil.

- **Heating mode with electric heater (if**

- present)**

The electric heater must be enabled by configuring the dip-switches on the thermostat again. Activate the heater-operated heating by positioning the control panel selector on AUX.

Standard operation is of the ON-OFF type.

The electric heater intervenes when there is a thermostat operation request and the water temperature is sufficiently low.

It should be noted that when the thermostat starts up, the heater is OFF, so it will only be activated if the water temperature is below the enabling threshold (35°C with normal band and 31°C with reduced band).

In any case, the activation of the electric heater involves a similar ventilation management to that in Automatic mode. The electric heater cannot be used in modulated power thermostat configuration.

If the fan coil is operated with continuous ventilation, then the electric heater will switch off when the set point is reached; following the post-ventilation phase (described below), the ventilation continues at speed V1.

Electric heater operation involves pre-ventilation and post-ventilation phases in relation to its activation and deactivation.

It should be noted that the pre-ventilation phase (20" at V1) always corresponds to the activation of the electric heater, while the post-ventilation phase always corresponds to the deactivation of the electric heater (60" at V1).

Example: the thermostat requests fan operation with the heater activated (i.e. the water temperature is sufficiently low), so we will have 20" of ventilation at speed V1 (pre-ventilation) after which the thermostat will operate at the ventilation speed determined by the microprocessor on the basis of the difference between the actual ambient

temperature and the set temperature. Once the set temperature has been reached, if the heater is still active (i.e. the water temperature is sufficiently low), we will have post-ventilation for 1 min at speed V1.

It should be noted that when the heater is switched off during operation because the water temperature is sufficiently high, then after reaching the set temperature, ventilation continues at speed V1 for the remaining time needed to terminate the post-ventilation cycle. Finally, please note that the heater is never enabled if the thermostat is in anti-freeze or emergency mode, due to the ambient probe.

- **Operation with purifying devices (if present)**

If purifying devices are installed (Plasmacluster or bactericidal lamp), they must be enabled by configuring the dip-switches on the thermostat again.

With the selector on "Aux", the ambient is purified regardless of the thermostat operation requests.

Unlike the electric heater however, this type of accessory is even activated if the operation speed selector is not positioned on "Aux".



On "Aux", the fan will always operate at minimum speed, closing any shutoff element whose use is recommended with this function and thereby avoiding any ambient alterations (overheating / under-cooling).

Adjusting a 2-pipe system				
	Upstream water probe		Downstream water probe	
	Water probe present	Water probe not fitted	Water probe present	Water probe not fitted
<b>With valve</b>	Water side changeover	Air side changeover	Air side changeover	Air side changeover
	Pre-heating delay	Pre-heating delay	No ventilation delay	Pre-heating delay
	Minimum and maximum controls active	No minimum and maximum control	Minimum and maximum controls active	No minimum and maximum control
	- Dynamic correction A:	Fixed correction	- Dynamic correction B:	Fixed correction
<b>Without valve</b>	Configuration not used		Water side changeover	Air side changeover
			No ventilation delay	No ventilation delay
			Minimum and maximum controls active	No minimum and maximum control
			- Dynamic correction B:	Fixed correction


Adjusting a 4-pipe system				
	Upstream water probe (Heating)		Downstream water probe (Heating)	
	Water probe (Heating) present	Water probe (Heating) absent	Water probe (Heating) present	Water probe (Heating) absent
<b>With Valve</b>	Delay for pre-heating	Delay for pre-heating	No ventilation delay	Delay for pre-heating
	Minimum temperature check activated (Heating)	Minimum temperature check deactivated (Heating)	Minimum temperature check activated (Heating)	Minimum temperature check deactivated (Heating)
	Maximum check activated if probe is present (Cooling)	Maximum check activated if probe is present (Cooling)	Maximum check activated if probe is present (Cooling)	Maximum check activated if probe is present (Cooling)
	- Dynamic correction A: / Fixed correction in Cooling, in absence of Cooling probe	Fixed correction	Dynamic correction B: / Fixed correction in Cooling, in absence of Cooling probe	Fixed correction
<b>Without valve</b>	Configuration not used		No ventilation delay	No ventilation delay
			Minimum temperature check activated (Heating)	Minimum temperature check activated (Heating)
			Maximum check activated if probe is present (Cooling)	Maximum check activated if probe is present (Cooling)
			Dynamic correction B: / Fixed correction in Cooling, in absence of Cooling probe	Fixed correction

**WARNING: for the correct operation of the thermostat in systems with centralised control (e.g. VMF-E5), it is necessary to:**

- Set Dip1=ON and Dip2=OFF.
- Install the water probe on the coil (even in the presence of a valve). With this setting, the thermostat operates as for the "Downstream hot water probe" configuration.



## NETWORK SETTINGS



### TTL NETWORK

- Consisting of up to 6 fan coils (one Master and 5 Slaves)
- Maximum TTL line length 30m.

The master fan coils are equipped with a control panel and an electronic board with microprocessor which has outputs in order to be inserted in a TTL network.

The Slave fan coils are equipped with an electronic board with microprocessor (VMF-E0 or VMF-E1 accessory) which has outputs in order to be inserted in a TTL network.

All the fan coils of the TTL network must have the same type of accessory.

The settings (or set points) of the panel on the main fan coil (Master) are received by the other fan coils (Slaves).

The units connected to the TTL network are automatically recognised (they require no configuration procedure).

## INSTALLATION

The essential indications to install the device correctly are given here.

The installer's experience will be necessary however, to perfect all the operations in accordance with the specific requirements.

Before beginning the installation, carefully read the information below:

- **WARNING:** check that the power supply is disconnected before carrying out any procedures on the unit.
- **WARNING:** before carrying out any work, put the proper individual protection equipment on.
- **WARNING:** the device must be installed in compliance with national plant engineering rules.
- **WARNING:** the electrical wirings and the installation of the units and their accessories must only be carried out by people possessing the technical/professional skills for system installation, transformation, extension and maintenance, and who are able to check these aspects in terms of safety and good working.

In particular, the electrical wirings require checks relating to:

- measurement of the electrical system insulation strength.
- Continuity of the protection wires.
- **WARNING:** install a device, main switch, or electric plug so you can fully disconnect the device from the power supply.
- **WARNING:** the unit is connected to the electrical mains. Any intervention by unqualified and untrained personnel

could cause injury to the worker and damage to the equipment and surrounding environment.

- Check the mains voltage complies with the one requested for the device to be installed.
- The electrical wiring measurements must be carried out according to the regulations in force, taking into account the system load.
- For the power supply, use undamaged cables with a section suitable for the load. You are advised to make the connections using a single cable for each one. Do not make connections on the power supply cable: use a longer cable. Junctions can cause overheating and/or fires.
- Only use the appropriate tools for the electrical wirings.
- Make an earth connection for the indoor unit.
- Use twisted cables for the connections to the wired panel.
- Follow the wiring diagrams supplied with the device and shown in this documentation when making the connections.
- The wiring diagrams are subject to continuous updates, so it is essential to use those on the machine as your reference.
- Do not attempt to repair the unit yourself. An incorrect intervention can cause electric shocks and/or fires, so you are advised to contact your local After Sales Service. For any installation or technical intervention, please contact your local After Sales Service.

All the cables must be piped or ducted until they are inside the fan coil. The cables leaving the pipe or raceway must be positioned in such a way that there are not traction or twisting stresses and they are anyway protected from outside agents.

- Stranded cables can only be used with cable terminals. Check the cable strands are well inserted.
- In installations with a 3-way valve, the minimum water temperature probe must be relocated from its standard housing in the coil, to the delivery pipe upstream from the valve. When relocating the water probe, the standard sensor must be replaced with an accessory VMF-SW sensor, fitted with a cable of suitable length.
- The connections must be made to the connectors on the electronic board.
- The electronic board is protected with a plastic box and a cover that can easily be removed with the help of a tool.
- **Warning:** the diagram showing the connections of the electronic board to the control board is printed inside its box cover.
- Make an earth connection for the indoor unit.

## CONNECTIONS TO THE BOARD

- The installation of the VMF-E1 kit requires that the standard control board is removed from the fan coil.

- Mount the thermostat housing to the side of the fan coil units, on the connections that were of the control board.

- Remove the cover of the thermostat housing.

- **WARNING:** make an earth connection for the thermostat board.

**DANGER:** it is compulsory to tighten the screw on the side of the fan coil, as this is what allows the earth connection of the entire system.

- Connect the power supply cables. Warning: respect the L and N polarities.

- Connect the electric cables of the electric motor. Respect the speed sequence: if the motor has 4 or more speeds, choose the 3 required.

- Connect the electric cables of the air temperature probe (SA).

- Connect the electric cables of the water temperature probe (SW).

- Connect the electric cables of the secondary water temperature probe (SW1) (in 4-pipe hydronic systems).

- Connect the cables for the external contact (if envisaged).

- Connect the cables for the presence sensor (if envisaged).

- Connect the cables for the microswitch (if envisaged).

- Connect the mains and RS485 power supply cables (if connected to the mains).

- Connect the TTL mains cables (if connected to the mains).

- Connect the cables of the control panel (if envisaged).







- Check all the connections and relative cables are well fixed.

- Arrange the cables so there is no risk of them being cut, crushed, jerked, scraped, or generally damaged.

- Check the board fuse is undamaged and possesses the necessary features.


- Close the box with the cover.

- Fix the power supply cables and valve cables using the cable clamp.



**DANGER:** it is compulsory to tighten the screw on the side of the fan coil, as this is what allows the earth connection of the entire system.

**WARNING:** Keep separate electrical connections from water connections. Water connections and drain should be on the side opposite of the electrical connections.





# ELECTRONIC BOARD CONNECTIONS

## Connections key:

### L - N = Power supply

230V AC - 50Hz

Screw clamps

Minimum cable section = 0.5mm<sup>2</sup>

Maximum cable section = 2.0mm<sup>2</sup>



### = EARTH connection

Screw clamp

Minimum cable section = 0.5mm<sup>2</sup>

Maximum cable section = 2.0mm<sup>2</sup>

### Y1 = VC/VF control

Screw clamps

Minimum cable section = 0.5mm<sup>2</sup>

Maximum cable section = 1.3mm<sup>2</sup>

Maximum cable length = 30m

### Y2 = Accessory control

Screw clamps

Minimum cable section = 0.5mm<sup>2</sup>

Maximum cable section = 1.3mm<sup>2</sup>

Maximum cable length = 30m

### N = Neutral

Faston-type connector

Minimum cable section = 0.5mm<sup>2</sup>

### FUSE = Protection fuse

Delayed 2A fuse

### V3 - V2 - V1 = Motor control

Faston-type connector

Minimum cable section = 0.5mm<sup>2</sup>

Maximum cable section = 2.0mm<sup>2</sup>

### SA = Air probe

Analogue input

Removable-type connector

Maximum cable length = 3m

### SW = Water probe

(2 pipes / 4 pipes on heating exchanger)

Analogue input

Faston-type connector

Maximum cable length = 3m

### SW1 = Water probe

(4 pipes on cooling exchanger)

Analogue input

Removable-type connector

Maximum cable length = 3m

### SP = Presence sensor

Digital input

Screw clamps

Minimum cable section = 0.2mm<sup>2</sup>

Maximum cable section = 1.0mm<sup>2</sup>

Maximum cable length = 30m

### CE = External contact

Digital input

Screw clamps

Minimum cable section = 0.2mm<sup>2</sup>

Maximum cable section = 1.0mm<sup>2</sup>

Maximum cable length = 100m

### MS = Microswitch

Sliding contact

Maximum cable length = 3m

### E5 = VMF-E5 power supply

Removable-type connector

Minimum cable section = 0.2mm<sup>2</sup>

Maximum cable section = 1.0mm<sup>2</sup>

Maximum cable length = 30m

### RS485 / E5 = Supervision serial + Power supply VMF-E5 (5 Poles)

Removable-type connector

Shielded cable size AWG22-5

(0,34 mm<sup>2</sup> - 5 poles + shield)

Maximum cable length for the complete network = 30 m

### RS485 = Supervision serial

Removable-type connector

Shielded cable size AWG22-3

(0,34 mm<sup>2</sup> - 3 poles + shield)

Maximum cable length for the complete network = 1000m

### TTL = Local serial

Removable-type connector

Shielded cable size AWG22-3

(0,34 mm<sup>2</sup> - 3 poles + shield)

Total maximum cable length = 30m (see the diagram showing the connections between the units)

### E2-E3-E4 = Connection to the control panel

Dedicated connector

Shielded Twisted Pair cable (Data transmission cable), size AWG 22-24

(0.33 - 0.20 mm<sup>2</sup> - 4 poles + shield)

### CN 18 = Expansion board

Connector

### CN 19 = Expansion board


Connector

### CN 21 = Expansion board

Connector

### CN 28 = Expansion board

Connector



## DIP-SWITCH SETTINGS

Turn off the power to the unit. This operation should be carried out in the installation phase, by suitably trained and qualified personnel only.

The dip-switches are on the electronic board.

\* **Warning:** if the thermostats are inserted in systems with

Centralised Control or Supervisor (e.g. VMF-E5), it is necessary to set: Dip1=ON and Dip2=OFF. The setting takes priority over the presence of the valve and the position of the sensor. The Continuous Ventilation and Modulated Output Thermostat settings are not compatible.







They can be used to obtain the following functions:

Position	Functions
<b>Dip 1 (Default OFF)</b>	<b>Check water valve / * Thermostat in centralised network(See table):</b>
OFF	No shut-off valve
ON	Shutoff valve present / * Thermostat in centralised network:
<b>Dip 2 (Default OFF)</b>	<b>Position water temperature sensor / * Thermostat in centralised network (See table ):</b>
OFF	Water temperature sensor downstream from shutoff valve / *Thermostat in centralised network
ON	Water temperature sensor upstream from shutoff valve
<b>Dip 3 (Default OFF)</b>	<b>Ventilation control:</b>
OFF	Thermostat-controlled ventilation
ON	Continuous ventilation
<b>Dip 4 (Default OFF)</b>	<b>Ventilation enabling:</b>
OFF	Enabling normal band
ON	Enabling reduced band
<b>Dip 5 (Default OFF)</b>	<b>**System type selection (See table)</b>
OFF	Combinations between Dip 5 and Dip 6
ON	
<b>Dip 6 (Default OFF)</b>	<b>**System type selection (See table)</b>
OFF	Combinations between Dip 5 and Dip 6
ON	
<b>Dip 7 (Default OFF)</b>	<b>Dead band:</b>
OFF	Dead band 5°C
ON	Dead band 2°C
<b>Dip 8 (Default OFF)</b>	<b>Thermostat settings:</b>
OFF	3-level thermostat
ON	Modulated output thermostat

### Functions dependent on the combination of 2 Dip

Dip 1	Dip 2	* Centralised control
ON	OFF	Centralised control enabled
Dip 6	Dip 5	** Type of system
OFF	OFF	Two-pipe system - Two-pipe system with electric heating element
OFF	ON	four-pipe system
ON	OFF	Two-pipe system with Plasmacluster / Bactericide lamp
ON	ON	Two-pipe system with bactericide lamp always on

### SOME EXAMPLES:




<b>E1 TECHNICAL FEATURES</b>	
Power supply	230V AC +/-10%, 50-60 Hz
Max input power (excluding loads controlled by TRIACs)	4.5VA
Digital inputs	3 free contacts
Analogue inputs	No. 3 for reading NTC 10K probes
Digital outputs	No. 5 - 230V AC with Triac
Assembly	On the machine
Protection rating	IP20 (referring to the containment plastic)
Storage conditions	-20T80°C, humidity 80% non-condensing
Operating conditions	0T50°C, humidity 80% non-condensing
Software class	Class A
<b>OUTPUTS: Control of fan</b>	
Voltage	230V AC
Max. current	0.7 A

<b>E1 CONNECTION SPECIFICATIONS</b>	
Power supply	Screw terminals, 5mm pitch
	Cable section - min=0.5mm <sup>2</sup> max=2.0mm <sup>2</sup>
Accessory control outputs (Valves-Plasmacluster germicidal lamp, etc.)	Screw terminals, 5mm pitch
	Cable section - min=0.5mm <sup>2</sup> max=1.3mm <sup>2</sup>
	Maximum cable length = 30m
EC digital input	Screw terminals, 3.81mm pitch
	Cable section - min=0.2mm <sup>2</sup> max=1.0mm <sup>2</sup>
	Maximum cable length = 100m
MS digital input - Sliding contact	Maximum cable length = 3m
SP digital input	Screw terminals, 3.81mm pitch
	Cable section - min=0.2mm <sup>2</sup> max=1.0mm <sup>2</sup>
	Maximum cable length = 30m
Analogue inputs (SA-SW)	Quick plug-in connections
	Maximum cable length = 3m
Analogue input (SC)	Quick plug-in connection
	Maximum cable length = 30m
TTL local serial	Screw terminals, 3.81mm pitch
	Cable section - min=0.2mm <sup>2</sup> max=1.0mm <sup>2</sup>
	Maximum cable length = 30m
RS485 supervision serial	Screw terminals, 3.81mm pitch
	Cable section - min=0.2mm <sup>2</sup> max=1.0mm <sup>2</sup>
	Maximum cable length = 500m
Output power supply	12V dc screw terminals, 3.81mm pitch
	Cable section - min=0.2mm <sup>2</sup> max=1.0mm <sup>2</sup>
	Maximum cable length = 30m


### COMPLIANCE WITH EC MARK

The following directives are used for reference:



- Low Voltage Directive 2006/95/CE
- Electromagnetic Compatibility Directive 2004/108/CE



Alimentazione elettrica  
Power supply  
Alimentation électrique  
Stromversorgung  
Alimentación eléctrica




Collegamento al pannello comandi  
Connection to the control panel  
Raccordement au panneau de commande  
Anschluss an die Bedientafel  
Conexión al tablero de mandos




Alimentazione motore ventilatore  
Fan motor power supply  
Alimentation du moteur du ventilateur  
Stromversorgung Ventilatormotor  
Alimentación motor ventilador

Y1 Comando valvola VC/VF + Y2 Comando accessorio  
Y1 VC/VF control + Y2 Accessory control  
Y1 Commande VC/VF + Y2 Commande accessoire  
Y1 Steuerung VC/VF + Y2 Steuerung des Zubehörteils  
Y1 Mando VC/VF + Y2 Mando Mando accessorio




TTL Seriale locale  
TTL Local serial  
TTL Liaison série locale  
TTL Lokale serielle Schnittstelle  
TTL Serial Local




## COLLEGAMENTI • CONNECTIONS • RACCORDEMENTS • ANSCHLÜSSE • CONEXIONES


SP Sensore presenza + CE Contatto esterno  
 SP Presence sensor + CE External contact  
 SP Capteur de présence + CE Contact extérieur  
 SP Anwesenheitssensor + CE Außenkontakt  
 SP Sensor de presencia + CE Contacto externo




Sonda temperatura aria  
 Air probe  
 Sonde d'air  
 Lufttemperaturfühler  
 Sonda aire




Sonda acqua su scambiatore riscaldamento  
 Water probe on heating exchanger  
 Sonde d'eau sur échangeur de chauffage  
 Wassertemperaturfühler auf Wärmetauscher für Heizbetrieb  
 Sonda de agua en intercambiador de calentamiento




Sonda acqua su scambiatore raffreddamento (4tubi)  
 Water probe on cooling exchanger (4 pipes)  
 Sonde d'eau sur échangeur de refroidissement 4 tubes  
 Wassertemperaturfühler auf Wärmetauscher für Kühlbetrieb  
 Sonda de agua en intercambiador de enfriamiento



Microswitch  
 Microswitch  
 Microrupteur  
 Mikroschalter  
 Microswitch




**RS485 - COLLEGAMENTI • CONNECTIONS • RACCORDEMENTS • ANSCHLÜSSE • CONEXIONES**




La schermatura di ogni cavo deve essere collegata a terra in un solo punto  
 Every shield cable must be connected to the ground  
 Le blindage de chaque cable doit être branché à la terre en un seul point.  
 Der Schirm eines jeden Kabels wird nur an einem Erdungspunkt angeklemt  
 La pantalla de cada cable debe ser conectada a tierra en un solo punto

RS485 Seriale supervizione + E5 alimentazione VMF-E5  
 RS485 Supervision serial + E5 VMF-E5 power supply  
 RS485 Liaison série de supervision + E5 Alimentation VMF-E5  
 RS485 Serielle Überwachungsschnittstelle + E5 Versorgung VMF-E5  
 RS485 Serial supervisión + E5 Alimentación VMF-E5




RS485 Seriale supervizione (Alimentazione esterna VMF-E5)  
 RS485 Supervision serial (VMF-E5 external power supply)  
 RS485 Liaison série de supervision (Alimentation externe VMF-E5)  
 RS485 Serielle Überwachungsschnittstelle (Externe Stromversorgung VMF-E5)  
 RS485 Serial supervisión (Alimentación externa VMF-E5)




# RS485 - COLLEGAMENTI • CONNECTIONS • RACCORDEMENTS • ANSCHLÜSSE • CONEXIONES


Seriale supervisione RS485 (VMF\_E01 - VMF\_E01)  
 Supervision serial RS485 (VMF\_E01 - VMF\_E01)  
 Liaison série de supervision RS485 (VMF\_E01 - VMF\_E01)  
 Serielle Überwachungsschnittstelle RS485 (VMF\_E01 - VMF\_E01)  
 Serial supervisión RS485 (VMF\_E01 - VMF\_E01)



Seriale supervisione RS485 (VMF\_E01 - MODU\_485A)  
 Supervision serial RS485 (VMF\_E01 - MODU\_485A)  
 Liaison série de supervision RS485 (VMF\_E01 - MODU\_485A)  
 Serielle Überwachungsschnittstelle E01 - MODU\_485A  
 Serial supervisión RS485 (VMF\_E01 - MODU\_485A)




Seriale supervisione RS485 (VMF\_E01 - VMF\_MCR)  
 Supervision serial RS485 (VMF\_E01 - VMF\_MCR)  
 Liaison série de supervision RS485 (VMF\_E01 - VMF\_MCR)  
 Serielle Überwachungsschnittstelle RS485 (VMF\_E01 - VMF\_MCR)  
 Serial supervisión RS485 (VMF\_E01 - VMF\_MCR)




LEGENDA • KEY • LEGENDE • LEGENDE • LEYENDA

- IG = Interruttore generale • Master switch • Interrupteur général • Hauptschalter • Interruptor general
  - M = Morsettiera • Control board • Bornier • Klemmleiste • Caja de conexiones
  - MS = Microinterruttore • Dip-switch • Microrupteur • Mikroschalter • Microinterruptor
  - MV = Motore ventilatore • Fan motor • Moteur du ventilateur • Ventilatormotor • Motor ventilador
  - PE = Collegamento di terra • Earth connection • Mise à la terre • Erdung • Toma de tierra
  - SA = Sonda ambiente • Ambient probe • Sonde ambiante • Raumtemperaturfühler • Sonda ambiente
  - SC = Sonda ambiente • Control card • carte de contrôle • Steuerplatine • Tarjeta de control
  - SW = Sonda minima temperatura acqua • Minimum water temperature probe • Sonde de température minimale de l'eau  
Sonde für Mindest-Wassertemperatur • Sonda mínima temperatura del agua
  - VCH = Valvola solenoide • Solenoid valve • Vanne solénoïde • Magnetventil • Válvula solenoide
  - = Componenti forniti optional • Components supplied as optional extras • Composants fournis en option  
Als Option lieferbare Teile • Componentes opcionales facilitados
  - = Collegamenti da eseguire in loco • Connections to be made on site • Branchements à effectuer sur les lieux  
Vor Ort auszuführende Anschlüsse • Conexiones que realizar in situ
- |                   |                   |                 |                |                     |
|-------------------|-------------------|-----------------|----------------|---------------------|
| AR = Arancio      | AR = Orange       | AR = orange     | AR = Orange    | AR = Naranja        |
| BI = Bianco       | BI = White        | BI = blanc      | BI = Weiß      | BI = Blanco         |
| BL = Blu          | BL = Blue         | BL = bleu       | BL = Blau      | BL = Azul           |
| GR = Grigio       | GR = Grey         | GR = gris       | GR = Grau      | GR = Gris           |
| GV = Giallo-Verde | GV = Yellow-green | GV = jaune-vert | GV = Gelb/Grün | GV = Amarillo-Verde |
| MA = Marrone      | MA = Brown        | MA = marron     | MA = Braun     | MA = Marrón         |
| NE = Nero         | NE = Black        | NE = noir       | NE = Schwarz   | NE = Negro          |
| RO = Rosso        | RO = Red          | RO = rouge      | RO = Rot       | RO = Rojo           |




Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.







Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina.  
 All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit.  
 Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils.  
 Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen.  
 El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.




Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina.  
 All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit.  
 Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils.  
 Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen.  
 El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.




Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina.  
 All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit.  
 Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils.  
 Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen.  
 El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.




Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gefieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.




Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.



Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.



Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.



Los esquemas eléctricos están sujetos a modificaciones continuas, por lo tanto es obligatorio tomar la referencia de los que se encuentran a bordo de la máquina. All wiring diagrams are constantly updated. Please refer to the ones supplied with the unit. Nos schémas électriques étant constamment mis à jour, il faut absolument se référer à ceux fournis à bord de nos appareils. Die Schaltpläne werden ständig aktualisiert, deswegen muss man sich stets auf das mit dem Gerät gelieferte Schaltschema beziehen. El cableado de las máquinas es sometido a actualizaciones constantes. Por favor, para cada unidad remitirse a los esquemas suministrados con la misma.



---

I dati tecnici riportati nella presente documentazione non sono impegnativi.

AERMEC S.p.A. si riserva la facoltà di apportare in qualsiasi momento tutte le modifiche ritenute necessarie per il miglioramento del prodotto.

Les données mentionnées dans ce manuel ne constituent aucun engagement de notre part. Aermec S.p.A. se réserve le droit de modifier à tous moments les données considérées nécessaires à l'amélioration du produit.

Technical data shown in this booklet are not binding.

Aermec S.p.A. shall have the right to introduce at any time whatever modifications deemed necessary to the improvement of the product.

Im Sinne des technischen Fortschrittes behält sich Aermec S.p.A. vor, in der Produktion Änderungen und Verbesserungen ohne Ankündigung durchzuführen.

Los datos técnicos indicados en la presente documentación no son vinculantes.

Aermec S.p.A. se reserva el derecho de realizar en cualquier momento las modificaciones que estime necesarias para mejorar el producto.

---

**AERMEC S.p.A.**

I-37040 Bevilacqua (VR) - Italia

Via Roma, 996 - Tel. (+39) 0442 633111

Telefax (+39) 0442 93730 - (+39) 0442 93566

www.aermec.com

---