


External Dimensions

Unit: mm [in.]





FM33568 / ISO 9001;2008

The Air Conditioning & Refrigeration Systems Works acquired ISO 9001 certification under Series 9000 of the International Standard Organization (ISO) based on a review of Quality management for the production of refrigeration and air conditioning equipment.

ISO Authorization System
The ISO 9000 series is a plant authorization system relating to quality management as stipulated by the ISO. ISO 9001 certifies quality management based on the "design, development, production, installation and auxiliary services" for products built at an authorized plant.



The Air Conditioning & Refrigeration Systems Works acquired environmental management system standard ISO 14001 certification.

The ISO 14000 series is a set of standards applying to environmental protection set by the International Standard Organization (ISO). Registered on March 10, 1998.

MITSUBISHI ELECTRIC CORPORATION

http://Global.MitsubishiElectric.com





Advanced Touch Controller





New Advanced Touch Controller AT-50A

With our new Advanced Touch Controller AT-50A, easy and simple operation on the touch panel offers an optimal air environment for individual unit.



NEW DESIGN

Backlit LCD (Liquid Crystal Display) Touch Panel

5-inch color LCD touch panel enables easy and simple operation.

The backlight lights up when the panel is touched, and lights off after certain period of time. The touch panel displays the operation status of the units in GRID, LIST or in GROUP.





GRID (zoom-in) screen
Displays the detailed
operation status of each
group.



group with group name.



Simple button arrangement

The F1 (Function 1) and the F2 (Function 2) button can be set as a run button of the following collective operation.

(Setback/Schedule/Operation Mode/Temperature Correction/Remote Controller Prohibition)

NEW FUNCTION —

Three in One

The following three features are integrated into AT-50A.

- Control up to 50 indoor units from one location
- A weekly programmable timer, being able to control up to 50 indoor units
- Control up to 50 units/50 groups of air conditioners

Weekly and daily schedule

5 patterns of one day and 12 patterns of weekly schedule (16 settings max. per pattern). Two types of weekly schedule can be set.

Night setback function

This function allows having a two-temperature setting to keep the desired room temperature when the units are not in operation and during the time this function is effective. The unit automatically starts heating (cooling) operation when the temperature drops below (rises above) the preset lower (upper) limit temperature. This is not only for comfort environment, but also for saving energy.

System changeover

Operation mode can be switched depending on indoor temperature setting and target temperature of each group or a representative indoor unit.

Main system controller/Sub system controller

AT-50A can be set to Sub System controller.

When connecting multiple system controllers, designate the system controller with many functions as the "Main", and set the system controllers with few functions as the "Sub".

Functions -

[Basic Functions]

- ON/OFF Operation mode switching Temperature setting Fan speed setting
- Airflow direction setting Louver setting

[Advanced Functions]

Item	Description	Operations	Display
Permit / Prohibit	The ON/OFF, operation mode, setting temperature and filter sign reset operations using the local remote controllers can be prohibited. Only ON/OFF and filter reset can be prohibited for the LOSSNAY group.	0	0
Operation lock	The operation lock can be set to the input operation of AT-50A. Each button can be set. (Function Button 1, Function Button 2, Collective ON/OFF, Touch Panel) Each function can be set. (Operation mode, Setting temperature, Fan speed, Menu button) The password for the lock release can be set.	0	0
Error display	When an error is currently occurring on an air conditioner unit, the afflicted unit and the error code are displayed. *When an error occurs, the "ON/OFF" LED flashes. The operation monitor screen show abnormal icon over the unit. The error monitor screen shows the abnormal unit address and error code. The error log monitor screen shows the time and date, the abnormal unit address, error code and source of detection.	x	
Ventilation (independent)	Switches the mode "Bypass/Heat recovery/Auto" for LOSSNAY groups.	0	0
Ventilation (interlocked)	The LOSSNAY will run in interlock with the operation of indoor unit. The mode cannot be changed. The LED will turn ON during operation after interlocking.	0	0
Temperature-set limitation	Batch-setting to temperature range limit at cooling, heating, and auto mode. This function cannot be used with the MA remote controller. (Depends on the Indoor unit model.)	0	0
Specific mode operation prohibit (Cooling prohibit, heating prohibit, cooling/ heating prohibit)	When set as the main controller, operation of the following modes with the local remote controllers can be prohibited. When cooling is prohibited: Cooling, dry, automatic can not be chosen. When heating is prohibited: Heating, automatic can not be chosen. When cooling/heating is prohibited: Cooling, dry, heating, automatic can not be chosen.	0	0
External input (Emergency stop input, etc.)	The following input with level signals or pulse signals are available. Level signal: "Emergency stop input" or "Collective ON/OFF" Pulse signal: "Collective ON/OFF" or "Local remote controller prohibit/permit" One Input can be selected from those above. " An external input/output adapter (PAC-VT41HAA (sold separately)) is required. Relays and DC power supply or other devices must be prepared at the site.	0	0
External output (Error output, operation output)	"ON/OFF" and "error/normal" are output with the level signal. *An external input/output adapter (PAC-YT41HAA (sold separately)) is required. Relays and DC power supply or other devices must be prepared at the site.	0	0
Checking the Gas Amount	Use this function to check for refrigerant leak from the outdoor unit. *When this function is used, the gas amount checking function of the outdoor unit cannot be used. This function is for CITY MULTI R2 and Y (PUMY is excluded.) series only.		
Schedule operation	Weekly schedule setting up to 12 pattern is available. In one pattern, up to 16 setting of "ON/OFF", "Operation mode", "Set Temperature", "Fan speed", "Air flow direction" and "Permit / Prohibit local operation" can be scheduled. Two types of weekly schedule(Summer/Winter) can be set. Today's schedule setting up to 5 pattern in available.	0	0

☐: Each unit ☐: Each group ☐: Group or collective X: Not available

^{*} Depending on the installation conditions, power supply unit (PAC-SC51KUA) is required. Please contact your local distributor or MITSUBISHI ELECTLIC branch office for further information