



Air-cooled Chilling Unit

Changes for the Better

e-series

2015

R410A

Service Handbook

Model




EAHV-P900YA(-N)(-BS)

EAHV-P900YA-H(-N)(-BS)

EACV-P900YA(-N)(-BS)

Safety Precautions

- Thoroughly read the following safety precautions prior to use.
- Observe these precautions carefully to ensure safety.

 WARNING	Indicates a risk of death or serious injury
 CAUTION	Indicates a risk of injury or structural damage
 IMPORTANT	Indicates a risk of damage to the unit or other components in the system

All electric work must be performed by personnel certified by Mitsubishi Electric.

General

WARNING

Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate.

- Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit.
- It may also be in violation of applicable laws.
- MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.

Do not install the unit in a place where large amounts of oil, steam, organic solvents, or corrosive gases, such as sulfuric gas, are present or where acidic/alkaline solutions or sprays containing sulfur are used frequently.

These substances can compromise the performance of the unit or cause certain components of the unit to corrode, which can result in refrigerant leakage, water leakage, injury, electric shock, malfunctions, smoke, or fire.

Do not try to defeat the safety features of the unit or make unauthorized setting changes.

Forcing the unit to operate the unit by defeating the safety features of the devices such as the pressure switch or the temperature switch, making unauthorized changes to the switch settings, or using accessories other than the ones recommended by Mitsubishi Electric may result in smoke, fire, or explosion.

To reduce the risk of fire or explosion, do not use volatile or flammable substances as a heat carrier.

To reduce the risk of burns or electric shock, do not touch exposed pipes and wires.

To reduce the risk of shorting, current leakage, electric shock, malfunctions, smoke, or fire, do not splash water on electric parts.

To reduce the risk of electric shock, malfunctions, smoke or fire, do not operate the switches/buttons or touch other electrical parts with wet hands.

To reduce the risk of electric shock and injury from the fan or other rotating parts, stop the operation and turn off the main power before cleaning, maintaining, or inspecting the unit.

To reduce the risk of burns or frost bites, do not touch the refrigerant pipes or refrigerant circuit components with bare hands during and immediately after operation.

Before cleaning the unit, switch off the power.
(Unplug the unit, if it is plugged in.)

To reduce the risk of injury, keep children away while installing, inspecting, or repairing the unit.

Children should be supervised to ensure that they do not play with the appliance.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Keep the space well ventilated. Refrigerant can displace air and cause oxygen starvation.

If leaked refrigerant comes in contact with a heat source, toxic gas may be generated.

Always replace a fuse with one with the correct current rating.

The use of improperly rated fuses or a substitution of fuses with steel or copper wire may result in fire or explosion.

If any abnormality (e.g., burning smell) is noticed, stop the operation, turn off the power switch, and consult your dealer.

Continuing the operation may result in electric shock, malfunctions, or fire.

Properly install all required covers and panels on the terminal box and control box to keep moisture and dust out.

Dust accumulation and water may result in electric shock, smoke, or fire.

Consult an authorized agency for the proper disposal of the unit.

Refrigerant oil and refrigerant that may be left in the unit pose a risk of fire, explosion, or environmental pollution.

CAUTION

To reduce the risk of fire or explosion, do not place flammable materials or use flammable sprays around the unit.	To prevent environmental pollution, dispose of brine in the unit and cleaning solutions according to the local regulations.
Do not operate the unit without panels and safety guards properly installed.	It is punishable by law not to dispose of them according to the applicable laws.
To reduce the risk of injury, do not sit, stand, or place objects on the unit.	The water heated by the heat pump is not suitable for use as drinking water or for cooking.
Do not connect the makeup water pipe directly to the potable water pipe. Use a cistern tank between them.	It may cause health problems or degrade food.
Connecting these pipes directly may cause the water in the unit to migrate into the potable water and cause health problems.	In areas where temperature drops to freezing during the periods of non-use, blow the water out of the pipes or fill the pipes with anti-freeze solution.
To reduce the risk of adverse effects on plants and animals, do not place them where they are directly exposed to discharge air from the unit.	Not doing so may cause the water to freeze, resulting in burst pipes and damage to the unit or the furnishings.
Do not install the unit on or over things that are vulnerable to water damage.	In areas where temperature drops to freezing, use an anti-freeze circuit and leave the main power turned on to prevent the water in the water circuit from freezing and damaging the unit or causing water leakage and resultant damage to the furnishings.
Condensation may drip from the unit.	Use clean tap water.
The model of heat pump unit described in this manual is not intended for use to preserve food, animals, plants, precision instruments, or art work.	The use of acidic or alkaline water or water high in chlorine may corrode the unit or the pipes, causing water leakage and resultant damage to the furnishings.
To reduce the risk of injury, do not touch the heat exchanger fins or sharp edges of components with bare hands.	In areas where temperature can drop low enough to cause the water in the pipes to freeze, operate the unit often enough to prevent the water from freezing.
Do not place a container filled with water on the unit.	Frozen water in the water circuit may cause the water to freeze, resulting in burst pipes and damage to the unit or the furnishings.
If water spills on the unit, it may result in shorting, current leakage, electric shock, malfunction, smoke, or fire.	Periodically inspect and clean the water circuit.
Always wear protective gears when touching electrical components on the unit.	Dirty water circuit may compromise the unit's performance or corrodes the unit or cause water leakage and resultant damage to the furnishings.
Several minutes after the power is switched off, residual voltage may still cause electric shock.	Ensure that the flow rate of the feed-water is within the permitted range.
To reduce the risk of injury, do not insert fingers or foreign objects into air inlet/outlet grills.	If the flow rate exceeds the permitted range, the unit may become damaged due to corrosion. Furniture may become wet due to water leaks.
To reduce the risk of injury, wear protective gear when working on the unit.	
Do not release refrigerant into the atmosphere. Collect and reuse the refrigerant, or have it properly disposed of by an authorized agency.	
Refrigerant poses environmental hazards if released into the air.	

Transportation

WARNING

Lift the unit by placing the slings at designated locations. Support the outdoor unit securely at four points to keep it from slipping and sliding.
If the unit is not properly supported, it may fall and cause personal injury.

CAUTION

To reduce the risk of injury, do not carry the product by the PP bands that are used on some packages.
To reduce the risk of injury, products weighing 20 kg or more should be carried by two or more people.

Installation

WARNING

Do not install the unit where there is a risk of leaking flammable gas.

If flammable gas accumulates around the unit, it may ignite and cause a fire or explosion.

Properly dispose of the packing materials.

Plastic bags pose suffocation hazard to children.

The unit should be installed only by personnel certified by Mitsubishi Electric according to the instructions detailed in the Installation/Operation Manual.

Improper installation may result in refrigerant leakage, water leakage, injury, electric shock, or fire.

Periodically check the installation base for damage.

If the unit is left on a damaged base, it may fall and cause injury.

Remove packing materials from the unit before operating the unit. Note that some accessories may be taped to the unit. Properly install all accessories that are required.

Failing to remove the packing materials or failing to install required accessories may result in refrigerant leakage, oxygen starvation, smoke, or fire.

Consult your dealer and take appropriate measures to safeguard against refrigerant leakage and resultant oxygen starvation. An installation of a refrigerant gas detector is recommended.

Any additional parts must be installed by qualified personnel. Only use the parts specified by Mitsubishi Electric.

Take appropriate safety measures against wind gusts and earthquakes to prevent the unit from toppling over and causing injury.

Be sure to install the unit horizontally, using a level.

If the unit is installed at an angle, it may fall and cause injury or cause water leakage.

The unit should be installed on a surface that is strong enough to support its weight.

As an anti-freeze, use ethylene glycol or propylene glycol diluted to the specified concentration.

The use of other types of anti-freeze solution may cause corrosion and resultant water leakage. The use of flammable anti-freeze may cause fire or explosion.

CAUTION

Do not install the unit on or over things that are vulnerable to water damage.

When the indoor humidity exceeds 80% or if the drain water outlet becomes clogged, condensation may drip from the indoor unit onto the ceiling or floor.

All drainage work should be performed by the dealer or qualified personnel according to the instructions detailed in the Installation Manual.

Improper drainage work may cause rain water or drain water to enter the buildings and damage the furnishings.

Pipe installation

WARNING

To prevent explosion, do not heat the unit with refrigerant gas in the refrigerant circuit.

Check for refrigerant leakage at the completion of installation.

If leaked refrigerant comes in contact with a heat source, toxic gas may be generated.

CAUTION

Check that no substance other than the specified refrigerant (R410A) is present in the refrigerant circuit.

Infiltration of other substances may cause the pressure to rise abnormally high and cause the pipes to explode.

To keep the ceiling and floor from getting wet due to condensation, properly insulate the pipes.

Piping work should be performed by the dealer or qualified personnel according to the instructions detailed in the Installation Manual.

Improper piping work may cause water leakage and damage the furnishings.

To keep the ceiling and floor from getting wet due to condensation, properly insulate the pipes.

Electrical wiring

To reduce the risk of wire breakage, overheating, smoke, and fire, keep undue force from being applied to the wires.

Properly secure the cables in place and provide adequate slack in the cables so as not to stress the terminals.

Improperly connected cables may break, overheat, and cause smoke or fire.

To reduce the risk of injury or electric shock, switch off the main power before performing electrical work.

All electric work must be performed by a qualified electrician according to the local regulations, standards, and the instructions detailed in the Installation Manual.

Capacity shortage to the power supply circuit or improper installation may result in malfunction, electric shock, smoke, or fire.

To reduce the risk of electric shock, smoke, or fire, install an inverter circuit breaker on the power supply to each unit.

Use properly rated breakers and fuses (inverter breaker, Local Switch <Switch + Type-B fuse>, or no-fuse breaker).

The use of improperly rated breakers may result in malfunctions or fire.

⚠ CAUTION

To reduce the risk of current leakage, wire breakage, smoke, or fire, keep the wiring out of contact with the refrigerant pipes and other parts, especially sharp edges.

To reduce the risk of current leakage, overheating, smoke, or fire, use properly rated cables with adequate current carrying capacity.

Keep the unsheathed part of cables inside the terminal block.

If unsheathed part of the cables come in contact with each other, electric shock, smoke, or fire may result.

Proper grounding must be provided by a licensed electrician. Do not connect the grounding wire to a gas pipe, water pipe, lightning rod, or telephone wire.

Improper grounding may result in electric shock, smoke, fire, or malfunction due to electrical noise interference.

To reduce the risk of electric shock, shorting, or malfunctions, keep wire pieces and sheath shavings out of the terminal block.

Transportation and repairs

⚠ WARNING

The unit should be moved, disassembled, or repaired only by qualified personnel. Do not alter or modify the unit.

Improper repair or unauthorized modifications may result in refrigerant leakage, water leakage, injury, electric shock, or fire.

After disassembling the unit or making repairs, replace all components as they were.

Failing to replace all components may result in injury, electric shock, or fire.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

⚠ CAUTION

To reduce the risk of shorting, electric shock, fire, or malfunction, do not touch the circuit board with tools or with your hands, and do not allow dust to accumulate on the circuit board.

IMPORTANT

To avoid damage to the unit, use appropriate tools to install, inspect, or repair the unit.

To reduce the risk or malfunction, turn on the power at least 12 hours before starting operation, and leave the power turned on throughout the operating season.

Recover all refrigerant from the unit.

It is punishable by law to release refrigerant into the atmosphere.

Do not unnecessarily change the switch settings or touch other parts in the refrigerant circuit.

Doing so may change the operation mode or damage the unit.

To reduce the risk of malfunctions, use the unit within its operating range.

Do not switch on or off the main power in a cycle of shorter than 10 minutes.

Short-cycling the compressor may damage the compressor.

To maintain optimum performance and reduce the risk of malfunction, keep the air pathway clear.

To reduce the risk of both the breaker on the product side and the upstream breaker from tripping and causing problems, split the power supply system or provide protection coordination between the earth leakage breaker and no-fuse breaker.

When servicing the refrigerant, open and close the check joint using two spanners, as there is the risk of refrigerant leaking due to damaged piping.



<p>Please build the water circuit so that it is a closed system.</p>	<p>Check the water system, using a relevant manual as a reference.</p>
<p>Do not use water directly for showers or other applications. Do not allow other heat source water to mix with the water circuit.</p>	<p>Using the system that does not meet the standards (including water quality and water flow rate) may cause the water pipes to corrode.</p>
<p>To ensure proper operation of the unit, periodically check for proper concentration of anti-freeze.</p>	<p>To reduce the risk of power capacity shortage, always use a dedicated power supply circuit.</p>
<p>Inadequate concentration of anti-freeze may compromise the performance of the unit or cause the unit to abnormally stop.</p>	<p>Have a backup system, if failure of the unit has a potential for causing significant problems or damages.</p>
<p>Take appropriate measures against electrical noise interference when installing the air conditioners in hospitals or facilities with radio communication capabilities.</p>	<p>This appliance is intended to be used by expert or trained users in shops, in light industry and on farms, or for commercial use by lay persons.</p>
<p>Inverter, high-frequency medical, or wireless communication equipment as well as power generators may cause the air conditioning system to malfunction. Air conditioning system may also adversely affect the operation of these types of equipment by creating electrical noise.</p>	

CONTENTS

I Read Before Servicing

[1] Read Before Servicing	3
[2] Necessary Tools and Materials	4
[3] Brazing	5
[4] Air Tightness Test	6
[5] Vacuum Drying (Evacuation)	7
[6] Refrigerant Charging	8
[7] Remedies to be taken in case of a Refrigerant Leak	8
[8] Characteristics of the Conventional and the New Refrigerants	9
[9] Notes on Refrigerating Machine Oil	10

II Restrictions

[1] System Configuration	13
[2] Types and Maximum allowable Length of Cables	14
[3] Electrical Wiring Installation	15
[4] Sample Installation	18
[5] Switch Types and the Factory Settings	19
[6] Configuring the Settings	20
[7] Water Pipe Installation	25

III Unit Components

[1] Unit Components and Refrigerant Circuit	35
[2] Control Box of the Unit	39
[3] Unit Circuit Board	41

IV Remote Controller

[1] Using the Remote Controller	49
[2] Function Settings	54

V Electrical Wiring Diagram

[1] Electrical Wiring Diagram	59
-------------------------------------	----

VI Refrigerant Circuit

[1] Refrigerant Circuit Diagram	65
[2] Principal Parts and Functions	66

VII Control

[1] Functions and Factory Settings of the Dipswitches	71
[2] Operating characteristics and Control Capabilities	85

VIII Test Run Mode

[1] Items to be checked before a Test Run	97
[2] Test Run Method	99
[3] Operating the Unit	100
[4] Refrigerant	101
[5] Symptoms that do not Signify Problems	101
[6] Standard operating characteristics (Reference data)	101

IX Troubleshooting

[1] Maintenance items	105
[2] Troubleshooting	108
[3] Troubleshooting Principal Parts	113
[4] Refrigerant Leak	128
[5] Parts Replacement Procedures	129

X Attachments

[1] R410A saturation temperature table	141
--	-----

CONTENTS

I Read Before Servicing

[1] Read Before Servicing	3
[2] Necessary Tools and Materials.....	4
[3] Brazing.....	5
[4] Air Tightness Test	6
[5] Vacuum Drying (Evacuation)	7
[6] Refrigerant Charging.....	8
[7] Remedies to be taken in case of a Refrigerant Leak.....	8
[8] Characteristics of the Conventional and the New Refrigerants	9
[9] Notes on Refrigerating Machine Oil	10

[1] Read Before Servicing

1. Check the type of refrigerant used in the system to be serviced.

Refrigerant Type

Air-cooled Chilling Unit e-series EAHV/EACV-P900YA: R410A

2. Check the symptoms exhibited by the unit to be serviced.

Refer to this service handbook for symptoms relating to the refrigerant cycle.

3. Thoroughly read the safety precautions at the beginning of this manual.

4. Preparing necessary tools: Prepare a set of tools to be used exclusively with each type of refrigerant.

Refer to "Necessary Tools and Materials" for information on the use of tools.(page 4)

5. If there is a leak of gaseous refrigerant and the remaining refrigerant is exposed to an open flame, a poisonous gas hydrofluoric acid may form. Keep workplace well ventilated.



CAUTION

- ♦Install new pipes immediately after removing old ones to keep moisture out of the refrigerant circuit.
- ♦The use of refrigerant that contains chloride, such as R22, will cause the refrigerating machine oil to deteriorate.

[2] Necessary Tools and Materials

Prepare the following tools and materials necessary for servicing the unit.

Tools for use with R410A (Adaptability of tools that are for use with R22 or R407C)

1. To be used exclusively with R410A (not to be used if used with R22 or R407C)

Tools/Materials	Use	Notes
Gauge Manifold	Evacuation and refrigerant charging	Higher than 4.82MPa on the high-pressure side
Charging Hose	Evacuation and refrigerant charging	
Refrigerant Recovery Cylinder	Refrigerant recovery	
Refrigerant Cylinder	Refrigerant charging	The refrigerant type is indicated. The cylinder is Gray
Charging Port on the Refrigerant Cylinder	Refrigerant charging	

2. Tools and materials that may be used with R410A with some restrictions

Tools/Materials	Use	Notes
Gas Leak Detector	Gas leak detection	The ones for use with HFC refrigerant may be used.
Vacuum Pump	Vacuum drying	May be used if a check valve adapter is attached.
Refrigerant Recovery Equipment	Refrigerant recovery	May be used if compatible with R410A.

3. Tools and materials that are used with R22 or R407C that may also be used with R410A

Tools/Materials	Use	Notes
Vacuum Pump with a Check Valve	Vacuum drying	
Bender	Bending pipes	
Torque Wrench	Tightening water pipes	
Pipe Cutter	Cutting pipes	
Welder and Nitrogen Cylinder	Welding pipes	
Refrigerant Charging Meter	Refrigerant charging	
Vacuum Gauge	Vacuum level check	

4. Tools and materials that must not be used with R410A

Tools/Materials	Use	Notes
Charging Cylinder	Refrigerant charging	Prohibited to use


Tools for R410A must be handled with special care to keep moisture and dust from infiltrating the cycle.

[3] Brazing


No changes have been made in the brazing procedures. Perform brazing with special care to keep foreign objects (such as oxide scale, water, and dust) out of the refrigerant system.

Example: Inside the brazed connection

Use of oxidized solder for brazing



Use of non-oxidized solder for brazing



1. Items to be strictly observed

- ♦ Do not conduct refrigerant piping work outdoors if raining.
- ♦ Use non-oxidized solder.
- ♦ Use a brazing material (BCuP-3) that requires no flux when brazing between copper pipes or between a copper pipe and copper coupling.
- ♦ If installed refrigerant pipes are not immediately connected to the equipment, then braze and seal both ends.

2. Reasons


- ♦ The new refrigerating machine oil is 10 times as hygroscopic as the conventional oil and is more likely to cause unit failure if water infiltrates into the system.
- ♦ Flux generally contains chloride. Residual flux in the refrigerant circuit will cause sludge to form.

3. Notes


Do not use commercially available antioxidants because they may cause the pipes to corrode or refrigerating machine oil to deteriorate.

[4] Air Tightness Test

No changes have been made in the detection method. Note that a refrigerant leak detector for R22 will not detect an R410A leak.



Halide torch



R22 leakage detector

1. Items to be strictly observed

- Pressurize the equipment with nitrogen up to the design pressure (4.15MPa), and then judge the equipment's air tightness, taking temperature variations into account.
- Refrigerant R410A must be charged in its liquid state (vs. gaseous state).

2. Reasons

- Oxygen, if used for an air tightness test, poses a risk of explosion. (Only use nitrogen to check air tightness.)
- Refrigerant R410A must be charged in its liquid state. If gaseous refrigerant in the cylinder is drawn out first, the composition of the remaining refrigerant in the cylinder will change and become unsuitable for use.

3. Notes

Procure a leak detector that is specifically designed to detect an HFC leak. A leak detector for R22 will not detect an HFC(R410A) leak.

[5] Vacuum Drying (Evacuation)



(Photo1) 15010H



(Photo2) 14010

Recommended vacuum gauge:
ROBINAIR 14010 Thermistor Vacuum Gauge

1. Vacuum pump with a reverse-flow check valve (Photo1)

To prevent the vacuum pump oil from flowing into the refrigerant circuit during power OFF or power failure, use a vacuum pump with a reverse-flow check valve.

A reverse-flow check valve may also be added to the vacuum pump currently in use.

2. Standard of vacuum degree (Photo 2)

Use a vacuum pump that attains 0.5Torr(65Pa) or lower degree of vacuum after 5 minutes of operation, and connect it directly to the vacuum gauge. Use a pump well-maintained with an appropriate lubricant. A poorly maintained vacuum pump may not be able to attain the desired degree of vacuum.

3. Required precision of vacuum gauge

Use a vacuum gauge that registers a vacuum degree of 5Torr(650Pa) and measures at intervals of 1Torr(130Pa). (A recommended vacuum gauge is shown in Photo2.)

Do not use a commonly used gauge manifold because it cannot register a vacuum degree of 5Torr(650Pa).

4. Evacuation time

- After the degree of vacuum has reached 5Torr(650Pa), evacuate for an additional 1 hour. (A thorough vacuum drying removes moisture in the pipes.)
- Verify that the vacuum degree has not risen by more than 1Torr(130Pa) 1hour after evacuation. A rise by less than 1Torr(130Pa) is acceptable.
- If the vacuum is lost by more than 1Torr(130Pa), conduct evacuation, following the instructions in section 6. Special vacuum drying.

5. Procedures for stopping vacuum pump

To prevent the reverse flow of vacuum pump oil, open the relief valve on the vacuum pump side, or draw in air by loosening the charge hose, and then stop the operation.

The same procedures should be followed when stopping a vacuum pump with a reverse-flow check valve.

6. Special vacuum drying


- When 5Torr(650Pa) or lower degree of vacuum cannot be attained after 3 hours of evacuation, it is likely that water has penetrated the system or that there is a leak.
- If water infiltrates the system, break the vacuum with nitrogen. Pressurize the system with nitrogen gas to 0.5kgf/cm²G(0.05MPa) and evacuate again. Repeat this cycle of pressurizing and evacuation either until the degree of vacuum below 5Torr(650Pa) is attained or until the pressure stops rising.
- Only use nitrogen gas for vacuum breaking. (The use of oxygen may result in an explosion.)

7. Notes

- Apply a vacuum through the check joints on the low pressure sides.
- Evacuating the system from the high-pressure side may damage the compressor.


[6] Refrigerant Charging

Cylinder with a siphon




Cylinder color R410A is Pink.


Cylinder without a siphon



Refrigerant charging in the liquid state



Charge refrigerant through the check joint on the high-pressure side.



Charging refrigerant through the check joint on the low-pressure side will create reverse pressure, resulting in compressor malfunctions.

1. Reasons

R410A is a mixture of 2 refrigerants, each with a different evaporation temperature. Therefore, if the equipment is charged with R410A gas, then the refrigerant whose evaporation temperature is closest to the outside temperature is charged first while the rest of refrigerants remain in the cylinder.

2. Notes

When using a cylinder with a siphon, refrigerant is charged in the liquid state without the need for turning it upside down. Check the type of the cylinder on the label before use.

[7] Remedies to be taken in case of a Refrigerant Leak

If the refrigerant leaks out, all of the remaining refrigerant must be replaced with a new charge to maintain the proper composition of the refrigerant. Repair the leak, and then charge the system with the specified amount of refrigerant (19 kg). (Charge refrigerant in the liquid state.)

Refer to "IX [4] Refrigerant Leak."(page 128)

[8] Characteristics of the Conventional and the New Refrigerants

1. Chemical property

As with R22, the new refrigerant (R410A) is low in toxicity and chemically stable nonflammable refrigerant.

However, because the specific gravity of vapor refrigerant is greater than that of air, leaked refrigerant in a closed room will accumulate at the bottom of the room and may cause hypoxia.

If exposed to an open flame, refrigerant will generate poisonous gases. Do not perform installation or service work in a confined area.

	New Refrigerant (HFC type)		Conventional Refrigerant (HCFC type)
	R410A	R407C	R22
	R32/R125	R32/R125/R134a	R22
Composition (wt%)	(50/50)	(23/25/52)	(100)
Type of Refrigerant	Pseudo-azeotropic Refrigerant	Non-azeotropic Refrigerant	Single Refrigerant
Chloride	Not included	Not included	Included
Safety Class	A1/A1	A1/A1	A1
Molecular Weight	72.6	86.2	86.5
Boiling Point (°C/°F)	-51.4/-60.5	-43.6/-46.4	-40.8/-41.4
Steam Pressure (25°C,MPa/77°F,psi) (gauge)	1.557/226	0.9177/133	0.94/136
Saturated Steam Density (25°C,kg/m ³ /77°F,psi)	64.0	42.5	44.4
Flammability	Nonflammable	Nonflammable	Nonflammable
Ozone Depletion Coefficient (ODP)*¹	0	0	0.055
Global Warming Coefficient (GWP)*²	2090	1774	1810
Refrigerant Charging Method	Refrigerant charging in the liquid state	Refrigerant charging in the liquid state	Refrigerant charging in the gaseous state
Replenishment of Refrigerant after a Refrigerant Leak	Available	Available	Available

*1 When CFC11 is used as a reference

*2 When CO₂ is used as a reference

2. Pressure characteristics

The pressure in the system using R410A is 1.6 times as great as that in the system using R22.

Temperature (°C/°F)	Saturation Pressure (gauge)		
	R410A	R407C	R22
	MPa/psi	MPa/psi	MPa/psi
-20/-4	0.30/44	0.18/26	0.14/20
0/32	0.70/102	0.47/68	0.40/58
20/68	1.34/194	0.94/136	0.81/117
40/104	2.31/335	1.44/209	1.44/209
60/140	3.73/541	2.43/354	2.33/338
65/149	4.17/605	2.74/399	2.60/377

[9] Notes on Refrigerating Machine Oil

1. Refrigerating machine oil in the HFC refrigerant system

HFC type refrigerants use a refrigerating machine oil different from that used in the R22 system.

Note that the ester oil used in the system has properties that are different from commercially available ester oil.

Refrigerant	Refrigerating machine oil
R22	Mineral oil
R407C	Ester oil
R410A	Ester oil

2. Effects of contaminants^{*1}

Refrigerating machine oil used in the HFC system must be handled with special care to keep contaminants out.

The table below shows the effect of contaminants in the refrigerating machine oil on the refrigeration cycle.

3. The effects of contaminants in the refrigerating machine oil on the refrigeration cycle.

Cause		Symptoms	Effects on the refrigerant cycle
Water infiltration		Frozen expansion valve and capillary tubes	Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat Motor insulation failure Burnt motor Coppering of the orbiting scroll Lock Burn-in on the orbiting scroll
		Hydrolysis	
Air infiltration		Oxidization	
Infiltration of contaminants	Dust, dirt	Adhesion to expansion valve and capillary tubes	Clogged expansion valve, capillary tubes, and drier Poor cooling performance Compressor overheat
		Infiltration of contaminants into the compressor	Burn-in on the orbiting scroll
	Mineral oil etc.	Sludge formation and adhesion	Clogged expansion valve and capillary tubes Poor cooling performance Compressor overheat
		Oil degradation	Burn-in on the orbiting scroll

*1. Contaminants is defined as moisture, air, processing oil, dust/dirt, wrong types of refrigerant, and refrigerating machine oil.

II Restrictions


[1]	System Configuration.....	13
[2]	Types and Maximum allowable Length of Cables	14
[3]	Electrical Wiring Installation	15
[4]	Sample Installation.....	18
[5]	Switch Types and the Factory Settings.....	19
[6]	Configuring the Settings.....	20
[7]	Water Pipe Installation	25

[1] System Configuration

The system must be configured only by personnel certified by Mitsubishi Electric.

[1] Schematic Diagrams of Individual and Multiple Module Connection Systems


(1) Individual system



Refer to the sections "Switch Types and the Factory Settings" (page19) and "System configuration procedures: Individual system" (page 22) for further details.

(2) Multiple module connection system (2-6 modules)

* A group of module that consists of one main module and up to 5 sub modules is operated collectively by connecting an external water temperature sensor and a dry contact switch/relay to the main module.



Refer to the sections "Switch Types and the Factory Settings" (page19) and "System configuration procedures: Multiple module connection system" (page 23) for further details.


[2] Types and Maximum allowable Length of Cables

1. Wiring work

(1) Notes

- 1) Have all electrical work performed by an authorized electrician according to the local regulations and instructions in this manual.
- 2) Install external transmission cables at least 5cm [1-31/32"] away from the power supply cable to avoid noise interference. (Do not put the control cable and power supply cable in the same conduit tube.)
- 3) Provide grounding for the unit as required.
- 4) Run the cable from the electric box of the unit in such way that the box is accessible for servicing.
- 5) Do not connect power supply wiring to the terminal block for transmission line. Doing so will damage the electronic components on the terminal block.
- 6) Use 2-core shielded cables as transmission cables.

Use a separate 2-core control cable for each refrigerant system. Do not use a single multiple-core cable to connect units that belong to different refrigerant systems. The use of a multiple-core cable may result in signal transmission errors and malfunctions.



(2) Control wiring

Different types of control wiring are used for different systems.

Types and maximum allowable length of cables

Control lines are categorized into 2 types: transmission line and remote controller line.

Use the appropriate type of cables and observe the maximum allowable length specified for a given system. If a given system has a long transmission line or if a noise source is located near the unit, place the unit away from the noise source to reduce noise interference.

[3] Electrical Wiring Installation


1 Main Power Supply Wiring and Switch Capacity

Schematic Drawing of Wiring (Example)

Ⓐ: Switch (with current breaking capability)

Ⓑ: Current leakage breaker

Ⓒ: Unit



Main power supply wire size, switch capacities, and system impedance

Model	Minimum wire thickness (mm ²)			Current leakage breaker	Local switch (A)		No-fuse breaker (A)	Max. Permissible System Impedance
	Main cable	Branch	Ground		Capacity	Fuse		
EAHV/EACV-P900YA	25	-	25	75 A 100 mA 0.1 sec. or less	75	75	75	0.12 Ω

1. Use a dedicated power supply for each unit. Ensure that each unit is wired individually.
2. When installing wiring, consider ambient conditions (e.g., temperature).
3. The wire size is the minimum value for metal conduit wiring. If voltage drop is a problem, use a wire that is one size thicker.
Make sure the power-supply voltage does not drop more than 5%.
4. Specific wiring requirements should adhere to the wiring regulations of the region.
5. Power supply cords of appliances shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57).
6. A switch with at least 3 mm contact separation in each pole shall be provided by the Air Conditioner installer.
7. Do not install a phase advancing capacitor on the motor. Doing so may damage the capacitor and result in fire.

⚠ Warning:

- Be sure to use specified wires and ensure no external force is imparted to terminal connections. Loose connections may cause overheating and fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that overcurrent may include direct current.

⚠ Caution:

- Some installation sites may require an installation of an earth leakage breaker for the inverter. If no earth leakage breaker is installed, there is a danger of electric shock.
- Only use properly rated breakers and fuses. Using a fuse or wire of the wrong capacity may cause malfunction or fire.

Note:

- This device is intended for the connection to a power supply system with a maximum permissible system impedance shown in the above table at the interface point (power service box) of the user's supply.
- Ensure that this device is connected only to a power supply system that fulfills the requirements above. If necessary, consult the public power supply company for the system impedance at the interface point.
- This equipment complies with IEC 61000-3-12 provided that the short-circuit power S_{SC} is greater than or equal to $S_{SC} (*2)$ at the interface point between the user's supply and the public system. It is the responsibility of the installer or user of the equipment to ensure, in consultation with the distribution network operator if necessary, that the equipment is connected only to a supply with a short-circuit power S_{SC} greater than or equal to $S_{SC} (*2)$.

$S_{SC} (*2)$

S_{SC} (MVA)
4.74

Control cable specifications


Remote controller cable	Size	0.3 - 1.25 mm ² (Max. 200 m total) *2
	Recommended cable types	CVV
M-NET cable between units *1	Size	Min. 1.25 mm ² (Max. 120 m total)
	Recommended cable types	Shielded cable CVVS, CPEVS or MVVS
External input wire size		Min. 0.3 mm ²
External output wire size		1.25 mm ²

*1 Use a CVVS or CPEVS cable (Max. total length of 200 m) if there is a source of electrical interference near by (e.g., factory) or the total length of control wiring exceeds 120 m.

*2 When the wiring length exceeds 10 m, use field-supplied wire of 1.25 mm².

2 Cable Connections

<1> Schematic Diagram of a Unit and Terminal Block Arrangement



- (1) Remove the front column and power supply box cover.
- (2) Wire the power supply and control wires. The power supply box is covered with a bush with membrane. Cut the bush with membrane before connecting wires to the terminal box.
- (3) Fasten the power supply wires by the cable strap.
- (4) Secure the cable conduit, and then waterproof the area around the pipe with silicon, etc.
- (5) Reattach the power supply box cover and front column.

<2> Precautions when fastening screws

- * Faulty contacts due to loose screws may cause overheating and fire.
- * Using the circuit board while it is damaged may cause overheating and fire.


① Screw fastening torque

Power supply terminal block (TB4)...M8 screw: **10 to 13.5 N·m**

Use the following methods to check that the screws have been fastened.


1. Check that the spring washer is in a parallel position.

* If the screw is biting into the washer, simply fastening the screw to the specified torque cannot determine whether it has been installed properly.



2. Check that the wiring does not move at the screw terminal.


- ② Take extra care not to ruin the screw thread due to fastening the screw at an angle.
* To prevent fastening the screw at an angle, install the round terminals so they are back to back.
- ③ After fastening the screw, use a permanent marker to tick off the screw head, washer and terminal.



Important: Power supply cables larger than 25 mm² in diameter are not connectable to the power supply terminal block (TB4). Use a pull box to connect them.

<3> Installing the conduit tube

- Always use a conduit to run the power supply wiring.
- Select the conduit size based on the hole.
- The cable conduits must be prepared locally.
- Do not store the 24VDC or less low-voltage circuit and 100VAC or higher main circuit and control circuit cables in the same multi-core cable, or bundle them together.
- Attach cable conduits securely to the foundation, etc. to ensure that excessive loads are not applied to the power supply terminal box.
- Seal the area around the cable conduit connection to ensure that no water penetrates the cable conduit connection port.




[4] Sample Installation

The system must be configured only by personnel certified by Mitsubishi Electric.

[1] Schematic Diagrams of Individual and Multiple Module Connection Systems


(1) Individual system



Refer to the sections "Switch Types and the Factory Settings" (page19) and "System configuration procedures: Individual system" (page 22) for further details.

(2) Multiple module connection system (2-6 modules)


* A group of module that consists of one main module and up to 5 sub modules is operated collectively by connecting an external water temperature sensor and a dry contact switch/relay to the main module.



Refer to the sections "Switch Types and the Factory Settings" (page19) and "System configuration procedures: Multiple module connection system" (page 23) for further details.

[5] Switch Types and the Factory Settings

(1) Switch names and functions




There are four main ways to set the settings as follows:

- ① Dip switches (SW1 - SW3, SW421)
- ② Dip switches used in combination with the push switches
- ③ Rotary switches
- ④ Slide switches


See below for how these switches are used to set certain items.

Different types of switches on the PCB


[Entire view of a PCB]



[Enlarged view of the switches]



		Initial Setting	
		MAIN circuit	SUB circuit
Rotary switch (SWU1)	Sets the 10's digit of the unit address (Multiple system).	"0"	"5"
Rotary switch (SWU2)	Sets the 1's digit of the unit address (Multiple system).	"1"	"1"
Rotary switch (SWU3)	Unused	"0"	"0"
Slide switch (SWS1)	LOCAL OFF REMOTE	REMOTE	OFF (Unused)
Slide switch (SWS2)	Cooling/Heating switching (Only EAHV-P900YA) (Effective only when SWS1 is set to LOCAL.)	A	A (Unused)
Push switch (SWP1)	Switches the display between the current value for a specific item. Increases value.	-	-
Push switch (SWP2)	Switches the display between the current value for a specific item. Decreases value.	-	-
Push switch (SWP3)	Enables the change of value. Saves the changed value.	-	-
Dip switches (SW1-3)	Setting change or view the settings	-	-
Dip switch (SW421)	Analog input type setting (Refer to Page 78)	-	(Unused)



[6] Configuring the Settings

The settings must be set only by a qualified personnel.


<1> Making the settings

Use the LED display and the three push switches (SWP1 (↑), SWP2 (↓), and SWP3 (Enter)) to change the current settings on the circuit board and to monitor various monitored values.

(1) Setting procedures

Take the following steps to set the push switches SWP1 through SWP3. These switches must be set after the dip switch SW1 has been set.

①




Normally a value of setting item appears on the display.



Press SWP3 (Enter) to enable the configuration changes.

②



The current setting value will blink.




The left figure shows that the current setting value is "60.0."

To decrease this value to 58.0, for example, press SWP2 (↓).

Press SWP1 (↑) to increase the value.

③



When the desired value is displayed (58.0 in the example at left), press SWP3 (Enter).



The displayed value will stop blinking and stay lit.

A lit LED indicates that the new setting has been saved.

* Pressing SWP1 (↑) or SWP2 (↓) will change the blinking setting value, but the change will not be saved until SWP3 (Enter) is pressed.

Press and hold SWP1 (↑) or SWP2 (↓) for one second or longer to fast forward through the numbers.

(2) Table of settings items

Set the dip switch SW1 as shown in the table below to set the value for the items in the "Setting item" column.

No.	Dip switch setting (SW1) *1 ■:ON □:OFF										Setting Item		Default	Notes
1				4	5	6		8	9	10	Maximum peak-demand capacity	100%	Range 60-100%	
2	1			4				7	8	10	Peak-demand control start time	13:00		
3		2		4				7	8	10	Peak-demand control end time	13:00		
4	1			4					9	10	Setting temp 1 (Cooling mode) *2	7°C	Range 5-25°C	
5	1					6			9	10	Setting temp 2 (Cooling mode) *2	20°C	Range 5-25°C	
6		2		4					9	10	Setting temp 1 (Heating mode) *3	45°C	Range 30-55°C	
7		2				6			9	10	Setting temp 2 (Heating mode) *3	55°C	Range 30-55°C	
8	1	2		4				7	8	10	Setting water temp A at Heating ECO mode *3	55°C	Range 30-55°C	
9			3	4				7	8	10	Setting outdoor temp A at Heating ECO mode *3	0°C	Range -30-50°C	
10	1		3	4				7	8	10	Setting water temp B at Heating ECO mode *3	35°C	Range 30-55°C	
11		2	3	4				7	8	10	Setting outdoor temp B at Heating ECO mode *3	25°C	Range -30-50°C	
12						5		7	8	10	Setting water temp C at Heating ECO mode *3	45°C	Range 30-55°C	
13	1					5		7	8	10	Setting outdoor temp C at Heating ECO mode *3	15°C	Range -30-50°C	
14			3			5			8	10	Enable/disable schedule setting *4	0	Set to "1" to enable scheduled operation.	
15			3	4					8	10	ON time 1 (at schedule mode without remote) *2	0:00	Cooling mode ON	
16	1		3	4					8	10	OFF time 1 (at schedule mode without remote) *2	0:00	Cooling mode OFF	
17		2	3	4					8	10	ON time 2 (at schedule mode without remote) *3	0:00	Heating mode ON	
18	1	2	3	4					8	10	OFF time 2 (at schedule mode without remote) *3	0:00	Heating mode OFF	
19	1	2				5		7	8	10	ON time 3 (at schedule mode without remote) *3	0:00	Heating ECO mode ON	
20			3			5		7	8	10	OFF time 3 (at schedule mode without remote) *3	0:00	Heating ECO mode OFF	
21	1	2		4						9	10	Thermo differential 1 (Cooling mode) *2	2°C	Range 0.2-5°C
22			3	4						9	10	Thermo differential 2 (Cooling mode) *2	2°C	Range 0.2-5°C
23	1		3	4						9	10	Thermo differential 1 (Heating mode) *3	2°C	Range 0.2-5°C
24		2	3	4						9	10	Thermo differential 2 (Heating mode) *3	2°C	Range 0.2-5°C
25						5	6		8	10	Drain pan heater operation outdoor temp	0°C	Range -40-20°C	
26	1		3					7	8	10	Supplementary heater operation water temp *3	40°C	Range 0-55°C	
27	1	2	3					7	8	10	Supplementary heater operation outdoor temp *3	-10°C	Range -30-50°C	
28		2				5		7	8	10	Select a heating curve *3	1	0: 2-point system, 1: curve	
29		2	3	4	5	6	7	8	9	10	Current time	-		
30	1		3	4	5	6	7	8	9	10	Month/Date setting	-		
31			3	4	5	6	7	8	9	10	Year setting	-		

*1: Do not apply undue force when changing the Dip switch settings as this may cause malfunctions.

*2: They are enabled during the cooling. (EAHV-P900YA, EACV-P900YA)

*3: They are enabled during the heating. (EAHV-P900YA, EAHV-P900YA-H)

*4: Disable the schedule setting when using the remote controller.

<2> System configuration

(1) System configuration procedures: Individual system


1. Set the dip switches on the MAIN circuit board.

Switch settings on the MAIN circuit

Set the dip switches (labeled A in the figure at right) that correspond to the items below, according to the local system.

- Water temperature control based on the external water temperature reading
- Analog signals from a remote location

Refer to "Dip switch settings table" (page 71) for further details.




2. Switch on the power to the unit.

Check for loose or incorrect wiring, and then switch on the power to the unit.

When the power is switched on, the following codes will appear on the LED:

- [EEEE] will appear on LED1 in the MAIN circuit board (labeled A in the figure at right).
- [9999] will appear on LED1 in the SUB circuit board (labeled B in the figure at right).



Within 50 seconds after the power is switched on, the following codes will appear on the LED:

- [****] will appear on LED1 in the MAIN circuit board (labeled A in the figure above).
- [0000]→[****] will appear on LED1 in the SUB circuit board (labeled B in the figure above).


****	Model
0000	EACV-P900YA
0001	EAHV-P900YA
0002	EAHV-P900YA-H

Then, the setting item "SW3-3" (page 71) will appear on the LED.

(2) System configuration procedures : Multiple modules connection system

1. Set the rotary switches.


System configuration diagram



Setting the switches on the main module

Make sure the address of the MAIN circuit on the main module is set to "1" (labeled A in the figure at right) and that the address of the SUB circuit on the main module is set to "51" (labeled B in the figure at right).

The address of each SUB circuit should equal the sum of the MAIN circuit address on the same module and 50.




Setting the switches on all sub modules

MAIN circuit

- (1) Set the MAIN circuit addresses with the rotary switches. (labeled A in the figure at right). Set the 10's digit with SWU1, and set the 1's digit with SWU2. Assign sequential addresses to the MAIN circuit on all sub modules starting with 2.

SUB circuit

- (2) Set the SUB circuit addresses with the rotary switches (labeled B in the figure at right). Set the 10's digit with SWU1, and set the 1's digit with SWU2. Assign sequential addresses to the SUB circuit on all sub modules starting with 52.



2. Switch on the power to the unit.

Check for loose or incorrect wiring, and then switch on the power to all modules.

When the power is switched on, the following codes will appear on the LED:


- [EEEE] will appear on LED1 in the MAIN circuit board.
- [9999] will appear on LED1 in the SUB circuit board.

Within 50 seconds after the power is switched on, the following codes will appear on the LED:

- [****] will appear on LED1 in the MAIN circuit board.
- [0000]→[****] will appear on LED1 in the SUB circuit board.

****	Model
0000	EACV-P900YA
0001	EAHV-P900YA
0002	EAHV-P900YA-H

Then, the setting item "SW3-3" (page 71) will appear on the LED.



3. Perform an initial setup on the main and sub modules

Perform the initial setup of all modules in accordance with the table below.

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Main module	Sub module	Default
1									8	10	Setting the multiple modules	1	1	0
2	1								8	10	Setting the main module	1	0	0
3		2							8	10	Setting the total number of modules	2-6	-	1
4			3						8	10	Setting the pump system *	0 or 1	0 or 1	1

*Change the setting to "0" in the multiple modules of the Standard piping type in one pump system and the Inside header piping type.


[7] Water Pipe Installation

1. Schematic Piping Diagram and Piping System Components

Please build the water circuit so that it is a closed system.

Do not use water directly for showers or other applications.
Do not allow other heat source water to mix with the water circuit.


Build a water circuit as inlet water temperature fluctuation is within 5°C/10 minutes.




①	Union joints/flange joints	Required to allow for a replacement of equipment.
②	Thermometer	Required to check the performance and monitor the operation of the units.
③	Water pressure gauge	Recommended for checking the operation status.
④	Valve	Required to allow for a replacement or cleaning of the flow adjuster.
⑤	Flexible joint	Recommended to prevent the noise and vibration from the pump from being transmitted.
⑥	Pump	Use a pump that is large enough to compensate for the total water pressure loss and supply sufficient water to the unit.
⑦	Air vent valve	Install air venting valves to the places where air can accumulate. Automatic air vent valves (such as ⑦ ') are effective.
⑧	Expansion tank	Install an expansion tank to accommodate expanded water and to supply water.
⑨	Water pipe	Use pipes that allow for easy air purging, and provide adequate insulation.
⑩	Drain valve	Install drain valves so that water can be drained for servicing.
a	Strainer	Install a strainer near the unit to keep foreign materials from entering the water-side head exchanger.
b	Flow switch	Required to protect the unit.
c	Drain pipe	Install the drain pipe with a downward inclination of between 1/100 and 1/200. To prevent drain water from freezing in winter, install the drain pipe as steep an angle as practically possible and minimize the straight line. For cold climate installation, take an appropriate measure (e.g., drain heater) to prevent the drain water from freezing.

2. Water piping attachment method

Standard piping type





* Victaulic standard groove specifications
Machine grooves to secure housing joints to field-supplied pipes based on the following dimensions.




	Pipe size
	50A
D	$\varnothing 60.3 \pm 0.61$
G	$\varnothing 57.15^{0}_{-0.38}$
L	15.88 ± 0.76
W	7.95 ± 0.76

Inside header piping type

It requires optional Inside heder piping kit.
Option Parts: EA-01HK



* Victaulic standard groove specifications
Machine grooves to secure housing joints to field-supplied pipes based on the following dimensions.



	Pipe size
	100A
D	$\varnothing 114.3^{+1.14}_{-0.79}$
G	$\varnothing 110.08^{0}_{-0.51}$
L	15.88 ± 0.76
W	9.53 ± 0.76


On-site module connection and terminal work

The module connection requires the option of both Inside header piping kit (EA-01HK) and Inside header connecting kit (EA-02HK). Inside header connecting kit requires the same number as the number of connections.

Option Parts: EA-01HK

EA-02HK

* Refer to the installation instructions for the details of installation of the optional parts.



The Victaulic joints and Straub joints used in the explanation are actual product names.

3. Notes on pipe corrosion

Water treatment and water quality control

Poor-quality circulating water can cause the water-side heat exchanger to scale up or corrode, reducing heat-exchange performance. Properly control the quality of the circulating water.

- Removing foreign objects and impurities in the pipes
During installation, keep foreign objects, such as welding and sealant fragments and rust, out of the pipes.

• Water Quality Control

- (1) Poor-quality water can corrode or scale up the heat exchanger. Regular water treatment is recommended.

Water circulation systems using open heat storage tanks are particularly prone to corrosion.

When using an open heat storage tank, install a water-to-water heat exchanger, and use a closed-loop circuit.

If a water supply tank is installed, keep contact with air to a minimum, and keep the level of dissolved oxygen in the water no higher than 1 mg/ℓ.

(2) Water quality standard

Items		Lower mid-range temperature water system Water Temp. ≤ 60°C		Higher mid-range temperature water system Water Temp. > 60°C		Tendency	
		Water Temp. ≤ 60°C		Water Temp. > 60°C		Tendency	
		Recirculating water	Make-up water	Recirculating water	Make-up water	Corrosive	Scale-forming
Standard items	pH (25°C)					○	○
	Electric conductivity (mS/m) (25°C) (μS/cm) (25°C)	30 or less [300 or less]	30 or less [300 or less]	30 or less [300 or less]	30 or less [300 or less]	○	○
	Chloride ion (mg Cl ⁻ /ℓ)	50 or less	50 or less	30 or less	30 or less	○	
	Sulfate ion (mg SO ₄ ²⁻ /ℓ)	50 or less	50 or less	30 or less	30 or less	○	
	Acid consumption (pH4.8) (mg CaCO ₃ /ℓ)	50 or less	50 or less	50 or less	50 or less		○
	Total hardness (mg CaCO ₃ /ℓ)	70 or less	70 or less	70 or less	70 or less		○
	Calcium hardness (mg CaCO ₃ /ℓ)	50 or less	50 or less	50 or less	50 or less		○
	Ionic silica (mg SiO ₂ /ℓ)	30 or less	30 or less	30 or less	30 or less		○
Reference items	Iron (mg Fe/ℓ)	1.0 or less	0.3 or less	1.0 or less	0.3 or less	○	○
	Copper (mg Cu/ℓ)	1.0 or less	1.0 or less	1.0 or less	1.0 or less	○	
	Sulfide ion (mg S ²⁻ /ℓ)	Not to be detected	Not to be detected	Not to be detected	Not to be detected	○	
	Ammonium ion (mg NH ₄ ⁺ /ℓ)	0.3 or less	0.1 or less	0.1 or less	0.1 or less	○	
	Residual chlorine (mg Cl/ℓ)	0.25 or less	0.3 or less	0.1 or less	0.3 or less	○	
	Free carbon dioxide (mg CO ₂ /ℓ)	0.4 or less	4.0 or less	0.4 or less	4.0 or less	○	
	Ryzner stability index	—	—	—	—	○	○

Reference: Guideline of Water Quality for Refrigeration and Air Conditioning Equipment. (JRA GL02E-1994)


- (3) Please consult with a water quality control specialist about water quality control methods and water quality calculations before using anti-corrosive solutions for water quality management.
- (4) When replacing an air conditioner (including when only the heat exchanger is replaced), first analyze the water quality and check for possible corrosion.
Corrosion can occur in water systems in which there has been no signs of corrosion. If the water quality level has dropped, adjust the water quality before replacing the unit.

(5) Suspended solids in the water

Sand, pebbles, suspended solids, and corrosion products in water can damage the heating surface of the heat exchanger and cause corrosion. Install a good quality strainer (20 mesh or better) at the inlet of the unit to filter out suspended solids.

Removing foreign substances from the water system

Consider installing a settlement tank or a bypass strainer to remove foreign substances from the water system. Select a strainer capable of handling two to three percent of the circulating water. The figure below shows a sample system with a bypass strainer.



(6) Connecting pipes made from different materials

If different types of metals are placed in direct contact with each other, the contact surface will corrode. Install an insulating material between pipes that are made of different materials to keep them out of direct contact with each other.

(7) Piping material

Use hot water output piping material that can withstand heat of 60°C or more. Use hot water input piping material that can withstand the maximum input water temperature. All piping must be made of SUS or similar material to withstand corrosion.

4. Installing the strainer and flow switch

(1) Installing the strainer


Install a strainer on the inlet pipe near the unit to filter out suspended solids and prevent clogging or corrosion of the heat exchanger.

Install a strainer in a way that allows for easy access for cleaning, and instruct the user to clean it regularly.

Operating the units with a clogged strainer may cause the units to make an abnormal stop.

Select a location to install a strainer, taking into consideration the installation angle, insulation thickness, and maintenance space.


* The dimensions given below indicate the amount of space necessary when screwing in a Y-shaped strainer.



Recommended torque :
200±20 (N·m)

Option Parts : YS-50A*

* YS-50A is for standard piping type.
Inside header type will need to supply a
strainer (20 mesh or its equivalent) for
100A piping to the site.



<Unit: mm>

Sample installation

(2) Installing a flow switch

Install a flow switch that meets the following specifications on the water pipe.

Connect the flow switch to the flow switch contact on the unit.

Minimum flow rate= 7.7 m³/h (128 L/min)

Unit usage range (water flow rate): 7.7 - 128 m³/h

5. Minimum and maximum water flow rates

A low flow rate will not only compromise the performance of the unit but also increase the water temperature difference between the periods when the unit is in operation and when the unit is stopped. A high flow rate will cause the pipes to corrode. Adjust the circulating flow rate so that the difference between the inlet and outlet temperatures will be between 3 °C and 10 °C. Refer to the table below for the standard, minimum, and maximum flow rates.

Standard, Minimum, and Maximum flow rates

Unit: m³/h

Standard flow rate	Minimum allowable flow rate	Maximum allowable flow rate
15.5	7.7	25.8

The hot water flow rate will be considered appropriate if the difference between the inlet and outlet water temperatures is between 3 °C and 10 °C.

• If the temperature difference is less than 3 °C
Decrease the flow rate.

• If the temperature difference is more than 10 °C
Increase the flow rate. Check the pipes for air pockets, and make sure that the pump has enough capacity to sustain appropriate water pressure in a given water circuit.

6. Maintaining the appropriate amount of water in the water circuit.

(1) Amount of water in the water circuit

Shortage of water in the circulating water circuit may shorten the operation time of the unit or cause large fluctuations of water temperature. The table below shows the minimum allowable amount of water in the water circuit. If the piping length is too short to secure this amount, install a cushion tank to ensure that the circuit has enough water in it.

Model	Minimum allowable amount of water (ℓ)
EAHV-P900YA(-H)	780
EACV-P900YA	420

(2) Calculating the amount of water in the circuit

The amount of water in the circuit can be obtained using the following formula.

Amount of water in the water circuit = Amount of water in the water piping + Amount of water in the unit + and Amount of water in the load-side or heat source unit

The table below shows the amount of water in the water piping per 1 m

Amount of water in the piping

	Pipe size					
	1 1/2B A(40A)	2B (50A)	2 1/2B (65A)	3B (80A)	4B (100A)	5B (125A)
Internal volume per meter (ℓ/m)	1.36	2.20	3.62	5.12	8.71	13.44

The table below shows the amount of water in the unit.

Amount of water in the unit

EAHV-P900YA(-H), EACV-P900YA	EAHV-P900YA(-H)-N, EACV-P900YA-N
20	55

7. Sizes and the material types of the pipes on the unit


The table below shows the sizes of the pipes.

Pipe sizes


Model	Inlet pipe connection	Outlet pipe connection
EAHV-P900YA(-H) EACV-P900YA	50A housing type joint (Field-supplied Victaulic joint) <SUS304 50A pipe>	50A housing type joint (Field-supplied Victaulic joint) <SUS304 50A pipe>
EAHV-P900YA(-H)-N EACV-P900YA-N	100A housing type joint (Field-supplied Victaulic joint) <SUS304 100A pipe>	100A housing type joint (Field-supplied Victaulic joint) <SUS304 100A pipe>

8. Water Piping Size and Location

<1> Standard piping type



<2> Inside header piping type





III Unit Components

[1] Unit Components and Refrigerant Circuit	35
[2] Control Box of the Unit.....	39
[3] Unit Circuit Board.....	41


[1] Unit Components and Refrigerant Circuit

1. Unit Components





Fan motor



Fan



SUB CONTROL BOX

TERMINAL BOX


FAN CONTROL BOX

MAIN CONTROL BOX

2. Refrigerant circuit




<Standard piping type>




[2] Control Box of the Unit


(1) Main circuit control box



(2) Sub circuit control box




(3) Fan control box



Note


- 1) Exercise caution not to damage the bottom and the front panel of the control box. Damage to these parts affect the waterproof and dust proof properties of the control box and may result in damage to its internal components.
- 2) Faston terminals have a locking function. Make sure the cable heads are securely locked in place. Press the tab on the terminals to remove them.

(4) Terminal box




[3] Unit Circuit Board

1. Control board (MAIN board)






3. INV board




Note

- 1) Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. It takes about 10 minutes to discharge electricity after the power supply is turned off.

4. Noise Filter (Compressor)



5. Fan control board






IV Remote Controller

[1] Using the Remote Controller.....	49
[2] Function Settings	54

[1] Using the Remote Controller

<1> Starting and Stopping Operation and Changing the Operation Mode



To Start Operation

1. Press the ON/OFF (BACK) button ①.
The power indicator ① and the display will light up.

To Stop Operation

1. Press the ON/OFF (BACK) button ① while the unit is in operation.
The power indicator ① and the display will light off.
The remote controller will remember the last mode and temperature settings when turned off.

To select the Mode

1. With the power turned on, press the Mode (BACK) button ② until the desired mode appears.
 - Each press changes the operation mode in the following sequence (see notes *1 and *2 below):
Heating→Heating ECO→Anti-freeze→Cooling→Back to Heating.
The currently selected mode will appear in the area labeled ②.

*1 If K07-K08 or K13-K15 is ON (CLOSE), the operation mode except Cooling mode cannot be changed from the remote controller.

*2 The available modes vary depending on the model.

*3 Refer to section [2] "Function Settings" [2]-2. (2) for how to change the settings for a specific function.

<2> Setting the Water Temperature

The current water temperature will appear in the area labeled [3].

How to Change the Temperature Setting

- To lower the water temperature setting
Press the ∇ Set Temperature button [3].
- To raise the water temperature setting
Press the Δ Set Temperature button [3].
 - Each press increases or decreases the temperature by 1 °C (1 °F).
The current setting will appear in the area labeled [3] in the figure on the previous page.
 - The settable ranges for the "Hot Water" and "Heating" modes are as follows. *1, *2

Heating	Cooling
30 °C - 55 °C 86 °F - 131 °F *3	5 °C - 25 °C 41 °F - 77 °F *3

Note:


- *1 Available ranges vary depending on the type of unit connected.
- *2 If the temperature ranges are restricted from the remote controller, the settable ranges may be narrower than shown above. If an attempt is made to set a value outside of the restricted range, the display will show a message indicating that the range is currently restricted.
For information about how to set and clear the restrictions, refer to section [2], item [2]-2. (3).
- *3 Temperatures can be displayed in Celsius or Fahrenheit (factory setting: Fahrenheit). For information about how to select °C or °F, refer to section [2], item [2]-4. (1).
- Water temperature can be controlled based on the outlet temperature.
- The water temperature range that can be displayed is between 0 °C to 100 °C. Outside this range, the display flashes either 0 °C or 100 °C.

<3> Setting the Day of the Week and Time


Use this screen to set and change the current day of the week and time settings.

Note:

The day and time will not appear if the clock display is disabled from the remote controller on the Function Selection menu.



How to Set the Day of the Week and Time



- Press the ∇ or Δ Set Time button [1] to bring up **TIME SET + ENTER** in the area labeled [2].
- Press the TIMER ON/OFF (SET DAY) button [1] to set the day (labeled [3] in the figure).
 - * Each press advances the day.
- Press the Set Time button [1] as necessary to set the time.
 - * When the button is held down, the time (at [4]) will increment first in one-minute intervals, then in ten-minute intervals, and then in one-hour intervals.
- After making the appropriate settings in Steps 2 and 3, press the CIR.WATER \leftarrow button [4] to save the values.

Note:

The changes will be lost unless the Mode (BACK) button [2] is pressed before the CIR.WATER \leftarrow button [4] is pressed.

- Press the Mode (BACK) button [2] to complete the setting procedure and return the display to the normal operation screen. The new day and time will appear in the area labeled [3].

<4> Using the Timer

Three types of timers are available as follows: ① Weekly timer, ② Simple timer, or ③ Auto-Off timer. The timer type can be selected from the remote controller on the Function Selection menu.

For information about how to use the Function Selection menu on the remote controller, refer to [2]-3. (3) (page 55).


Using the Weekly Timer

- The weekly timer can be used to schedule up to six events for each day of the week.
 - Each operation event can consist of any of the following: ON/OFF time together with a temperature setting, ON/OFF time only, or temperature setting only.
 - When the timer reaches the preset time, the schedule event will take place.
- The time can be set to the nearest minute.











Note:

- *1 The Weekly, Simple, and Auto-Off timers cannot be used concurrently.
- *2 The weekly timer will not operate when any of the following conditions is met.
The timer is off; the system is in error; a test run is in progress; the remote controller is performing self-check or remote controller check; the timer, function, day, or time is being set. If the ON/OFF status and/or the temperature setting is centrally controlled, their settings cannot be changed according to a schedule that was set from the remote controller.

Operation No.



How to Set the Weekly Timer

1. On the Normal Operation screen, make sure that the weekly timer icon  is displayed.
 2. Press the TIMER MENU button , so that the "Set Up" appears on the screen (). (Each press toggles between "Set Up" and "Monitor".)
 3. Press the TIMER ON/OFF (SET DAY) button  to set the day. Each press advances the day, which appears in the area labeled .
 4. Press the  or  INITIAL SETTING button ( or ) to select a desired operation pattern number (1 through 6) .
- * (The remote-controller display on the previous page shows how the display would appear if operation #1 for Sunday were set to the values shown below.)


Setup Matrix


Op No.	Sunday	Monday	...	Saturday	
No. 1	• 8:30 • ON • 23 °C (73 °F)				→ <Operation 1 settings for Sunday> Start the unit at 8:30, with the temperature set to 23 °C (73 °F).
No. 2	• 10:00 • OFF	• 10:00 • OFF	• 10:00 • OFF	• 10:00 • OFF	
...					→ <Operation 2 settings for every day> Turn off the unit at 10:00.
No. 6					

Note:

By selecting the day to “Sun Mon Tues Wed Thurs Fri Sat”, the same action can be carried out at the same time every day.

(Example: In Operation #2 above, the unit is scheduled to be turned off at 10:00 every day.)



5. Press the Set Time button **(5)** to set the time **(5)**.
 - * Time will first increment in one-minute intervals, then in ten-minute intervals, and then in one-hour intervals.
6. Press the ON/OFF button **(1)** to select the desired operation (ON or OFF), at **(6)**.
 - * Each press toggles through the following options:
No display (no setting) → "ON" → "OFF"
7. Press the Set Temperature button **(3)** to set the temperature **(7)**.
 - * Each press:
No display (no setting) ↔ 5 (41) → 6 (43) → ... ↔ 89 (192) ↔ 90 (194) ↔ No display. (Available temperature range: The temperature display range is between 5 °C (41 °F) and 90 °C (194 °F). The actual range which the temperature can be controlled will vary according to the type of the connected unit.)
8. To clear the current values for the selected operation, press and quickly release the CHECK (CLEAR) button **(10)** once.
 - * The displayed time setting will change to "—:—", and the ON/OFF and temperature settings will disappear.
(To clear all weekly timer settings at once, hold down the CHECK (CLEAR) button **(10)** for two seconds or more. The display will begin flashing, indicating that all settings have been cleared.)
9. After making the appropriate settings in Steps 5, 6, and 7, press the CIR.WATER  button **(4)** to save the values.


Note:

The changes will not be saved unless the Mode (BACK) button ② is pressed before the CIR.WATER ← button ④ is pressed.

If two or more different operation patterns have been scheduled for exactly the same time, only the operation with the highest Operation No. will be carried out.

10. Repeat Steps 3 through 9 as necessary to add more settings.
11. Press the Mode (BACK) button (2) to return to complete the setting procedure and return to the Normal Operation screen.
12. To activate the timer, press the TIMER ON/OFF button (9), so that the "Timer Off" icon (10) disappears.
 - * If no timer settings have been made, the "Timer Off" icon will flash on the screen.


How to View the Weekly Timer Settings



1. Make sure that "WEEKLY" is displayed (1).
2. Press the TIMER MENU button (2) so that "Monitor" appears on the screen (8).
3. Press the TIMER ON/OFF (SET DAY) button (9) to select the desired day.
4. Press the (▽) or (△) INITIAL SETTING ((7) or (8)) to toggle through the settings ((9)).
 - * Each press will advance the display to the next timer operation in order of time.
5. To close the monitor display and return to the Normal Operation screen, press the Mode (BACK) button (2).


To Turn Off the Weekly Timer

Press the TIMER ON/OFF button ⑨ so that “Timer Off” appears at [10].



To Turn On the Weekly Timer

Press the TIMER ON/OFF button ⑨ so that the "Timer Off" icon (10) disappears.




Using the Simple Timer

1. The simple timer can be set in any of the following three ways.
 - Start time only The unit starts when the set time has elapsed.
 - Stop time only The unit stops when the set time has elapsed.
 - Start & stop times The unit starts and stops at the respective elapsed times.
2. The simple timer can be set to start and stop the unit only once each within a 72-hour period.


The time setting can be made in one-hour increments.

Note:

- *1 Weekly, Simple, and AUTO-off timers cannot be used concurrently.
- *2 The simple timer will not operate when any of the following conditions is met. The timer is disabled; the system is in error; a test run is in progress; the remote controller is performing self-check or remote controller check; or a function or the timer is being set. If the ON/OFF status and/or the temperature setting is centrally controlled, their settings cannot be changed according to the schedule that was set from the remote controller.



How to Set the Simple Timer




- On the normal operation screen, make sure that the simple timer icon is displayed (1). If anything other than "SIMPLE" is displayed, select the simple timer by referring to [2]-3(3) (page 55).
- Press the TIMER MENU button (2), so that "Set Up" appears (2). (Each press toggles between "Set Up" and "Monitor".)
- Press the ON/OFF button (1) to display the current ON or OFF setting. Each press toggles between the time remaining until the unit turns on or off. ("ON" or "OFF" will appear in the area labeled 3.)
 - ON timer The unit will start operation when the specified hours have elapsed.
 - OFF timer The unit will stop operation when the specified hours have elapsed.
- With "ON" or "OFF" displayed on the screen (3), press the Set Time button (1) to set the hours until the unit turns on or off (4).
 - Available Range: 1 to 72 hours
- To set both the ON and OFF times, repeat Steps 3 and 4.
 - * Note that ON and OFF times cannot be set to the same value.
- To clear the current ON or OFF setting: Display the ON or OFF setting (see step 3) and then press the CHECK (CLEAR) button (10) so that "-" appears where the remaining time was. To use only the ON-timer or the OFF-timer, make sure that the time setting for the timer that will not be used is set to "-".
- After completing steps 3 through 6 above, press the CIR.WATER button (4) to save the value.

Note:

The changes will not be saved unless the Mode (BACK) button (2) is pressed before the CIR.WATER button (4) is pressed.

- Press the Mode (BACK) button (2) to return to the Normal Operation screen.
- Press the TIMER ON/OFF button (9) to start the timer countdown. When the timer is running, the remaining time should appear on the screen. **Make sure that the remaining time is displayed on the screen and that it is correct.**


Viewing the Current Simple Timer Settings



- Make sure that "SIMPLE" is displayed (1).
- Press the TIMER MENU button (2), so that "Monitor" appears on the screen (5).
 - If the ON or OFF simple timer is running, the current timer value will appear in the area labeled 6.
 - If ON and OFF values have both been set, the two values will appear alternately.
- Press the Mode (BACK) button (2) to close the monitor display and return to the Normal Operation screen.


To Turn Off the Simple Timer

Press the TIMER ON/OFF button (9) so that the timer setting no longer appears on the screen (at 7).



To Turn On the Simple Timer

Press the TIMER ON/OFF button (9) so that the timer setting appears in the area labeled 7.




Examples

The two examples below show how the screen will appear when both the ON- and Off- timers have been set.


Example 1:

The ON-timer is set to 3 hours, and the OFF-timer is set to 7 hours.



Example 2:

The ON-timer is set to 5 hours, and the OFF-timer is set to 2 hours.




Using the Auto-Off Timer


1. This timer begins countdown when the unit starts, and shuts the unit off when the set time has elapsed.
2. Available settings range from 30 minutes to 4 hours in 30-minute intervals.

Note:

- *1 Weekly Timer/Simple Timer/Auto Off Timer cannot be used at the same time.
- *2 The Auto Off timer will not operate when any of the following conditions is in effect.
The timer is off; the system is in error; a test run is in progress; the remote controller is performing self-check or remote controller check; or a function or the timer is being set. If the ON/OFF status and/or the temperature setting is centrally controlled, their settings cannot be changed according to the schedule that was set from the remote controller.



How to Set the Auto-Off TIMER




1. On the Normal Operation screen, make sure that "AUTO OFF" is displayed (1).
If anything other than "AUTO OFF" is displayed, select the Auto-Off timer by referring to [2]-3(3) (page 55).
2. Press and hold the TIMER MENU button (12) for 3 seconds, so that "Set Up" appears on the screen (2).
(Each press toggles between "Set Up" and "Monitor".)
3. Press the Set Time button (11) to set the OFF time (3).
4. Press the CIR.WATER button (4) to save the setting.

Note:

The changes will not be saved unless the Mode (BACK) button (2) is pressed before the CIR.WATER button (4) is pressed.

5. Press the Mode (BACK) button (2) to complete the setting procedure and return to the Normal Operation screen.
6. If the unit is already running, the timer will start counting down immediately. **Make sure that the remaining time is displayed on the screen and that it is correct.**


Checking the Current Auto-Off Timer Setting




1. Make sure that "AUTO OFF" is displayed (1).
2. Press and hold the TIMER MENU button (12) for 3 seconds so that "Monitor" appears (4).
• The time remaining until the unit will turn off will appear in the area labeled 5.
3. To close the monitor display and return to the Normal Operation screen, press the Mode (BACK) button (2).

To Turn Off the Auto-Off Timer

- Press and hold the TIMER ON/OFF button (9) for 3 seconds so that "Timer Off" appears (6) and the timer value (7) disappears.




- Alternatively, turn off the unit itself. The timer value (7) will disappear from the screen.



To Turn On the Auto-Off Timer

- Press and hold the TIMER ON/OFF button (9) for 3 seconds. The "Timer Off" will disappear (6), and the timer setting will appear on the display (7).
- Alternatively, turn on the unit. The timer value will appear in the area labeled 7.




[2] Function Settings

The settings for the following remote controller functions can be changed using the remote controller function selection mode. Change the settings as necessary.


Item 1	Item 2	Item 3 (Setting content)
1. Display language setting ("CHANGE LANGUAGE")	Display language selection	<ul style="list-style-type: none"> Use to select the display language from available languages.
2. Function lock settings ("FUNCTION SELECTION")	(1) Function lock ("LOCKING FUNCTION")	<ul style="list-style-type: none"> Use to lock functions.
	(2) Operation mode skip setting ("SELECT MODE")	<ul style="list-style-type: none"> Use to show or hide specific modes.
	(3) Temperature range limit setting ("LIMIT TEMP FUNCTION")	<ul style="list-style-type: none"> Use to restrict the temperature range.
3. Basic function settings ("MODE SELECTION")	(1) Remote controller main/sub setting ("CONTROLLER MAIN/SUB")	<ul style="list-style-type: none"> Use to designate the remote controller as Main or Sub. *When two remote controllers are connected to one group, one controller must be set to sub.
	(2) Use of clock setting ("CLOCK")	<ul style="list-style-type: none"> Use to enable or disable the clock.
	(3) Timer function setting ("WEEKLY TIMER")	<ul style="list-style-type: none"> Use to select a timer type.
	(4) Contact number setting ("CALL.")	<ul style="list-style-type: none"> Use to show or hide, or enter the emergency contact number.
	(5) Temp offset setting ("TEMP OFF SET FUNCTION")	<ul style="list-style-type: none"> Use to show or hide the offset value.
4. Display options ("DISP MODE SETTING")	(1) Temperature unit °C/°F setting ("TEMP MODE °C/°F")	<ul style="list-style-type: none"> Use to show or hide the temperature unit (°C or °F).
	(2) Water temperature display setting ("WATER TEMP DISP SELECT")	<ul style="list-style-type: none"> Use to show or hide the water temperature.

Function setting flowchart

[1] Stop the unit and go into the remote controller function selection mode. → [2] Select from item 1. → [3] Select from item 2. → [4] Make the setting. → [5] Return to the Normal Operation screen.




Dot display
The texts will appear in the selected language. In this manual, the texts are in English.



Settings details




[2]-1. Display language setting

The display language can be selected from the languages listed below.

- Press the [ MENU] button to change the language.
 - English (GB), ② German (D), ③ Spanish (E), ④ Russian (RU),
 - Italian (I), ⑥ French (F), ⑦ Swedish (SW)


[2]-2. Function lock settings

(1) Function lock

- Press the [ ON/OFF] button to toggle through the following options.
 - no1: All buttons except the [ ON/OFF] button will be locked.
 - no2: All buttons will be locked.
 - OFF (Default): No buttons will be locked.
- Press and hold the [CIR.WATER] and [ ON/OFF] buttons simultaneously for two seconds on the Normal Operation screen to enable the button-lock function.





(2) Operation mode skip setting

The following modes can be made available for selection or can be hidden.

- Press the [ ON/OFF] button to toggle through the following options.
 - Heating mode
 - Heating ECO mode
 - Hot Water mode
 - Anti-freeze mode
 - Cooling mode
 - OFF (Default): All modes will be available for selection.
- The mode that is not supported on the connected unit will not be available, even if the mode is available for selection on the display.

(3) Temperature range limit setting



The temperature range for the following modes can be restricted. Once the range has been restricted, the preset temperature can only be set to a value within the restricted range.

- Press the [ ON/OFF] button to toggle through the following options.
 - LIMIT TEMP HEATING MODE
 - LIMIT TEMP HOT WATER MODE
 - LIMIT TEMP ANTI-FREEZE MODE
 - LIMIT TEMP COOLING MODE
 - OFF (Default) : The temperature ranges are not active.
- To increase or decrease the temperature, press the [ TEMP.  or ] button.
- Settable range



Heating mode	: Lower limit: 30 ~55 °C (86 ~131 °F)
	Upper limit: 55 ~30 °C (131 ~ 86 °F)
Cooling mode	: Lower limit: 5 ~ 25 °C (41 ~ 77 °F)
	Upper limit: 25 ~ 5 °C (77 ~ 41 °F)
- The settable range varies depending on the type of unit to be connected.

[2]-3. Basic functions



(1) Remote controller main/sub setting

- Press the [ ON/OFF] button  to toggle between the following options.
 - Main The controller will be designated as the main controller.
 - Sub The controller will be designated as the sub controller.











(2) Use of clock setting

- Press the [ ON/OFF] button  to toggle between the following options.
 - ON The clock function.
 - OFF The clock function.



(3) Timer function setting

- Press the [ ON/OFF] button  to toggle through the following options.
 - WEEKLY TIMER (Default)
 - AUTO OFF TIMER
 - SIMPLE TIMER
 - TIMER MODE OFF
- When the use of clock setting is set to OFF, the "WEEKLY TIMER" cannot be used.

(4) Contact number setting



- Press the [ ON/OFF] button  to toggle through the following options.
 - CALL OFF The contact number will not be displayed when a problem occurs.
 - CALL **** * Use this option to enter the contact number.
- Setting the contact number
To set the contact number, follow the following procedures.
Press the [ TEMP.  or ] button  to move the cursor to the right (left). Press the [ CLOCK  or ] button  to set the contact number.

(5) Temp offset setting



- Press the [ ON/OFF] button  to toggle between the following options.
 - ON The offset value will be displayed under the water temperature initial setting mode.
 - OFF The offset value will not be displayed.

[2]-4. Display options

(1) Temperature unit °C/°F setting

- Press the [ ON/OFF] button  to toggle between the following options.
 - °C Celcius
 - °F Fahrenheit


(2) Water temperature display setting

- Press the [ ON/OFF] button  to toggle between the following options.
 - ON The water temperature will be displayed.
 - OFF The water temperature will not be displayed.


V Electrical Wiring Diagram

[1] Electrical Wiring Diagram.....	59
------------------------------------	----


[1] Electrical Wiring Diagram




The specification of the product might be changed without a previous notice for the improvement.



FAN control (front view)



Inside of the control box (front view)



Error Codes

No.	Error code	Error type	Error reset *1
1	1102	Discharge temperature fault	○
2	1138	Hot water abnormal rise	○
3	1176	Discharge SH fault	○
4	1189	ACC inlet SH fault	○
5	1301	Low pressure fault	○
6	1302,1303	High pressure fault	○
7	1503	Cold water abnormal drop	○
8	1510	Gas leak fault	○
9	1512	Low evaporation temperature fault	○
10	2500	Water supply cutoff (Flow switch)	○
11	2501,2550	Water supply cutoff (Sensor)	○
12	4102	Open phase	×
13	4106	Power supply fault *2	○
14	4115	Power supply frequency fault	×
15	4116	Fan motor fault	○
16	4122	Fan interlock fault	○
17	4126	Analog input error	—
18	4220	Inverter bus voltage fault	○
19	4230	Inverter overheat protection fault	○
20	4240	Inverter overload protection	○
21	4250	IPM error(inclusive)/overcurrent relay	○
22	5101	Water inlet temp 1 thermistor error(TH1)	○
23	5102	Water inlet temp 2 thermistor error(TH2)	○
24	5103	Water inlet temp 3 thermistor error(TH3)	○
25	5105	ACC inlet refrigerant temperature thermistor error(TH5/TH25)	○
26	5106	Air heat exchanger refrigerant thermistor error(TH6/TH26)	○
27	5107	Water heat exchanger refrigerant thermistor error(TH7/TH27)	○
28	5110	Outdoor temperature thermistor error(TH10)	○
29	5111	Discharge refrigerant temperature thermistor error(TH11/TH21)	○
30	5114	THHS sensor/Circuit fault	○
31	5115	External water sensor fault	○
32	5201	High pressure sensor fault	○
33	5202	Low pressure sensor fault	○
34	5301	ACCT sensor fault/Circuit fault	○
35	0403	Serial communication error	○
36	6500	Communication error between the MAIN and SUB units	—
37	6600		×
38	6602		—
39	6603	Communication error between the MAIN and SUB units	—
40	6606	(Simple multiple unit control)	—
41	6607		—
42	6831	Remote controller signal reception error 1	—
43	6832	Remote controller signal transmission error	—
44	6834	Remote controller signal reception error 2	—
45	6833	Remote controller over current	×
46	7113,7117	Model setting error	×

*1. Definition of symbols in the "Error reset" column.

○ ... Errors that can be reset

×

... Errors that cannot be reset

— ... Errors that will be automatically reset after the cause of the error is removed

*2. Power supply fault can be detected only when the switch setting "Automatic recovery after power supply fault" on the unit is set to "Disable." (The default setting is "Enable.")

Display setting (Control board display *)

SW3-3: OFF	SW3-3: ON
High pressure Low pressure	High pressure Low pressure Inlet water temperature Outlet water temperature Ambient temperature


* Display settings can be either of the MAIN BOX and the SUB box.
Display is switched in the 3 second intervals.

VI Refrigerant Circuit

[1] Refrigerant Circuit Diagram	65
[2] Principal Parts and Functions	66

[1] Refrigerant Circuit Diagram


◆ EAHV-P900YA(-H)



MAIN Circuit

SUB Circuit

◆ EACV-P900YA






MAIN Circuit

SUB Circuit

[2] Principal Parts and Functions

1. Outdoor unit

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Com-pressor	MC (Comp)		Adjusts the amount of circulating refrigerant by adjusting the operating frequency based on the operating pressure data	Low-pressure shell scroll compressor Wirewound resistance 20°C[68°F] : 0.092 ohm	
High pressure sensor	63HS (HP)		1) Detects high pressure 2) Regulates frequency and provides high-pressure protection	 <p>Pressure 0~4.15 MPa Vout 0.5~3.5V 0.071V/0.098 MPa Pressure [MPa] =1.38 x Vout [V]-0.69 Pressure =(1.38 x Vout [V] - 0.69) x 145 1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
Low pressure sensor	63LS (LP)		1) Detects low pressure 2) Provides low-pressure protection	 <p>Pressure 0~1.7 MPa Vout 0.5~3.5V 0.173V/0.098 MPa Pressure [MPa] =0.566 x Vout [V] - 0.283 Pressure =(0.566 x Vout [V] - 0.283) x 145 1 GND (Black) 2 Vout (White) 3 Vcc (DC5V) (Red)</p>	
Pressure switch	63H		1) Detects high pressure 2) Provides high-pressure protection	4.15MPa OFF setting	
Thermistor	TH11,21 (Discharge)		1) Detects discharge temperature 2) Provides high-pressure protection	<p>Degrees Celsius</p> $R_{120} = 7.465k\Omega$ $R_{25/120} = 4057$ $R_t = 7.465 \exp \left\{ 4057 \left(\frac{1}{273+t} - \frac{1}{393} \right) \right\}$ <p>0°C[32°F] : 698kohm 10°C[50°F] : 413kohm 20°C[68°F] : 250kohm 30°C[86°F] : 160kohm 40°C[104°F] : 104kohm 50°C[122°F] : 70kohm 60°C[140°F] : 48kohm 70°C[158°F] : 34kohm 80°C[176°F] : 24kohm 90°C[194°F] : 17.5kohm 100°C[212°F] : 13.0kohm 110°C[230°F] : 9.8kohm</p>	Resistance check

Part name	Symbols (functions)	Notes	Usage	Specifications	Check method
Thermistor	TH5,25 (ACC inlet Ref temperature)		1) Detects suction temperature 2) Provide low pressure protection	Degrees Celsius $R_{0} = 15k\Omega$ $R_{0/80} = 3385$ $R_t = 15 \exp\{3385 (\frac{1}{273+t} - \frac{1}{273})\}$	Resistance check
	TH6,26 (Air HEX Ref temperature)		Controls SC during cooling operation	0°C[32°F] :15kohm 10°C[50°F] :9.7kohm 20°C[68°F] :6.5kohm 25°C[77°F] :5.3kohm 30°C[86°F] :4.4kohm 40°C[104°F] :3.0kohm	
	TH7,27 (Water HEX Ref temperature)		Controls SC during heating operation		
	TH10 (Outdoor temperature)		1) Detects outdoor air temperature 2) Controls fan and compressor operation		
	TH1-3		1) Detects water temperature 2) Controls water temperature		
	THHS Inverter heat sink temperature		Provide the inverter circuit protection	Degrees Celsius $R_{50} = 17k\Omega$ $R_{25/120} = 4016$ $R_t = 17 \exp\{4016 (\frac{1}{273+t} - \frac{1}{323})\}$ 0°C[32°F] :161kohm 10°C[50°F] :97kohm 20°C[68°F] :60kohm 25°C[77°F] :48kohm 30°C[86°F] :39kohm 40°C[104°F] :25kohm	
4-way valve	MV (EAHV only)		Changeover between heating and cooling or defrost	AC220 - 240V OFF: cooling or defrost cycle ON: heating cycle	Continuity check with a tester
Heater	H		Heats the refrigerant in the compressor	Belt heater 240V 45W	Resistance check
Fan motor	FAN motor		Adjusts the operating frequency of the propeller fan based on the condensation or evaporation temperature	DC280V 187W	
Linear expansion valve	LEV (Refrigerant flow adjustment)		Adjusts refrigerant flow during heating	DC12V Opening of a valve driven by a stepping motor 2000 pulses	Refer to the section "Continuity Test with a Tester". Continuity between white, red, and orange. Continuity between yellow, and blue. 

VII Control

[1] Functions and Factory Settings of the Dipswitches	71
[2] Operating characteristics and Control Capabilities	85

[1] Functions and Factory Settings of the Dipswitches


1. Factory Switch Settings (Dip switch settings table)

				Factory setting				
SW		Function	Usage	MAIN circuit	SUB circuit	OFF setting	ON setting	Setting timing
SW1	1	Settings change or view the settings	These switches are used for setting change with push switch SWP 1, 2 and 3.	OFF	OFF	The 7-segment LED display is changed.		Depends on the setting
	2							
	3							
	4							
	5							
	6							
	7							
	8							
	9							
	10							
SW2	1	Model setting		Depends on the unit	-	Leave the setting as it is.		At a reset
	2							
	3							
	4							
	5	Water-temperature control option	Selects either the external water temperature sensor or the built-in sensor to be used to control water temperature.	OFF	-	Built-in sensor on the unit	External water temperature sensor	At a reset
	6	Model setting		OFF	-	Leave the setting as it is.		At a reset
	7	Analog input setting	Allows or disallows the analog signals from a remote location.	OFF	-	Disallows the external analog signals.	Allows the external analog signals.	At a reset
	8	Analog input signal switching	Selects either the water temperature or the capacity control ratio. (Effective only when SW2-7 is set to ON.)	OFF	-	Water temperature	Capacity control ratio	At a reset
	9	Auto restart after power failure	Enables or disables the automatic restoration of operation after power failure (in the same mode as the unit was in before a power failure).	ON	-	An alarm will be issued when power is restored after a power outage. The alarm will be reset when the power is turned off and then turned back on.	Automatically restores operation after power failure.	Any time
	10	Model setting		OFF	OFF	Leave the setting as it is.		Any time
SW3	1	Analog input type setting	Selects analog input 4-20mA/0-10V/1-5V/2-10V. (Effective only when SW2-7 is set to ON.)	OFF	OFF	1 / 2 4-20mA : OFF OFF 0-10V : ON OFF 1-5V : OFF ON 2-10V : ON ON		Any time
	2							
	3	Display setting *	Switches the LED display of the control board. (Display is switched in the 3 second intervals.)	ON	ON	High pressure Low pressure Low pressure	High pressure Low pressure Inlet water temperature Outlet water temperature Ambient temperature	Any time
	4	Model setting		OFF	-	Leave the setting as it is.		At a reset
	5							
	6							
	7							
	8	Model setting		OFF	OFF	Leave the setting as it is.		Any time
	9							
	10							


"-" in the table indicates that the function in the corresponding row will be disabled regardless of the actual switch setting. The factory setting for these items is OFF.

* LED display


High pressure




Inlet water temperature




Ambient temperature



Low pressure



Outlet water temperature



2. Slide switch (SWS1) settings

Individual system (SWS1 in the SUB circuit is ineffective.)

SWS1 Setting		Unit Operation	
MAIN circuit	SUB circuit	MAIN circuit	SUB circuit
LOCAL	-	Follows the input signal of the MAIN circuit	Follows the input signal of the MAIN circuit
OFF	-	Ignores the signal input	Ignores the signal input
REMOTE	-	Follows the input signal fed through a No-voltage contact interface	Follows the input signal of the MAIN circuit

Multiple system (SWS1 in the SUB circuit is ineffective.)

SWS1 Setting		Unit Operation			
Main module MAIN circuit	Sub module MAIN circuit	Main module MAIN circuit	Main module SUB circuit	Sub module MAIN circuit	Sub module SUB circuit
LOCAL	LOCAL	Follows the input signal of the MAIN circuit on the Main module	Follows the input signal of the MAIN circuit on the Main module	Follows the input signal of the MAIN circuit on the Sub module	Follows the input signal of the MAIN circuit on the Sub module
	OFF			Ignores the signal input	Ignores the signal input
	REMOTE			Follows the input signal of the MAIN circuit on the Main module	Follows the input signal of the MAIN circuit on the Main module
OFF	LOCAL	Ignores the signal input	Ignores the signal input	Follows the input signal of the MAIN circuit on the Sub module	Follows the input signal of the MAIN circuit on the Sub module
	OFF			Ignores the signal input	Ignores the signal input
	REMOTE				
REMOTE	LOCAL	Follows the input signal fed through a dry contact interface	Follows the input signal of the MAIN circuit on the Main module	Follows the input signal of the MAIN circuit on the Sub module	Follows the input signal of the MAIN circuit on the Sub module
	OFF			Ignores the signal input	Ignores the signal input
	REMOTE			Follows the input signal of the MAIN circuit on the Main module	Follows the input signal of the MAIN circuit on the Main module

Priority order of the water-temperature-setting-input-signal sources

Water temperature can be controlled by using the signals from the four types of input sources listed below. The setting for the item with higher priority will override the settings for the items with lower priorities. The water temperature will be controlled according to the temperature setting in the "Target water temperature" column that corresponds to a specific combination of the settings for the four items.

No-voltage contact input K04-K05 ON: Heating (EAHV-P900YA, EAHV-P900YA-H)

Priority 1	Priority 2	Priority 3	Priority 4	Priority 5			Target water temperature	Sensor that becomes active (when SW2-5 is set to ON) (*1)
No-voltage contact input K07-K08	Analog input	Main board on the unit	No-voltage contact input K13-K15	Remote controller PAR-W21MAA				
Anti freeze		Schedule setting	Mode change	No remote controller	Manual setting	Schedule setting		
ON	Ineffective	Ineffective	Ineffective	-	Ineffective	Ineffective	30°C	TH3
OFF	SW2-7: ON	Ineffective	Ineffective	-	Ineffective	Ineffective	Temperature setting for the analog signal input	TH15
	SW2-7: OFF	When schedule has been set	Ineffective	-	Ineffective	Ineffective	Heating or Heating ECO	TH15
		When no schedule has been set	ON (Heating ECO)	-	Ineffective	Ineffective	Heating ECO	TH15
			OFF (Heating)	When no RC is used	-	-	Heating	TH15
				-	Anti freeze	-	30°C	TH3
				-	Heating ECO	-	Heating ECO	TH15
				-	Heating	-	Heating	TH15
				-	Cooling (*2)	-	Cooling	TH15
				-	-	When schedule has been set (*3)	Target water temp is controlled according to the setting on the remote controller.	TH15

*1 If SW2-5 is set to OFF, water temperature will be controlled by the built-in thermistor TH3 on the unit.

*2 This mode is disabled in EAHV-P900YA-H.

*3 EAHV-P900YA can also set Cooling.

No-voltage contact input K04-K05 OFF: Cooling (EAHV-P900YA, EACV-P900YA)

* When the operation mode is Cooling, K07-K08 (Anti freeze) and K13-K15 (Mode change) are disabled.

Priority 1	Priority 2	Priority 3			Target water temperature	Sensor that becomes active (when SW2-5 is set to ON) (*1)
Analog input	Main board on the unit	Remote controller PAR-W21MAA				
	Schedule setting	No remote controller	Manual setting	Schedule setting		
SW2-7: ON	Ineffective	-	Ineffective	Ineffective	Temperature setting for the analog signal input	TH15
SW2-7: OFF	When schedule has been set	-	Ineffective (Cooling)	Ineffective (Cooling)	Cooling	TH15
	When no schedule has been set	When no RC is used	-	-	Cooling	TH15
		-	Anti freeze (*2)	-	30°C	TH3
		-	Heating ECO (*2)	-	Heating ECO	TH15
		-	Heating (*2)	-	Heating	TH15
		-	Cooling	-	Cooling	TH15
		-	-	When schedule has been set (*3)	Target water temp is controlled according to the setting on the remote controller.	TH15

*1 If SW2-5 is set to OFF, water temperature will be controlled by the built-in thermistor TH3 on the unit.

*2 This mode is disabled in EACV-P900YA.

*3 EAHV-P900YA can also set Heating or Heating ECO.

3. Setting procedures

(1) Water-temperature setting

Different water temperature settings can be set for different modes.

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.

When the desired value is displayed, press SWP3 to save the setting value.

Settings table


No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting			Setting change from an optional remote controller (PAR-W21MAA) *1
														Increments	Lower limit	Upper limit	
1	1			4					9	10	Setting temp 1 (Cooling mode)	7	°C	0.1°C	5	25	Possible *2
2	1					6			9	10	Setting temp 2 (Cooling mode)	20	°C	0.1°C	5	25	Possible *3
3		2		4					9	10	Setting temp 1 (Heating mode)	45	°C	0.1°C	30	55	Possible *2
4		2				6			9	10	Setting temp 2 (Heating mode)	55	°C	0.1°C	30	55	Possible *3
5	1	2		4			7	8		10	Setting water temp A at Heating ECO mode	55	°C	0.1°C	30	55	Not possible
6			3	4			7	8		10	Setting outdoor temp A at Heating ECO mode	0	°C	0.1°C	-30	50	Not possible
7	1		3	4			7	8		10	Setting water temp B at Heating ECO mode	35	°C	0.1°C	30	55	Not possible
8		2	3	4			7	8		10	Setting outdoor temp B at Heating ECO mode	25	°C	0.1°C	-30	50	Not possible
9					5		7	8		10	Setting water temp C at Heating ECO mode	45	°C	0.1°C	30	55	Not possible
10	1				5		7	8		10	Setting outdoor temp C at Heating ECO mode	15	°C	0.1°C	-30	50	Not possible
11		2			5		7	8		10	Select a heating curve	1	-	0: 2-point system, 1: curve			Not possible

*1 Temperature setting increments: 1°C


*2 No-voltage contact K10-K12: OFF

*3 No-voltage contact K10-K12: ON

Heating ECO (2-point system)




When the outdoor temp A and B are set to the same value.



* Setting temp C cannot be used.

Heating ECO (Curve)



* Always use a value for setting C that is between setting value A and setting value B.

(2) Scheduled operation

Up to three sets of start/end times can be assigned for each day.

Note Disable the schedule setting when using the remote controller.

Note The operation schedule function will operate only when SWS1 is set to "REMOTE."

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.


When the desired value is displayed, press SWP3 to save the setting value.

Settings table

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting		
														Increments	Lower limit	Upper limit
1			3		5			8		10	Enable/disable schedule setting	0	-	0: Disable, 1: Enable		
2			3	4				8		10	ON time 1 (Cooling mode without remote)	0000	Hour: minute	1 minute	0000	2359
3	1		3	4				8		10	OFF time 1 (Cooling mode without remote)	0000	Hour: minute	1 minute	0000	2359
4		2	3	4				8		10	ON time 2 (Heating mode without remote)	0000	Hour: minute	1 minute	0000	2359
5	1	2	3	4				8		10	OFF time 2 (Heating mode without remote)	0000	Hour: minute	1 minute	0000	2359
6	1	2			5		7	8		10	ON time 3 (Heating ECO mode without remote)	0000	Hour: minute	1 minute	0000	2359
7			3		5		7	8		10	OFF time 3 (Heating ECO mode without remote)	0000	Hour: minute	1 minute	0000	2359
8		2	3	4	5	6	7	8	9	10	Current time	-	Hour: minute	1 minute	0000	2359
9	1		3	4	5	6	7	8	9	10	Month/Date setting	-	Month: day	1 day	0101	1231
10			3	4	5	6	7	8	9	10	Year setting	-	Year	1 year	2000	2099


Note A mode (preset temperatures) can be selected for each operation time period. See the next page for how to make the settings.

[When the operation ON/OFF times do not overlap]




If two operation periods overlap, the settings for the period with a larger number will be ineffective.
If ON time 1 and ON time 3 are set to the same value, the setting for ON time 3 will be ineffective.


[When operation period 1 and 2 overlap]



[When operation periods 1 and 3 overlap]




[When operation periods 2 and 3 overlap]



If "ON time1 - OFF time 1", "ON time 2 - OFF time 2", "ON time 3 - OFF time 3" overlap, the settings for the period with a larger number will be ineffective.

[When operation periods 1 and 2 overlap and operation periods 2 and 3 overlap]



(3) Peak-demand control operation

Peak-demand control is a function used to control the power consumptions of the units during peak-demand hours.

The compressor's maximum operating frequency will be controlled according to the peak-demand control signal.

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.

When the desired value is displayed, press SWP3 to save the setting value.

Settings table

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting			Setting change from an optional remote controller (PAR-W21MAA)		
	IncrementsLower limitUpper limit																		
1				4	5	6		8	9	10	Maximum peak-demand capacity	100	%	1%	60	100	Not possible		
2	1			4				7	8		10	Peak-demand control start time	1300	Hour: minute	1 minute	0000	2359	Not possible	
3		2		4					7	8		10	Peak-demand control end time	1300	Hour: minute	1 minute	0000	2359	Not possible

(4) Remote water temperature or capacity control ratio setting input signal type

When SW2-7 is ON and SW2-8 is OFF, external analog signals can be used to set the water temperatures.

When SW2-7 and SW2-8 are ON, external analog signals can be used to set the capacity control ratio.

Analog input type can be selected from the following four types:

4-20 mA

0-10 V

1-5 V

2-10 V

Select SW3-1 and SW3-2 to set the type of analog input signal from a remote location.

Set the dip switches on the circuit board as follows to change the settings.

	SW421-1	SW421-2	SW3-1	SW3-2
4-20 mA	ON	ON	OFF	OFF
0-10 V	OFF	OFF	ON	OFF
1-5 V	OFF	ON	OFF	ON
2-10 V	OFF	OFF	ON	ON

*Incorrectly setting SW421 may cause damage to the circuit board.

(5) Setting the water temperature using analog signal input

When dip switch SW2-7 is set to ON (Enable external input) and SW2-8 is set to OFF, the target water temperature varies with the preset temperatures A and B and the type of analog input signal.

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.

When the desired value is displayed, press SWP3 to save the setting value.


Settings table

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting			Setting change from an optional remote controller (PAR-W21MAA)	
														Increments	Lower limit	Upper limit		
1		2		4	5	6		8		10	Preset temp. A (Cooling)	5	°C	1°C	5	25	Not possible	
2	1	2		4	5	6		8		10	Preset temp. B (Cooling)	25	°C	1°C	5	25	Not possible	
3	1							7	8		10	Preset temp. A (Heating)	30	°C	1°C	30	55	Not possible
4		2						7	8		10	Preset temp. B (Heating)	55	°C	1°C	30	55	Not possible


* Due to the resistance of the wire that is connected to the analog input, the preset temperature may not properly be sent. If this is the case, check the current value of the analog input, and adjust the output value of the connected signal output device. Refer to the tables below for how to display the value of the analog input.

No.	Dip switch setting (SW1) ■:ON □:OFF										Monitorable items	Unit
1		2						7			Current value (4-20 mA)	mA
2	1	2						7			SV voltage value (1-5 V)	V
3			3					7			10V voltage value (0-10 V or 2-10 V)	V

- When the water temperature setting input signal type is 4-20 mA
 - External analog input signal of 6 mA: Preset temp. A
 - External analog input signal of 18 mA: Preset temp. B
 - External analog input signal of between 6 and 18 mA: the preset temperature will be linearly interpolated.




- When the water temperature setting input signal type is 0-10 V
 - External analog input signal of 1 V: Preset temp. A
 - External analog input signal of 9 V: Preset temp. B
 - External analog input signal of between 1 and 9 V: the preset temperature will be linearly interpolated.




- When the water temperature setting input signal type is 1-5 V

- External analog input signal of 1.5 V: Preset temp. A
- External analog input signal of 4.5 V: Preset temp. B
- External analog input signal of between 1.5 and 4.5 V: the preset temperature will be linearly interpolated.



- When the water temperature setting input signal type is 2-10 V


- External analog input signal of 3 V: Preset temp. A
- External analog input signal of 9 V: Preset temp. B
- External analog input signal of between 3 and 9 V: the preset temperature will be linearly interpolated.




(6) Setting the capacity control ratio using analog signal input

When dip switch SW2-7 is set to ON (Enable external input) and SW2-8 is set to ON, the capacity control ratio varies with the type of analog input signal.


- When the water temperature setting input signal type is 4-20 mA
 - External analog input signal of 6 mA: 0%
 - External analog input signal of 18 mA: 100%
 - External analog input signal of between 6 and 18 mA: the percent will be linearly interpolated.




- When the water temperature setting input signal type is 0-10 V
 - External analog input signal of 1 V: 0%
 - External analog input signal of 9 V: 100%
 - External analog input signal of between 1 and 9 V: the percent will be linearly interpolated.



- When the water temperature setting input signal type is 1-5 V
 - External analog input signal of 1.5 V: 0%
 - External analog input signal of 4.5 V: 100%
 - External analog input signal of between 1.5 and 4.5 V: the percent will be linearly interpolated.



- When the water temperature setting input signal type is 2-10 V
 - External analog input signal of 3 V: 0%
 - External analog input signal of 9 V: 100%
 - External analog input signal of between 3 and 9 V: the percent will be linearly interpolated.



*%: When the compressor frequency drops below 16 Hz, the compressor stops.
The frequency value that causes the compressor to stop varies depending on the outside temperature and water temperature.

(7) Setting the supplementary heater signal output conditions

A temperature at which the signal output to operate supplementary heaters can be selected.

Supplementary heater signal output conditions

The operation command signal is ON and at least one of the following two conditions is met.

- 1 Water-temperature control option (SW2-5) is set to OFF, the inlet water temperature drops below a set water temperature, and the outdoor temperature drops below a set outdoor temperature.
- 2 Water-temperature control option (SW2-5) is set to ON, the external water temperature sensor reading (TH15) drops below a set water temperature, and the outdoor temperature drops below a set outdoor temperature.

The supplementary heater signal is output from K51-K52.

Supplementary heater signal output stop conditions

The operation command signal is OFF or at least one of the following two conditions is met.

- 1 The inlet water temperature is at or above a set water temperature +2°C or the outdoor temperature is at or above a set outdoor temperature +2°C.
- 2 External water temperature sensor reading (TH15) is at or above a set water temperature +2°C.

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.

When the desired value is displayed, press SWP3 to save the setting value.

Settings table

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting			Setting change from an optional remote controller (PAR-W21MAA)
														Increments	Lower limit	Upper limit	
1	1		3				7	8		10	Supplementary heater operation water temp	40	°C	0.1°C	0	55	Not possible
2	1	2	3				7	8		10	Supplementary heater operation outdoor temp	-10		0.1°C	-30	50	Not possible

(8) Setting the drain pan heater signal output condition

A temperature at which the signal output to operate drain pan heaters can be selected.

Drain pan heater signal output condition

The following condition is met.

The outdoor temperature drops below a set outdoor temperature.

The drain pan signal is output from K63-K64.

Drain pan heater signal output stop condition

The following condition is met.

The outdoor temperature is at or above a set outdoor temperature +2°C.

Set the dip switches on the circuit board as follows to make the settings for the items described in this section.

Press the push switch SWP3 to enable the configuration changes.

Press the push switches SWP1 (↑) or SWP2 (↓) to increase or decrease the value.

When the desired value is displayed, press SWP3 to save the setting value.

Settings table

No.	Dip switch setting (SW1) ■:ON □:OFF										Setting Item	Initial value	Unit	Setting			Setting change from an optional remote controller (PAR-W21MAA)
														Increments	Lower limit	Upper limit	
1					5	6		8		10	Drain pan heater operation outdoor temp	0	°C	1°C	-40	20	Not possible

[2] Operating characteristics and Control Capabilities

-1- Operating characteristics



Function	Component		Symbol	Control/ Detection	Action	Unit	Trigger condition
Unit protection	Pressure switch	High-pressure switch	63H	HP	ON	MPa	(3.25)
					OFF	MPa	$4.15^{+0}_{-0.15}$
	Pressure sensor	High-pressure sensor	HP	HP	OFF	MPa	3.9
		Low-pressure sensor	LP	LP	OFF	MPa	♦The low pressure has dropped below 0.1 MPa. ♦During water cooling, the low pressure has dropped below 0.56 MPa.
	Compressor overcurrent relay			Compressor current	OFF	A	33
	Fan overcurrent protection			Fan current	Limit	A	1.9
	Thermistor	Discharge refrigerant temp. (Discharge temp. override protection)	TH11 TH21	Discharge gas temp.	OFF	°C	♦If a discharge gas temperature of 120°C or above was detected three times in 1 hour, the unit will make an abnormal stop.
		Outlet water	TH3	Outlet water temp. (cooling)	OFF	°C	An outlet water temperature of 3°C was detected.
				Outlet water temp. (heating)	OFF	°C	An outlet water temperature of -65°C was detected.
		Air-side HEX refrigerant temp.	TH6 TH26	SC (cooling)	-	°C	-
		Water-side HEX refrigerant temp.	TH7 TH27	SC (heating)	-	°C	-
		ACC inlet refrigerant temp.	TH5 TH25	SH	OFF	°C	ACC inlet SH above 20°C has been detected for 10 minutes.
		Inverter heatsink temp.	THHS	INV. heat-sink temp.	OFF	°C	A temperature above 95°C has been detected for 10 minutes.
Pump control	Water temperature thermister		TH1-3	Water temp.	ON	°C	3
					OFF	°C	5
	Freeze-up protection circuit						The pump turns on when the water temperature has reached below the "ON" threshold when the compressor is stopped.

-2- Initial control

- When the power is turned on, the initial processing of the microcomputer is given top priority.
- During the initial processing, processing of the operation signal is suspended and is resumed after the initial processing is completed.
(Initial processing involves data processing by the microcomputer and initial setup of the LEV opening. This process takes up to one minute.)
- During the initial processing " EEE " will appear on the LED monitor on the MAIN board of the MAIN circuit.
- During the initial processing " 999 " will appear on the LED monitor on the MAIN board of the SUB circuit.

-3- Compressor frequency

- The upper limit of frequency during the first 60 seconds of operation is 20 Hz.
- The upper limit of frequency during the first 180 seconds of operation is 50 Hz.
- For 180 seconds after the startup, the compressor will be controlled every 15 seconds so that the frequency fluctuation will be kept within $\pm 20\%$ of the current frequency.
- The amount of frequency change is controlled to approximate the target value that are determined based on the temperature difference between the current and the preset water temperatures.
- The minimum operating frequency is 16 Hz.
- The maximum frequency will be determined based on the outlet water temperature during cooling or the outdoor temperature during heating.




-4- Defrost operation

1. Defrost start

Defrost operations will be performed simultaneously in both circuits that meets the defrost-start condition below.

Defrost-start conditions

- 1) Ten minutes have passed since the compressor started up.
- 2) Forty minutes have passed since the unit received an operation command signal.
- 3) Cumulative compressor operation time after the completion of the last defrost cycle has reached 40 minutes.
- 4) The ACC inlet refrigerant temperature is equal to or below the defrost-start temperature. (See the figure at right.)
- 5) Inlet water temperature is above 15°C.





2. Defrost end

The defrost cycle will end when one of the following conditions is met.

- 1) Twenty seconds have passed since the beginning of the defrost cycle or later, the high-pressure has reached 3.0 MPa or above.
- 2) The inlet water temperature has dropped below 15 °C.
- 3) Fifteen minutes have passed since the beginning of the defrost start.
- 4) When the operation command signal is off.

-5- Outdoor unit fan

The fan's rotation speed will be controlled to approximate the values in the graph below that are obtained based on the outdoor temperature and the low pressure during heating or the high pressure during cooling.



-6- LEV in the main circuit**Operating range of the LEV**

The opening range of the LEV is between 100 and 2000 (fully open).

LEV operation speed

- Open 100 plus/sec
- Close 200 plus/sec

At startup

- During startup, the valve will be moved to the Initial Setting.

During operation


- After startup, the LEV opening will be controlled every 20 seconds according to the changes in compressor frequency, pressure, and temperature.
- The LEV will be controlled to keep the suction SH in 5K.
- If the low pressure reaches 1.45 MPa or above, the MOP function will be triggered to keep the low pressure from rising too high.

-7- Operation during power failure


Duration of power failure		20 ms or shorter	20 ~ 200ms	200 ms or longer
Detection of power failure		Undetectable	Instantaneous power failure	Detection of power failure
Operation during power failure		Normal operation	During an instantaneous power failure, the unit will be controlled according to the input status of the circuit board immediately before the instantaneous power failure.	All outputs will be turned off immediately after power failure.
Operation after power is restored	Automatic restoration after power failure is set to "Enabled" (SW2-9 is set to ON.)	Normal operation	The circuit board will start receiving input.	The unit will be controlled according to the input status of the circuit board immediately before the power failure, except that the input status of the No-voltage contact after the power is restored will override the one before the power failure. For three minutes after the power is restored, the unit will not operate.
	Automatic restoration after power failure is set to "Disabled" (SW2-9 is set to OFF.)			The unit will stop, displaying the error code for power failure. The error will be cleared when the operation command signal is off.

-8- Anti-short-cycling protection

The unit has a 3-minute restart-delay function to protect the compressor from short-cycling. This function is effective even after a power failure.



The unit has a function to keep the compressor from short-cycling when the amount of circulating water is low or when the load is light. After the compressor cycles off, it will not restart for 12 minutes.




-9- Automatic operation of pump for freeze-up protection

1. Purpose

This is a function to protect the water circuit from freezing up in winter.

2. Pump wire connection



3. Natural freeze-up protection

Control method		Natural freeze-up protection based on the water temperature
Details	Pump start conditions	Water temperature is within 3 °C
	Pump stop conditions	Water temperature is more than 5 °C

-10- Water-temperature control

Water temperature can be controlled in the following way.

	SW2-5
Outlet-water-temperature-based control	OFF (Factory setting)
Water temperature control based on the external water temperature reading	ON

1. When the units are restarted after stopping for under a condition other than Thermo-OFF

Conditions for the units to stop other than the Thermo-OFF condition

- Pump interlock is off.
- When one of the units in a set is forced to stop
- When the units were stopped under the following conditions:
 1. Outlet water temperature has reached 57°C (Heating)
 2. Outlet water temperature has reached 3.6°C (Cooling)

sensor	Control method	Thermo-ON conditions
Built-in thermistor	Outlet-water-temperature-based control	Outlet water temperatures < 52 °C (Heating) OR Outlet water temperatures > 8.6 °C (Cooling)
External water temperature	External water temperature	External water temperature < 52 °C (Heating) OR External water temperature > 8.6 °C (Cooling)

2. Normal Thermo-ON/OFF operations


DIFF1 = 2 °C (Initial setting)

DIFF2 = 2 °C (Initial setting)

sensor	Control method	Thermo-ON conditions	Thermo-OFF conditions
Built-in thermistor	Outlet-water-temperature-based control	Outlet water temperature is below the "Preset temperature - DIFF1 (°C)". (Heating) OR Outlet water temperature is greater than "Preset temperature + DIFF1 (°C)". (Cooling) Except the short-cycling protection mode.	Outlet water temperature is greater than the "Preset temperature + DIFF2 (°C)". (Heating) OR Outlet water temperature is below the "Preset temperature - DIFF2 (°C)". (Cooling) At least 60 seconds have passed since the last Thermo-ON.
External water temperature	Water temperature control based on the external water temperature reading	External water temperature is below the "Preset temperature - DIFF1 (°C)". (Heating) OR External water temperature is greater than "Preset temperature + DIFF1 (°C)". (Cooling) Except the short-cycling protection mode.	External water temperature is greater than the "Preset temperature + DIFF2 (°C)". (Heating) OR External water temperature is below the "Preset temperature - DIFF2 (°C)". (Cooling) At least 60 seconds have passed since the last Thermo-ON.


1) Thermo-ON/OFF temperature conditions

◆Water temperature control



When the water temperature is controlled based on the outlet water temperature, compressor frequency will be controlled in the way that the target water temperature will be maintained.

2) Thermo-ON/OFF conditions (time)



-11- Controlling the operation of unit using external water temperature sensors

The water temperature can be controlled using the built-in sensor on the unit or a separately sold external water temperature sensor.

The factory setting for the sensor option is "built-in sensor on the unit." (SW2-5: OFF)

To control the water temperature with an external water temperature sensor, set SW2-5 to ON.

(Note) If the setting for the dip switch is changed, reset the power supply to enable the setting.

A separately sold water temperature sensor "TW-TH16" will be required to control the water temperature based on the external water temperature reading.

Install the external water temperature sensor and wiring according to the instructions on the next page.

-12- Remote water temperature setting input signal type

By setting SW2-7 to ON, external analog signals can be used to set the water temperatures.

Analog input type can be selected from the following four types:

4-20 mA

0-10 V

1-5 V

2-10 V

External water temperature sensor TW-TH16

1. Parts that are required to install an external water temperature sensor

- (1) External water temperature sensor
- (2) Wiring to connect the sensor and the unit*
- (3) Wiring terminals to connect the wiring to the sensor and the terminal block on the unit

(Four for M4 screws)*


*Items (1) and (2) are field supplied.

2. Installing the external water temperature sensor


- Install the external water temperature sensor where the water pipes merge or on the load-side tank as shown in the figure at right.
- Install horizontally or vertically on top of the pipe.
- When installing horizontally, make sure the wire faces down.

Wire specifications

Wire size	2-core cable Min. 1.25 mm ²
Type	CVVS or CPEVS
Maximum length	20 m




Vertical installation



Horizontal installation

3. Wiring the external water temperature sensor

Connect the external temperature sensor wiring to the terminal block in the control box on the unit as shown in the figure below.




Connect the sensor wiring to terminals T1 and T2 of the 12-pin terminal block in the control box on the unit.

Connect the shield to the earth terminal.

Thread the wire to the external water temperature sensor through parts ② through ④ as shown in the figure at right. Attach M4 terminals (field-supplied) to the wires, and connect them to ⑤ and ⑥ (terminals A and B).

Cut the shield wire. Do not connect it to the terminal. (Connect the shield on the unit side to the ground terminal.)

After the wire is connected, securely tighten the tightening screw ④, and then caulk the gap between the wire ① and the tightening screw to keep water from entering.



Detailed view of the area labeled "A" in the figure above

VIII Test Run Mode

[1] Items to be checked before a Test Run	97
[2] Test Run Method	99
[3] Operating the Unit.....	100
[4] Refrigerant	101
[5] Symptoms that do not Signify Problems	101
[6] Standard operating characteristics (Reference data)	101

[1] Items to be checked before a Test Run

(1) Check for refrigerant leak and loose cables and connectors.

(2) Measure the insulation resistance between the power supply terminal block and the ground with a 500V megger and make sure it reads at least 1.0Mohm.

Note

- Do not operate the unit if the insulation resistance is below 1.0Mohm.
- Do not apply megger voltage to the terminal block for transmission line. Doing so will damage the controller board.
- Never measure the insulation resistance of the transmission terminal block for the RA, RB, MA, MB (TB3). Do not attempt to measure the insulation resistance of TB7.
- The insulation resistance between the power supply terminal block and the ground could go down to close to 1Mohm immediately after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor.
- If insulation resistance reads at least 1Mohm, by turning on the main power and powering the belt heater for at least 12 hours, the refrigerant in the compressor will evaporate and the insulation resistance will go up.
- Do not measure the insulation resistance of the terminal block for transmission line for the unit remote controller.

Note

Securely tighten the cap.

(3) Check the phase order of the 3-phase power source and the voltage between each phase.

Note

Open phase or reverse phase causes the emergency stop of test run. (4102 error)

(4) When a power supply unit is connected to the transmission line for centralized control, perform a test run with the power supply unit being energized.

(5) Pre-energize the compressor.

- A case heater is attached to the bottom of the compressor to prevent the refrigerant oil from foaming when starting up. Switch on the power to the case heater and keep it turned on for **at least 12 hours** before starting a test run. (Compression of liquid refrigerant that may happen if the unit is started up without pre-energizing the compressor may damage the valve or cause other problems. When foaming is happening, the compressor will make cracking sounds for a few seconds at the beginning of operation.)
- Supply water to the water circuit before operating the pump. Operating the pump without water may damage the shaft seal.

(6) Check the pressure.

Translate the pressure readings into saturating temperatures, and make sure these values fall into the ranges specified in the table below.

Condensing and evaporating temperatures during operation

Saturation pressure equivalent to refrigerant pressure	During normal operation (outdoor temperature: between -15 °C and +43 °C)	
	Heating	Cooling
Condensing temperature	Outlet water temperature + (0 - 5 °C)	Outdoor temperature + (3 - 8 °C)*
Evaporating temperature	5 - 11 °C	Outlet water temperature. - (0 - 5 °C)

* To maintain proper compression ratio, when the outdoor temperature is below 20 °C, condensing temperature may exceed "(Outdoor temperature) - 8 °C"

(7) Check that the correct voltage is applied.

Check that the voltage that is applied while the unit is stopped and the load-side voltage of the solenoid contactor in the relay box during operation are within the voltage ranges. Check the voltage in all phases (L1, L2, and L3), and make sure that the voltage imbalance between the phases is 2% or less.

(8) Check either the power supply current or the compressor current.

Check the compressor current in all phases (L1, L2, and L3).

(9) Check for short-cycling of discharge air.

Check that the intake air temperature is not unusually higher or lower than the outside temperature. During operation, the difference between the heat exchanger inlet temperature and outside temperature should be 1 °C or less.

(10) Check for proper circulating water flow rate.

Measure the circulating water flow rate, if possible. If it is not, check that the temperature difference between the outlet and inlet temperatures is between 3 and 10 °C. A temperature difference of 12 °C or more indicates not enough water flow. Check for air pockets in the pipe, and make sure that the pump has the appropriate capacity for the circuit.

(11) Check that the unit is operating properly according to the temperature adjustment function.

When a start-up operation is completed, check that the hot water temperature adjustment function will come on and that the unit will automatically go on and off. Make sure the ON/OFF cycle (beginning of an operation until the next) is at least 12 minutes. (The unit features an anti-short-cycling protection.)

Notes on temperature adjustment function

The water temperature can be controlled based on the inlet or the outlet temperature sensor reading. Select one to use. Refer to "VII [1]1.Factory Switch Settings (Dip switch settings table) (page 71) and "(1)Water-temperature setting"(page 74) for how to select the water temperature control method and how to set the water temperature.

Do not disconnect the power wire to the compressor in an attempt to keep the compressor from going into operation during test run. (If it is done, the control board will not sense that the compressor is stopped, and the water temperature will not be controlled properly and the unit may come to an abnormal stop.)


(12) Connect the pump-interlock wire to the appropriate contacts.

1) Connecting the pump-interlock wire

Connect the pump-interlock wire to the pump-interlock circuit (Terminal block K04 and K06). The unit will not operate unless this circuit is complete.

2) Notes on connecting the pump-interlock wire


- Connect an NO relay (solenoid switch) for the pump.
- This circuit is a low-voltage circuit. Keep the pump-interlock wire at least 5 cm away from any wire that carries a voltage of 100 V or above to avoid damage to the circuit board.



(13) Checking the rotation direction of the pump

Check that the circulating water pump is rotating in the correct direction. If the pump is rotating in the wrong direction, disconnect the pump wiring from the solenoid switch, and reconnect them so that the pump will rotate in the correct direction.

[2] Test Run Method



Operation procedures	
Turn on the main power.	→ "PLEASE WAIT" appears on the LCD for up to five minutes.
Set the water temperature to a temperature at least 5 °C above the current settings.	
Press the ⑪ [ON/OFF] button to start operation.	→ Run
To stop the operation, press the ⑪ [ON/OFF] button.	→ Stop
Note 1: Refer to the following pages if an error code appears on the remote controller or when the unit malfunctions.	

[3] Operating the Unit

1. Initial Operation

- (1) Make sure the Run/Stop switch that controls the unit on the local control panel is switched off.
- (2) Switch on the main power.
- (3) Leave the main power switched on for at least 12 hours before turning on the Run/Stop switch that controls the unit on the on-site control panel to warm up the compressor.
- (4) Switch on the Run/Stop switch that controls the unit on the on-site control panel.

2. Daily Operation

To start an operation

Switch on the Run/Stop switch that controls the unit on the local control panel, or press the ON/OFF button on the remote controller. (*1)

Note

The unit described in this manual features a circuit that protects the compressor from short-cycling. Once the compressor stops, it will not start up again for up to 12 minutes. If the unit does not start when the ON/OFF switch is turned on, leave the switch turned on for 12 minutes. The unit will automatically start up within 12 minutes.

To stop an operation

Switch off the Run/Stop switch that controls the unit on the on-site control panel, or press the ON/OFF button on the remote controller. (*1)

*1 Refer to [2] Test Run Method (page 99) for how to use the remote controller.

IMPORTANT

- Keep the main power turned on throughout the operating season, in which the unit is stopped for three days or shorter (e.g., during the night and on weekends).
- Unless in areas where the outside temperature drops to freezing, switch off the main power when the unit will not be operated for four days or longer. (Switch off the water circulating pump if the pump is connected to a separate circuit.)
- When resuming operation after the main power has been turned off for a full day or longer, follow the steps under "Initial Operation" above.
- If the main power was turned off for six days or longer, make sure that the clock on the unit is correct.

3. Operating the unit from the control board on the unit.

- (1) To start the unit
Set the switch SWS1 on the circuit board to "LOCAL."
- (2) To stop the unit
Set the switch SWS1 on the circuit board to "OFF."

[4] Refrigerant

Unit type	EAHV/EACV-P900YA
Refrigerant type	R410A
Refrigerant charge	19kg × 2

[5] Symptoms that do not Signify Problems

Symptom	Remote controller display	Cause
Fan does not stop while stopping operation.	Extinguished	If terminals K01 and K03 on TB5 are short-circuited, the fan will be forced to operate even after the compressor has stopped.
The display shown right will appear on the unit remote controller for about 5 minutes when the main power source is turned on.	"PLEASE WAIT" ("HO") blinking display	The system is under starting up. Operate the remote controller after the blinking of "PLEASE WAIT" ("HO") is disappeared.

[6] Standard operating characteristics (Reference data)

Reference data

			Heating	Cooling
Ambient temperature	DB	°C	7	35
	WB	°C	6	24
Temperature	Discharge refrigerant	°C	80	82
	ACC inlet refrigerant	°C	3	9
	Water heat exchanger refrigerant	°C	43	7
	Air heat exchanger refrigerant	°C	1	37
	Outdoor temperature	°C	7	35
	Inlet water temperature	°C	40	12
	Outlet water temperature	°C	45	7
Pressure	High pressure	MPa	2.81	3.03
	Low pressure	MPa	0.77	0.94
LEV opening	Main circuit	pulse	1180	1300
Compressor	Frequency	Hz	94	94
Fan	Frequency	Hz	57	57

IX Troubleshooting

[1] Maintenance items.....	105
[2] Troubleshooting	108
[3] Troubleshooting Principal Parts	113
[4] Refrigerant Leak	128
[5] Parts Replacement Procedures	129

[1] Maintenance items

1. Operation status monitor

Check the contents in the maintenance tool.

Input

Mark	Official Name	Meaning
Water temp Ctrl	-	IN→Inlet water temperature emperature control OUT→Outlet water temperature based control
Main Water temp Ctrl	-	ON→Built-in sensor on the unit OFF→External water temperature sensor
Multi Ctrl	-	ON→Multiple Ctrl , OFF→Individual control
Temp setting	-	ON→Effective , OFF→Invalid
On/Off setting	-	ON→Enable schedule setting

Status

Mark	Official Name	Meaning
On/Off Ctrl	-	Run/Stop
Fan Mode	-	ON→Control fan
Defrost Mode	-	Other/Wait/Limit/On
Demand	-	ON→Control demand
Restart Lim	-	ON→Control restart
Remain (min)	-	Restart (minute)
Pre err (cnt)	-	Error count
Err code	-	Error content (M-NET code)
Detail	-	Detail error code
Total (hr)	-	Total hour
Mode	-	Heating/Heating Eco/Cooling/Anti Freeze
Schedule	-	ON→Control schedule

Schedule

Mark	Official Name	Meaning
Time	-	Current Time
Thr-diff1	-	Thermo differential 1
Thr-diff2	-	Thermo differential 2
Demand (max%)	-	Maximum capacity demand [%]
Demand	Peak-demand control	Start time - End time
On/Off1	Scheduled operation 1	Operation start time 1 - Operation end time 1
On/Off2	Scheduled operation 2	Operation start time 2 - Operation end time 2
On/Off3	Scheduled operation 3	Operation start time 3 - Operation end time 3
Setting temp1	-	Water temp. setting 1
Setting temp2	-	Water temp. setting 2
Setting temp3	-	Water temp. setting 3

Input(CN142)

Mark	Official Name	Meaning
A1	RUN	Run/Stop
A3	Fan Mode	Forced/Normal
B1	Cooling/Heating switching	ON→Heating/OFF→Cooling
B3	Pump Interlock	Normal/Error
C5	Anti-Freeze	ON/OFF
C6	Capacity	ON→COP priority/OFF→Capacity priority
D3	Flow Switch	Normal/Error
D4	Outlet water temp. switching	ON→2nd(temp.2)/OFF→1st(temp.1)
D5	Demand	ON/OFF
D6	Mode Change	Heating Eco/Heating

Output

Mark	Official Name	Meaning
X01	MAIN BOX=- SUB BOX=-	MAIN BOX=Solenoid valve(4-way valve) SUB BOX=Solenoid valve(4-way valve)

X02	MAIN BOX=- SUB BOX=-	MAIN BOX=Case heater(for heating the compressor) SUB BOX=Case heater(for heating the compressor)
X03	MAIN BOX= SUB BOX=-	MAIN BOX=- SUB BOX=-
X04	MAIN BOX=- SUB BOX=-	MAIN BOX=Pump operation command output SUB BOX=-
X05	MAIN BOX=- SUB BOX=-	MAIN BOX=Drain pan heater signal output SUB BOX=Supplementary heater signal output
X06	MAIN BOX=- SUB BOX=-	MAIN BOX=Operation display output SUB BOX=-
X07	MAIN BOX=- SUB BOX=-	MAIN BOX=Error display output SUB BOX=-
X08	MAIN BOX=- SUB BOX=-	MAIN BOX=Defrost signal output SUB BOX=-
X09	MAIN BOX=- SUB BOX=-	MAIN BOX=Cooling/Heating operation display output SUB BOX=-

12Voutput

Mark	Official Name	Meaning
52C	-	Electromagnetic relay(Inverter main circuit)

Unit condition Unit1 to Unit6

Mark	Official Name	Meaning
TH1	Thermistor	Water inlet temp. 1
TH2	Thermistor	Water inlet temp. 2
TH3	Thermistor	Water outlet temperature
TH5	Thermistor	ACC Inlet Ref temperature
TH6	Thermistor	Air hex Ref temperature
TH7	Thermistor	Water hex Ref temperature
TH10	Thermistor	Outdoor temperature
TH11	Thermistor	Discharge Ref temperature
TH15	Thermistor	External Water sensor
THc1	-	Water Inlet temp. 1 compensation TH1
THc2	-	Water Inlet temp. 2 compensation TH2
THc3	-	Water Outlet temperature compensation TH3
THc15	-	External water temperature compensation TH15
63H1	-	High pressure switch
HP	63HS	High pressure sensor
LP	63LS	Low pressure sensor
Vdc	-	COMP bus voltage [V]
Iu	-	Phase-U current of compressor [A]
Iw	-	Phase-W current of compressor [A]
Ts	-	Target water temperature
Twi	-	Current inlet water temperature
Two	-	Current outlet water temperature
Twg	-	External water temperature
Tout	-	Outdoor temperature
SHs	-	Target superheat value at the ACC inlet pipe
SCs	-	Target subcool value at the condenser outlet pipe
SH	-	-
SC	-	-
Td-SH	-	Superheat value at the discharge pipe
THHS	Thermistor	IGBT temperature
LEV1	-	Electronic expansion valve(Main/Sub circuit)
COMP1(Hz)	-	Operating frequency in main circuit [Hz]
FAN1(Hz)	-	Operating frequency of fan moter1 [Hz]
FAN2(Hz)	-	Operating frequency of fan moter2 [Hz]
FAN3(Hz)	-	Operating frequency of fan moter3 [Hz]
4-20mA1	-	External analog input for Target water temp (4-20mA1)
0-10V	-	External analog input for Target water temp (0-10V/2-10V)
1-5V	-	External analog input for Target water temp (1-5V)

2. Operation status before error
Check the contents in the maintenance tool.

Time of data storage before error

Mark	Official Name	Meaning
Ver	Software Version	Program ROM
TH1	Thermistor	Water inlet temp. 1
TH2	Thermistor	Water inlet temp. 2
TH3	Thermistor	Water outlet temperature
TH5	Thermistor	ACC Inlet Ref temperature
TH6	Thermistor	Air hex Ref temperature
TH7	Thermistor	Water hex Ref temperature
TH10	Thermistor	Outdoor temperature
TH11	Thermistor	Discharge Ref temperature
TH15	Thermistor	External Water sensor
HP	63HS	High pressure sensor
LP	63LS	Low pressure sensor
Vdc	-	COMP bus voltage [V]
Iu	-	Phase-U current of compressor [A]
Iw	-	Phase-W current of compressor [A]
Ts	-	Target water temperature
Twi	-	Current inlet water temperature
Two	-	Current outlet water temperature
Twg	-	External water temperature
SHs	-	Target superheat value at the ACC inlet pipe
SCs	-	Target subcool value at the condenser outlet pipe
SH	-	-
SC	-	-
Td-SH	-	Superheat value at the discharge pipe
THHS	Thermistor	IGBT temperature
LEV1	-	Electronic expansion valve(Main/Sub circuit)
COMP1(Hz)	-	Operating frequency in main circuit [Hz]
FAN1(Hz)	-	Operating frequency of fan moter1 [Hz]
FAN2(Hz)	-	Operating frequency of fan moter2 [Hz]
FAN3(Hz)	-	Operating frequency of fan moter3 [Hz]
4-20mA1	-	External analog input for Target water temp (4-20mA1)
0-10V	-	External analog input for Target water temp (0-10V/2-10V)
1-5V	-	External analog input for Target water temp (1-5V)

[2] Troubleshooting

1. If a problem occurs, please check the following. If a protection device has tripped and brought the unit to stop (when an error code is blinking on the LED), resolve the cause of the error before resuming operation. Resuming operation without removing the causes of an error may damage the unit and its components.

Problem	Check item		Cause		Solution
The unit does not operate.	The fuse in the control box is not blown.	The power lamp on the circuit board is not lit.	The main power is not turned on.		Switch on the power.
		The power lamp on the circuit board is lit.	The pump interlock circuit is not connected.	Connect the pump interlock circuit wiring to the system.	
			The flow switch wiring is not connected.	Connect the flow switch wiring to the system.	
	The fuse in the control box is blown.	Measure the circuit resistance and the earth resistance.	Short-circuited circuit or ground fault		Resolve the cause, and replace the fuse.
	The compressor does not operate.	Protection devices have not tripped.	INV board problem		Repair or replace the INV board.
			Noise filter board problem		Repair or replace the noise filter board.
		High-pressure cutout switch has tripped. 1303	Abnormal high pressure	Dirty condenser (scaling formation)	Clean the condenser.
				Air in the refrigerant circuit	Vacuum the refrigerant circuit, and charge it with refrigerant.
				Water flow shortage	Secure enough water flow rate.
		The discharge temperature thermistor has tripped. 1102	LEV fault in the main circuit		Replace the LEV in the main circuit.
			Refrigerant gas leakage		Leakage test
			Refrigerant undercharge		Repair the cause of refrigerant shortage, evacuate the system, and charge the refrigerant circuit with refrigerant.
		A thermistor error was detected. 5101~5115	Broken or short-circuited thermistor wiring		Check the thermistor wiring for broken connections or short circuit. Replace the thermistor.
		Overcurrent passed through the compressor. 4250	Compressor motor		Replace the compressor.
			Overload operation		Check the operation patterns.
			Seized compressor shaft		Replace the compressor.
		The pump interlock has tripped.	The pump interlock circuit is not connected.		Connect the pump interlock wiring.
			The water pump is not operating.		Operate the pump.
			Problem with the solenoid contactor for the pump		Replace the solenoid contactor.
		The flow switch has tripped.	The flow switch wiring is not connected.		Connect the flow switch wiring to the system.
			Water flow shortage		Increase the water flow rate.
			Flow switch contact failure		Polish the contact point.
		Automatic Start/Stop thermistor has tripped.	The water temperature has reached above the preset temperature.		Normal
		The motor whines, but will not turn.	Contact failure at a connector terminal		Polish the contact point.
			Loose wire connection		Tighten the wire connection.
			Seized compressor or fan bearing		Disassemble the compressor or the fan, and repair as necessary.
			High-pressure is too high.		Check the operation patterns.
		A momentary overcurrent was detected.	Burned, short-circuited, or ground faulted motor		Replace the compressor, and clean the refrigerant circuit.

Problem	Check item		Cause	Solution
The unit has stopped during operation and does not restart.	Automatic Start/Stop thermistor has tripped.	Water temperature is high.		Normal
		Water temperature is low.	The setting for the automatic Start/Stop thermistor is too low.	Change the setting for the automatic Start/Stop thermistor.
	The high-pressure switch has tripped. 1302, 1303	Water temperature is not high.	Dirty condenser	Clean the condenser.
			Refrigerant overcharge	Evacuate the system, and charge the system with refrigerant.
			Air in the refrigerant circuit	Evacuate the system, and charge the system with refrigerant.
			Water flow shortage	Secure enough water flow rate.
	The vacuum protection has tripped. 1301	Outdoor temperature is not low.	Refrigerant undercharge, refrigerant gas leakage	Perform a leakage test, repair the leaks, evacuate the system, and charge the refrigerant circuit with refrigerant.
			Dirty evaporator	Clean the evaporator.
			LEV fault in the main circuit	Replace the LEV in the main circuit.
			Clogged strainer	Replace the strainer.
			Clogged check valve	Replace the check valve.
			Excessive frosting	Install a snow hood to keep snow from accumulating on the unit.
	The discharge temperature thermistor has tripped. 1102	Suction gas is overheated.	Refrigerant undercharge, refrigerant gas leakage	Perform a leakage test, repair the leaks, evacuate the system, and charge the refrigerant circuit with refrigerant.
			LEV fault in the main circuit	Replace the LEV in the main circuit.
			Clogged strainer	Replace the strainer.
			The cooling fan is stopped.	Check the fan for proper operation, and replace it if necessary.
			High pressure is too high.	Check the items above and make necessary adjustments so that the suction gas temperature falls within the specified temperature range.
The unit has stopped during operation and does not restart.	Overcurrent passed through the compressor. 4250	Outdoor temperature is high.	Overload operation Burnt motor Seized compressor	Reduce the operation load, and check the operation patterns. Replace the compressor.
	A water supply cutoff was detected. 2500, 2501, 2550	The pump is operating normally.	Water flow shortage	Increase the water flow rate.
			Flow switch fault	Replace the flow switch.
		The pump does not operate.	Problem with the solenoid contactor for the pump	Replace the electromagnetic contactor.
			Pump fault	Replace the pump.
	The freeze-up protection function has tripped. 1503	Water flow shortage	Plate heat exchanger freeze-up	Increase the water flow rate.
		The water flow rate is sufficient.	4-way valve fault	Replace the 4-way valve.
The unit is in operation, but the water does not heat up/cool down.	Water temperature is low/high.	The water inlet/outlet temperature differential is normal.	The water-heating/cooling load is too high.	Install more units
			Low refrigerant charge due to a leak.	Perform a leakage test, repair the leaks, evacuate the system, and charge the refrigerant circuit with refrigerant.
		The water inlet/outlet temperature differential is small.	LEV fault in the main circuit	Replace the LEV in the main circuit.
			Compressor failure	Replace the compressor.
			High pressure is too high, or low pressure is too low.	Operate the units within the specified pressure range.
	Water temperature is high/low.		Water flow shortage	Increase the water flow rate.
			Problem with the external devices	Repair the devices.
The unit is making a great deal of vibrations and noise.	The compressor is being flooded.		LEV fault in the main circuit	Replace the LEV.

2. Error code list

If a problem occurs, please check the following before calling for service.

(1) Check the error code against the table below.

(2) Check for possible causes of problems listed in the "Cause" column that correspond to the error code.

(3) If the error codes that appear on the display are not listed in the table below, or no problems were found with the items listed in the "Cause" column, please consult your dealer or servicer.

Diagnosing Problems Using Error Codes

Error code *1	Error type		Cause (Installation/Setting error)	Cause (Parts problems)	Error reset *2	
					Unit side (PCB)	Remote
					SWS1	Operation SW
4106	Power supply fault *3		Power supply fault occurred when the operation switch is switched on.	-	○	○
2500	Water supply cutoff (Flow switch has been triggered.)		The water flow rate dropped below the flow switch threshold. Water supply cutoff	<ul style="list-style-type: none"> Open-circuited flow switch Broken flow switch wiring 	○	○
2501 2550	Water supply cutoff (detection by sensor)		No water Water supply cutoff	<ul style="list-style-type: none"> Inlet water thermistor fault Outlet water thermistor fault 	○	○
1302 1303	High pressure fault		No water Water supply cutoff	<ul style="list-style-type: none"> Linear expansion valve fault High-pressure sensor fault 	○	○
1176	Discharge SH fault		-	<ul style="list-style-type: none"> Low-pressure sensor fault ACC inlet refrigerant temperature thermistor fault High-pressure sensor fault Discharge refrigerant temperature thermistor fault Linear expansion valve fault 	○	○
1301	Low pressure fault		The outdoor temperature was below the operating range.	<ul style="list-style-type: none"> Low-pressure sensor fault ACC inlet refrigerant temperature thermistor fault Linear expansion valve fault Refrigerant deficiency (refrigerant gas leak) 	○	○
1189	ACC inlet SH fault		-	<ul style="list-style-type: none"> ACC inlet refrigerant temperature thermistor fault Linear expansion valve fault Low-pressure sensor fault 	○	○
5110	Thermistor fault	Outdoor temperature (TH10)	-	Broken or shorted thermistor wiring	○	○
5101		Inlet water temperature (TH1)	-	Broken or shorted thermistor wiring	○	○
5102		Inlet water temperature (TH2)	-	Broken or shorted thermistor wiring	○	○
5103		Outlet water temperature (TH3)	-	Broken or shorted thermistor wiring	○	○
5105		ACC inlet refrigerant temperature (TH5/TH25)	-	Broken or shorted thermistor wiring	○	○
5106		Air heat exchanger refrigerant temperature (TH6/TH26)	-	Broken or shorted thermistor wiring	○	○
5107		Water heat exchanger refrigerant temperature (TH7/TH27)	-	Broken or shorted thermistor wiring	○	○
5111		Discharge refrigerant temperature (TH11/TH21)	-	Broken or shorted thermistor wiring	○	○
5115		External water temperature (TH15)	-	Broken or shorted thermistor wiring	○	○
5201	High-pressure sensor fault/high-pressure fault		-	Broken or shorted pressure sensor wiring	○	○
5202	Low-pressure sensor fault/low-pressure fault		-	Broken or shorted pressure sensor wiring	○	○
7113	Model setting error 1		Dip switches on the PCB were set incorrectly during maintenance.	-	×	×
7117	Model setting error 2		-	CNTYP1 resistor fault (connected to the Main control board)	×	×
4115	Power supply frequency fault		Power supply frequency is a frequency other than 50 Hz or 60 Hz.	-	×	×
4102	Open phase		There is an open phase.	<ul style="list-style-type: none"> Circuit board fault 	×	×
1102	Discharge temperature fault (A discharge refrigerant temperature of 120°C or above is detected momentarily while the compressor is in operation.)		No water Abrupt change in water temperature (5K/min. or greater) Pump failure	<ul style="list-style-type: none"> High-pressure sensor fault Linear expansion valve fault Refrigerant deficiency (refrigerant gas leak) 	○	○
1138	Hot water abnormal rise		Drop in water flow or water supply cutoff Water temperature rise	-	○	○
1503	Cold water abnormal drop *4		Drop in water flow or water supply cutoff Water temperature drop	-	○	○

Error code *1	Error type		Cause (Installation/Setting error)	Cause (Parts problems)	Error reset *2	
					Unit side (PCB)	Remote
					SWS1	Operation SW
1510	Gas leak fault		-	<ul style="list-style-type: none"> High pressure sensor fault Refrigerant deficiency (refrigerant gas leak) 	○	○
1512	Low evaporation temperature fault		Drop in water flow Water temperature drop	-	○	○
4116	Fan motor fault		Strong wind from the outside	<ul style="list-style-type: none"> Fan motor fault FANCONT board fault 	○	○
4122	Fan interlock fault		Disconnection of wiring	<ul style="list-style-type: none"> Fan motor fault FANCONT board fault 	○	○
4250 (101)	Inverter error	IPM error	-	<ul style="list-style-type: none"> INV board fault Ground fault of the compressor Coil problem IPM error (loose terminal screws, cracked due to swelling) Items listed under "Heatsink overheat protection" below 	○	○
4250 (102)		ACCT overcurrent	-	<ul style="list-style-type: none"> INV board fault Ground fault of the compressor Coil problem IPM error (loose terminal screws, cracked due to swelling) 	○	○
4250 (103)		DCCT overcurrent	-	<ul style="list-style-type: none"> IPM error (loose terminal screws, cracked due to swelling) 	○	○
4250 (107)		Overcurrent relay trip (effective value) (During operation)	-		○	○
4250 (106)		Overcurrent relay trip (momentary value) (During operation)	-		○	○
4250 (104)		Short-circuited IPM/ground fault (During operation)	-	<ul style="list-style-type: none"> Ground fault of the compressor IPM error (loose terminal screws, cracked due to swelling) 	○	○
4250 (105)		Overcurrent error due to a short-circuited (During operation)	Inter-phase voltage drop (Inter-phase voltage at or below 180 V)	<ul style="list-style-type: none"> Ground fault of the compressor Shorted output wiring 	○	○
4220 (108)	Voltage related problems during operation	Bus voltage drop protection	Momentary power failure/power failure Power supply voltage drop (Inter-phase voltage is 180 V or below.) Voltage drop	<ul style="list-style-type: none"> INV board CND2 wiring fault INV board fault 52C fault Diode stack failure 	○	○
4220 (109)		Bus voltage rise protection	Incorrect power supply voltage	<ul style="list-style-type: none"> INV board fault 	○	○
4220 (110)		VDC error	Power supply voltage rise or drop	<ul style="list-style-type: none"> PCB fault 	○	○
4220 (111)		Logic error	Malfunction due to external noise interference <ul style="list-style-type: none"> Faulty grounding Improper transmission and external wiring installation (Shielded cable is not used.) Low-voltage signal wire and high-voltage wire are in contact. (Placing the signal wire and power wire in the same conduit) 	<ul style="list-style-type: none"> INV board fault 	○	○
4230	Heatsink fault (Heatsink overheat protection)		Power supply voltage drop (Inter-phase voltage is 180 V or below.) Clogged heatsink cooling air passage	<ul style="list-style-type: none"> Fan motor fault THHS sensor fault IPM error (loose terminal screws, cracked due to swelling) 	○	○
4240	Overload protection		Clogged heatsink cooling air passage Power supply voltage drop (Inter-phase voltage is 180 V or below.)	<ul style="list-style-type: none"> THHS sensor fault Current sensor fault INV circuit fault Compressor fault 	○	○
5301 (115)	ACCT sensor fault		-	<ul style="list-style-type: none"> INV board fault Ground fault of the compressor and IPM error 	○	○
5301 (116)	DCCT sensor		-	<ul style="list-style-type: none"> Poor contact at the INV board connector CNCT Poor contact at the INV board connector DCCT Ground fault of the compressor and IPM error 	○	○
5301 (117)	ACCT sensor/circuit fault		-	<ul style="list-style-type: none"> Poor contact at the INV board connector CNCT2 (ACCT) ACCT sensor fault 	○	○

Error code *1	Error type		Cause (Installation/Setting error)	Cause (Parts problems)	Error reset *2	
					Unit side (PCB)	Remote
					SWS1	Operation SW
5301 (118)	Inverter error	DCCT sensor/circuit fault	-	<ul style="list-style-type: none">• Poor contact at the INV board connector CNCT• Poor contact at the INV board connector DCCT• DCCT sensor fault• INV board fault	○	○
5301 (119)		Open-circuited IPM/loose ACCT sensor	-	<ul style="list-style-type: none">• Disconnected ACCT sensor (CNCT2)• ACCT sensor fault• Broken compressor wiring• INV circuit fault (IPM error etc.)	○	○
5301 (120)		Faulty wiring	-	<ul style="list-style-type: none">• ACCT sensor is connected in the wrong phase.• ACCT sensor is connected in the wrong orientation.	○	○
5114		THHS sensor/circuit fault	-	<ul style="list-style-type: none">• THHS sensor contact failure• THHS sensor fault• INV board fault	○	○
0403		Serial communication error	-	<ul style="list-style-type: none">• Communication error between control board and INV board (noise interference, broken wiring)	○	○
—		IPM system error	INV board switch setting error	<ul style="list-style-type: none">• Wiring or connector connection between connectors on IPM-driven power supply circuit• INV board fault	○	○
6831	Remote controller error (incl. remote controller wiring fault)	Remote controller signal reception error 1	Remote controller cable is not connected. Broken wiring	<ul style="list-style-type: none">• Broken remote controller wiring• Main control board communication circuit fault	—	—
6832		Remote controller signal transmission error	Communication error due to external noise interference	<ul style="list-style-type: none">• Main control board communication circuit fault	—	—
6834		Remote controller signal reception error 2	Communication error due to external noise interference	<ul style="list-style-type: none">• Main control board communication circuit fault	—	—
6833		Remote controller over current	Remote controller cable short circuit Remote controller malfunction	<ul style="list-style-type: none">• Broken remote controller wiring	×	×
4126	Analog input error (Control board (MAIN) CN421)		Analog input type fault (SW3-1, SW3-2)	<ul style="list-style-type: none">• Broken or open analog signal output device wiring (CN421)	—	—
6500	Communication error between the main and sub units Communication error between the MAIN and SUB circuits		-	-	—	—
6600	Transmission line power supply PCB fault		Communication error due to external noise interference	<ul style="list-style-type: none">• Broken wiring to the transmission power supply circuit board (between the main and sub units)• Transmission power supply PCB communication circuit fault	×	×
6602	Communication error between the main and sub units (Simple multiple unit control mode)				—	—
6603						
6606						
6607						

*1: If an error occurs, error codes shown above will appear in the 4-digit digital display on the PCB and the remote controller.

*2: Definition of symbols in the "Error reset" column.

○: Errors that can be reset if the remote reset setting on the unit is set to "Enable" (factory setting)
Errors that cannot be reset if the remote reset setting on the unit is set to "Disable"

×: Errors that cannot be reset

—: Errors that will be automatically cancelled once its cause is removed

*3: Power failure will be detected as an error only when the "Automatic recovery after power failure" setting on the unit is set to "Disable."
(The default setting for the "Automatic recovery after power failure" setting is "Enable.")

*4: Before resetting this error, remove its causes. Resuming operation without removing the causes of heat exchanger freeze up will cause heat exchanger damage.

[3] Troubleshooting Principal Parts


-1- High-Pressure Sensor (63HS)

1. Compare the pressure that is detected by the high pressure sensor, and the high-pressure gauge pressure to check for failure.

Error history, temperature and pressure readings of the sensor, and LEV opening

SW1									
1	2	3	4	5	6	7	8	9	10
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

High pressure and low pressure will appear alternately on the 7-segment LED. See below for how they are displayed.



Indicates that the high pressure is displayed



Indicates that the low pressure is displayed

(1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.

- 1) When the gauge pressure is between 0 and 0.1MPa, internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.1MPa, the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 4.15MPa, go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

(2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running. (Compare them by MPa unit.)

- 1) When the difference between both pressures is within 0.1MPa, both the high pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.1MPa, the high pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on self-diagnosis LED1 does not change, the high pressure sensor has a problem.

(3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1.

- 1) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.1MPa, the high pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 4.15MPa, the control board has a problem.



(4) Remove the high pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63HS:CN63HS) to check the pressure with self-diagnosis LED1.

- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 4.15MPa, the high pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.

2. Pressure sensor configuration

The high pressure sensor consists of the circuit shown in the figure below. If DC 5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.071V per 0.098MPa.

	Control board side
Vcc	Pin 3
Vout	Pin 2
GND	Pin 1






-2- Low-Pressure Sensor (63LS)

1. Compare the pressure that is detected by the low pressure sensor, and the low pressure gauge pressure to check for failure.

Error history, temperature and pressure readings of the sensor, and LEV opening

SW1									
1	2	3	4	5	6	7	8	9	10
OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF

High pressure and low pressure will appear alternately on the 7-segment LED. See below for how they are displayed.



- (1) While the sensor is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1.

- 1) When the gauge pressure is between 0 and 0.1MPa, internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1 is between 0 and 0.1MPa, the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the pressure displayed on self-diagnosis LED1 exceeds 1.7MPa, go to (3).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1 while the sensor is running.(Compare them by MPa unit.)

- 1) When the difference between both pressures is within 0.03MPa, both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.03MPa, the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1 does not change, the low pressure sensor has a problem.

- (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1 display.

- 1) When the pressure displayed on the self-diagnosis LED1 is between 0 and 0.1MPa, the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1 is approximately 1.7MPa, the control board has a problem.
- When the outdoor temperature is 43°C or less, the control board has a problem.
- When the outdoor temperature exceeds 43°C, go to (5).

- (4) Remove the low pressure sensor from the control board, and short-circuit between the No.2 and 3 connectors (63LS:CN63LS) to check the pressure with the self-diagnosis LED1.

- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa, the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.



- (5) Remove the high pressure sensor (63HS) from the control board, and insert it into the connector for the low pressure sensor (63LS:CN63LS) to check the pressure with the self-diagnosis LED1.

- 1) When the pressure displayed on the self-diagnosis LED1 exceeds 1.7MPa, the control board has a problem.
- 2) If other than 1), the control board has a problem.

2. Low-pressure sensor configuration

The low pressure sensor consists of the circuit shown in the figure below. If DC5V is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microcomputer. The output voltage is 0.173V per 0.098MPa.

	Control board side
Vcc	Pin 3
Vout	Pin 2
GND	Pin 1




-3- Temperature sensor

Use the flowchart below to troubleshoot the temperature sensor.

Troubleshooting the thermistor

(1) Thermistor <Heatsink temperature> : THHS




* 1 The table below shows the thermistor numbers and their corresponding connectors. Check each sensor by disconnecting the corresponding connector.

TH11 · TH21	CN401	TH6 · TH26	CN404
TH5 · TH25	CN408 1-2	TH10	CN405
TH1	CN407 1-2	TH3	CN407 3-4
TH7 · TH27	CN406 1-2	TH2	CN406 5-6


- * 2
- Pull out the sensor connector from the I/O board.
 - Do not pull on the lead wire.
 - Measure the resistance with a tester.
 - If the measured value is within $\pm 10\%$ of the value as shown in the table below, the circuit sensor is normal.
- * 3 Use the maintenance tool to view the sensor reading.

Thermistor $R_{50} = 17\text{ k}\Omega \pm 2\%$
 $R_t = 17 \exp\left\{4016\left(\frac{1}{273+t} - \frac{1}{323}\right)\right\}$




(2) Low-temperature-range thermistor
: TH1,2,3,5,6,7,10,25,26,27

Thermistor $R_0 = 15\text{ k}\Omega \pm 3\%$
 $R_t = 15 \exp\left\{3385\left(\frac{1}{273+t} - \frac{1}{273}\right)\right\}$



(3) High-temperature-range thermistor: TH11,21

Thermistor $R_{120} = 7.465\text{ k}\Omega \pm 2\%$
 $R_t = 7.465 \exp\left\{4057\left(\frac{1}{273+t} - \frac{1}{393}\right)\right\}$




-4- LEV

1. General descriptions of the operation of the LEV in the main circuit

LEV1 is driven by the pulse signal from the circuit board and is controlled by a stepping motor.

The valve opening changes according to the number of pulses

1) Control board and LEV




2) Pulse signal output and valve operation

Output (phase) number	Output state			
	1	2	3	4
ø 1	ON	OFF	OFF	ON
ø 2	ON	ON	OFF	OFF
ø 3	OFF	ON	ON	OFF
ø 4	OFF	OFF	ON	ON

Output pulses change in the following orders when the
 Valve is closed; 1 → 2 → 3 → 4 → 1
 Valve is open; 4 → 3 → 2 → 1 → 4

- *1. When the LEV opening angle does not change, all the output phases will be off.
- *2. When the output is open phase or remains ON, the motor cannot run smoothly, and rattles and vibrates.

3) LEV valve closing and opening operation




*Upon power on, a 2260 pulse signal is sent to the LEV to determine the valve position and bring the valve to the position indicated by "A" in the diagram

When the valve operates smoothly, no sound from LEV or no vibration occurs, however, when the pulses change from E to A in the chart or the valve is locked, a big sound occurs.

*Whether a sound is generated or not can be determined by holding a screwdriver against it, then placing your ear against the handle.


*If liquid refrigerant is present in the LEV, it may make the operating sound of the LEV difficult to detect.

(1) Judgment methods and possible failure mode

Malfunction mode	Judgment method	Remedy
Microcomputer driver circuit failure	<p>Disconnect the control board connector and connect the check LED as shown in the figure below.</p>  <p>Pulse signal is output for 17 seconds when the main power is turned on. If there is any LED that remains unlit or remains lit, there is a problem with the drive circuit.</p>	When the drive circuit has a problem, replace the control board.
LEV mechanism is locked	<p>If the LEV is locked, the drive motor runs idle, and makes a small clicking sound. When the valve makes a closing and opening sound, the valve has a problem.</p>	Replace the LEV.
Disconnected or short-circuited LEV motor coil	<p>Measure resistance between the coils (red - white, red -orange, red - yellow, red - blue) using a tester. They are normal if resistance is 150ohm \pm 10%.</p>	Replace the LEV coils.
Faulty wire connections in the connector or faulty contact	<ol style="list-style-type: none"> 1. Check for loose pins on the connector and check the colors of the lead wires visually 2. Disconnect the control board's connector and conduct a continuity check using a tester. 	Check the continuity at the points where an error occurs.


2. LEV coil removal procedure

The LEV consists of a coil and a valve body that can be separated from each other.



(1) Removing the coils


Fasten the body tightly at the bottom (Part A in the figure) so that the body will not move, then pull out the coils toward the top. If the coils are pulled out without the body gripped, undue force will be applied and the pipe will be bent.



(2) Installing the coils

Fix the body tightly at the bottom (Part A in the figure) so that the body will not move, then insert the coils from the top, and insert the coil stopper securely in the pipe on the body. Hold the body when pulling out the coils to prevent so that the pipe will not be bent.

If the coils are pushed without the body gripped, undue force will be applied and the pipe will be bent. Hold the body when pulling out the coils to prevent so that the pipe will not be bent.




-5- Inverter

- Replace only the compressor if only the compressor is found to be defective.
- Replace only the fan motor if only the fan motor is found to be defective.
- Replace the defective components if the inverter is found to be defective.
- If both the compressor and the inverter are found to be defective, replace the defective component(s) of both devices.

(1) Inverter-related problems: Troubleshooting and remedies

- 1) The INV board has a large-capacity electrolytic capacitor, in which residual voltage remains even after the main power is turned off, posing a risk of electric shock. Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less. (It takes about 10 minutes to discharge electricity after the power supply is turn off.)
- 2) The IPM on the inverter becomes damaged if there are loose screws or connectors. If a problem occurs after replacing some of the parts, mixed up wiring is often the cause of the problem. Check for proper connection of the wiring, screws, connectors, and Faston terminals.
- 3) To avoid damage to the circuit board, do not connect or disconnect the inverter-related connectors with the main power turned on.
- 4) Faston terminals have a locking function. Make sure the terminals are securely locked in place after insertion.

Press the tab on the terminals to remove them.



- 5) When the IPM or IGBT is replaced, apply a thin layer of heat radiation grease that is supplied evenly to these parts. Wipe off any grease that may get on the wiring terminal to avoid terminal contact failure.
- 6) Faulty wiring to the compressor damages the compressor. Connect the wiring in the correct phase sequence.

	Error display/failure condition	Measure/inspection item
[1]	Inverter related errors 4250, 4220, 4230, 4240, 5301, 5114, 0403	Check the details of the inverter error in the error log at maintenance tool. Take appropriate measures to the error code and the error details in accordance with [2] 2.Error code list.
[2]	Main power breaker trip	Refer to "(3) Trouble treatment when the main power breaker is tripped".(page 123)
[3]	Main power earth leakage breaker trip	Refer to "(4) Trouble treatment when the main power earth leakage breaker is tripped".(page 123)
[4]	Only the compressor does not operate.	Check the inverter frequency on the LED monitor and proceed to (2) - [4] if the compressor is in operation.(page 122)
[5]	The compressor vibrates violently at all times or makes an abnormal sound.	See (2)-[4].(page 122)
[6]	Noise is picked up by the peripheral device	<1> Check that power supply wiring of the peripheral device does not run close to the power supply wiring of the unit.
		<2> Check if the inverter output wiring is not running parallel to the power supply wiring and the transmission lines.
		<3> Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire.
		<4> Meg failure for electrical system other than the inverter
		<5> Attach a ferrite core to the inverter output wiring. (Contact the factory for details of the service part settings.)
		<6> Provide separate power supply to the air conditioner and other electric appliances.
		<7> If the error occurred suddenly, a ground fault of the inverter output can be considered. See (2)-[4].(page 122)
		*Contact the factory for cases other than those listed above.
[7]	Sudden malfunction (as a result of external noise.)	<1> Check that the grounding work is performed properly.
		<2>Check that the shielded wire is used as the transmission line when it is required, and check that the grounding work is performed properly on the shielded wire.
		<3>Check that neither the transmission line nor the external connection wiring does not run close to another power supply system or does not run through the same conduit pipe.
		* Contact the factory for cases other than those listed above.

(2) Inverter output related troubles

	Items to be checked	Phenomena	Remedy
[1] Check the INV board error detection circuit.	(1) Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	1) Overcurrent error (4250 Detail code No. 101, 102, 103, 106, and 107)	Replace the INV board.
	(2) Put the outdoor unit into operation.	2) Logic error (4220 Detail code No. 111)	Replace the INV board.
		3) ACCT sensor circuit failure (5301 Detail code No.117)	Replace the INV board.
		4) IPM open (5301 Detail code No.119)	Normal
[2] Check for compressor ground fault or coil error.	Disconnect the compressor wiring, and check the compressor Meg, and coil resistance.	1) Compressor Meg failure Error if less than 1 Mohm.	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.
		2) Compressor coil resistance failure Coil resistance value of 0.092 ohm (20°C)	Replace the compressor.
[3] Check whether the inverter is damaged. (No load)	(1) Disconnect the inverter output wire from the terminals of the INV board (SC-U, SC-V, SC-W).	1) Inverter-related problems are detected.	Connect the short-circuit connector to CN6, and go to section [1].
	(2) Disconnect the short-circuit connector from CN6 on the INV board.	2) Inverter voltage is not output at the terminals (SC-U, SC-V, and SC-W)	Replace the INV board.
	(3) Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	3) There is a voltage imbalance between the wires. Greater than 5% imbalance or 5V	Replace the INV board.
		4) There is no voltage imbalance between the wires.	Normal *Reconnect the short-circuit connector to CN6 after checking the voltage.

	Items to be checked	Phenomena	Remedy
[4] Check whether the inverter is damaged. (During compressor operation)	Put the outdoor unit into operation. Check the inverter output voltage after the inverter output frequency has stabilized.	1) Overcurrent-related problems occur immediately after compressor startup. Error code : 4250 Detail code : 101, 106, 107	a. Check items [1] through [3] for problems. b. Check that high and low pressures are balanced. c. Check that no liquid refrigerant is present in the compressor. →Go to "d." when the problem persists after compressor startup was repeated several times. If normal operation is restored, check the crankcase heater for problems. d. Check that there is a pressure difference between high and low pressures after compressor startup. →Check the high pressure with LED monitor for changes. Replace the compressor if there is no pressure difference. (the compressor may be locked.)
		2) There is a voltage imbalance between the wires after the inverter output voltage is stabilized. Greater than the larger of the following values: imbalance of 5% or 5V	Replace the INV board if there is a voltage imbalance. Check the crankcase heater for problems if there is no voltage imbalance. →When the error occurred, liquid refrigerant may have been present in the compressor.
[5] Check the fan motor ground fault or the winding.	Remove the wire for the outdoor fan motor, and check the fan motor megger and the winding resistance.	1) Fan motor megger failure Failure when the megger is 1Mohm or less.	Replace the fan motor.
		2) Fan motor disconnection Standard: The winding resistance is approximately several ohm. (It varies depending on the temperature, or while the inner thermo is operating, it will be ∞ ohm)	
[6] Check the fan board failure.	(1) Check the fan output wiring.	Connector contact failure •Board side •Fan motor side	Connect the connector.
	(2) Check the connector CNVDC connection.	Cnconnector contact failure	Connect the connector.
	(3) Check the FAN board failure.	1) The voltage imbalance among each motor wiring during operation (The voltage imbalance is greater than the larger of the values represented by 5% or 5V.)	Replace the FAN board.
		2) The same error occurs even after the operation is restarted.	

(3) Trouble treatment when the main power breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the breaker capacity.	Use of a non-specified breaker	Replace it with a specified breaker.
[2]	Perform Meg check between the terminals on the power terminal block TB4.	Zero to several ohm, or Meg failure	Check each part and wiring. *Refer to (5) "Simple checking procedure for individual components of main inverter circuit".(page 124) ♦IGBT module ♦Rush current protection resistor ♦Electromagnetic relay ♦DC reactor
[3]	Turn on the power again and check again.	1) Main power breaker trip 2) No remote control display	
[4]	Turn on the unit and check that it operates normally.	1) Operates normally without tripping the main breaker. 2) Main power breaker trip	a) The wiring may have been short-circuited. Search for the wire that short-circuited, and repair it. b) If item a) above is not the cause of the problem, refer to (2)-[1]-[6].

(4) Trouble treatment when the main power earth leakage breaker is tripped

	Items to be checked	Phenomena	Remedy
[1]	Check the earth leakage breaker capacity and the sensitivity current.	Use of a non-specified earth leakage breaker	Replace with a regulation earth leakage breaker.
[2]	Check the resistance at the power supply terminal block with a megger.	Failure resistance value	Check each part and wiring. *Refer to (5) "Simple checking procedure for individual components of main inverter circuit".(page 124) ♦IGBT module ♦Rush current protection resistor ♦Electromagnetic relay ♦DC reactor
[3]	Disconnect the compressor wirings and check the resistance of the compressor with a megger.	Failure compressor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 Mohm or less.	Check that there is no liquid refrigerant in the compressor. If there is none, replace the compressor.
[4]	Disconnect the fan motor wirings and check the resistance of the fan motor with a megger.	Failure fan motor if the insulating resistance value is not in specified range. Failure when the insulating resistance value is 1 Mohm or less.	Replace the fan motor.

Note

The insulation resistance could go down to close to 1Mohm after installation or when the power is kept off for an extended period of time because of the accumulation of refrigerant in the compressor. If the earth leakage breaker is triggered, please use the following procedure to take care of this.

- ♦Disconnect the wires from the compressor's terminal block.
- ♦If the resistance is less than 1 Mohm, switch on the power for the unit with the wires still disconnected.
- ♦Leave the power on for at least 12 hours.
- ♦Check that the resistance has recovered to 1 Mohm or greater.

Earth leakage current measurement method

- ♦For easy on-site measurement of the earth leakage current, enable the filter with a measurement instrument that has filter functions as below, clamp all the power supply wires, and measure.

Recommended measurement instrument: CLAMP ON LEAK HiTESTER 3283 made by HIOKI E.E. CORPORATION

- ♦When measuring one device alone, measure near the device's power supply terminal block.

(5) Simple checking procedure for individual components of main inverter circuit

Note

Before inspecting the inside of the control box, turn off the power, keep the unit off for at least 10 minutes, and confirm that the voltage between FT-P and FT-N on INV Board has dropped to DC20V or less.

Part name	Judgment method												
IGBT module	See "Troubleshooting for IGBT Module ". (IX [4] -5- (6))(page 124)												
Rush current protection resistor R11, 12, 21, 22	Measure the resistance between terminals R1 and R5: 22 ohm ± 10%												
Electromagnetic relay 52C	<div>Note</div> <p>This electromagnetic relay is rated at DC12V and is driven by a coil. Check the resistance between terminals</p> <div><div><div>Upper</div><div>Installation direction</div><div><div><div>1</div><div>2</div><div>3</div><div>4</div></div><div><div>6</div><div>5</div></div></div></div><div><table><tr><th></th><th>Check point</th><th>Checking criteria(W)</th></tr><tr><td>Coil</td><td>Between Terminals 5 and 6</td><td>Not to be short-circuited (Center value 75 ohm)</td></tr><tr><td>Contact</td><td>Between Terminals 1 and 2</td><td>∞</td></tr><tr><td></td><td>Between Terminals 3 and 4</td><td>∞</td></tr></table></div></div>		Check point	Checking criteria(W)	Coil	Between Terminals 5 and 6	Not to be short-circuited (Center value 75 ohm)	Contact	Between Terminals 1 and 2	∞		Between Terminals 3 and 4	∞
	Check point	Checking criteria(W)											
Coil	Between Terminals 5 and 6	Not to be short-circuited (Center value 75 ohm)											
Contact	Between Terminals 1 and 2	∞											
	Between Terminals 3 and 4	∞											
DC reactor DCL	Measure the resistance between terminals: 1ohm or lower (almost 0 ohm) Measure the resistance between terminals and the chassis: ∞												

(6) Troubleshooting for IGBT Module

Measure the resistances between each pair of terminals on the IGBT with a tester, and use the results for troubleshooting. The terminals on the INV board are used for the measurement.

1) Notes on measurement

- Check the polarity before measuring. (On the tester, black normally indicates plus.)
- Check that the resistance is not open (∞ ohm) or not shorted (to 0 ohm).
- The values are for reference, and the margin of errors is allowed.
- The result that is more than double or half of the result that is measured at the same measurement point is not allowed.
- Disconnect all the wiring connected the INV board, and make the measurement.

2) Tester restriction

- Use the tester whose internal electrical power source is 1.5V or greater
- Use the dry-battery-powered tester.

Note

(The accurate diode-specific resistance cannot be measured with the button-battery-powered card tester, as the applied voltage is low.)


- Use a low-range tester if possible. A more accurate resistance can be measured.

Judgment value (reference)

		Black (+)				
		SC-P1	FT-N	SC-L1	SC-L2	SC-L3
Red (-)	SC-P1	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	FT-N	-	-	∞	∞	∞
	SC-L1	∞	5 - 200 ohm	-	-	-
	SC-L2	∞	5 - 200 ohm	-	-	-
	SC-L3	∞	5 - 200 ohm	-	-	-


		Black (+)				
		SC-P2	FT-N	SC-U	SC-V	SC-W
Red (-)	SC-P2	-	-	5 - 200 ohm	5 - 200 ohm	5 - 200 ohm
	FT-N	-	-	∞	∞	∞
	SC-U	∞	5 - 200 ohm	-	-	-
	SC-V	∞	5 - 200 ohm	-	-	-
	SC-W	∞	5 - 200 ohm	-	-	-

INV board external diagram



-6- Control Circuit

Troubleshooting transmission power circuit of unit



-7- Troubleshooting

1. Important notes

If the unit or its refrigerant circuit components experience malfunctions, take the following steps to prevent recurrence.

- (1) Diagnose the problem and find the cause.
- (2) Before repairing leaks on the brazed sections on the pipes, recover the refrigerant. Braze under nitrogen purge to prevent oxidation.
- (3) If any component (including the compressor) malfunctions, only replace the affected parts; it is not necessary to replace the entire unit.
- (4) Be sure to recover the refrigerant from the unit before disposing of the unit.
- (5) If the cause of the problem cannot be identified, contact the service desk with the following information: unit model, serial number, and the nature of the problem.

[4] Refrigerant Leak

WARNING

Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate.

- Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit.
- It may also be in violation of applicable laws.
- MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.

1. Leak spot: In the case of unit (Heating season)

- 1) Collect the refrigerant in the entire system (unit). Do not discharge refrigerant into the atmosphere when it is collected.
- 2) Repair the leak.
- 3) Repair the leak, and evacuate the air from the entire system ^{*1}.
Charge the system with 19 kg of R410A.


*1. Refer to Chapter I [5] Vacuum Drying (Evacuation) for detailed procedure. (page 7)


[5] Parts Replacement Procedures

⚠ WARNING




Do not use refrigerant other than the type indicated in the manuals provided with the unit and on the nameplate.

- Doing so may cause the unit or pipes to burst, or result in explosion or fire during use, during repair, or at the time of disposal of the unit.
- It may also be in violation of applicable laws.
- MITSUBISHI ELECTRIC CORPORATION cannot be held responsible for malfunctions or accidents resulting from the use of the wrong type of refrigerant.











Main Compressor Replacement Instructions



<p>1</p>	<ol style="list-style-type: none"> 1. Switch off the power of the unit. 2. Collect the refrigerant.
<p>2</p>  <p>Diagram showing the front of the unit with labels: Decoration panel SR, Panel SR, and Panel F.</p>	<ol style="list-style-type: none"> 1. Remove the decoration panel SR and panels SR and F on the front of the unit.
<p>3</p>  <p>Diagram showing the front of the unit with a label: Control box.</p>	<ol style="list-style-type: none"> 1. Remove the control box.
<p>4</p>  <p>Diagram showing the interior of the unit with labels: Pipe connections and Fixing screws.</p>	<ol style="list-style-type: none"> 1. Remove the belt heater and the wires. 2. Debraze the pipe connections at two locations. 3. Unscrew the four fixing screws, and remove the compressor. 4. Install the new compressor. 5. Connect the pipes by brazing. 6. Re-place the belt heater and the wires.
<p>5</p>	<ol style="list-style-type: none"> 1. Re-place the control box. 2. Re-place the decoration panel SR and panels SR and F. 3. Charge the unit with refrigerant.

Sub Compressor Replacement Instructions




<p>1</p>	<ol style="list-style-type: none"> 1. Switch off the power of the unit. 2. Collect the refrigerant.
<p>2</p> 	<ol style="list-style-type: none"> 1. Remove the decoration panel SL and panels SL and F on the front of the unit.
<p>3</p> 	<ol style="list-style-type: none"> 1. Remove the control box.
<p>4</p> 	<ol style="list-style-type: none"> 1. Remove the belt heater and the wires. 2. Debraze the pipe connections at two locations. 3. Unscrew the four fixing screws, and remove the compressor. 4. Install the new compressor. 5. Connect the pipes by brazing. 6. Re-place the belt heater and the wires.
<p>5</p>	<ol style="list-style-type: none"> 1. Re-place the control box. 2. Re-place the decoration panel SL and panels SL and F. 3. Charge the unit with refrigerant.



Water-to-Refrigerant Heat Exchanger Replacement Instructions (EAHV)

<p>1</p>	<ol style="list-style-type: none"> 1. Switch off the power of the unit. 2. Collect the refrigerant.
<p>2</p> 	<ol style="list-style-type: none"> 1. Remove the decoration panels SL and SR, panels SL, M, and SR, and the three panels F on the front of the unit.
<p>3</p> 	<ol style="list-style-type: none"> 1. Remove the fan control box.
<p>4</p> 	<ol style="list-style-type: none"> 1. Cut the pipes at the eight locations as indicated in the figure at left to allow for the removal of the element.




<p>5</p> 	<ol style="list-style-type: none"> 1. Unscrew the two element-fixing screws, and remove the element.
<p>6</p> 	<ol style="list-style-type: none"> 1. Replace the plate heat exchanger by unscrewing the four fixing screws. 2. Re-place the element.
<p>7</p>	<ol style="list-style-type: none"> 1. Using the replacement pipe kit for water-to-refrigerant heat exchanger, braze-connect all pipes as they were.
<p>8</p>	<ol style="list-style-type: none"> 1. Re-place the fan control box. 2. Replace the decoration panels SL and SR, panels SL, M, and SR, and the three panels F. 3. Charge the unit with refrigerant.




Water-to-Refrigerant Heat Exchanger Replacement Instructions (EACV)

<p>1</p>	<ol style="list-style-type: none"> 1. Switch off the power of the unit. 2. Collect the refrigerant.
<p>2</p>  <p>Diagram showing the front of the unit with labels for the panels to be removed: Decoration panel SL, Panel SL, Panel M, Panel F, and Panel SL.</p>	<ol style="list-style-type: none"> 1. Remove the decoration panels SL and SR, panels SL, M, and SR, and the three panels F on the front of the unit.
<p>3</p>  <p>Diagram showing the unit with the fan control box labeled.</p>	<ol style="list-style-type: none"> 1. Remove the fan control box.
<p>4</p>  <p>Diagram showing the unit with the heat exchanger element removed. Four locations are marked with circles and numbers 1, 2, 3, and 4, indicating where to cut the pipes.</p>	<ol style="list-style-type: none"> 1. Cut the pipes at four locations as shown in the figure at left to allow for the removal of the element.

<p>5</p> 	<p>1. Remove the element by unscrewing the two fixing screws.</p>
<p>6</p> 	<p>1. Replace the plate heat exchanger by unscrewing the four fixing screws.</p> <p>2. Re-place the element.</p>
<p>7</p>	<p>1. Using the replacement pipe kit for water-to-refrigerant heat exchanger, braze-connect all pipes as they were.</p>
<p>8</p>	<p>1. Re-place fan control box.</p> <p>2. Re-place the decoration panels SL and SR, panels SL, M, and SR, and the three panels F.</p> <p>3. Charge the unit with refrigerant.</p>

Fan Replacement Instructions

<div>1</div>	<div>1. Switch off the power of the unit.</div>
<div>2</div> <div><p>A line drawing of a fan unit. A label 'Air guide' points to the top cover of the unit.</p></div>	<div>1. Remove the air guide.</div>
<div>3</div> <div><p>A line drawing of a fan unit. Labels 'Panel S' point to the top covers, and 'Panel M' points to the middle section of the unit.</p></div>	<div>1. Remove panels S and M.</div>
<div>4</div> <div><p>A line drawing of a fan unit. A label 'Bellmouths' points to the front openings of the fan blades.</p></div>	<div>1. Remove the bellmouths.</div>

<p>5</p>  <p>Detailed view of the relay connectors and their surrounding parts</p>	<ol style="list-style-type: none"> 1. Disconnect the relay connectors from the fan. (Remove the cable protector with snap buttons.)
<p>6</p>  <p>Detailed view of the fan</p>	<ol style="list-style-type: none"> 1. Unscrew the screws holding the ferrite core mounting plate in place. (Save the ferrite core mounting plate for later use.) 2. Remove the fan. (Remove the ferrite core mounting plate as well.)
<p>7</p>  <p>Cable strap</p> <p>Ferrite core mounting plate</p>	<ol style="list-style-type: none"> 1. Remove the ferrite core mounting plate from the fan to be replaced, and attach it to the wire on the new fan. (Untie the cable strap from the ferrite core mounting plate, and attach it to the ferrite core on the new fan.) 2. Re-place the fan. 3. Attach the ferrite core mounting plate to the new fan. 4. Connect the relay connectors on the fan. (Replace the cable protector with snap buttons as it was.)
<p>8</p>	<ol style="list-style-type: none"> 1. Re-place the bellmouths. 2. Install the pillar. 3. Install the air guide.

X Attachments

[1] R410A saturation temperature table	141
--	-----

[1] R410A saturation temperature table

Saturation pressure	Saturation temperature °C		Saturation pressure	Saturation temperature °C		Saturation pressure	Saturation temperature °C		Saturation pressure	Saturation temperature °C		Saturation pressure	Saturation temperature °C	
MPa(gauge)	Saturated liquid	Saturated gas	MPa(gauge)	Saturated liquid	Saturated gas	MPa(gauge)	Saturated liquid	Saturated gas	MPa(gauge)	Saturated liquid	Saturated gas	MPa(gauge)	Saturated liquid	Saturated gas
0.00	-51.86	-51.81	0.80	3.80	3.89	1.60	26.09	26.20	2.40	41.40	41.51	3.20	53.30	53.40
0.01	-49.96	-49.91	0.81	4.16	4.25	1.61	26.31	26.43	2.41	41.56	41.68	3.21	53.43	53.53
0.02	-48.20	-48.15	0.82	4.51	4.61	1.62	26.53	26.65	2.42	41.73	41.84	3.22	53.56	53.66
0.03	-46.55	-46.50	0.83	4.86	4.96	1.63	26.75	26.87	2.43	41.89	42.01	3.23	53.70	53.80
0.04	-44.99	-44.94	0.84	5.21	5.31	1.64	26.97	27.09	2.44	42.06	42.17	3.24	53.83	53.93
0.05	-43.52	-43.47	0.85	5.56	5.66	1.65	27.19	27.31	2.45	42.22	42.33	3.25	53.96	54.06
0.06	-42.13	-42.08	0.86	5.90	6.00	1.66	27.41	27.52	2.46	42.38	42.50	3.26	54.09	54.19
0.07	-40.81	-40.75	0.87	6.25	6.35	1.67	27.63	27.74	2.47	42.55	42.66	3.27	54.22	54.32
0.08	-39.54	-39.48	0.88	6.58	6.68	1.68	27.84	27.96	2.48	42.71	42.82	3.28	54.36	54.45
0.09	-38.33	-38.27	0.89	6.92	7.02	1.69	28.06	28.17	2.49	42.87	42.98	3.29	54.49	54.59
0.10	-37.16	-37.11	0.90	7.25	7.35	1.70	28.27	28.38	2.50	43.03	43.15	3.30	54.62	54.72
0.11	-36.04	-35.99	0.91	7.58	7.69	1.71	28.18	28.60	2.51	43.19	43.31	3.31	54.75	54.85
0.12	-34.97	-34.91	0.92	7.91	8.02	1.72	28.69	28.81	2.52	43.35	43.47	3.32	54.88	54.98
0.13	-33.93	-33.86	0.93	8.24	8.34	1.73	28.91	29.02	2.53	43.51	43.63	3.33	55.01	55.11
0.14	-32.92	-32.86	0.94	8.56	8.67	1.74	29.12	29.23	2.54	43.67	43.79	3.34	55.14	55.24
0.15	-31.95	-31.88	0.95	8.88	8.99	1.75	29.33	29.44	2.55	43.83	43.94	3.35	55.27	55.36
0.16	-31.00	-30.94	0.96	9.20	9.31	1.76	29.53	29.65	2.56	43.99	44.10	3.36	55.40	55.49
0.17	-30.09	-30.02	0.97	9.52	9.62	1.77	29.74	29.86	2.57	44.15	44.26	3.37	55.53	55.62
0.18	-29.19	-29.13	0.98	9.84	9.94	1.78	29.95	30.06	2.58	44.31	44.42	3.38	55.65	55.75
0.19	-28.33	-28.26	0.99	10.15	10.25	1.79	30.15	30.27	2.59	44.46	44.58	3.39	55.78	55.88
0.20	-27.49	-27.42	1.00	10.46	10.56	1.80	30.36	30.47	2.60	44.62	44.73	3.40	55.91	56.01
0.21	-26.66	-26.20	1.01	10.77	10.87	1.81	30.56	30.68	2.61	44.78	44.89	3.41	56.04	56.13
0.22	-25.86	-25.79	1.02	11.07	11.18	1.82	30.77	30.88	2.62	44.93	45.04	3.42	56.16	56.26
0.23	-25.08	-25.01	1.03	11.38	11.48	1.83	30.97	31.09	2.63	45.09	45.20	3.43	56.29	56.39
0.24	-24.31	-24.25	1.04	11.68	11.78	1.84	31.17	31.29	2.64	45.24	45.35	3.44	56.42	56.51
0.25	-23.57	-23.50	1.05	11.98	12.08	1.85	31.37	31.49	2.65	45.40	45.51	3.45	56.54	56.64
0.26	-22.84	-22.77	1.06	12.28	12.38	1.86	31.57	31.69	2.66	45.55	45.66	3.46	56.67	56.76
0.27	-22.12	-22.05	1.07	12.57	12.68	1.87	31.77	31.89	2.67	45.71	45.82	3.47	56.80	56.89
0.28	-21.42	-21.35	1.08	12.87	12.97	1.88	31.97	32.09	2.68	45.86	45.97	3.48	56.92	57.02
0.29	-20.73	-20.66	1.09	13.16	13.27	1.89	32.17	32.29	2.69	46.01	46.12	3.49	57.05	57.14
0.30	-20.06	-19.99	1.10	13.45	13.56	1.90	32.37	32.48	2.70	46.16	46.27	3.50	57.17	57.26
0.31	-19.40	-19.32	1.11	13.74	13.85	1.91	32.56	32.68	2.71	46.32	46.43	3.51	57.30	57.39
0.32	-18.75	-18.68	1.12	14.03	14.13	1.92	32.76	32.88	2.72	46.47	46.58	3.52	57.42	57.51
0.33	-18.11	-18.04	1.13	14.31	14.42	1.93	32.95	33.07	2.73	46.62	46.73	3.53	57.55	57.64
0.34	-17.49	-17.41	1.14	14.59	14.70	1.94	33.15	33.27	2.74	46.77	46.88	3.54	57.67	57.76
0.35	-16.87	-16.80	1.15	14.88	14.98	1.95	33.34	33.46	2.75	46.92	47.03	3.55	57.79	57.88
0.36	-16.27	-16.19	1.16	15.16	15.26	1.96	33.54	33.65	2.76	47.07	47.18	3.56	57.92	58.01
0.37	-15.67	-15.60	1.17	15.43	15.54	1.97	33.73	33.84	2.77	47.22	47.33	3.57	58.04	58.13
0.38	-15.09	-15.01	1.18	15.71	15.82	1.98	33.92	34.04	2.78	47.37	47.48	3.58	58.16	58.25
0.39	-14.51	-14.44	1.19	15.99	16.09	1.99	34.11	34.23	2.79	47.52	47.63	3.59	58.28	58.37
0.40	-13.95	-13.87	1.20	16.26	16.37	2.00	34.30	34.42	2.80	47.67	47.78	3.60	58.41	58.50
0.41	-13.39	-13.31	1.21	16.53	16.64	2.01	34.49	34.61	2.81	47.81	47.92	3.61	58.53	58.62
0.42	-12.84	-12.76	1.22	16.80	16.91	2.02	34.68	34.79	2.82	47.96	48.07	3.62	58.65	58.74
0.43	-12.30	-12.22	1.23	17.07	17.18	2.03	34.87	34.98	2.83	48.11	48.22	3.63	58.77	58.86
0.44	-11.76	-11.68	1.24	17.34	17.45	2.04	35.05	35.17	2.84	48.26	48.36	3.64	58.89	58.98
0.45	-11.24	-11.16	1.25	17.60	17.71	2.05	35.24	35.36	2.85	48.40	48.51	3.65	59.01	59.10
0.46	-10.72	-10.64	1.26	17.87	17.98	2.06	35.43	35.54	2.86	48.55	48.66	3.66	59.13	59.22
0.47	-10.21	-10.12	1.27	18.13	18.24	2.07	35.61	35.73	2.87	48.69	48.80	3.67	59.25	59.34
0.48	-9.70	-9.62	1.28	18.39	18.50	2.08	35.80	35.91	2.88	48.84	48.95	3.68	59.37	59.46
0.49	-9.20	-9.12	1.29	18.65	18.76	2.09	35.98	36.10	2.89	48.98	49.09	3.69	59.49	59.58
0.50	-8.71	-8.62	1.30	18.91	19.02	2.10	36.16	36.28	2.90	49.13	49.24	3.70	59.61	59.70
0.51	-8.22	-8.14	1.31	19.17	19.28	2.11	36.35	36.46	2.91	49.27	49.38	3.71	59.73	59.82
0.52	-7.74	-7.66	1.32	19.42	19.53	2.12	36.53	36.65	2.92	49.42	49.52	3.72	59.85	59.94
0.53	-7.27	-7.18	1.33	19.68	19.79	2.13	36.71	36.83	2.93	49.56	49.67	3.73	59.97	60.06
0.54	-6.80	-6.71	1.34	19.93	20.04	2.14	36.89	37.01	2.94	49.70	49.81	3.74	60.09	60.17
0.55	-6.34	-6.25	1.35	20.18	20.29	2.15	37.07	37.19	2.95	49.84	49.95	3.75	60.21	60.29
0.56	-5.88	-5.79	1.36	20.43	20.55	2.16	37.25	37.37	2.96	49.99	50.09	3.76	60.33	60.41
0.57	-5.43	-5.34	1.37	20.68	20.79	2.17	37.43	37.55	2.97	50.13	50.23	3.77	60.44	60.53
0.58	-4.98	-4.89	1.38	20.93	21.04	2.18	37.61	37.73	2.98	50.27	50.38	3.78	60.56	60.64
0.59	-4.54	-4.45	1.39	21.18	21.29	2.19	37.79	37.90	2.99	50.41	50.52	3.79	60.68	60.76
0.60	-4.10	-4.01	1.40	21.42	21.54	2.20	37.97	38.08	3.00	50.55	50.66	3.80	60.79	60.88
0.61	-3.67	-3.58	1.41	21.67	21.78	2.21	38.14	38.26	3.01	50.69	50.80	3.81	60.91	60.99
0.62	-3.24	-3.15	1.42	21.91	22.02	2.22	38.32	38.43	3.02	50.83	50.94	3.82	61.03	61.11
0.63	-2.81	-2.72	1.43	22.15	22.26	2.23	38.49	38.61	3.03	50.97	51.08	3.83	61.14	61.23
0.64	-2.40	-2.30	1.44	22.39	22.51	2.24	38.67	38.78	3.04	51.11	51.22	3.84	61.26	61.34
0.65	-1.98	-1.89	1.45	22.63	22.74	2.25	38.84	38.96	3.05	51.25	51.36	3.85	61.38	61.46
0.66	-1.57	-1.48	1.46	22.87	22.98	2.26	39.02	39.13	3.06	51.39	51.49	3.86	61.49	61.57
0.67	-1.16	-1.07	1.47	23.11	23.22	2.27	39.19	39.31	3.07	51.53	51.63	3.87	61.61	61.69
0.68	-0.76	-0.67	1.48	23.34	23.46	2.28	39.36	39.48	3.08	51.67	51.77	3.88	61.72	61.80
0.69	-0.36	-0.27	1.49	23.58	23.69	2.29	39.54	39.65	3.09	51.80	51.91	3.89	61.84	61.91
0.70	0.04	0.13	1.50	23.81	23.93	2.30	39.71	39.82	3.10	51.94	52.04	3.90	61.95	62.03
0.71	0.43	0.52	1.51	24.04	24.16	2.31	39.88	39.99	3.11	52.08	52.18	3.91	62.06	62.14
0.72	0.82	0.91	1.52	24.28	24.39	2.32	40.05	40.16	3.12	52.21	52.32	3.92	62.18	62.26
0.73	1.20	1.30	1.53	24.51	24.62	2.33	40.22	40.33	3.13	52.35	52.45	3.93	62.29	62.37
0.74	1.58	1.68	1.54	24.74	24.85	2.34	40.39	40.50	3.14	52.49	52.59	3.94	62.41	62.48
0.75	1.96	2.05	1.55	24.96	25.08	2.35	40.56	40.67	3.15	52.62	52.72	3.95	62.52	62.60
0.76	2.33	2.43	1.56	25.19	25.31	2.36	40.73	40.84	3.16	52.76	52.86	3.96	62.63	62.71
0.77	2.70	2.80	1.57	25.42	25.53	2.37	40.89	41.01	3.17	52.89	52.99	3.97	62.75	62.82
0.78	3.07	3.17	1.58	25.64	25.76	2.38	41.06	41.18	3.18	53.03	53.13	3.98	62.86	62.93
0.79	3.44	3.53	1.59	25.87	25.98	2.39	41.23	41.34	3.19	53.16	53.26	3.99	62.97	63.04

Saturation pressure	Saturating temperature °C	
MPa(gauge)	Saturated liquid	Saturated gas
4.00	63.08	63.19
4.01	63.19	63.27
4.02	63.31	63.38
4.03	63.42	63.49
4.04	63.53	63.60
4.05	63.64	63.71
4.06	63.75	63.82
4.07	63.86	63.93
4.08	63.97	64.04
4.09	64.08	64.15
4.10	64.19	64.26
4.11	64.30	64.37
4.12	64.41	64.48
4.13	64.52	64.59
4.14	64.63	64.69
4.15	64.74	64.80

The background of the page is decorated with several concentric, curved green lines that sweep from the left side towards the right, creating a sense of motion and depth.

Service Handbook

Model

EAHV-P900YA(-N)(-BS)

EAHV-P900YA-H(-N)(-BS)

EACV-P900YA(-N)(-BS)

mitsubishi **Electric Corporation**

www.MitsubishiElectric.com