

INDOOR UNIT

SERVICE MANUAL

Models MSZ-AP15VG - E1, ET1, ER1 MSZ-AP20VG - E1, ET1, ER1

> Outdoor unit service manual MUZ-AP·VG Series (OBH839) MXZ-D·VA Series (OBH626) MXZ-E·VA Series (OBH723) MXZ-F·VF Series (OBH790)

CONTENTS

1. TECHNICAL CHANGES	3
2. PART NAMES AND FUNCTIONS	4
3. SPECIFICATION	5
4. NOISE CRITERIA CURVES	6
5. OUTLINES AND DIMENSIONS	·· 7
6. WIRING DIAGRAM	8
7. REFRIGERANT SYSTEM DIAGRAM	9
8. SERVICE FUNCTIONS	10
9. MICROPROCESSOR CONTROL	·11
10. TROUBLESHOOTING	18
11. DISASSEMBLY INSTRUCTIONS	30

PARTS CATALOG (OBB838A)

MSZ-AP15VG MSZ-AP20VG

Revision A: • MSZ-AP15/20VG-<u>ER1</u> have been added. OBB838 is void.

No. OBH838A

Use the specified refrigerant only

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by

failure to follow the instructions.

<Preparation before the repair service>

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker and remove the power plug.
- Discharge the capacitor before the work involving the electric parts.

<Precautions during the repair service>

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigeration cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.

Revision A:

• MSZ-AP15/20VG-____ have been added.

TECHNICAL CHANGES

These models are compatible with the outdoor units with low standby power control.

Connecting these models to the MUZ-AP-VG series outdoor units enables the low standby power control.

These models may be connected to the **MUZ-AP-VG** series after once connected to the **MXZ** series and operated, for example because of relocation. In that case, the **MUZ-AP-VG** series outdoor units will not operate without taking a step. Follow the procedure "Deleting the memorized abnormal condition" described in 10-2.1.

 $\begin{array}{l} MSZ\text{-}AP15VG \mbox{-}\ \mbox{et}\ , \ \ \mbox{et}\ , \ \mbox{et}\ , \ \mbox{et}\ , \ \mbox{et}\ \ \mbox{et}\ , \ \mbox{et}\ , \ \mbox{et}\ , \ \mbox{et}\ , \ \mbox$

1. New model

MSZ-AP15VG MSZ-AP20VG

2



ACCESSORIES

1	Installation plate	1
2	Installation plate fixing screw 4 × 25 mm	5
3	Wireless remote controller	1
4	Felt tape (Used for left or left-rear piping)	1
5	Battery (AAA) for remote controller	2

SPECIFICATION

		Indo	or model		MSZ-AP15VG	MSZ-AP20VG
Power supply					Single phase	230 V, 50 Hz
	Powe	r	Cooling		17	19
Electrical data	input	* 1	Heating	W	17	19
actri	Runni	ina	Cooling		0.17	0.19
dat	currer	nt * 1	Heating	A	0.17	0.19
	Model			RC0J30-CW		
Fan motor	Curre	in the start	Cooling	•	0.17	0.19
Ба	Curre	nt * 1	Heating	A	0.17	0.19
Dimensions W × H × D				mm	760 × 25	50 × 178
Weight				kg	8	.2
	Air dir	ectior	1		Ę	5
			Super High		384	414
		bC	High	1	330	330
		Cooling	Med.	m³/h	276	276
		ö	Low	1	234	234
	Airflow		Silent		21	10
	Airfl		Super High		408	438
		ng	High		36	50
			Med.	m³/h	30	00
			Low		264	
			Silent		22	22
		Ð	Super High		40	42
			High		3	5
S		Cooling	Med.	dB(A)	3	0
ark	/el	ပိ	Low		2	6
en l	le		Silent	1	2	1
Special remarks	Sound level		Super High		40	42
Sec	So	bC	High	1	3	5
S		Heating	Med.	dB(A)	3	0
		He	Low	1	2	6
			Silent	1	2	1
			Super High		1,430	1,530
		bC	High] [1,250	1,250
		oling	Med.	rpm	1,080	1,080
	þ	õ	Low	1	940	940
	Fan speed		Silent	1	86	50
	ร นเ	ls u	Super High		1,430	1,530
	ц	br	High		1,2	290
		Heating	Med.	rpm	1,1	10
		He	Low		99	90
			Silent		87	70
	Fan s	peed	regulator		Ę	5
Rem			er model		SG	
			litions are ha			

NOTE: Test conditions are based on ISO 5151. Cooling: Indoor Dry-bulb temperature 27°C Outdoor Dry-bulb temperature 35°C Heating: Indoor Dry-bulb temperature 20°C Outdoor Dry-bulb temperature 7°C ¥1 Measured under rated operating frequency.

Wet-bulb temperature 19°C

Wet-bulb temperature 6°C

Specifications and rating conditions of main electric parts

Fuse	(F11)	T3.15AL250V
Horizontal vane motor	(MV)	12 V DC
Varistor	(NR11)	470 V
Terminal block	(TB)	3P

3



NOISE CRITERIA CURVES

MSZ-AP15VG

4



MSZ-AP20VG

Test conditions

Cooling: Dry-bulb temperature 27°C Wet-bulb temperature 19°C Heating: Dry-bulb temperature 20°C



OUTLINES AND DIMENSIONS

MSZ-AP15VG MSZ-AP20VG

Unit: mm



MSZ-AP15VG - E1, ER1 MSZ-AP20VG - E1, ER1



1	SYMBOL	NAME	SYMBOL	NAME
	F11	FUSE (T3. 15AL250V)	RT11	ROOM TEMP. THERMISTOR
)	MF	FAN MOTOR	RT12	COIL TEMP. THERMISTOR (MAIN)
	MV1 VANE MOTOR (HORIZONTAL UPPER		RT13	COIL TEMP. THERMISTOR (SUB)
	MV2	VANE MOTOR (HORIZONTAL LOWER)	TB	TERMINAL BLOCK
	NR11	VARISTOR	R111	RESISTOR
,	X1	RELAY		

1. About the outdoor side electronic wiring refer to the outdoor unit electronic wiring diagram for servicing.

2 Use copper supply wires 3 Symbols indicate

: Terminal block

0000 : Connector

MSZ-AP15VG - ET1 MSZ-AP20VG - ET1



SEMBOL	PARÇA ADI	SEMBOL	PARÇA ADI
F11	SIGORTA (T3.15AL250V)	RT11	ODA SICAKLIK TERMİSTÖRÜ
MF	FAN MOTORU	RT12	BORU SICAKLIK TERMİSTÖRÜ(ANA)
MV1	KANAT MOTORU (YATAY ÜST)	RT13	BORU SICAKLIK TERMİSTÖRÜ(YARDIMCI)
MV2	KANAT MOTORU (YATAY ALT)	TB	TERMİNAL BLOĞU
NR11	VARİSTÖR	R111	RESİSTÖR
X1	RÖLE		

NOTLAR: 1. Dış ünite elektronik kablolaması için dış ünite elektronik kablo devre şemasını referans alınız. 2. Sadece bakır besleme kablosu kullanın

3. Sembolleri gösterir

Terminal bloğu

OOOO: Konektör

REFRIGERANT SYSTEM DIAGRAM

MSZ-AP15VG MSZ-AP20VG



Unit: mm

MSZ-AP15VG MSZ-AP20VG

8-1. TIMER SHORT MODE

For service, the following set time can be shortened by bridging the timer short mode point on the electronic control P.C. board. (Refer to 10-7.)

- The set time for the ON/OFF timer can be reduced to 1 second for each minute.
- After the breaker is turned on, the time for starting the compressor, which normally takes 3 minutes, can be reduced to 3 seconds. Restarting the compressor, which takes 3 minutes, cannot be reduced.

8-2. HOW TO SET REMOTE CONTROLLER EXCLUSIVELY FOR A PARTICULAR INDOOR UNIT

A maximum of 4 indoor units with wireless remote controllers can be used in a room.

To operate the indoor units individually with each remote controller, assign a number to each remote controller according to the number of the indoor unit.

This setting can be set only when all the following conditions are met:

• The remote controller is powered OFF.

• Weekly timer is not set.

• Weekly timer is not being edited.

- (1) Hold down 1~4 button on the remote controller for 2 seconds to enter the pairing mode.
- (2) Press $1 \sim 4$ button again and assign a number to each remote controller.
 - Each press of $\boxed{1\sim4}$ button advances the number in the following order: $1 \rightarrow 2 \rightarrow 3 \rightarrow 4$.
- (3) Press SET button to complete the pairing setting.

8-3. AUTO RESTART FUNCTION

When the indoor unit is controlled with the remote controller, the operation mode, the set temperature, and the fan speed are memorized by the indoor electronic control P.C. board. "AUTO RESTART FUNCTION" automatically starts operation in the same mode just before the shutoff of the main power.

Operation

① If the main power has been cut, the operation settings remain.

- ② After the power is restored, the unit restarts automatically according to the memory.
- (However, it takes at least 3 minutes for the compressor to start running.)

How to disable "AUTO RESTART FUNCTION"

- ① Turn off the main power for the unit.
- 2 Cut the jumper wire to JR77 on the indoor electronic control P.C. board. (Refer to 10-7.)



NOTE:

- The operation settings are memorized when 10 seconds has passed after the indoor unit was operated with the remote controller.
- If main power is turned OFF or a power failure occurs while AUTO START/STOP timer is active, the timer setting is cancelled.
- If the unit has been off with the remote controller before power failure, the auto restart function does not work as the power button of the remote controller is OFF.
- To prevent breaker OFF due to the rush of starting current, systematize other home appliance not to turn ON at the same time.
- When some air conditioners are connected to the same supply system, if they are operated before power failure, the starting current of all the compressors may flow simultaneously at restart.

Therefore, the special counter-measures are required to prevent the main voltage-drop or the rush of the starting current by adding to the system that allows the units to start one by one.



MICROPROCESSOR CONTROL

MSZ-AP15VG MSZ-AP20VG WIRELESS REMOTE CONTROLLER



NOTE: Last setting will be stored after the unit is turned OFF with the remote controller. Indoor unit receives the signal of the remote controller with beeps.

INDOOR UNIT DISPLAY SECTION

Operation Indicator lamp

The operation indicator at the right side of the indoor unit indicates the operation state.

•The following indication applies regardless of shape of the indication.

Indication	Operation state	Room temperature	
* *	The unit is operating to reach the set temperature	About 2°C or more away from set temperature	-┿ָ- Lit -沖ִ- Blinking
÷ 0	The room temperature is approaching the set temperature	About 1 to 2°C from set temperature	O Not lit
-☆ ☆-	Standby mode (Only during multi system operation)	—	

9-1. COOL (\$) OPERATION

- (1) Press STOP/OPERATE(OFF/ON) button.
- OPERATION INDICATOR lamp of the indoor unit turns on with a beep tone.
- (2) Select COOL mode with OPERATION SELECT button.

(3) Press TEMPERATURE buttons (TEMP 🗢 or 🗘 button) to select the desired temperature. The setting range is 16 - 31°C. **1. Coil frost prevention**

The compressor operational frequency is controlled by the temperature of the indoor heat exchanger to prevent the coil from frosting.

When the temperature of indoor heat exchanger becomes too low, the coil frost prevention mode works.

The indoor fan operates at the set speed and the compressor stops. This mode continues until the temperature of indoor heat exchanger rises.

2. Low outside temperature operation

When the outside temperature is lower, low outside temperature operation starts, and the outdoor fan slows or stops.

9-2. DRY (A) OPERATION

- (1) Press STOP/OPERATE(OFF/ON) button.
 - OPERATION INDICATOR lamp of the indoor unit turns on with a beep tone.
- (2) Select DRY mode with OPERATION SELECT button.
- (3) The set temperature is determined from the initial room temperature.
- 1. Coil frost prevention
 - Coil frost prevention works the same way as that in COOL mode. (9-1.1.)
- 2. Low outside temperature operation
 - Low outside temperature operation works the same way as that in COOL mode. (9-1.2.)

9-3. FAN (S) OPERATION

- (1) OPERATION INDICATOR lamp of the indoor unit turns on with a beep tone.
- (2) Select FAN mode with OPERATION SELECT button.
- (3) Select the desired fan speed. When AUTO, it becomes Low.
 - Only indoor fan operates.

Outdoor unit does not operate.

9-4. HEAT (©) OPERATION

- (1) Press STOP/OPERATE(OFF/ON) button.
 - OPERATION INDICATOR lamp of the indoor unit turns on with a beep tone.
- (2) Select HEAT mode with OPERATION SELECT button.
- (3) Press TEMPERATURE buttons (TEMP or button) to select the desired temperature. The setting range is 10 31°C.

1. Cold air prevention control

When the compressor is not operating or is starting, and the temperature of indoor heat exchanger and/or the room temperature is low or when defrosting is being done, the indoor fan will stop or rotate in Very Low speed.

2. High pressure protection

The compressor operational frequency is controlled by the temperature of the indoor heat exchanger to prevent the condensing pressure from increasing excessively.

When the temperature of indoor heat exchanger becomes too high, the high pressure protection works.

The indoor fan operates following the cold air prevention control. This mode continues until the temperature of indoor heat exchanger falls.

3. Defrosting

Defrosting starts when the temperature of outdoor heat exchanger becomes too low.

The compressor stops once, the indoor/outdoor fans stop, the 4-way valve reverses, and the compressor re-starts. This mode continues until the temperature of outdoor heat exchanger rises or the fixed time passes.

9-5. AUTO CHANGE OVER --- AUTO MODE OPERATION

Once desired temperature is set, unit operation is switched automatically between COOL and HEAT operation. **Mode selection**

(1) Initial mode

- When unit starts the operation with AUTO operation from OFF:
 - If the room temperature is higher than the set temperature, operation starts in COOL mode.
- If the room temperature is equal to or lower than the set temperature, operation starts in HEAT mode.
- (2) Mode change

COOL mode changes to HEAT mode when about 15 minutes has passed with the room temperature 1°C below the set temperature.

HEAT mode changes to COOL mode when about 15 minutes has passed with the room temperature 1°C above the set temperature.

NOTE 1

If 2 or more indoor units are operating in multi system, there might be a case that the indoor unit, which is operating in \square (AUTO), cannot change over to the other operating mode (COOL \leftrightarrow HEAT) and becomes a state of standby.

Refer to NOTE 2 "FOR MULTI SYSTEM AIR CONDITIONER".

NOTE 2

FOR MULTI SYSTEM AIR CONDITIONER OUTDOOR UNIT: MXZ series

Multi system air conditioner can connect 2 or more indoor units with one outdoor unit.

• When you try to operate 2 or more indoor units with one outdoor unit simultaneously, one for the cooling and the others for heating, the operation mode of the indoor unit that operates first is selected. Other indoor units cannot operate, and operation indicator lamp blinks as shown in the figure below. In this case, please set all the indoor units to the same operation mode.

OPERATION INDICATOR



- When indoor unit starts the operation while the defrosting of outdoor unit is being done, it takes a few minutes (max. 10 minutes) to blow out the warm air.
- In HEAT operation, though indoor unit that does not operate may get warm or the sound of refrigerant flowing may be heard, they are not malfunction. The reason is that the refrigerant continuously flows into it.

9-6. AUTO VANE OPERATION

1. Horizontal vane

(1) Vane motor drive

These models are equipped with a stepping motor for the horizontal vane. The rotating direction, speed, and angle of the motor are controlled by pulse signals (approximately 12 V) transmitted from indoor microprocessor.

(2) The horizontal vane angle and mode change as follows by pressing VANE CONTROL button.

$$\rightarrow \text{AUTO} @ \rightarrow 1 \checkmark @ \rightarrow 2 \checkmark @ \rightarrow 3 \checkmark @ \rightarrow 4 \checkmark @ \rightarrow 5 \checkmark \to \text{SWING}$$

(3) Positioning

To confirm the standard position, the vane moves until it touches the vane stopper. Then the vane is set to the selected angle.

Confirming of standard position is performed in the following cases:

- (a) When the operation starts or finishes (including timer operation).
- (b) When the test run starts.
- (c) When standby mode (only during multi system operation) starts or finishes.
- (4) VANE AUTO (2) mode

In VANE AUTO mode, the microprocessor automatically determines the vane angle to make the optimum room temperature distribution.

In COOL and DRY operation





In HEAT operation Vane angle is fixed to Angle 4.



- (5) STOP (operation OFF) and ON TIMER standby
 - In the following cases, the horizontal vane returns to the closed position.
 - (a) When STOP/OPERATE(OFF/ON) button is pressed (POWER OFF).
 - (b) When the operation is stopped by the emergency operation.
 - (c) When ON TIMER is ON standby.
- (6) Dew prevention

During COOL or DRY operation with the vane angle at Angle 4 or 5 when the compressor cumulative operation time exceeds 1 hour, the vane angle automatically changes to Angle 1 for dew prevention.

- (7) SWING (🔊 mode
- By selecting SWING mode with VANE CONTROL button, the horizontal vane swings vertically.
- (8) Cold air prevention in HEAT operation

The horizontal vane position is set to Upward.

- **NOTE:** When 2 or more indoor units are operated with multi outdoor unit, even if any indoor unit turns thermostat off, this control does not work in the indoor unit.
- (9) ECONO COOL (尊) operation (ECONOmical operation)

When ECONO COOL button is pressed in COOL mode, set temperature is automatically set 2°C higher by the microprocessor. However, the temperature on the LCD screen on the remote controller is not changed. Also the horizontal vane swings in various cycle.

SWING operation makes you feel cooler than set temperature. So, even though the set temperature is higher, the air conditioner can keep comfort. As a result, energy can be saved.

To cancel this operation, select a different mode or press one of the following buttons in ECONO COOL operation: ECONO COOL, VANE CONTROL button.

9-7. TIMER OPERATION

1. How to set the time

(1) Check that the current time is set correctly.

NOTE: Timer operation will not work without setting the current time. Initially "0:00" blinks at the current time display of TIME MONITOR, so set the current time correctly with CLOCK SET button.

How to set the current time

- (a) Press the CLOCK set button.
- (b) Press the TIME SET buttons (and) to set the current time.
 - Each time FORWARD button () is pressed, the set time increases by 1 minute, and each time BACKWARD button () is pressed, the set time decreases by 1 minute.
 - Pressing those buttons longer, the set time increases/decreases by 10 minutes.
- (c) Press the CLOCK set button.
- (2) Press STOP/OPERATE(OFF/ON) button to start the air conditioner.
- (3) Set the time of timer.

ON timer setting

- (a) Press ON TIMER button(ON) during operation.
- (b) Set the time of the timer using TIME SET buttons (and). *

OFF timer setting

- (a) Press OFF TIMER button (OOFF) during operation.
- (b) Set the time of the timer using TIME SET buttons (and). *
- * Each time FORWARD button (___) is pressed, the set time increases by 10 minutes: each time BACKWARD button (___) is pressed, the set time decreases by 10 minutes.

2. To release the timer

To release ON timer, press ON TIMER button (CON).

To release OFF timer, press OFF TIMER button((@OFF)).

TIMER is cancelled and the display of set time disappears.

OBH838A

PROGRAM TIMER

- OFF timer and ON timer can be used in combination. The set time that is reached first will operate first.

(Example 1) The current time is 8:00 PM. The unit turns off at 11:00 PM, and on at 6:00 AM.

(Example 2) The current time is 11:00 AM.



NOTE: If the main power is turned OFF or a power failure occurs while ON/OFF timer is active, the timer setting is cancelled. As these models are equipped with an auto restart function, the air conditioner starts operating with timer cancelled when power is restored.

9-8. WEEKLY TIMER OPERATION

• A maximum of 4 ON or OFF timers can be set for individual days of the week. • A maximum of 28 ON or OFF timers can be set for a week.



NOTE:

- The simple ON/OFF timer setting is available while the weekly timer is on. In this case, the ON/OFF timer has priority over the weekly timer; the weekly timer operation will start again after the simple ON/OFF timer is complete.
- When the weekly timer is set, temperature cannot be set to 10°C.
- The weekly timer operation and i-save operation cannot be used together.

1. How to set the weekly timer * Make sure that the current time and day are set correctly.

(1) Press SET button to enter the weekly timer setting mode.

(2) Press DAY and $1\sim4$ buttons to select setting day and number.







* Hold down the button to change the time quickly.

Press DAY and $1\sim4$ buttons to continue setting the timer for other days and/or numbers.

(4) Press [SET] button to complete and transmit the weekly timer setting.



- Press SET button to transmit the setting information of weekly timer to the indoor unit. Point the remote controller toward the indoor unit for 3 seconds.
- When setting the timer for more than one day of the week or one number, SET button does not have to be pressed per each setting. Press SET button once after all the settings are complete. All the weekly timer settings will be saved.
- Press SET button to enter the weekly timer setting mode, and press and hold DELETE button for 5 seconds to erase all weekly timer settings. Point the remote controller toward the indoor unit.

(5) Press THER button to turn the weekly timer ON. (

•When the weekly timer is ON, the day of the week whose timer setting is complete, will light.

Press TMER button again to turn the weekly timer OFF. (MER goes out.)

NOTE:

The saved settings will not be cleared when the weekly timer is turned OFF.

2. Checking weekly timer setting

(1) Press SET button to enter the weekly timer setting mode.

* SET blinks.

(2) Press DAY or $1 \sim 4$ buttons to view the setting of the particular day or number.

(3) Press CANCEL button to exit the weekly timer setting.

NOTE:

9-9. NIGHT MODE (D) OPERATION

NIGHT MODE changes the brightness of the operation indicator, disables the beep sound and limits the noise level of the outdoor unit.

- (1) Press NIGHT MODE button during operation to activate NIGHT MODE (20).
 - The operation indicator lamp dims.
 - The beep sound will be disabled except that emitted when the operation is started or stopped.

• Noise level of the outdoor unit will be lower than that mentioned in SPECIFICATIONS.(Except the connection to MXZ.)

(2) Press NIGHT MODE button to cancel NIGHT MODE (19).

NOTE:

•The cooling / heating capacity may drop.

•Noise level of the outdoor unit may not change after startup of the unit, during the protection operation, or depending on other operating conditions.

•The fan speed of the indoor unit will not change.

•The operation indicator lamp will be hard to be seen in a bright room.

•Noise level of the outdoor unit will not decrease during Multi system operation.

•Operating POWERFUL operation during NIGHT MODE operation will increase the noise level of the outdoor unit.

•Noise level of the outdoor unit will not decrease during Multi system operation.



9-10. i-save (2) OPERATION

1. How to set i-save operation

- (1) Press STOP/OPERATE(OFF/ON) button.
- (2) Select COOL, HEAT, ECONO COOL or NIGHT MODE.
- (3) Press i-save button.

(4) Set the temperature, fan speed, and airflow direction for i-save operation. **NOTE:**

- i-save operation cannot be selected during DRY or AUTO mode operation.
- The setting range of HEAT mode i-save operation is 10°C and 16 31°C.
- 2 groups of setting can be saved. (One for COOL/ECONO COOL, one for HEAT)
- i-save operation and the weekly timer operation cannot be used together.
- 2. How to cancel operation
 - Press i-save button again.

• i-save operation can also be cancelled by pressing OPERATION SELECT button to change the operation mode. The same setting is selected from the next time by simply pressing i-save button.

9-11. EMERGENCY/TEST OPERATION

In the case of test run operation or emergency operation, use EMERGENCY OPERATION switch on the right side of the indoor unit. Emergency operation is available when the remote controller is missing or has failed, or when the batteries in the remote controller are running down. The unit will start and OPERATION INDICATOR lamp will light up.

The first 30 minutes of operation is the test run operation. This operation is for servicing. The indoor fan runs at High speed and the temperature control does not work. After 30 minutes of test run operation, the system shifts to EMERGENCY COOL/HEAT MODE with a set temperature of 24°C. The fan speed shifts to Med. The coil frost prevention works even in the test run or the emergency operation. In the test run or emergency operation, the horizontal vane operates in VANE AUTO (@) mode. Emergency operation continues until EMERGENCY OPERATION switch is pressed once or twice or the unit receives any signal from the remote controller. In the latter case, normal operation will start.



The operation mode is indicated by the Operation Indicator lamp as following

Operation Indicator lamp



NOTE: Do not press EMERGENCY OPERATION switch during normal operation.



9-12. 3-MINUTE TIME DELAY OPERATION

When the system turns OFF, compressor will not restart for 3 minutes as 3-minute time delay function operates to protect compressor from overload.

MSZ-AP15VG MSZ-AP20VG

10-1. CAUTIONS ON TROUBLESHOOTING

1. Before troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.
- 2. Take care of the following during servicing
 - 1) Before servicing the air conditioner, be sure to turn OFF the main unit first with the remote controller, and then after confirming the horizontal vane is closed, turn OFF the breaker and/or disconnect the power plug.
 - 2) Be sure to turn OFF the power supply before removing the front panel, the cabinet, the top panel, and the P.C. board.
 - 3) When removing the P.C. board, hold the edge of the board with care NOT to apply stress on the components.
 - 4) When connecting or disconnecting the connectors, hold the connector housing. DO NOT pull the lead wires.

<Incorrect>







Connector housing

3. Troubleshooting procedure

- Check if the OPERATION INDICATOR lamp on the indoor unit is blinking ON and OFF to indicate an abnormality. To make sure, check how many times the OPERATION INDICATOR is blinking ON and OFF before starting service work.
- 2) Before servicing, check that the connector and terminal are connected properly.
- If the P.C. board is supposed to be defective, check the copper foil pattern for disconnection and the components for bursting and discoloration.
- 4) When troubleshooting, refer to 10-2., 10-3. and 10-4.

4. How to replace batteries

Weak batteries may cause the remote controller malfunction.

In this case, replace the batteries to operate the remote controller normally.

Remove the front lid and insert batteries.
 Then reattach the front lid.
 Press RESET button with a fine-tipped object, and then use the remote controller.





- NOTE: 1. If RESET button is not pressed, the remote controller may not operate correctly.
 - This remote controller has a circuit to automatically reset the microcomputer when batteries are replaced. This function is equipped to prevent the microcomputer from malfunctioning due to the voltage drop caused by the battery replacement.
 - 3. Do not use the leaking batteries.

10-2. FAILURE MODE RECALL FUNCTION

Outline of the function

This air conditioner can memorize the abnormal condition which has occurred once.

Even though LED indication listed on the troubleshooting check table (10-4.) disappears, the memorized failure details can be recalled.

1. Flow chart of failure mode recall function for the indoor/outdoor unit



OBH838A

2. Table of indoor unit failure mode recall function

Left lamp of OP- ERATION INDICA- TOR lamp	Abnormal point (Failure mode)	Condition	Remedy
Not lit	Normal	—	—
1-time blink every 0.5-second	Room temperature thermistor	The room temperature thermistor short or open circuit is detected every 8 seconds during operation.	Refer to the characteristics of the room temperature thermistor (10-7.).
2-time blink 2.5-second OFF	Indoor coil thermistor	The indoor coil thermistor short or open circuit is detected every 8 seconds during operation.	Refer to the characteristics of the main indoor coil ther- mistor, the sub indoor coil thermistor (10-7.).
3-time blink 2.5-second OFF	Serial signal	The serial signal from outdoor unit is not re- ceived for a maximum of 6 minutes.	Refer to 10-6. ⁽ⁱⁱⁱⁱ) "How to check miswiring and serial signal error".
11-time blink 2.5-second OFF	Indoor fan motor	The rotational frequency feedback signal is not emitted during the 12 seconds the indoor fan operation.	Refer to 10-6. I "Check of indoor fan motor".
12-time blink 2.5-second OFF	Indoor control system	It cannot properly read data in the nonvolatile memory of the indoor electronic control P.C. board.	Replace the indoor electronic control P.C. board.

NOTE: Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-4.).

10-3. INSTRUCTION OF TROUBLESHOOTING



10-4. TROUBLESHOOTING CHECK TABLE

Before taking measures, make sure that the symptom reappears for accurate troubleshooting. When the indoor unit has started operation and detected an abnormality of the following condition (the first detection after the power ON), the indoor fan motor turns OFF and OPERATION INDICATOR lamp blinks.

OPERATION INDICAT		
-č:- O		
<i></i>	-ờ:-	Blinking
	0	Not lit

No.	Abnormal point	Operation indicator lamp	Symptom	Condition	Remedy
1	Miswiring or serial signal	Left lamp blinks. 0.5-second ON ★ ○ ★ ○ ★ ○ ★ ○ 0.5-second OFF		The serial signal from the outdoor unit is not received for 6 minutes. The indoor unit is connected to a low-stand- by-power model after once connected to a non-low-standby-power model.	Refer to 10-6. "How to check miswiring and serial signal error". Refer to NOTE.
2	Indoor coil thermistor Room tem- perature thermistor	Left lamp blinks. 2-time blink ★ ○ ★ ○ ○ ○ ○ ○ ★ ○ ★ ○ ○ ○ 2.5-second OFF		The indoor coil or the room temperature ther- mistor is short or open circuit.	Refer to the characteristics of indoor coil thermistor, and the room temperature thermistor. (10-7.)
3	Indoor fan motor	Left lamp blinks. 3-time blink ★ ○ ★ ○ ★ ○ ○ ○ ○ ○ ★ ○ ★ ○ ★ ○ ○ ○ ○ 2.5-second OFF		The rotational frequency feedback signal is not emitted during the indoor fan operation.	Refer to 10-6. "Check of in- door fan motor".
4	Indoor con- trol system	Left lamp blinks. 4-time blink ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○	Indoor unit and	It cannot properly read data in the nonvolatile memory of the indoor electronic control P.C. board.	Replace the indoor electronic control P.C. board.
5	Outdoor power sys- tem	Left lamp blinks. 5-time blink ★○★○★○★○★○★○○○○★○★○ 2.5-second OFF	- outdoor unit do not operate.	It consecutively occurs 3 times that the com- pressor stops for overcurrent protection or startup failure protection within 1 minute after startup.	Refer to "How to check of in- verter/compressor". Refer to outdoor unit service manual Check the stop valve.
6	Outdoor thermistors	Left lamp blinks. 6-time blink ★○★○★○★○★○★○★○○○○ 2.5-second OFF	-	The outdoor thermistors short or open circuit during the compressor operation.	 Refer to "Check of outdoor thermistor". Refer to outdoor unit service manual.
7	Outdoor control sys- tem	Left lamp blinks. 7-time blink ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○ ★ ○	-	It cannot properly read data in the nonvolatile memory of the inverter P.C. board or the out- door electronic control P.C. board.	Replace the inverter P.C. board or the outdoor electronic control P.C. board. Refer to outdoor unit service manual.
8	Other ab- normality	Left lamp blinks. 14-time blink or more	-	An abnormality other than above mentioned is detected.	 Check the stop valve. Check the 4-way valve. Check the abnormality in detail using the failure mode recall function for outdoor unit.
9	Outdoor control sys- tem	Left lamp lights up 🗎	Outdoor unit does not oper- ate	It cannot properly read data in the nonvolatile memory of the inverter P.C. board or the out- door electronic control P.C. board.	• Check the blinking pattern of the LED on the inverter P.C. board or the outdoor electronic control P.C. board.

NOTE: The indoor unit may have been connected to a non-low-standby-power model outdoor unit. To use a low-standby-power model, clear the error history by referring to "Deleting the memorized abnormal condition" described in 10-2.1. When the error history is being cleared, the connection information also will be initialized. The indoor unit will be compatible with a low-standby-power model after initialization. If the operation indicator lamp continues to blink as shown in No.1 after the procedure, refer to 10-6. D "How to check miswiring and serial error".



OPERATION INDICATOR

-<u>`</u>, -<u>`</u>,

-∳- Lit -☆- Blinking

 $_{\bigcirc}$ Not lit

No	Abnormal point	Operation indicator lamp	Symptom	Condition	Remedy
1	MXZ type Operation mode setting	¥00000¥00000¥	indoor unit does	HEAT at the same time, the operation mode	 Unify the operation mode. Refer to outdoor unit service manual.

10-5. TROUBLE CRITERION OF MAIN PARTS MSZ-AP15VG MSZ-AP20VG

Part name	Check method and criterion			Figure	
Room temperature thermistor (RT11) Indoor coil thermistor (RT12, RT13)	Measure the resistance with a te Refer to 10-7. "Test point diagrar P.C. board", for the chart of therr				
Indoor fan motor (MF)	Refer to 10-6. Theck of indoo				
	Measure the resistance between the terminals with a tester. (Temperature: 10 - 30°C)				
Vane motor (MV)	Color of the lead wire RED - YLW	Normal 223 - 268 Ω		YLW RED YLW YLW	

10-6. TROUBLESHOOTING FLOW



OBH838A





OBH838A



×1. Electric charge may remain immediately after the main power supply is turned OFF. Perform the procedure after 3 minutes.

(E) Electromagnetic noise enters into TV sets or radios



OBH838A



OBH838A

DISASSEMBLY INSTRUCTIONS

<Detaching method of the terminal with locking mechanism>

The terminal which has the locking mechanism can be detached as shown below.

There are following 2 types of the terminal with locking mechanism.

The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.



(2) The terminal with this connector shown below has the locking mechanism.



①Hold the sleeve, and pull out the terminal slowly.

11-1. MSZ-AP15VG MSZ-AP20VG

NOTE: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE

1. Removing the panel

11

- (1) Remove the horizontal vanes.
- (2) Remove the screw caps of the panel. Remove the screws.
- (3) Unhook the lower part (\mathbb{A}) of the panel.
- (4) Hold the lower part of both ends of the panel and pull it slightly toward you, and then remove the panel by pushing it upward.

Indicates the visible parts in the photos/figures.
 Indicates the invisible parts in the photos/figures.



OPERATING PROCEDURE

2. Removing the indoor electronic control P.C. board, receiver P.C. board, display P.C. board, and SW P.C. board

- (1) Remove the panel (refer to section 1) and the corner box.
- (2) Remove the screw of the V.A. clamp. Remove the V.A. clamp and the indoor/outdoor connecting wire. (Photo 2)
- (3) Remove the screw of the electrical cover, and then the electrical cover. (Photo 2)
- (4) Remove the display holder and SW holder. (Photo 3)
- (5) Unhook the catches

 A open the cover of the display holder and remove the receiver P.C. board.
 (Photo 5, 6)
- (6) Unhook the catches ^(B) and remove the display P.C. board. (Photo 6)
- (7) Open the SW holder and pull out the SW P.C. board.(8) Disconnect the following connectors on the electronic

control P.C. board:

- CN211 (Indoor fan motor)
- CN201 (Terminal block)
- CN112 (Indoor coil thermistor)
- CN151 (Horizontal vane motor)
- CN109 (Receiver P.C. board)
- (9) Pull out the electronic control P.C. board from the electrical box.
- (10) Remove the earth wire connected to the indoor electronic control P.C. board from the electrical box. (Photo 3) NOTE:

 $\mathsf{MSZ}\text{-}\mathsf{AP15VG}$ and $\mathsf{MSZ}\text{-}\mathsf{AP20VG}$ have locking mechanism.



proper direction.

OPERATING PROCEDURE	PHOTOS/FIGURES	
 Removing the electrical box (1) Remove the panel (refer to section 1) and the corner box. (2) Remove the indoor/outdoor connecting wire, the SW holder, the display holder, the electrical cover and the earth wire connected to the indoor electronic control P.C. board from the electrical box (refer to section 2). (3) Remove the earth wire connected to the heat exchanger from the electrical box. (4) Disconnect the following connectors on the electronic control P.C. board: CN211 (Fan motor) CN112 (Indoor coil thermistor) CN151 (Horizontal vane motor) (5) Remove the fixing screw of the electrical box. (6) Unhook the catches of the electrical box, and pull out the electrical box. 	Photo 5 Front cover of the display holder Catch (a) Catch (b) Photo 6 Catch (b) Catch (b) Catch (b) Catch (c) Catch Removing the nozzle assembly (1) Remove the panel (refer to section 1) and the corner box. (2) Remove the V.A. clamp. (Photo 2) (3) Remove the electrical cover. (Photo 3.) (4) Disconnect the following connector on the electronic control P.C. board: CN151 (Horizontal vane motor) (5) Pull out the drain hose from the nozzle assembly and remove the nozzle assembly. 	Receiver P.C. board Display P.C. board
 5. Removing the horizontal vane motor Remove the nozzle assembly (refer to section 4). Remove the screw of the lead cover and remove the lead cover. Remove the screws of the horizontal vane motor unit, and pull out the horizontal vane motor unit. Remove the screws of the horizontal vane motor unit cover. Remove the horizontal vane motors from the horizontal vane motor unit. Disconnect the connectors from the horizontal vane motor. 	Photo 7 Screws of the horizontal vane motor unit cover Lead cove	
	Screws of the horizontal Screw of the vane motor unit lead cover	

OPERATING PROCEDURE

6. Removing the indoor fan motor and the line flow fan

(1) Remove the panel (refer to section 1) and the corner box.

- (2) Remove the SW holder, the display P.C. board holder, the electrical box (refer to section 3) and the nozzle assembly (refer to section 4).
- (4) Remove the screws fixing the motor bed. (Photo 8)
- (5) Loosen the screw fixing the line flow fan. (Photo 9)
- (6) Push the upper part of the water cover and unhook the catch.
- (7) Pull the water cover to the right to remove it.
- (8) Remove the motor bed together with fan motor and motor band.
- (9) Release the hooks of the motor band. Remove the motor band. Pull out the indoor fan motor.
- (10) Remove the screws fixing the left side of the heat exchanger. (Photo 10)
- (11) Lift the heat exchanger, and pull out the line flow fan to the lower-left.
- * When attaching the line flow fan, screw the line flow fan so 5 mm gap is provided between the right end of the line flow fan and the right wall of the air passage of the box (Figure 1).

Figure 1





PHOTOS/FIGURES

Fixing the indoor coil thermistor



Do not pull the lead wire when removing the indoor coil thermistor.

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING., 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2019 MITSUBISHI ELECTRIC CORPORATION Issued: Dec. 2019. No. OBH838 REVISED EDITION-A Published: Apr. 2019. No. OBH838 Made in Japan

Specifications are subject to change without notice.