


## Multiple Split type Air-Conditioners

# TECHNICAL & SERVICE MANUAL

## Series PEFY Ceiling Concealed (Fresh Air Intake type)

<Indoor unit>

Models **PEFY-P80VMH-E-F**  
**PEFY-P140VMH-E-F**  
**PEFY-P200VMH-E-F**  
**PEFY-P250VMH-E-F**



INDOOR UNIT

### CONTENTS

SAFETY PRECAUTIONS .....	1
1. FEATURES .....	3
2. PART NAMES AND FUNCTIONS .....	4
3. SPECIFICATION .....	6
4. OUTLINES AND DIMENSIONS .....	8
5. WIRING DIAGRAM .....	10
6. REFRIGERANT SYSTEM DIAGRAM .....	12
7. TROUBLE SHOOTING .....	13
8. DISASSEMBLY PROCEDURE .....	16

# CITY MULTI

For use with the R410A & R407C & R22

# SAFETY PRECAUTIONS

## 1. Before installation and electric work

- ▶ Before installing the unit, make sure you read all the “Safety precautions”.
- ▶ The “Safety precautions” provide very important points regarding safety. Make sure you follow them.
- ▶ This equipment may cause the adverse effect on the same supply system.
- ▶ Please report to or take consent by the supply authority before connection to the system.

### Symbols used in the text

#### **Warning:**

Describes precautions that should be observed to prevent danger of injury or death to the user.

#### **Caution:**

Describes precautions that should be observed to prevent damage to the unit.

### Symbols used in the illustrations



: Indicates an action that must be avoided.



: Indicates that important instructions must be followed.



: Indicates a part which must be grounded.



: Indicates that caution should be taken with rotating parts. (This symbol is displayed on the main unit label.) <Color: Yellow>



: Beware of electric shock (This symbol is displayed on the main unit label.) <Color: Yellow>

#### **Warning:**

Carefully read the labels affixed to the main unit.

#### **Warning:**

- **Ask the dealer or an authorized technician to install the air conditioner.**
  - Improper installation by the user may result in water leakage, electric shock, or fire.
- **Install the air unit at a place that can withstand its weight.**
  - Inadequate strength may cause the unit to fall down, resulting in injuries.
- **Use the specified cables for wiring. Make the connections securely so that the outside force of the cable is not applied to the terminals.**
  - Inadequate connection and fastening may generate heat and cause a fire.
- **Prepare for typhoons and other strong winds and earthquakes and install the unit at the specified place.**
  - Improper installation may cause the unit to topple and result in injury.
- **Always use an air cleaner, humidifier, electric heater, and other accessories specified by Mitsubishi Electric.**
  - Ask an authorized technician to install the accessories. Improper installation by the user may result in water leakage, electric shock, or fire.


- **Never repair the unit. If the air conditioner must be repaired, consult the dealer.**
  - If the unit is repaired improperly, water leakage, electric shock, or fire may result.
- **Do not touch the heat exchanger fins.**
  - Improper handling may result in injury.
- **If refrigerant gas leaks during installation work, ventilate the room.**
  - If the refrigerant gas comes into contact with a flame, poisonous gases will be released.
- **Install the air conditioner according to this Installation Manual.**
  - If the unit is installed improperly, water leakage, electric shock, or fire may result.
- **Have all electric work done by a licensed electrician according to “Electric Facility Engineering Standard” and “Interior Wire Regulations” and the instructions given in this manual and always use a special circuit.**
  - If the power source capacity is inadequate or electric work is performed improperly, electric shock and fire may result.
- **Keep the electric parts away from water (washing water etc.).**
  - It might result in electric shock, catching fire or smoke.
- **Securely install the cover of control box and the panel.**
  - If the cover and panel are not installed properly, dust or water may enter the outdoor unit and fire or electric shock may result.
- **When installing and moving the air conditioner to another site, do not charge it with a refrigerant different from the refrigerant specified on the unit.**
  - If a different refrigerant or air is mixed with the original refrigerant, the refrigerant cycle may malfunction and the unit may be damaged.
- **If the air conditioner is installed in a small room, measures must be taken to prevent the refrigerant concentration from exceeding the safety limit even if the refrigerant should leak.**
  - Consult the dealer regarding the appropriate measures to prevent the safety limit from being exceeded. Should the refrigerant leak and cause the safety limit to be exceeded, hazards due to lack of oxygen in the room could result.
- **When moving and reinstalling the air conditioner, consult the dealer or an authorized technician.**
  - If the air conditioner is installed improperly, water leakage, electric shock, or fire may result.
- **After completing installation work, make sure that refrigerant gas is not leaking.**
  - If the refrigerant gas leaks and is exposed to a fan heater, stove, oven, or other heat source, it may generate noxious gases.
- **Do not reconstruct or change the settings of the protection devices.**
  - If the pressure switch, thermal switch, or other protection device is shorted and operated forcibly, or parts other than those specified by Mitsubishi Electric are used, fire or explosion may result.
- **To dispose of this product, consult your dealer.**
- **Do not use a leak detection additive.**

## 2. Precautions for devices that use R410A or R407C refrigerant

### Caution:

- **Do not use the existing refrigerant piping.**
  - The old refrigerant and refrigerator oil in the existing piping contains a large amount of chlorine which may cause the refrigerator oil of the new unit to deteriorate.
- **Use refrigerant piping made of C1220 (Cu-DHP) phosphorus deoxidized copper as specified in the \*JIS H3300 "Copper and copper alloy seamless pipes and tubes". In addition, be sure that the inner and outer surfaces of the pipes are clean and free of hazardous sulphur, oxides, dust/dirt, shaving particles, oils, moisture, or any other contaminant.**
  - Contaminants on the inside of the refrigerant piping may cause the refrigerant residual oil to deteriorate.

\*JIS: Japanese Industrial Standard
- **Store the piping to be used during installation indoors and keep both ends of the piping sealed until just before brazing. (Store elbows and other joints in a plastic bag.)**
  - If dust, dirt, or water enters the refrigerant cycle, deterioration of the oil and compressor trouble may result.
- **Use ester oil, ether oil or alkylbenzene (small amount) as the refrigerator oil to coat flares and flange connections.**
  - The refrigerator oil will degrade if it is mixed with a large amount of mineral oil.
- **Use liquid refrigerant to fill the system.**
  - If gas refrigerant is used to seal the system, the composition of the refrigerant in the cylinder will change and performance may drop.
- **Do not use a refrigerant other than R410A or R407C.**
  - If another refrigerant (R22, etc.) is used, the chlorine in the refrigerant may cause the refrigerator oil to deteriorate.
- **Use a vacuum pump with a reverse flow check valve..**
  - The vacuum pump oil may flow back into the refrigerant cycle and cause the refrigerator oil to deteriorate.
- **Do not use the following tools that are used with conventional refrigerants. (Gauge manifold, charge hose, gas leak detector, reverse flow check valve, refrigerant charge base, vacuum gauge, refrigerant recovery equipment)**
  - If the conventional refrigerant and refrigerator oil are mixed in the R410A or R407C, the refrigerant may deteriorate.
  - If water is mixed in the R410A or R407C, the refrigerator oil may deteriorate.
  - Since R410A or R407C does not contain any chlorine, gas leak detectors for conventional refrigerants will not react to it.
- **Do not use a charging cylinder.**
  - Using a charging cylinder may cause the refrigerant to deteriorate.
- **Be especially careful when managing the tools.**
  - If dust, dirt, or water gets in the refrigerant cycle, the refrigerant may deteriorate.

**1****FEATURES****Series PEFY Ceiling Concealed**


Indoor unit

Models	Cooling capacity/Heating capacity
	kW
PEFY-P80VMH-E-F	9.0 / 8.5
PEFY-P140VMH-E-F	16.0 / 15.1
PEFY-P200VMH-E-F	22.4 / 21.2
PEFY-P250VMH-E-F	28.0 / 26.5

## 2

# PART NAMES AND FUNCTIONS

### ● Indoor (Main) Unit




### ● Remote controller

#### [PAR-20MAA]

- Once the controls are set, the same operation mode can be repeated by simply pressing the ON/OFF button.


#### [Operation buttons]



- |  |   |
|--|---|
| ① [Room temperature adjustment] Button | ⑦ [Up/down airflow direction] Button    |
| ② [Timer/continuous] Button            | ⑧ [Ventilation] Button                  |
| ③ [Selecting operation] Button         | ⑨ [Checking/built-in] Button            |
| ④ [Time selection] Button              | ⑩ [Test run] Button                     |
| ⑤ [Louver] Button                      | ⑪ [Filter] Button                       |
| ⑥ [Fan speed adjustment] Button        | ⑫ [ON/OFF] Button                       |
|  | ⑬ Position of built-in room temperature |

- Never expose the remote controller to direct sunlight. Doing so can result in the erroneous measurement of room temperature.
- Never place any obstacle around the lower right-hand section of the remote controller. Doing so can result in the erroneous measurement of room temperature.

[Display]



- (A) Current time/Timer
- (B) Centralized control
- (C) Timer ON
- (D) Abnormality occurs
- (E) Operation mode: COOL, DRY, AUTO, FAN, HEAT
- (F) Preparing for Heating mode
- (G) Defrost mode
- (H) Set temperature
- (I) Power ON
- (J) Louver
- (K) Not available function
- (L) Ventilation
- (M) Function setting mode
- (N) Test run mode
- (O) Error check mode
- (P) Filter sign
- (Q) Set effective for 1 hr.
- (R) Sensor position
- (S) Room temperature
- (T) Airflow
- (U) Fan speed

## 3-1. Specification

			PEFY-P80VMH-E-F	PEFY-P140VMH-E-F	PEFY-P200VMH-E-F	PEFY-P250VMH-E-F						
Power source			~ 220-240V 50Hz / ~ 208-230V 60Hz		3N~ 380-415V 50Hz / 60Hz							
Cooling capacity	*1	kW	9.0		16.0		22.4	28.0				
	*1	BTU/h	30,700		54,580		76,400	95,500				
Heating capacity	*1	kW	8.5		15.1		21.2	26.5				
	*1	BTU/h	29,000		51,520		72,300	90,400				
Power consumption (50/60Hz)	Cooling	kW	0.16/0.21		0.29/0.33		0.34/0.42	0.39/0.50				
	Heating	kW	0.16/0.21		0.29/0.33		0.34/0.42	0.39/0.50				
Current (50/60Hz)	Cooling	A	0.67/0.91		1.24/1.48		0.58/0.74	0.68/0.86				
	Heating	A	0.67/0.91		1.24/1.48		0.58/0.74	0.68/0.86				
External finish			Galvanizing									
Dimension	Height	mm	380			470						
	Width	mm	1000		1200		1250					
	Depth	mm	900			1120						
Net weight	kg	50		70		100						
Heat exchanger			Cross fin (Aluminum plate fin and copper tube)									
Fan	Type	Sirocco fan X 1		Sirocco fan X 2								
	Airflow rate	m <sup>3</sup> /min	9.0		18.0		28.0		35.0			
	External static pressure (Low/Mid/High)	Pa	208V	35/85/170		208V	35/85/170		—	—		
		Pa	220V	40/115/190		220V	50/115/190		380V	140/-/200	380V	110/-/190
		Pa	230V	50/130/210		230V	60/130/220		400V	150/-/210	400V	120/-/200
Pa		240V	80/170/220		240V	100/170/240		415V	160/-/220	415V	130/-/210	
Motor	Type	Single phase induction motor						3-phase induction motor				
	Output	kW	0.09		0.14		0.20		0.23			
Air filter (option)			Synthetic fiber unwoven cloth filter (long life)									
Refrigerant pipe dimension (80,140 : Flare / 200,250 : Brazing)	Gas	mm	ø 15.88		ø 15.88 (R410A) ø 19.05 (R22,R407C)		ø 19.05 (R410A) ø 25.4 (R22,R407C)		ø 22.2 (R410A) ø 28.58 (R22,R407C)			
	Liquid	mm	ø 9.52			ø 9.52 (R410A) ø 12.7 (R22,R407C)						
Drain pipe dimension			32 (1-1/4 inch)									
Noise level (Low/Mid/High)	*2	dB(A)	208, 220V	27/38/43	208, 220V	28/38/43	380V	39/-/42	380V	40/-/44		
		dB(A)	230, 240V	33/43/45	230, 240V	34/43/45	400V	40/-/43	400V	40/-/45		
		dB(A)					415V	40/-/44	415V	41/-/46		

Note: \*1 Cooling/Heating capacity indicates the maximum value at operation under the following condition.

Cooling : Indoor 33°CDB/28°CWB, Outdoor 33°CDB

Heating : Indoor 0°CDB/-2.9°CWB, Outdoor 0°CDB/-2.9°CWB

\*2 It is measured in anechoic room.

- The cooling and heating capacities are the maximum capacities that were obtained by operating in the above air conditions and with a refrigerant pipe of about 7.5m.
- The actual capacity characteristics vary with the combination of indoor and outdoor units. See the technical information.
- The operating noise is the data that was obtained by measuring it 1.5m from the bottom of the unit in an anechoic room. (Noise meter A-scale value)
- The figures of Electrical characteristic of P80 and P140 models indicate at 220V and at middle external static pressure, electrical characteristic of P200 and P250 models indicate at 440V and at high external static pressure.
- When the 100% fresh air indoor units are connected, the maximum connectable indoor units to 1 outdoor unit are as follows.

Heat pump models	Cooling only
110%(100% in case of heating below-5°C)	110%

- Operational temp range is cooling : from 21°CDB/15.5°C WB to 43°CDB/35°CWB.

Heating : from -10°CDB to 20°CDB

\*Thermo off (Fan) operation automatically starts either when temperature is lower than 21°CDB in cooling mode or when the temperature exceeds 20°CDB in heating mode.

- As the room temp is sensed by the thermo in the remote controller or the one in the room, be sure to use ether remote controller or room thermo.
- Dry mode is Not available. Fan mode operation during the thermo off in Cooling/Heating mode.
- The fan would temporarily stops either with R2/WR2 system or in defrost.
- In any case, the air flow rate should be kept lower than 110% of the above chart. Please see " Fan curves " for the details.
- When this unit is used as sole A/C system, be careful about the dew in air outlet grilles in cooling mode.
- Un-conditioned outdoor air such as humid air or cold air blows to the indoor during thermo off operation. Please be careful when positioning indoor unit air outlet grilles, ie take the necessary precautions for cold air, and also insulate rooms for dew condensation prevention as required.
- Air filter must be installed in the air intake side. The filter should be attached where easy maintenance is possible in case of usage of field supply filters.
- Long life filter cannot be used with Hi-efficiency filter together.






### 3-2. Electrical parts specifications

Model Parts name	Symbol	PEFY-P80VMH-E-F	PEFY-P140VMH-E-F	PEFY-P200VMH-E-F	PEFY-P250VMH-E-F
Transformer	T	(Primary) 50/60Hz 220-240V (Secondary) (23.5V 0.9A)			
Liquid pipe thermistor	TH22	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ			
Gas pipe thermistor	TH23	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ			
Outdoor air temperature thermistor	TH24	Resistance 0°C/15kΩ, 10°C/9.6kΩ, 20°C/6.3kΩ, 25°C/5.4kΩ, 30°C/4.3kΩ, 40°C/3.0kΩ			
Fuse (Indoor controller board)	FUSE	250V 6.3A			
Fan motor (with Inner-thermostat)	MF1,2	4-pole OUTPUT 90W NS-80VMHF	4-pole OUTPUT 130W NS-100VMHF	4-pole OUTPUT 200W NS-200VMH-E-F	4-pole OUTPUT 230W NS-250VMH-E-F
Inner-thermostat (Fan motor)		OFF 135°C±5°C ON 95°C±20°C			
Fan motor capacitor	C1	4.0μF×440V			-
Linear expansion valve	LEV	DC12V Stepping motor drive port dimension ø 5.2 (0~1800pulse <at R410A outdoor unit> 0~2000pulse <at the other outdoor unit>)	DC12V Stepping motor drive port dimension ø 6.4 (0~1800pulse <at R410A outdoor unit> 0~2000pulse <at the other outdoor unit>)	DC12V Stepping motor drive port dimension ø 5.2 (0~1800pulse <at R410A outdoor unit> 0~2000pulse <at the other outdoor unit>)	
Power supply terminal block	TB2	(L,N,⊕) 330V 30A			(L1,L2,L3,N,⊕) 660V 40A
Transmission terminal block	TB5 TB15	(1,2),(M1,M2,S) 300V 10A			



PEFY-P80-140VMH-E-F

Unit : mm




- Note 1. Use M10 screw for the lifting bolt (field supply).  
 2. Keep the service space for the maintenance from the bottom when the heat exchanger is cleaned.  
 3. This chart indicates for PEFY-P140/VMH-E-F models, which have 2 fans.  
 PEFY-P80/VMH-E-F model has 1 fan.  
 4. Make sure to install the air filter (field supply) on the air intake side.  
 In case field supplied air filter is used, attach it where the filter service is easily done.  
 5. On Model:140, you would use flare nut packed with the Indoor Unit, when connecting the Outdoor Unit for R407C, R22.  
 6. In order to increase the strength of the flare nut, the size of some of them has been increased.
- Refrigerant piping flare connection (gas M copper tube): LP  
 Refrigerant piping flare connection (liquid N copper tube): HP  
 Drain hose 32mm (1-1/4inch) <flexible joint 200mm> (accessory)
- ①  
 ..... ②  
 ..... ③

Model	A	B	C	D	E	F	G	H	J	K	L	M	N	P (Liquid)	P (Gas)
PEFY-P80/VMH-E-F	1050	1004	930	850	800	25	17	800	15	700	1030		#9.52	22	29
PEFY-P140/VMH-E-F	1250	1204	1130	1050	1000	25	21	1000	19	900	1230		#9.52	22	36

\*1:R410A outdoor unit  
 \*2:R407C,R22 outdoor unit



PEFY-P80-140VMH-E-F



SYMBOL EXPLANATION

SYMBOL	NAME	SYMBOL	NAME
MF	Fan motor	CN20	Connector (remote sensor)
C	#B Capacitor (for MF)	TH22	Thermistor (piping temp.detection/liquid)
I.B	Indoor controller board	TH23	Thermistor (piping temp.detection/gas)
<DS>	Drain sensor	TH24	Thermistor (outdoor air temp.detection)
A.B	Address board	SW11(A,B)	Switch (1st digit address set)
TB2	Power source terminal block	SW12(A,B)	Switch (2nd digit address set)
TB5	Transmission terminal block	SW14(A,B)	Switch (connection No.set)
TB15	Transmission terminal block	SW1(A,B)	Switch (for mode selection)
F1	Fuse AC250V 6.3A F	SW2(L,B)	Switch (for capacity code)
<F2>	Fuse AC250V 5A F	SW3(L,B)	Switch (for mode selection)
T	Transformer	SW4(L,B)	Switch (for model selection)
<DP>	Drain Pump	SW5(A,B)	Switch (for voltage selection)
LEV	Electronic linear expans. valve	SW7(A,B)	Switch (for model selection)
S.B	Surge absorber board	X04 ~ X06	Aux.relay

Inside < > is the optional parts.


Symbol	LED operation under normal state
LED1	At applying main power source (indoor unit 200V) → Lighting
LED2	At receiving M-NET transmission power source → Lighting

- NOTE : 1.** The part of the broken line indicates the circuit for optional parts.
- 2.\*A** in the chart is the connector for a drain pump test run operation. (The Drain Pump operates continuously if the connector is inserted and the power is supplied.) After the test run, make sure to remove the \*A connector.
- 3.** The wirings to TB2, TB5 (shown in dotted line) are field work.
- 4.** Mark ☉ indicates terminal block, ⊕ connector, ⊞ board insertion connector or fastening connector of control board.



# 6

# REFRIGERANT SYSTEM DIAGRAM










Item \ Capacity	PEFY-P80VMH-E-F	PEFY-P140VMH-E-F
Gas pipe	∅ 15.88 <5/8F>	∅ 15.88 <5/8F> (R410A) ∅ 19.05 <3/4F> (R22,R407C)
Liquid pipe	∅ 9.52 <3/8F>	∅ 9.52 <3/8F>

Item \ Capacity	PEFY-P200VMH-E-F	PEFY-P250VMH-E-F
Gas pipe	∅ 19.05 <3/4> (R410A) ∅ 25.4 <1> (R22,R407C)	∅ 22.2 <7/8> (R410A) ∅ 28.58 <1-1/8> (R22,R407C)
Liquid pipe	∅ 9.52 <3/8> (R410A) ∅ 12.7 <1/2> (R22,R407C)	∅ 9.52 <3/8> (R410A) ∅ 12.7 <1/2> (R22,R407C)

# 7

# TROUBLE SHOOTING

## 7-1. How to check the parts

Parts name	Check points	
Liquid pipe thermistor (TH22) Gas pipe thermistor (TH23) Outdoor air temperature thermistor (TH24)	Disconnect the connector, then measure the resistance using a tester. (Surrounding temperature 10°C~30°C)	
	Normal	Abnormal
	4.3kΩ~9.6kΩ	Open or short
	(Refer to the thermistor characteristic graph)	
Trans 	Disconnect the connector and measure the resistance using a tester.	
	Normal	Abnormal
	CNT(1)-(3)	App.15Ω
	CN3T(1)-(3)	App.4Ω
	Open or short	
Fan motor PEFY-P80•140 	Measure the resistance between the terminals using a tester. (at 20°C)	
	Motor terminal or Relay connector	Normal
		PEFY-P80
		PEFY-P140
	Gray-Orange	76.4Ω
		22.8Ω
	Gray-Black	89.8Ω
		27.4Ω
	Gray-Brown	115.2Ω
		32.8Ω
	Gray-Red	148.1Ω
		67.9Ω
	Abnormal	
	Open or short	
Fan motor PEFY-P200•250 	Measure the resistance between the terminals using a tester. (at 20°C)	
	Motor terminal or Relay connector	Normal
		PEFY-P200
		PEFY-P250
	Red-White	4.17Ω
		4.17Ω
	White-Black	4.17Ω
		4.17Ω
	Red-Black	4.17Ω
		4.17Ω
	Brown-Gray	11.14Ω
		12.44Ω
	Gray-Yellow	11.14Ω
		12.44Ω
	Brown-Yellow	11.14Ω
		12.44Ω
	Abnormal	
	Open or short	
Linear expansion valve 	Disconnect the connector then measure the resistance valve using a tester.	
	Normal	
	(1)-(5)	(2)-(6)
	(3)-(5)	(4)-(6)
	White-Red	Yellow-Brown
		Orange-Red
		Blue-Brown
	150Ω ±10%	
	Abnormal	
	Open or short	
Drain Pump (Drain water lift up kit) 	Disconnect the connector then measure the resistance valve using a tester. (Surrounding temperature 20°C~30°C)	
	Normal	Abnormal
	399Ω	Open or short
Drain sensor (Drain water lift up kit) 	Measure the resistance between the terminals using a tester. (Refer to the thermistor characteristic graph)	
	0°C/6.0kΩ, 10°C/3.9kΩ 20°C/2.6kΩ, 25°C/2.2kΩ 30°C/1.8kΩ, 40°C/1.3kΩ	
	<p>&lt;Thermistor characteristic graph&gt; Room temperature thermistor(TH21) Liquid pipe thermistor(TH22) Gas pipe temperature thermistor(TH23) Drain sensor(DS)</p> <p>Thermistor R<sub>0</sub>=15kΩ ± 3% Fixed number of B=3480kΩ ± 2% R<sub>t</sub>=15exp { 3480( <math>\frac{1}{273+t} - \frac{1}{273} </math> ) }</p> <p>0°C 15kΩ 10°C 9.6kΩ 20°C 6.3kΩ 25°C 5.2kΩ 30°C 4.3kΩ 40°C 3.0kΩ</p> 	






### 7-3. Setting of Dip-switch (at delivery)

Models	Dip-SW							SWA 1	SWC Standard Indicate “標準”
PEFY-P80 VMH-E-F	SW1 ON OFF 1 2 3 4 5 6 7 8 9 10	SW2 ON OFF 1 2 3 4 5 6	SW3 ON OFF 1 2 3 4 5 6 7 8 9 10	SW4 ON OFF 1 2 3 4 5	SW5 ON OFF 220V 240V	SW7 ON OFF 1 2 3			
PEFY-P140 VMH-E-F	SW1 ON OFF 1 2 3 4 5 6 7 8 9 10	SW2 ON OFF 1 2 3 4 5 6	SW3 ON OFF 1 2 3 4 5 6 7 8 9 10	SW4 ON OFF 1 2 3 4 5	SW5 ON OFF 220V 240V	SW7 ON OFF 1 2 3			
PEFY-P200 VMH-E-F	SW1 ON OFF 1 2 3 4 5 6 7 8 9 10	SW2 ON OFF 1 2 3 4 5 6	SW3 ON OFF 1 2 3 4 5 6 7 8 9 10	SW4 ON OFF 1 2 3 4 5	SW5 ON OFF 220V 240V	SW7 ON OFF 1 2 3			
PEFY-P250 VMH-E-F	SW1 ON OFF 1 2 3 4 5 6 7 8 9 10	SW2 ON OFF 1 2 3 4 5 6	SW3 ON OFF 1 2 3 4 5 6 7 8 9 10	SW4 ON OFF 1 2 3 4 5	SW5 ON OFF 220V 240V	SW7 ON OFF 1 2 3			

### 7-4. Attention for test run

Equipment which is attached drain water lift up kit can be tested pump out test when power supplied.(connect the connector(A))

#### < Drain-up machine >



After pump out test, remove the connector and put in the dummy connector.

After test run,remove the connector (A)(Fig .1)




### 7-5. Function the LED of the indoor unit service board

Symbol	LED operation under normal state
LED1	At applying main power source (indoor unit 200V) → Lighting
LED2	At receiving M-NET transmission power source → Lighting





## 8-1. CONTROL BOX

Be careful on removing heavy parts.





OPERATING PROCEDURE	PHOTOS
<p><b>Models 80-140</b></p> <p><b>1.Removing the control box cover</b></p> <p>(1) Remove the fixing screws (two) of the control box (A), and remove the cover. (Fig. 1)</p> <p>*At this stage, the following servicing is possible.</p> <p><b>1</b> Operation and check of the switches (listed below) which are on the control board.</p> <ul style="list-style-type: none"> <li>• Dip switch SW2 ..... Capacity code setting</li> <li>• Dip switch SW3 ..... Function change</li> <li>• Dip switch SW4 ..... Model code setting</li> </ul> <p><b>2</b> Connection check of the lead wires (listed below) which are connected to the controller board.</p> <ul style="list-style-type: none"> <li>• Power supply lead wire.</li> <li>• MA remote controller transmission lead wire.</li> <li>• Fan motor lead wire.</li> <li>• LEV lead wire</li> <li>• Intake air sensor lead wire</li> <li>• Liquid piping sensor lead wire</li> <li>• Gas piping sensor lead wire</li> <li>• Power supply transformer lead wire</li> <li>Address board lead wire               <ul style="list-style-type: none"> <li>(• Drain pump lead wire)</li> <li>(• Drain sensor lead wire)</li> </ul> </li> </ul> <p><b>3</b> Control board exchange</p> <p><b>4</b> Condenser exchange</p> <p><b>5</b> Power supply transformer exchange</p> <p><b>6</b> Arrest exchange</p> <p><b>7</b> Intake air sensor exchange</p> <p>( ):Optional parts</p> <p><b>2.Removing the terminal bed cover</b></p> <p>(1) Remove the fixing screws (two) of the terminal bed cover (B), and remove the cover. (Fig. 2)</p> <p>*At this stage, the following servicing is possible.(Fig. 3)</p> <p><b>1</b> Operation and check of the switches (listed below) which are on the address board.</p> <ul style="list-style-type: none"> <li>• Rotary switches SW11, 12 ... Address setting</li> <li>• Rotary switch SW14 ..... Branch port setting</li> <li>• Dip switch SW1 ..... Function change (main)</li> <li>• Dip switch SW7 ..... Model code setting</li> </ul> <p><b>2</b> Address board exchange</p> <p><b>3</b> Power supply terminal block exchange</p> <p><b>4</b> Transmission terminal block exchange</p>	<p><b>Fig.1</b></p>  <p><b>Fig.2</b></p>  <p><b>Fig.3</b></p> 

Be careful on removing heavy parts.

OPERATING PROCEDURE	PHOTOS
<p><b>Models 200 • 250</b></p> <p><b>1.Removing the control box cover</b></p> <p>(1) Remove the fixing screws (four) of the control box cover (C), and remove the cover. (Fig. 4)</p> <p>*At this stage, the following servicing is possible.(Fig. 5)</p> <ol style="list-style-type: none"><li>1 Operation and check of the switches (listed below) which are on the control board.<ul style="list-style-type: none"><li>• Dip switch SW2 .....Capacity code setting</li><li>• Dip switch SW3 .....Function change</li><li>• Dip switch SW4 .....Model code setting</li></ul></li><li>2 Connection check of the lead wires (listed below) which are connected to the controller board.<ul style="list-style-type: none"><li>• Power supply lead wire.</li><li>• MA remote controller transmission lead wire.</li><li>• Fan motor lead wire.</li><li>• LEV lead wire</li><li>• Intake air sensor lead wire</li><li>• Liquid piping sensor lead wire</li><li>• Gas piping sensor lead wire</li><li>• Power supply transformer lead wire</li><li>• Address board lead wire<ul style="list-style-type: none"><li>(• Drain pump lead wire)</li><li>(• Drain sensor lead wire)</li></ul></li></ul></li><li>3 Control board exchange</li><li>4 Power supply transformer exchange</li><li>5 Arrest exchange</li><li>6 Intake air sensor exchange</li><li>7 Operation and check of the switches (listed below) which are on the address board<ul style="list-style-type: none"><li>• Rotary switches SW11, 12 ....Address setting</li><li>• Rotary switch SW14 ..... Branch port setting</li><li>• Dip switch SW1..... Function change (main)</li><li>• Dip switch SW7 ..... Model code setting</li></ul></li><li>8 Address board exchange</li><li>9 Power supply terminal block exchange</li><li>10 Transmission terminal block exchange</li></ol> <p>( ):Optional parts</p>	<p><b>Fig.4</b></p>  <p><b>Fig.5</b></p> 

Be careful on removing heavy parts.

## 8-2. FAN and FAN MOTOR



OPERATING PROCEDURE	PHOTOS
<p><b>Models 80 ·140</b></p> <p><b>1.Removing the control box.</b></p> <ol style="list-style-type: none"><li>(1) Remove the control box cover and terminal block cover with procedure 8-1.</li><li>(2) Remove the fan motor connectors.</li><li>(3) Remove the fixing screws (two) of the control box and slide the control box to remove.(Fig. 1)</li><li>(4) Move the control box to place that is not block operation. (Fig. 2)</li></ol>	<p><b>Fig.1</b></p>  <p><b>Fig.2</b></p> <p>Control box</p> 
<p><b>2.Removing the fan motor</b></p> <p><b>Model 80</b></p> <p>*After motor base (D) and bell mouse (C) attached the fan case (B) removed,motor (A) can be pull with motor base and fan along rail.</p> <ol style="list-style-type: none"><li>(1) Remove the fan motor connector (E).</li><li>(2) Loosen the fixing screws (F) (three) of the bell mouse (C), and removed the bell mouse (D) turning screws in direction arrow (counterclockwise).(Fig. 3)</li><li>(3) Remove the fixing screws (four) of the motor base(D).</li></ol> <p>Notice: It's necessary using the driver over 30cm length to remove the fixing screws (a) . (Fixing screws are placed back)</p>	<p><b>Fig.3</b></p>  <p>(A) (D) (E) (B)</p> <p>(C) Fixing screws (F) Loosen fixing screws (not remove)</p> <p><b>Model 80</b></p> <p><b>Fig.4</b></p> <p>Fixing screws</p>  <p>Fixing screws (a) Motor base (D)</p>

Be careful on removing heavy parts.

### OPERATING PROCEDURE

- (4) Slide the motor (A) with motor base (D) in direction of allow ①. (Fig. 5)

### PHOTOS




#### Model 140

\*Motor maintenance procedure is almost 80 model procedure.  
Model 140 has twin shaft motor. After removing the fan and fan case which are in front of motor, remove the motor.

- (1) Remove the bell mouse of the front fan motor with procedure model 80.
- (2) Loosen the setting screws of the front fan , removed the fan.
- (3) Remove the front fan case.
- (4) Operate with procedure model 80.

Notice: Fixing screws of the fan case are shown Fig. 7.  
Remove the fixing screws (H), fan case can be removed.

**Fig.7**



Be careful on removing heavy parts.

## OPERATING PROCEDURE

## PHOTOS

### Models 200-250

#### 1.Removing the control box.

- (1) Remove the control box cover1 with procedure 8-1.
- (2) Remove the fixing screws (four) of the control cover 2, and remove the control cover2. (Fig. 7)
- (3) Remove the fan motor connectors.
- (4) Remove the fixing screws (three) of the control box and remove the control box (Fig. 8)
- (5) Move the control box to place that is not block operation. (Fig. 9)

Fig.7




Fig.8





Fig.9




#### 2.Removing the fan motor

\*After the fan (A) ,the fan case (B) and the bell mouse (C) removed, motor can be pull with motor base and inner fan along rail.

- (1) Remove the fixing screws (three) of the bell mouse (C), and remove the bell mouse (C). (Fig. 3)
- (2) Loosen the setting screws (G) of the front fan , removed the fan.(Fig. 10)

Fig.10



Be careful on removing heavy parts.

## OPERATING PROCEDURE

(3) After removing the fixing screws (H) (as shown models 80, 140) of the front fan case (B) and remove the fan. Pull the fan case (B).

(4) Remove the fixing screws (K) (three) of the bell mouse (J) attached fan case (L), and remove the bell mouse (J). (Fig.12)

(5) Remove the fixing screws (four) of the motor base(D).

Notice: It's necessary using the driver over 30cm length to remove the fixing screws (a) . (Fixing screws are placed back)(Fig. 13)

(6) Slide the motor (M) with motor base (D) in direction of arrow ②. (Fig. 14)

Notice: It's not necessary removing the fan case (L).

## PHOTOS

Fig.11




Fig.12




Fig.13




Fig.14








Fig.15



### 8-3. LEV,THERMISTOR (Liquid/Gas piping temperature detection)

Be careful on removing heavy parts.

OPERATING PROCEDURE	PHOTOS
<p><b>Models 80-140</b></p> <p><b>1.Removing the LEV.</b></p> <p>(1) Remove the control box cover with procedure 8-1.</p> <p>(2) Remove the fixing screws (four) of the heat exchanger cover (A), and remove the cover (A).(Fig. 1)</p> <p>(3) Remove the LEV driving motor with a double spanner.(Fig. 2)</p> <p><b>2.Removing the thermistors.</b></p> <p>(1) Remove the thermistors from the thermistor holders which are installed on the piping.(Fig. 2)</p> <p>(liquid piping : fine piping , gas piping : thick piping)</p>	<p><b>Fig.1</b></p>  <p><b>Fig.2</b></p> 
<p><b>Models 200-250</b></p> <p><b>1.Removing the LEV. (These models have 2 LEV)</b></p> <p>(1) Remove the fixing screws (three) of the heat exchanger cover (A), and remove the cover (A).</p> <p>(2) Remove the fixing screws (four) of the maintenance cover (B), and remove the cover (B).(Fig. 3)</p> <p>(3) Remove the LEV driving motor with a double spanner.(Fig. 4)</p> <p><b>2.Removing the thermistors.</b></p> <p>(1) Remove the thermistors from the thermistor holders which are installed on the piping.(Fig. 4)</p> <p>(liquid piping : fine piping , gas piping : thick piping)</p>	<p><b>Fig.3</b></p>  <p><b>Fig.4</b></p> 

## 8-4. HEAT EXCHANGER

Be careful on removing heavy parts.

### OPERATING PROCEDURE

#### Models 80 ·140

#### 1.Removing the heat exchanger.

- (1) Remove the heat exchanger cover with procedure 8-3-1.
- (2) Remove the bottom plate which is air outlet side.(fixing screws : ten) (Fig. 1)
- (3) Remove the drainpan.(Fig. 2)

### PHOTOS

Fig.1




Fig.2





Fig.3





Be careful on removing heavy parts.


### OPERATING PROCEDURE

- (4) Remove the maintenance cover.(fixing screws : two) (Fig. 4)
- (5) Remove the heat exchanger.(fixing screws : four) (Fig. 3,5)

\*Removed heat exchanger is as shown Fig.6


### PHOTOS

**Fig.4**




Maintenance cover    Fixing screws

**Fig.5**



Fixing screws

**Fig.6**



Be careful on removing heavy parts.

## OPERATING PROCEDURE

### Models 200-250

#### 1.Removing the heat exchanger.

- (1) Remove the refrigerant piping and drain hose from main unit.(Be care that water is not leaking from drain hose. )
- (2) Remove the power supply wire and the transmission line. (Make sure that power source is turning off. )
- (3) Pull down the main unit.
- (4) Turn over the main unit upside the bottom plate
- (5) Remove the bottom plate which is air outlet side.(fixing screws : fifteen) (Fig. 7)
- (6) Remove the drainpan.(Fig. 8)

## PHOTOS

Fig.7




Fig.8





Fig.9



Be careful on removing heavy parts.


### OPERATING PROCEDURE

- (7) Remove the fixing screws (three) of the heat exchanger cover, and remove the cover. Remove the fixing screws (four) of the maintenance cover, and remove the cover. (Fig. 10)
- (7) Remove the heat exchanger.
  - Fixing screws(non-piping side) : two (Fig. 9)
  - Fixing screws(piping side) : two (Fig. 11)


\*Removerd heat exchanger is as shown Fig.12

### PHOTOS

**Fig.10**



**Fig.11**




**Fig.12**






### 8-5. CONTROL BOX INSIDE LAYOUT

Models 80-140




Models 200-250






## 8-6. SENSOR POSITION


●PEFY-P80VMH-E-F




●PEFY-P140VMH-E-F



●PEFY-P200VMH-E-F



●PEFY-P250VMH-E-F





HEAD OFFICE: MITSUBISHI DENKI BLDG., 2-2-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

---