

March 2020

**No. OCH668**  
**REVISED EDITION-E**

# TECHNICAL & SERVICE MANUAL

## <Outdoor unit>

### [Model Name]

### [Service Ref.]

PUMY-SP112VKM	PUMY-SP112VKM.TH	PUMY-SP112VKMR1.TH
PUMY-SP125VKM	PUMY-SP125VKM.TH	PUMY-SP125VKMR1.TH
PUMY-SP140VKM	PUMY-SP140VKM.TH	PUMY-SP140VKMR1.TH
PUMY-SP112YKM	PUMY-SP112YKM.TH	PUMY-SP112YKMR1.TH
PUMY-SP125YKM	PUMY-SP125YKM.TH	PUMY-SP125YKMR1.TH
PUMY-SP140YKM	PUMY-SP140YKM.TH	PUMY-SP140YKMR1.TH

#### Revision:

- Connectable indoor units have been added in REVISED EDITION-E.


OCH668 REVISED EDITION-D  
 is void.

#### Note:

- This service manual describes technical data of the outdoor units only.

## Salt proof model

PUMY-SP112VKM-BS	PUMY-SP112VKM.TH-BS	PUMY-SP112VKMR1.TH-BS
PUMY-SP125VKM-BS	PUMY-SP125VKM.TH-BS	PUMY-SP125VKMR1.TH-BS
PUMY-SP140VKM-BS	PUMY-SP140VKM.TH-BS	PUMY-SP140VKMR1.TH-BS
PUMY-SP112YKM-BS	PUMY-SP112YKM.TH-BS	PUMY-SP112YKMR1.TH-BS
PUMY-SP125YKM-BS	PUMY-SP125YKM.TH-BS	PUMY-SP125YKMR1.TH-BS
PUMY-SP140YKM-BS	PUMY-SP140YKM.TH-BS	PUMY-SP140YKMR1.TH-BS



OUTDOOR UNIT

## CONTENTS

1. SAFETY PRECAUTION.....	2
2. OVERVIEW OF UNITS.....	5
3. SPECIFICATIONS.....	9
4. DATA.....	11
5. OUTLINES AND DIMENSIONS.....	26
6. WIRING DIAGRAM.....	27
7. NECESSARY CONDITIONS FOR SYSTEM CONSTRUCTION.....	29
8. TROUBLESHOOTING.....	47
9. ELECTRICAL WIRING.....	124
10. REFRIGERANT PIPING TASKS.....	130
11. DISASSEMBLY PROCEDURE.....	137

**PARTS CATALOG (OCB668)**

# CITY MULTI

## 1-1. CAUTIONS RELATED TO NEW REFRIGERANT

Cautions for units utilizing refrigerant R410A

**Preparation before the repair service**

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker.
- Discharge the condenser before the work involving the electric parts.

**Use new refrigerant pipes.**

Avoid using thin pipes.

**Make sure that the inside and outside of refrigerant piping is clean and it has no contaminants such as sulfur, oxides, dirt, shaving particles, etc., which are hazard to refrigerant cycle. In addition, use pipes with specified thickness.**

Contamination inside refrigerant piping can cause deterioration of refrigerant oil, etc.

**Store the piping indoors, and keep both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**The refrigerant oil applied to flare and flange connections must be ester oil, ether oil or alkylbenzene oil in a small amount.**

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil, etc.

**Charge refrigerant from liquid phase of gas cylinder.**

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

**Do not use refrigerant other than R410A.**

If other refrigerant (R22, etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil, etc.

**Precautions during the repair service**

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigerating cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.

**Use a vacuum pump with a reverse flow check valve.**

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil, etc.

**Use the following tools specifically designed for use with R410A refrigerant.**

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

**Handle tools with care.**

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

**Do not use a charging cylinder.**

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

**Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.**

**Use the specified refrigerant only.**

**Never use any refrigerant other than that specified.** Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of. Correct refrigerant is specified in the manuals and on the spec labels provided with our products. We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.


## [1] Cautions for service

- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) If moisture or foreign matter might have entered the refrigerant piping during service, ensure to remove them.

## [2] Additional refrigerant charge

### When charging directly from cylinder

- (1) Check that cylinder for R410A on the market is a syphon type.
- (2) Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



## [3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.

No.	Tool name	Specifications
①	Gauge manifold	· Only for R410A · Use the existing fitting specifications. (UNF1/2) · Use high-tension side pressure of 5.3MPa·G or over.
②	Charge hose	· Only for R410A · Use pressure performance of 5.09MPa·G or over.
③	Electronic weighing scale	—
④	Gas leak detector	· Use the detector for R134a, R407C or R410A.
⑤	Adaptor for reverse flow check	· Attach on vacuum pump.
⑥	Refrigerant charge base	—
⑦	Refrigerant cylinder	· Only for R410A · Top of cylinder (Pink) · Cylinder with syphon
⑧	Refrigerant recovery equipment	—

## 1-2. PRECAUTIONS FOR SALT PROOF TYPE "-BS" MODEL

Although "-BS" model has been designed to be resistant to salt damage, observe the following precautions to maintain the performance of the unit.

- (1) Avoid installing the unit in a location where it will be exposed directly to seawater or sea breeze.
- (2) If the cover panel may become covered with salt, be sure to install the unit in a location where the salt will be washed away by rainwater. (If a sunshade is installed, rainwater may not clean the panel.)
- (3) To ensure that water does not collect in the base of the outdoor unit, make sure that the base is level, not at angle. Water collecting in the base of the outdoor unit could cause rust.
- (4) If the unit is installed in a coastal area, clean the unit with water regularly to remove any salt build-up.
- (5) If the unit is damaged during installation or maintenance, be sure to repair it.
- (6) Be sure to check the condition of the unit regularly.
- (7) Be sure to install the unit in a location with good drainage.

## Cautions for refrigerant piping work

New refrigerant R410A is adopted for replacement inverter series. Although the refrigerant piping work for R410A is same as for R22, exclusive tools are necessary so as not to mix with different kind of refrigerant. Furthermore as the working pressure of R410A is 1.6 times higher than that of R22, their sizes of flared sections and flare nuts are different.

### ① Thickness of pipes

Because the working pressure of R410A is higher compared to R22, be sure to use refrigerant piping with thickness shown below. (Never use pipes of 0.7 mm or below.)



Diagram below: Piping diameter and thickness

Nominal dimensions (in)	Outside diameter (mm)	Thickness (mm)	
		R410A	R22
1/4	6.35	0.8	0.8
3/8	9.52	0.8	0.8
1/2	12.70	0.8	0.8
5/8	15.88	1.0	1.0
3/4	19.05	—	1.0

### ② Dimensions of flare cutting and flare nut

The component molecules in HFC refrigerant are smaller compared to conventional refrigerants. In addition to that, R410A is a refrigerant, which has higher risk of leakage because its working pressure is higher than that of other refrigerants. Therefore, to enhance airtightness and strength, flare cutting dimension of copper pipe for R410A has been specified separately from the dimensions for other refrigerants as shown below. The dimension B of flare nut for R410A also has partly been changed to increase strength as shown below. Set copper pipe correctly referring to copper pipe flaring dimensions for R410A below. For 1/2 and 5/8 inch pipes, the dimension B changes.

Use torque wrench corresponding to each dimension.



Flare cutting dimensions

Nominal dimensions (in)	Outside diameter (mm)	Dimension A ( $\begin{smallmatrix} +0 \\ -0.4 \end{smallmatrix}$ ) (mm)	
		R410A	R22
1/4	6.35	9.1	9.0
3/8	9.52	13.2	13.0
1/2	12.70	16.6	16.2
5/8	15.88	19.7	19.4
3/4	19.05	—	23.3

Flare nut dimensions

Nominal dimensions (in)	Outside diameter (mm)	Dimension B (mm)	
		R410A	R22
1/4	6.35	17.0	17.0
3/8	9.52	22.0	22.0
1/2	12.70	26.0	24.0
5/8	15.88	29.0	27.0
3/4	19.05	—	36.0

### ③ Tools for R410A (The following table shows whether conventional tools can be used or not.)

Tools and materials	Use	R410A tools	Can R22 tools be used?	Can R407C tools be used?
Gauge manifold	Air purge, refrigerant charge and operation check	Tool exclusive for R410A	×	×
Charge hose		Tool exclusive for R410A	×	×
Gas leak detector	Gas leak check	Tool for HFC refrigerant	×	○
Refrigerant recovery equipment	Refrigerant recovery	Tool exclusive for R410A	×	×
Refrigerant cylinder	Refrigerant charge	Tool exclusive for R410A	×	×
Applied oil	Apply to flared section	Ester oil, ether oil and alkylbenzene oil (minimum amount)	×	Ester oil, ether oil: ○ Alkylbenzene oil: minimum amount
Safety charger	Prevent compressor malfunction when charging refrigerant by spraying liquid refrigerant	Tool exclusive for R410A	×	×
Charge valve	Prevent gas from blowing out when detaching charge hose	Tool exclusive for R410A	×	×
Vacuum pump	Vacuum drying and air purge	Tools for other refrigerants can be used if equipped with adapter for reverse flow check	△ (Usable if equipped with adapter for reverse flow)	△ (Usable if equipped with adapter for reverse flow)
Flare tool	Flaring work of piping	Tools for other refrigerants can be used by adjusting flaring dimension	△ (Usable by adjusting flaring dimension)	△ (Usable by adjusting flaring dimension)
Bender	Bend the pipes	Tools for other refrigerants can be used	○	○
Pipe cutter	Cut the pipes	Tools for other refrigerants can be used	○	○
Welder and nitrogen gas cylinder	Weld the pipes	Tools for other refrigerants can be used	○	○
Refrigerant charging scale	Refrigerant charge	Tools for other refrigerants can be used	○	○
Vacuum gauge or thermistor vacuum gauge and vacuum valve	Check the degree of vacuum. (Vacuum valve prevents back flow of oil and refrigerant to thermistor vacuum gauge)	Tools for other refrigerants can be used	○	○
Charging cylinder	Refrigerant charge	Tool exclusive for R410A	×	-

×: Prepare a new tool. (Use the new tool as the tool exclusive for R410A.)

△: Tools for other refrigerants can be used under certain conditions.

○: Tools for other refrigerants can be used.

## 2-1. SYSTEM CONSTRUCTION

Outdoor unit		4.5HP	5HP	6HP
		PUMY-SP112VKM(R1).TH(-BS) PUMY-SP112YKM(R1).TH(-BS)	PUMY-SP125VKM(R1).TH(-BS) PUMY-SP125YKM(R1).TH(-BS)	PUMY-SP140VKM(R1).TH(-BS) PUMY-SP140YKM(R1).TH(-BS)
Applicable indoor unit	Capacity	Type 10 to Type 140		
	Number of units	1 to 12 units	1 to 12 units	1 to 12 units
	Total system capacity range	50 to 130% of outdoor unit capacity <sup>*1</sup>		

Branching pipe components	CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E
	Branch header (2 branches)	Branch header (4 branches)	Branch header (8 branches)

Model Capacity	Cassette Ceiling					Ceiling concealed	Wall Mounted	Ceiling Suspended	Floor standing		Ceiling concealed		Lossnay	CONNECTION KIT PAC-LV11M-J
	2 by 2	4-way flow	2-way flow	1-way flow					Exposed	Concealed	Fresh air <sup>*3</sup>	Built-in		
	PLFY-P	PLFY-P	PLFY-EP <sup>*2</sup>	PLFY-P	PMFY-P	PEFY-P	PKFY-P	PCFY-P	PFFY-P	PFFY-P	PEFY-P	PDFY-P	GUF <sup>*4</sup>	
10	-	-	-	-	-	-	10VLM-E/ET	-	-	-	-	-	-	
15	15VFM-E1	-	-	-	-	15VMS1(L)-E	15VBM-E 15VLM-E/ET	-	-	-	-	-	-	
20	20VFM-E1	20VEM-E	-	20VLMD-E	20VBM-E	20VMS1(L)-E 20VMA(L)-E 20VMR-E-L/R	20VBM-E 20VLM-E/ET	-	20VLEM-E 20VKM-E(2)	20VLRM-E 20VLRMM-E 20VCM-E	-	20VM-E	-	
25	25VFM-E1	25VEM-E	-	25VLMD-E	25VBM-E	25VMS1(L)-E 25VMA(L)-E 25VMR-E-L/R 25VMA3-E <sup>*5</sup>	25VBM-E 25VLM-E/ET	-	25VLEM-E 25VKM-E(2)	25VLRM-E 25VLRMM-E 25VCM-E	-	25VM-E	-	
32	32VFM-E1	32VEM-E	-	32VLMD-E	32VBM-E	32VMS1(L)-E 32VMA(L)-E 32VMR-E-L/R 32VMA3-E <sup>*5</sup>	32VHM-E 32VLM-E/ET	-	32VLEM-E 32VKM-E(2)	32VLRM-E 32VLRMM-E 32VCM-E	-	32VM-E	-	
40	40VFM-E1	40VEM-E	-	40VLMD-E	40VBM-E	40VMS1(L)-E 40VMA(L)-E 40VMH(S)-E 40VMA3-E <sup>*5</sup>	40VHM-E 40VLM-E/ET	40VKM-E	40VLEM-E 40VKM-E(2)	40VLRM-E 40VLRMM-E 40VCM-E	-	40VM-E	-	
50	50VFM-E1	50VEM-E	50VEM-E	50VLMD-E	-	50VMS1(L)-E 50VMA(L)-E 50VMH(S)-E	50VHM-E 50VLM-E/ET	-	50VLEM-E	50VLRM-E 50VLRMM-E 50VCM-E	-	50VM-E	50RD(H)4	
63	-	63VEM-E	63VEM-E	63VLMD-E	-	63VMS1(L)-E 63VMA(L)-E 63VMH(S)-E	63VKM-E	63VKM-E	63VLEM-E	63VLRM-E 63VLRMM-E 63VCM-E	-	63VM-E	-	
71	-	-	-	-	-	71VMA(L)-E 71VMH(S)-E	-	-	-	-	-	71VM-E	-	
80	-	80VEM-E	80VEM-E	80VLMD-E	-	80VMA(L)-E 80VMH(S)-E	-	-	-	-	80VMH-E-F	80VM-E	-	
100	-	100VEM-E	-	100VLMD-E	-	100VMA(L)-E 100VMH(S)-E	100VKM-E	100VKM-E	-	-	-	100VM-E	100RD(H)4	
125	-	125VEM-E	-	125VLMD-E	-	125VMA(L)-E 125VMH(S)-E	-	125VKM-E	-	-	-	125VM-E	-	
140	-	-	-	-	-	140VMA(L)-E 140VMH(S)-E	-	-	-	-	140VMH-E-F	-	-	

M series indoor unit <sup>\*6</sup>  
MSZ-GE Series  
MSZ-SF Series  
MSZ-EF Series  
MSZ-FH Series  
MSZ-LN Series  
MSZ-AP Series <sup>\*7</sup>

M series remote controller

Remote controller	Name	M-NET remote controller	MA remote controller
	Model number	PAR-F27MEA-E, PAR-U02MEDA	PAR-4xMAA, PAR-3xMAA ("x" represents 0 or later)
	Functions	<ul style="list-style-type: none"> <li>A handy remote controller for use in conjunction with the Melans centralized management system.</li> <li>Addresses must be set.</li> </ul>	<ul style="list-style-type: none"> <li>Addresses setting is not necessary.</li> </ul>

<sup>\*1</sup> When the indoor unit of Fresh Air type is connected with the outdoor unit, the maximum connectable total indoor unit capacity is 110%.

<sup>\*2</sup> For the PLFY-EP/VEM-E, up to 2 units can be connected. Other indoor units (Excluding the PEFY-P/ VMA3-E and PEFY-P/ VMH-E-F) can be connected within the total rated capacity and maximum number of connected units.

<sup>\*3</sup> PUMY is connectable to Fresh Air type indoor unit.

It is possible to connect 1 Fresh Air type indoor unit to 1 outdoor unit. (1:1 system)

Operating temperature range (outdoor temperature) for fresh air type indoor units differ from other indoor units.

Refer to "2-4-(3). Operating temperature range".

<sup>\*4</sup> Do not connect Lossnay remote controller(s). (PZ-61DR-E, PZ-60DR-E, PZ-52SF-E, PZ-43SMF-E)

<sup>\*5</sup> Authorized connectable indoor units are as follows;

PUMY-SP112: PEFY-P25VMA3-E×2 + PEFY-P32VMA3-E×2

PUMY-SP125: PEFY-P25VMA3-E×1 + PEFY-P32VMA3-E×3

PUMY-SP140: PEFY-P32VMA3-E×2 + PEFY-P40VMA3-E×2

<sup>\*6</sup> When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT.

<sup>\*7</sup> Connectable only for PUMY-SP-VKMR1.TH(-BS), PUMY-SP-YKMR1.TH(-BS).

## 2-2. SYSTEM CONSTRUCTION (BRANCH BOX SYSTEM)

Outdoor unit		4.5HP	5HP	6HP
		PUMY-SP112VKM(R1).TH(-BS) PUMY-SP112YKM(R1).TH(-BS)	PUMY-SP125VKM(R1).TH(-BS) PUMY-SP125YKM(R1).TH(-BS)	PUMY-SP140VKM(R1).TH(-BS) PUMY-SP140YKM(R1).TH(-BS)
Applicable indoor unit	Capacity	kW unit: Type 15 to Type 100		
	Number of units	2 to 8 units		
	Total system capacity range	50 to 130% of outdoor unit capacity (6.3 to 16.2 kW)	50 to 130% of outdoor unit capacity (7.1 to 18.2 kW)	50 to 130% of outdoor unit capacity (8.0 to 20.2 kW)
Branch box that can be connected	Number of units	1 to 2 units		

Model Capacity [kW type]	Wall Mounted								1-way ceiling cassette		4-way ceiling cassette			
											2 by 2 type		Standard	
	MSZ-FH	MSZ-LN	MSZ-GE	MSZ-GF	MSZ-SF	MSZ-EF	MSZ-SF	MSZ-AP*1	MLZ-KA	MLZ-KP*1	SLZ-KF	SLZ-M*1	PLA-RP	PLA-M
15	-	-	-	-	-	-	15VA	15VF 15VG	-	-	-	15FA	-	-
18	-	-	-	-	-	18VE3 18VG	-	-	-	-	-	-	-	-
20	-	-	-	-	-	-	20VA	20VF 20VG	-	-	-	-	-	-
22	-	-	22VA	-	-	22VE3 22VG	-	-	-	-	-	-	-	-
25	25VE2	25VG	25VA	-	25VE3	25VE3 25VG	-	25VG	25VA	25VE	25VA2	25FA	-	-
35	35VE2	35VG	35VA	-	35VE3	35VE3 35VG	-	35VG	35VA	35VE	35VA2	35FA	35EA	35EA
42	-	-	42VA	-	42VE3	42VE3 42VG	-	42VG	-	-	-	-	-	-
50	50VE2	50VG	50VA	-	50VE3	50VE3 50VG	-	50VG	50VA	50VE	50VA2	50FA	50EA	50EA
60	-	-	60VA	60VE	-	-	-	-	-	-	-	-	60EA	60EA
71	-	-	71VA	71VE	-	-	-	-	-	-	-	-	71EA	71EA
80	-	-	80VA	-	-	-	-	-	-	-	-	-	-	-
100	-	-	-	-	-	-	-	-	-	-	-	-	100EA	100EA

Model Capacity [kW type]	Ceiling concealed				Ceiling suspended		Floor standing
	Low static pressure		Middle static pressure				
	SEZ-KD	SEZ-M*1	PEAD-RP	PEAD-M	PCA-RP	PCA-M	MFZ-KJ*1
15	-	-	-	-	-	-	-
18	-	-	-	-	-	-	-
20	-	-	-	-	-	-	-
22	-	-	-	-	-	-	-
25	25VAQ(L)	25DA	-	-	-	-	25VE
35	35VAQ(L)	35DA	-	-	35KAQ	35KA	35VE
42	-	-	-	-	-	-	-
50	50VAQ(L)	50DA	50JAQ(L)	50JA(L)	50KAQ	50KA	50VE
60	60VAQ(L)	60DA	60JAQ(L)	60JA(L)	60KAQ	60KA	-
71	71VAQ(L)	71DA	71JAQ(L)	71JA(L)	71KAQ	71KA	-
80	-	-	-	-	-	-	-
100	-	-	100JAQ(L)	100JA(L)	100KAQ	100KA	-

\*1 Connectable for only PUMY-SP•VKMR1.TH(-BS),PUMY-SP•YKMR1.TH(-BS)

Note: The lineup of a connectable indoor unit depends on a district/areas/country.

Branch box	PAC-MK5*BC	PAC-MK3*BC
Number of branches (Indoor unit that can be connected)	5-branches (MAX. 5 units)	3-branches (MAX. 3 units)

\* changes such as 1, 2...

Note:  
A maximum of 2 branch boxes can be connected to 1 outdoor unit.  
PUMY-SP•VKM.TH(-BS),PUMY-SP•YKM.TH(-BS)  
cannot connect 32/33/52/53 series.  
PUMY-SP•VKMR1.TH(-BS),PUMY-SP•YKMR1.TH(-BS)  
cannot connect 31/32/51/52 series.

2-branch pipe (joint): Optional parts	
In the case of using 1- branch box	No need
In the case of using 2- branch boxes	Model name
	MSDD-50AR-E
	MSDD-50BR-E
Connection method	
flare	
brazing	
Select a model according to the connection method.	

Option	Optional accessories of indoor units and outdoor units are available.
--------	---

## 2-3. SYSTEM CONSTRUCTION (MIXED SYSTEM)

Outdoor unit			4.5HP		5HP		6HP	
			PUMY-SP112VKM(R1).TH(-BS) PUMY-SP112YKM(R1).TH(-BS)		PUMY-SP125VKM(R1).TH(-BS) PUMY-SP125YKM(R1).TH(-BS)		PUMY-SP140VKM(R1).TH(-BS) PUMY-SP140YKM(R1).TH(-BS)	
Applicable indoor unit	Capacity	CITY MULTI indoor unit	Type 10 to Type 140					
		Via branch box	kW unit: Type 15 to Type 100					
	Number of units		Via branch box	CITY MULTI indoor	Via branch box	CITY MULTI indoor	Via branch box	CITY MULTI indoor
		1 branch box	5	5	5	5	5	5
		2 branch boxes	8	3	8	3	8	3
	Total system capacity range		6.3 to 16.2 kW		7.1 to 18.2 kW		8.0 to 20.2 kW	


Branching pipe components	CMY-Y62-G-E	CMY-Y64-G-E	CMY-Y68-G-E
	Branch header (2-branches)	Branch header (4-branches)	Branch header (8-branches)



Branch box Number of branches	PAC-MK5*BC	PAC-MK3*BC
	5-branches (MAX. 5 units)	3-branches (MAX. 3 units)

\* changes such as 1, 2...

PUMY-SP · VKM.TH(-BS), PUMY-SP · YKM.TH(-BS)  
cannot connect 32/33/52/53 series.  
PUMY-SP · VKMR1.TH(-BS), PUMY-SP · YKMR1.TH(-BS)  
cannot connect 31/32/51/52 series.



\*1 Refer to "2-1. SYSTEM CONSTRUCTION" or "2-2. SYSTEM CONSTRUCTION (BRANCH BOX SYSTEM)", for more detail.



## 2-4. SYSTEM SPECIFICATIONS

### (1) Outdoor Unit

Outdoor unit		PUMY-SP112VKM.TH(-BS) PUMY-SP112YKM.TH(-BS) PUMY-SP112VKMR1.TH(-BS) PUMY-SP112YKMR1.TH(-BS)	PUMY-SP125VKM.TH(-BS) PUMY-SP125YKM.TH(-BS) PUMY-SP125VKMR1.TH(-BS) PUMY-SP125YKMR1.TH(-BS)	PUMY-SP140VKM.TH(-BS) PUMY-SP140YKM.TH(-BS) PUMY-SP140VKMR1.TH(-BS) PUMY-SP140YKMR1.TH(-BS)
Capacity	Cooling (kW)	12.5	14.0	15.5
	Heating (kW)	14.0	16.0	16.5

Cooling capacity indicates the maximum value at operation under the following condition.

\*Cooling Indoor : D.B. 27°C/W.B. 19°C


Outdoor : D.B. 35°C

\*Heating Indoor : D.B. 20°C

Outdoor : D.B. 7°C/W.B. 6°C

### (2) Method for identifying MULTI-S model

#### ■ Outdoor unit <When using model 125 >



### (3) Operating temperature range

	Cooling	Heating
Indoor-side intake air temperature	W.B. 15 to 24°C	D.B. 15 to 27°C
Outdoor-side intake air temperature	D.B. -5 to 52°C <sup>*1</sup>	W.B. -20 to 15°C

Note: D.B.: Dry Bulb Temperature  
W.B.: Wet Bulb Temperature

<sup>\*1</sup> 10 to 52°C D.B.: When connecting PKFY-P15/20/25VBM, PKFY-P10/15/20/25/32VLM, PFFY-P20/25/32VKM, PFFY-P20/25/32VLE(R)M(M), PFFY-P20/25/32VCM; and M series, S series, and P series type indoor unit.

#### ■ When connecting fresh air type indoor unit

	Capacity of Fresh air type indoor	Cooling	Heating
Indoor-side and Outdoor-side intake air temperature	P80	D.B. 21 to 43°C <sup>*1</sup> W.B. 15.5 to 35°C	D.B. -10 to 20°C <sup>*2</sup>
	P140	D.B. 21 to 43°C <sup>*1</sup> W.B. 15.5 to 35°C	D.B. -5 to 20°C <sup>*2</sup>

<sup>\*1</sup> Thermo-OFF (FAN-mode) automatically starts if the outdoor temp. is lower than 21°C D.B.

<sup>\*2</sup> Thermo-OFF (FAN-mode) automatically starts if the outdoor temp. is lower than 20°C D.B.



Model					PUMY-SP112VKM(R1).TH(-BS)			PUMY-SP125VKM(R1).TH(-BS)			PUMY-SP140VKM(R1).TH(-BS)					
Power source					1-phase 220-230-240 V, 50 Hz; 1-phase 220 V, 60 Hz											
Cooling capacity (Nominal)		kW	*1		12.5			14.0			15.5					
		kcal/h	*1		10,750			12,040			13,330					
		Btu/h	*1		42,650			47,768			52,886					
		Power input	kW		3.10			3.84			4.70					
		Current input	A		14.38	13.75	13.18	17.81	17.04	16.33	21.80	20.85	19.98			
COP		kW/kW		4.03			3.65			3.30						
Temp. range of cooling		Indoor temp.	W.B.		15 to 24°C											
		Outdoor temp.	D.B.		-5 to 52°C *3,*4											
Heating capacity (Nominal)		kW	*2		14.0			16.0			16.5					
		kcal/h	*2		12,040			13,760			14,190					
		Btu/h	*2		47,768			54,592			56,298					
		Power input	kW		3.17			3.90			4.02					
		Current input	A		14.70	14.06	13.48	18.09	17.30	16.58	18.65	17.83	17.09			
COP		kW/kW		4.42			4.10			4.10						
Temp. range of heating		Indoor temp.	D.B.		15 to 27°C											
		Outdoor temp.	W.B.		-20 to 15°C											
Indoor unit connectable		Total capacity			50 to 130% of outdoor unit capacity											
		Model/ Quantity	CITY MULTI			P10-P140/12			P10-P140/12			P10-P140/12				
			Branch box			*5 P15-P100/8			P15-P100/8			P15-P100/8				
			Mixed system	Branch box 1 unit*5	CITY MULTI	P10-P140/5			P10-P140/5			P10-P140/5				
					Branch box	P15-P100/5			P15-P100/5			P15-P100/5				
				Branch box 2 units*5	CITY MULTI	P10-P140/3			P10-P140/3			P10-P140/3				
					Branch box	P15-P100/8			P15-P100/8			P15-P100/8				
Sound pressure level (measured in anechoic room)		dB <A>			52/54			53/56			54/56					
		dB <A>			72/74			73/76			74/76					
Power pressure level (measured in anechoic room)																
Refrigerant piping diameter		Liquid pipe	mm (inch)		9.52 (3/8)											
		Gas pipe	mm (inch)		15.88 (5/8)											
Fan*2		Type x Quantity			Propeller Fan x 1											
		Airflow rate	m³/min		77			83			83					
			L/s		1283			1383			1383					
			cfm		2719			2931			2931					
			Control, Driving mechanism			DC control										
		Motor output	kW		0.20 x 1											
		External static press.			0 Pa/30 Pa*6											
Compressor		Type x Quantity			Twin rotary hermetic compressor x 1											
		Manufacturer			Mitsubishi Electric Corporation											
		Starting method			Inverter											
		Capacity control	%		Cooling 26 to 100 Heating 20 to 100			Cooling 24 to 100 Heating 18 to 100			Cooling 21 to 100 Heating 17 to 100					
		Motor output	kW		3.1			3.5			3.7					
		Case heater	kW		0											
Lubricant		FV50S (1.4liter)														
External finish					Galvanized Steel Sheet Munsell No. 3Y 7.8/1.1											
External dimension H x W x D		mm			981 x 1,050 x 330 (+40)											
		inch			38-5/8 x 41-3/8 x 13 (+1-37/64)											
Protection devices		High pressure protection			High pressure Switch											
		Inverter circuit (COMP./FAN)			Overcurrent detection, Overheat detection(Heat sink thermistor)											
		Compressor			Compressor thermistor, Overcurrent detection											
		Fan motor			Overheating, Voltage protection											
Refrigerant		Type x original charge			R410A 3.5 kg											
		Control			Linear expansion valve											
Net weight		kg (lb)			93 (205)*7											
Heat exchanger					Cross Fin and Copper tube											
HIC circuit (HIC: Heat Inter-Changer)					HIC circuit											
Defrosting method					Reversed refrigerant circuit											
Drawing		External			RK01B171											
		Wiring			BH79J995											
Standard attachment		Document			Installation Manual											
		Accessory			Grounded lead wire											
Optional parts					Joint: CMY-Y62-G-E Header: CMY-Y64/68-G-E											
Remarks					*1 Nominal cooling conditions									Unit converter		
					*2 Nominal heating conditions											



Model			PUMY-SP112YKM(R1).TH(-BS)			PUMY-SP125YKM.(R1)TH(-BS)			PUMY-SP140YKM(R1).TH(-BS)				
Power source			3-phase380-400-415V, 50 Hz; 3-phase 380 V, 60 Hz										
Cooling capacity (Nominal)		kW	12.5			14.0			15.5				
		kcal/h	10,750			12,040			13,330				
		Btu/h	42,650			47,768			52,886				
	Power input	kW	3.10			3.84			4.70				
	Current input	A	4.96	4.71	4.54	6.14	5.83	5.62	7.52	7.14	6.88		
	COP	kW/kW	4.03			3.65			3.30				
Temp. range of cooling	Indoor temp.	W.B.	15 to 24°C										
	Outdoor temp.	D.B.	-5 to 52°C <sup>*3,*4</sup>										
Heating capacity (Nominal)		kW	14.0			16.0			16.5				
		kcal/h	12,040			13,760			14,190				
		Btu/h	47,768			54,592			56,298				
	Power input	kW	3.17			3.90			4.02				
	Current input	A	5.07	4.82	4.64	6.24	5.93	5.71	6.43	6.11	5.89		
	COP	kW/kW	4.42			4.10			4.10				
Temp. range of heating	Indoor temp.	D.B.	15 to 27°C										
	Outdoor temp.	W.B.	-20 to 15°C										
Indoor unit connectable	Total capacity		50 to 130% of outdoor unit capacity										
	Model/ Quantity	CITY MULTI		P10-P140/12			P10-P140/12			P10-P140/12			
		Branch box <sup>*5</sup>		P15-P100/8			P15-P100/8			P15-P100/8			
		Mixed system	Branch box 1 unit <sup>*5</sup>	CITY MULTI	P10-P140/5			P10-P140/5			P10-P140/5		
			Branch box	Branch box	P15-P100/5			P15-P100/5			P15-P100/5		
			Branch box 2 units <sup>*5</sup>	CITY MULTI	P10-P140/3			P10-P140/3			P10-P140/3		
		Branch box	P15-P100/8			P15-P100/8			P15-P100/8				
Sound pressure level (measured in anechoic room)		dB <A>	52/54			53/56			54/56				
Power pressure level (measured in anechoic room)		dB <A>	72/74			73/76			74/76				
Refrigerant piping diameter	Liquid pipe	mm (inch)	9.52 (3/8)										
	Gas pipe	mm (inch)	15.88 (5/8)										
Fan <sup>*2</sup>	Type x Quantity		Propeller Fan x 1										
	Airflow rate	m³/min	77			83			83				
		L/s	1283			1383			1383				
		cfm	2719			2931			2931				
	Control, Driving mechanism		DC control										
	Motor output	kW	0.20 x 1										
External static press.		0 Pa/30 Pa <sup>*6</sup>											
Compressor	Type x Quantity		Twin rotary hermetic compressor x 1										
	Manufacturer		Mitsubishi Electric Corporation										
	Starting method		Inverter										
	Capacity control	%	Cooling 26 to 100 Heating 20 to 100			Cooling 24 to 100 Heating 18 to 100			Cooling 21 to 100 Heating 17 to 100				
	Motor output	kW	3.1			3.5			3.7				
	Case heater	kW	0										
Lubricant		FV50S (1.4litter)											
External finish			Galvanized Steel Sheet Munsell No. 3Y 7.8/1.1										
External dimension H x W x D		mm	981 x 1,050 x 330(+40)										
		inch	38-5/8 x 41-3/8 x 13 (+1-37/64)										
Protection devices	High pressure protection		High pressure Switch										
	Inverter circuit (COMP./FAN)		Overcurrent detection, Overheat detection(Heat sink thermistor)										
	Compressor		Compressor thermistor, Overcurrent detection										
	Fan motor		Overheating, Voltage protection										
Refrigerant	Type x original charge		R410A 3.5 kg										
	Control		Linear expansion valve										
Net weight		kg (lb)	94 (207) <sup>*7</sup>										
Heat exchanger			Cross Fin and Copper tube										
HIC circuit (HIC: Heat Inter-Changer)			HIC circuit										
Defrosting method			Reversed refrigerant circuit										
Drawing	External		RK01B171										
	Wiring		BH79J996										
Standard attachment	Document		Installation Manual										
	Accessory		Grounded lead wire										
Optional parts			Joint: CMY-Y62-G-E Header: CMY-Y64/68-G-E										
Remarks													
<div><div><div><div><div><sup>*1</sup> Nominal cooling conditions</div><div>Indoor : 27°C D.B./19°C W.B. [81°F D.B./66°F W.B.]</div><div>Outdoor : 35°C D.B. [95°F D.B.]</div><div>Pipe length : 7.5 m [24-9/16 ft]</div><div>Level difference : 0 m [0 ft]</div></div><div><div><sup>*2</sup> Nominal heating conditions</div><div>20°C D.B. [68°F D.B.]</div><div>7°C DB/6°C W.B. [45°F D.B./43°F W.B.]</div><div>7.5 m [24-9/16 ft]</div><div>0 m [0 ft]</div></div></div></div></div> <div><div>kcal/h = kW x 860</div><div>Btu/h = kW x 3,412</div><div>cfm = m³/min x 35.31</div><div>lb = kg/0.4536</div></div> <div>Above specification data is subject to rounding variation.</div>													
<sup>*3</sup> 10 to 52°C(D.B): When connecting PFFY-P20/25/32VCM, PKFY-P15/20/25VBM, PKFY-P10/15/20/25/32VLM, PFFY-P20/25/32VKM, PFFY-P20/25/32VLE(R)M(M), and M series, S series, and P series type indoor unit.													
<sup>*4</sup> -15 to 52°C(D.B): When using an optional air protect guide [PAC-SH95AG-E]. However, this condition does not apply to the indoor unit listed in <sup>*3</sup> .													
<sup>*5</sup> At least two indoors must be connected when using branch box.													
<sup>*6</sup> It is psooible to set the External static pressure to 30 Pa by Dip Switch.													
<sup>*7</sup> 95 (209), for PUMY-SP112/125/140YKM(R1).TH-BS.													
Notes : 1. Nominal conditions <sup>*1</sup> , <sup>*2</sup> are subject to ISO 15042.													
2. Due to continuing improvement, above specifications may be subject to change without notice.													

## 4-1. SELECTION OF COOLING/HEATING UNITS

### <Cooling>

Design Condition	
Outdoor Design Dry Bulb Temperature	45°C
Total Cooling Load	10.6 kW
Room1	
Indoor Design Dry Bulb Temperature	27°C
Indoor Design Wet Bulb Temperature	20°C
Cooling Load	4.6 kW
Room2	
Indoor Design Dry Bulb Temperature	24°C
Indoor Design Wet Bulb Temperature	18°C
Cooling Load	6.0 kW
<Other>	
Indoor/Outdoor Equivalent Piping Length	60 m

### Capacity of indoor unit

P•FY Series	Model Number for indoor unit (kW type)	Model 10	Model 15	Model 20	Model 25	Model 32	Model 40	Model 50	Model 63	Model 71	Model 80	Model 100	Model 125	Model 140
	Model Capacity	1.2	1.7	2.2	2.8	3.6	4.5	5.6	7.1	8.0	9.0	11.2	14.0	16.0
M Series S Series P Series	Model Number for indoor unit (kW type)	Model 15	Model 18	Model 20	Model 22	Model 25	Model 35	Model 42	Model 50	Model 60	Model 71	Model 80	Model 100	-
	Model Capacity	1.5	1.8	2.0	2.2	2.5	3.5	4.2	5.0	6.0	7.1	8.0	10.0	-

### 1. Cooling Calculation

#### (1) Temporary Selection of Indoor Units

Room1	PEFY-P50	5.6 kW (Rated)
Room2	PEFY-P71	8.0 kW (Rated)

#### (2) Total Indoor Units Capacity

P50 + P71 = P121

#### (3) Selection of Outdoor Unit

The SP125 outdoor unit is selected as total indoor units capacity is P121  
PUMY-SP125 14.0 kW

#### (4) Total Indoor Units Capacity Correction Calculation

Room1	Indoor Design Wet Bulb Temperature Correction (20°C)	1.03 (Refer to Figure 1)
Room2	Indoor Design Wet Bulb Temperature Correction (18°C)	0.94 (Refer to Figure 1)

Total Indoor Units Capacity (CTi)

$$CTi = \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction})$$

$$= 5.6 \times 1.03 + 8.0 \times 0.94$$

$$= 13.3 \text{ kW}$$

#### (5) Outdoor Unit Correction Calculation

Outdoor Design Dry Bulb Temperature Correction (45°C)	0.86 (Refer to Figure 2)
Piping Length Correction (60 m)	0.90 (Refer to Figure 3)

Total Outdoor Unit Capacity (CTo)

$$CTo = \text{Outdoor Rating} \times \text{Outdoor Design Temperature Correction} \times \text{Piping Length Correction}$$

$$= 14.0 \times 0.86 \times 0.90$$

$$= 10.8 \text{ kW}$$

#### (6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

$$CTi = 13.3 > CTo = 10.8, \text{ thus, select } CTo.$$

$$CTx = CTo = 10.8 \text{ kW}$$

#### (7) Comparison with Essential Load

Against the essential load 10.6kW, the maximum system capacity is 10.8 kW: Proper outdoor units have been selected.

#### (8) Calculation of Maximum Indoor Unit Capacity of Each Room

CTx = CTo, thus, calculate by the calculation below

Room1

$$\text{Maximum Capacity} \times \text{Room1 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction})$$

$$= 10.8 \times (5.6 \times 1.03) / (5.6 \times 1.03 + 8.0 \times 0.94)$$

$$= 4.7 \text{ kW} \quad \text{OK: fulfills the load 4.6 kW}$$

Room2

$$\text{Maximum Capacity} \times \text{Room2 Capacity after the Temperature Correction} / (\text{Room1,2 Total Capacity after the Temperature Correction})$$

$$= 10.8 \times (8.0 \times 0.94) / (5.6 \times 1.03 + 8.0 \times 0.94)$$

$$= 6.1 \text{ kW} \quad \text{OK: fulfills the load 6.0 kW}$$

Note: If CTx = CTi, please refer to the <Heating> section to calculate the Maximum Indoor Unit Capacity of Each Room.

Go on to the heating trial calculation since the selected units fulfill the cooling loads of Room 1, 2.




Figure 1 Indoor unit temperature correction  
To be used to correct indoor unit only




Figure 2 Outdoor unit temperature correction  
To be used to correct outdoor unit only




Figure 3 Correction of refrigerant piping length

## <Heating>

Design Condition	
Outdoor Design Wet Bulb Temperature	2°C
Total Heating Load	13.2 kW
Room1	
Indoor Design Dry Bulb Temperature	23°C
Heating Load	5.4 kW
Room2	
Indoor Design Dry Bulb Temperature	23°C
Heating Load	7.8 kW
<Other>	
Indoor/Outdoor Equivalent Piping Length	60 m

### Capacity of indoor unit

P•FY Series	Model Number for indoor unit (kW type)	Model 10	Model 15	Model 20	Model 25	Model 32	Model 40	Model 50	Model 63	Model 71	Model 80	Model 100	Model 125	Model 140
	Model Capacity	1.4	1.9	2.5	3.2	4.0	5.0	6.3	8.0	9.0	10.0	12.5	16.0	18.0
M Series S Series P Series	Model Number for indoor unit (kW type)	Model 15	Model 18	Model 20	Model 22	Model 25	Model 35	Model 42	Model 50	Model 60	Model 71	Model 80	Model 100	-
	Model Capacity	1.7	2.1	2.3	2.5	2.9	4.0	4.8	5.7	6.9	8.1	9.3	11.2	-

## 2. Heating Calculation

### (1) Temporary Selection of Indoor Units

Room1  
PEFY-P50 **6.3 kW (Rated)**

Room2  
PEFY-P71 **9.0 kW (Rated)**

### (2) Total Indoor Units Capacity

P50 + P71 = P121

### (3) Selection of Outdoor Unit

The SP125 outdoor unit is selected as total indoor units capacity is P121

PUMY-SP125 **16.0 kW**

### (4) Total Indoor Units Capacity Correction Calculation

Room1  
Indoor Design Dry Bulb Temperature Correction (23°C) 0.88 (Refer to Figure 4)

Room2  
Indoor Design Dry Bulb Temperature Correction (23°C) 0.88 (Refer to Figure 4)

Total Indoor Units Capacity (CTi)

$CTi = \Sigma (\text{Indoor Unit Rating} \times \text{Indoor Design Temperature Correction})$   
 $= 6.3 \times 0.88 + 9.0 \times 0.88$   
 $= 13.5 \text{ kW}$

### (5) Outdoor Unit Correction Calculation

Outdoor Design Wet Bulb Temperature Correction (2°C) 1.00 (Refer to Figure 5)

Piping Length Correction (60 m) 0.96 (Refer to Figure 6)

Defrost Correction 0.89 (Refer to Table 1)

Total Outdoor Unit Capacity (CTo)

$CTo = \text{Outdoor Unit Rating} \times \text{Outdoor Design Temperature Correction} \times \text{Piping Length Correction} \times \text{Defrost Correction}$   
 $= 16.0 \times 1.00 \times 0.96 \times 0.89$   
 $= 13.7 \text{ kW}$

### (6) Determination of Maximum System Capacity

Comparison of Capacity between Total Indoor Units Capacity (CTi) and Total Outdoor Unit Capacity (CTo)

$CTi = 13.5 < CTo = 13.7$ , thus, select CTi.

$CTx = CTi = 13.5 \text{ kW}$

### (7) Comparison with Essential Load

Against the essential load 13.2kW, the maximum system capacity is 13.5 kW: Proper indoor units have been selected.

### (8) Calculation of Maximum Indoor Unit Capacity of Each Room

$CTx = CTi$ , thus, calculate by the calculation below

Room1  
Indoor Unit Rating  $\times$  Indoor Design Temperature Correction  
 $= 6.3 \times 0.88$   
 $= 5.5 \text{ kW}$  **OK: fulfills the load 5.4 kW**

Room2  
Indoor Unit Rating  $\times$  Indoor Design Temperature Correction  
 $= 9.0 \times 0.88$   
 $= 7.9 \text{ kW}$  **OK: fulfills the load 7.8 kW**

Note: If  $CTx = CTo$ , please refer to the <Cooling> section to calculate the Maximum Indoor Unit Capacity of Each Room.

Completed selecting units since the selected units fulfill the heating loads of Room 1, 2.




Figure 4 Indoor unit temperature correction  
To be used to correct indoor unit only




Figure 5 Outdoor unit temperature correction  
To be used to correct outdoor unit only




Figure 6 Correction of refrigerant piping length

Table 1 Table of correction factor at frost and defrost

Outdoor Intake Temperature (°C W.B.)	6	4	2	0	-2	-4	-6	-8	-10	-15	-20
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95


## 4-2. CORRECTION BY TEMPERATURE

The outdoor units have varied capacity at different designing temperature. Using the nominal cooling capacity value and the ratio below, the capacity can be observed at various temperature.

### <Cooling>


**Figure 7 Indoor unit temperature correction**

To be used to correct indoor unit capacity only



**Figure 8 Outdoor unit temperature correction**


To be used to correct outdoor unit capacity only



**Figure 9 Outdoor unit temperature correction**  
To be used to correct outdoor unit capacity only


PUMY-SP112VKM.TH(-BS),  
PUMY-SP112VKMR1.TH(-BS),  
PUMY-SP125VKM.TH(-BS),  
PUMY-SP125VKMR1.TH(-BS),

PUMY-SP112YKM.TH(-BS)  
PUMY-SP112YKMR1.TH(-BS)  
PUMY-SP125YKM.TH(-BS)  
PUMY-SP125YKMR1.TH(-BS)



PUMY-SP140VKM.TH(-BS),  
PUMY-SP140VKMR1.TH(-BS),


PUMY-SP140YKM.TH(-BS)  
PUMY-SP140YKMR1.TH(-BS)



# <Heating>



**Figure 10 Indoor unit temperature correction**

To be used to correct indoor unit capacity only



**Figure 11 Outdoor unit temperature correction**

To be used to correct outdoor unit capacity only





### 4-3. STANDARD OPERATION DATA (REFERENCE DATA)

Operation				PUMY-SP					
				112VKM.TH(-BS) 112VKMR1.TH(-BS) 112YKM.TH(-BS) 112YKMR1.TH(-BS)	125VKM.TH(-BS) 125VKMR1.TH(-BS) 125YKM.TH(-BS) 125YKMR1.TH(-BS)	140VKM.TH(-BS) 140VKMR1.TH(-BS) 140YKM.TH(-BS) 140YKMR1.TH(-BS)			
Operating conditions	Ambient temperature	Indoor	D.B./W.B.	27/19°C	20°C	27/19°C	20°C	27/19°C	20°C
		Outdoor		35°C	7/6°C	35°C	7/6°C	35°C	7/6°C
	Indoor unit	No. of connected units	Unit	4	4	4			
		No. of units in operation		4	4	4			
		Model	—	25×2 + 32×2	25×1 + 32×3	32×2 + 40×2			
	Piping	Main pipe	m	5	5	5			
		Branch pipe		2.5	2.5	2.5			
		Total pipe length		15	15	15			
	Fan speed		—	Hi	Hi	Hi			
	Amount of refrigerant		kg	6.5	6.5	6.5			
Outdoor unit	Electric current		A	11.65/3.99	11.28/3.86	14.74/5.05	14.78/5.06	17.95/6.15	15.74/5.39
	Voltage		V	230/400	230/400	230/400	230/400	230/400	230/400
	Compressor frequency		Hz	57	74	65	84	73	88
LEV opening	Indoor unit		Pulse	226	396	264	335	262	358
Pressure	High pressure/Low pressure		MPaG	2.96/1.08	1.93/0.63	3.12/1.02	2.06/0.60	3.25/0.99	2.08/0.60
Temp. of each section	Outdoor unit	Discharge	°C	67.6	43.1	81.6	46.4	83.9	47.6
		Heat exchanger outlet		48.5	2.0	49.9	1.3	51.2	-0.3
		Accumulator inlet		14.8	-1.2	17.6	-2.0	15.4	-2.4
		Compressor inlet		15.7	-1.6	19.6	-2.7	17.5	-2.8
	Indoor unit	LEV inlet		30.6	25.2	32.7	24.4	33.7	26.5
		Heat exchanger inlet		16.6	39.2	14.5	44.6	14.3	45.0

## 4-4. STANDARD CAPACITY DIAGRAM

4-4-1. PUMY-SP112VKM.TH(-BS)





PUMY-SP112YKM.TH(-BS)

<Cooling>

PUMY-SP112VKMR1.TH(-BS)

PUMY-SP112YKMR1.TH(-BS)





Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on "4-1. SELECTION OF COOLING/HEATING UNITS".



4-4-2. PUMY-SP112VKM.TH(-BS)  
PUMY-SP112VKMR1.TH(-BS)

PUMY-SP112YKM.TH(-BS)  
PUMY-SP112YKMR1.TH(-BS)

<Heating>







#### 4-4-3. PUMY-SP125VKM.TH(-BS) PUMY-SP125VKMR1.TH(-BS)





#### PUMY-SP125YKM.TH(-BS) PUMY-SP125YKMR1.TH(-BS)

<Cooling>

Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on "4-1. SELECTION OF COOLING/HEATING UNITS".



4-4-4. PUMY-SP125VKM.TH(-BS) PUMY-SP125YKM.TH(-BS) <Heating>  
PUMY-SP125VKMR1.TH(-BS) PUMY-SP125YKMR1.TH(-BS)







#### 4-4-5. PUMY-SP140VKM.TH(-BS) PUMY-SP140VKMR1.TH(-BS)

#### PUMY-SP140YKM.TH(-BS) PUMY-SP140YKMR1.TH(-BS)

<Cooling>





Before calculating the sum of total capacity of indoor units, please convert the value into the kW model capacity following the formula on "4-1. SELECTION OF COOLING/HEATING UNITS".



4-4-6. PUMY-SP140VKM.TH(-BS)  
PUMY-SP140VKMR1.TH(-BS)

PUMY-SP140YKM.TH(-BS)  
PUMY-SP140YKMR1.TH(-BS)

<Heating>






## 4-5. CORRECTING CAPACITY FOR CHANGES IN THE LENGTH OF REFRIGERANT PIPING


During cooling, obtain the ratio (and the equivalent piping length) of the outdoor units rated capacity and the total in-use indoor capacity, and find the capacity ratio corresponding to the standard piping length from Figure 12 to 14. Then multiply by the cooling capacity from Figure 7 to 9 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity. During heating, find the equivalent piping length, and find the capacity ratio corresponding to standard piping length from Figure 15. Then multiply by the heating capacity from Figure 10 and 11 in "4-2. CORRECTION BY TEMPERATURE" to obtain the actual capacity.

### (1) Capacity Correction Curve


**Figure 12** PUMY-SP112VKM.TH(-BS) PUMY-SP112VKMR1.TH(-BS) PUMY-SP112YKM.TH(-BS) PUMY-SP112YKMR1.TH(-BS) <Cooling>




**Figure 13** PUMY-SP125VKM.TH(-BS) PUMY-SP125VKMR1.TH(-BS) PUMY-SP125YKM.TH(-BS) PUMY-SP125YKMR1.TH(-BS) <Cooling>



**Figure 14** PUMY-SP140VKM.TH(-BS) PUMY-SP140YKM.TH(-BS) <Cooling>  
PUMY-SP140VKMR1.TH(-BS) PUMY-SP140YKMR1.TH(-BS)  
Total capacity of indoor unit



**Figure 15** PUMY-SP112/125/140VKM(-BS) PUMY-SP112/125/140VKMR1(-BS) <Heating>  
PUMY-SP112/125/140YKM(-BS) PUMY-SP112/125/140YKMR1(-BS)



## (2) Method for Obtaining the Equivalent Piping Length

Equivalent length = (length of piping to farthest indoor unit) + (0.3 × number of bends in the piping) (m)

## (3) Correction of Heating Capacity for Frost and Defrosting


If heating capacity has been reduced due to frost formation or defrosting, multiply the capacity by the appropriate correction factor from the following table to obtain the actual heating capacity.

### Correction factor diagram


Outdoor Intake temperature (°C W.B.)	6	4	2	0	-2	-4	-6	-8	-10	-15	-20
Correction factor	1.00	0.98	0.89	0.88	0.89	0.90	0.95	0.95	0.95	0.95	0.95

## 4-6. NOISE CRITERION CURVES



PUMY-SP112VKM.TH(-BS)	MODE	SPL(dB)	LINE
PUMY-SP112VKMR1.TH(-BS)	HEATING	54	■—■
PUMY-SP112YKM.TH(-BS)	COOLING	52	○—○
PUMY-SP112YKMR1.TH(-BS)	SILENT(Cooling)	49	●—●
	SUPER SILENT 1(Cooling)	46	△—△
	SUPER SILENT 2(Cooling)	42	▲—▲



PUMY-SP125VKM.TH(-BS)	MODE	SPL(dB)	LINE
PUMY-SP125VKMR1.TH(-BS)	HEATING	56	■—■
PUMY-SP125YKM.TH(-BS)	COOLING	53	○—○
PUMY-SP125YKMR1.TH(-BS)	SILENT(Cooling)	50	●—●
	SUPER SILENT 1(Cooling)	47	△—△
	SUPER SILENT 2(Cooling)	43	▲—▲




PUMY-SP140VKM.TH(-BS)	MODE	SPL(dB)	LINE
PUMY-SP140VKMR1.TH(-BS)	HEATING	56	■—■
PUMY-SP140YKM.TH(-BS)	COOLING	54	○—○
PUMY-SP140YKMR1.TH(-BS)	SILENT(Cooling)	51	●—●
	SUPER SILENT 1(Cooling)	48	△—△
	SUPER SILENT 2(Cooling)	44	▲—▲






PUMY-SP112VKM(R1).TH PUMY-SP125VKM(R1).TH PUMY-SP140VKM(R1).TH  
PUMY-SP112VKM(R1).TH-BS PUMY-SP125VKM(R1).TH-BS PUMY-SP140VKM(R1).TH-BS




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block <Power Supply/Branch Box>	TH8	Thermistor <Heat Sink>	SW8	Switch <Model Selection>
TB3	Terminal Block <Indoor/Outdoor, Branch Box/Outdoor Transmission Line>	LEV-A, LEV-B	Linear Expansion Valve	SW9	Switch <Function Selection>
TB7	Terminal Block <Centralized Control Transmission Line>	DCL1, DCL2, DCL3	Reactor	SWU1	Switch <Unit Address Selection, ones digit>
FUSE1, FUSE2	Fuse <T20AL250V>	P.B.	Power Circuit Board	SWU2	Switch <Unit Address Selection, tens digit>
MC	Motor for Compressor	U/V/W	Connection Terminal <U/V/W-Phase>	CNS1	Connector <Indoor/Outdoor, Branch Box/Outdoor Transmission Line>
MF1	Fan Motor	LI	Connection Terminal <L-Phase>	CNS2	Connector <Centralized Control Transmission Line>
63HS	High Pressure Sensor	NI	Connection Terminal <N-Phase>	SS	Connector <Connection for Option>
63LS	Low Pressure Sensor	TB1A, TB2A, TB3A, TB1B, TB2B, TB3B	Connection Terminal <Reactor>	CN3D	Connector <Connection for Option>
SV1	Solenoid Valve Coil <Bypass Valve>	E1, E3, E4	Connection Terminal <Electrical Parts Box>	CN3S	Connector <Connection for Option>
21S4	Solenoid Valve Coil <4-Way Valve>	MULTI.B.	Multi Controller Circuit Board	CN3N	Connector <Connection for Option>
TH2	Thermistor <Hic Pipe>	SW1	Switch <Display Selection>	CN51	Connector <Connection for Option>
TH3	Thermistor <Outdoor Liquid Pipe>	SW2	Switch <Function Selection>	LED1, LED2	LED <Operation Inspection Display>
TH4	Thermistor <Compressor>	SW3	Switch <Test Run>	LED3	LED <Power Supply to Main Microcomputer>
TH6	Thermistor <Suction Pipe>	SW4	Switch <Model Selection>	F1, F2	Fuse <T6.3AL250V>
TH7	Thermistor <Ambient>	SW5	Switch <Function Selection>	X501~505	Relay
		SW6	Switch <Function Selection>	M-NET P.B.	M-NET Power Circuit Board
		SW7	Switch <Function Selection>	TB1	Connection Terminal <Electrical Parts Box>

PUMY-SP112YKM(R1).TH PUMY-SP125YKM(R1).TH PUMY-SP140YKM(R1).TH  
PUMY-SP112YKM(R1).TH-BS PUMY-SP125YKM(R1).TH-BS PUMY-SP140YKM(R1).TH-BS



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block <Power Supply>	RS	Rush Current Protect Resistor	SW6	Switch <Function Selection>
TB1B	Terminal Block <Branch Box>	LEV-A, LEV-B	Linear Expansion Valve	SW7	Switch <Function Selection>
TB3	Terminal Block <Indoor/Outdoor, Branch Box/Outdoor Transmission Line>	ACL4	Reactor	SW8	Switch <Model Selection>
TB7	Terminal Block <Centralized Control Transmission Line>	DCL	Reactor	SW9	Switch <Function Selection>
FUSE1,FUSE2	Fuse <T20AL250V>	P.B.	Power Circuit Board	SWU1	Switch <Unit Address Selection, ones digit>
MC	Motor for Compressor	TB-U/V/W	Connection Terminal <U/V/W-Phase>	SWU2	Switch <Unit Address Selection, tens digit>
MF1	Fan Motor	TB-L1/L2/L3	Connection Terminal <L1/L2/L3-Power Supply>	CNS1	Connector <Indoor/Outdoor, Branch Box/Outdoor Transmission Line>
63H	High Pressure Switch	TB-P1/P3	Connection Terminal	CNS2	Connector <Centralized Control Transmission Line>
63HS	High Pressure Sensor	X52CA/B	52C Relay	SS	Connector <Connection for Option>
63LS	Low Pressure Sensor	N.F.	Noise Filter Circuit Board	CN3D	Connector <Connection for Option>
SV1	Solenoid Valve Coil <Bypass Valve>	L01/L02/L03	Connection Terminal <L1/L2/L3-Power Supply>	CN3S	Connector <Connection for Option>
21S4	Solenoid Valve Coil <4-Way Valve>	LI1/LI2/LI3/NI	Connection Terminal <L1/L2/L3-Power Supply>	CN3N	Connector <Connection for Option>
TH2	Thermistor <Hic Pipe>	EI, E2, E3	Connection Terminal <Electrical Parts Box>	CN51	Connector <Connection for Option>
TH3	Thermistor <Outdoor Liquid Pipe>	F1	Fuse <T6.3AL250V>	LED1,LED2	LED <Operation Inspection Display>
TH4	Thermistor <Compressor>	MULTI.B.	Multi Controller Circuit Board	LED3	LED <Power Supply to Main Microcomputer>
TH6	Thermistor <Suction Pipe>	SW1	Switch <Display Selection>	F1,F2	Fuse <T6.3AL250V>
TH7	Thermistor <Ambient>	SW2	Switch <Function Selection>	X501~505	Relay
TH8	Thermistor <Heat Sink>	SW3	Switch <Test Run>	M-NET P.B.	M-NET Power Circuit Board
		SW4	Switch <Model Selection>	TB1	Connection Terminal <Electrical Parts Box>
		SW5	Switch <Function Selection>		

## 7-1. TRANSMISSION SYSTEM SETUP





## 7-2. Special Function Operation and Settings for M-NET Remote Controller


(M-NET remote controller cannot be connected with a refrigerant system which includes branch box.)

- It is necessary to perform “group settings” and “Interlocked LOSSNAY” at making group settings of different refrigerant systems (multiple outdoor unit).

(A) Group settings: Enter the indoor unit controlled by the remote controller, check the content of entries, and clear entries, etc.


(B) Interlocked LOSSNAY: Used to set the linked operation of a Lossnay unit.

### How to display the setup screen




#### ● HOME screen

Touch the [MENU] button.




#### ● Menu (User) screen

Touch the [Service] button.



#### ● Menu (Service) screen

Touch the [Setup] button.  
Setup screen will appear.



#### (a) Group setting

Use this screen to register the indoor units and the AHC to be controlled from the controller.

[Group setting]			
IC	Address	▼ 001 ▲	
001 002 003 004	Unit	IC	
005 006 007 008	Function	Set Del	
009 010 011 012			
013 014 015 016			
AHC 201			
Back			

- 1 Select an indoor unit or an AHC address in the [Address] field.  
The number of units that can be registered.  
Indoor unit: 16 units maximum  
AHC: 1 unit maximum  
\* AHC cannot be controlled from the controller unless indoor units are registered with the system.
- 2 Touch the [Set] button to register the address, and [Del] to delete the address.
  - Successful address registration/deletion:  
The registered address(es) will appear on the left side of the screen.  
Deleted address will not appear on the screen.
  - Error:  
"Request denied." or "Is not to be connected" will appear.

#### (b) Interlocked LOSSNAY

Use this function to interlock the operation of indoor units and LOSSNAY units.

[Interlocked LOSSNAY]			
001 IC 007 IC	Add. 1	▼ 001 ▲	
002 IC 008 IC	Add. 2	▼ 013 ▲	
003 IC 009 IC	Function	Set Conf Del	
004 IC 010 IC			
005 IC 011 IC			
006 IC 012 IC			
Back			

- 1 To register LOSSNAY units  
Select the indoor unit address in the Add. 1 section.  
Select the interlocked LOSSNAY address in the Add. 2 section. Touch the [Set] button to save the setting.
- 2 To search for an interlocked setting  
Touch the [Conf] button to display in the left column the addresses of the units that are interlocked with the unit whose address was set in the Add. 1 section.
- 3 To delete the interlock settings  
After taking Step 2 above, select the address to be deleted in the Add. 2 section, and then touch the [Del] button.

When the setting or deletion is successfully completed, "Completed" will appear below [Function] field on the screen.  
If setting or deletion fails, "Request denied" will appear below [Function] field on the screen.

#### (c) Search connection information

Use this screen to specify a unit and search for the controllers that are connected to the unit.


[Search connection information]	
001 IC	Address ▼ 051 ▲
002 IC	
003 IC	
004 IC	Function Conf
005 IC	
006 IC	
Back	

- 1 Select an address in the [Address] field.
- 2 Touch the [Conf] button to search for the interlocked units.  
The results will appear in the left column. (When multiple units are found, the addresses that do not fit on the first page will appear on the successive pages.)
  - Search error:  
"Request denied." will appear.

After completing the settings, touch the [Back] button on the [Setup] screen. The message "Collecting the information from the air conditioner." will appear, and then the screen will jump to the HOME screen. This signals the completion of the setup process.  
Access the Service Menu from the HOME screen to make the settings for other items as necessary.

### 7-3. REFRIGERANT SYSTEM DIAGRAM

**PUMY-SP112VKM(R1).TH      PUMY-SP125VKM(R1).TH      PUMY-SP140VKM(R1).TH**  
**PUMY-SP112YKM(R1).TH      PUMY-SP125YKM(R1).TH      PUMY-SP140YKM(R1).TH**  
**PUMY-SP112VKM(R1).TH-BS      PUMY-SP125VKM(R1).TH-BS      PUMY-SP140VKM(R1).TH-BS**  
**PUMY-SP112YKM(R1).TH-BS      PUMY-SP125YKM(R1).TH-BS      PUMY-SP140YKM(R1).TH-BS**



Capillary tube for oil separator :  $\phi 2.5 \times \phi 0.6 \times L1000$

Refrigerant piping specifications <dimensions of flared connector>


Unit: mm <inch>

Capacity	Item	Liquid piping		Gas piping
CITY MULTI indoor unit	P10, P15, P20, P25, P32, P40, P50	The farthest piping length from the first joint $\leq 30$ m	$\phi 6.35$ <1/4>	$\phi 12.7$ <1/2>
		The farthest piping length from the first joint $> 30$ m	$\phi 9.52$ <3/8>	
	P63, P80, P100, P125, P140	$\phi 9.52$ <3/8>		$\phi 15.88$ <5/8>
Outdoor unit	SP112, SP125, SP140	$\phi 9.52$ <3/8>		$\phi 15.88$ <5/8>

Note:

When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT.

## 7-4. REFRIGERANT SYSTEM DIAGRAM (WHEN USING BRANCH BOX)



Unit: mm


		Capillary tube behind LEV (in cooling mode)
Branch box	PAC-MK3*BC(B)	( $\phi 4.0 \times \phi 3.0 \times L130$ ) $\times 3$
	PAC-MK5*BC(B)	( $\phi 4.0 \times \phi 3.0 \times L130$ ) $\times 5$

Note:  
A maximum of 2 branch boxes can be connected to 1 outdoor unit.  
PUMY-SP\*VKM.TH(-BS), PUMY-SP\*YKM.TH(-BS) cannot connect 32/33/52/53 series.  
PUMY-SP\*VKMR1.TH(-BS), PUMY-SP\*YKMR1.TH(-BS) cannot connect 31/32/51/52 series.


### Piping connection size

	A	B
Liquid (mm)	$\phi 9.52$	The pipe connection size differs according to the type and capacity of indoor units. Match the piping connection size of branch box with indoor unit. If the piping connection size of branch box does not match the piping connection size of indoor unit, use optional different-diameter (deformed) joints to the branch box side. (Connect deformed joint directly to the branch box side.)
Gas (mm)	$\phi 15.88$	

- In the case of using 1-branch box  
Flare connection employed (No brazing)



- In the case of using 2-branch boxes



- Installation procedure (2 branch pipe (joint))  
Refer to the installation manuals of MSDD-50AR-E.

## ■ Pipe size (Branch box-indoor unit)

Indoor unit series	Model number	Liquid pipe (mm)	Gas pipe (mm)
M series or S series	15-42	ø6.35	ø9.52
	50	ø6.35	ø12.7
	60	ø6.35	ø15.88
	71, 80	ø9.52	ø15.88
P series	35-50	ø6.35	ø12.7
	60-100	ø9.52	ø15.88

\* If the pipe size of indoor unit is different, use a different-diameter joint.

**When using 35, 50 type indoor unit of P series, use the flare nut (for R410A) attached to the indoor unit.  
Do not use the flare nut (for R407C) in the indoor unit accessory. If it is used, a gas leakage or even a pipe extraction may occur.**

### (1) Valve size for outdoor unit

For liquid	ø9.52 mm
For gas	ø15.88 mm


### (2) Valve size for branch unit

A UNIT *	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
B UNIT *	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
C UNIT *	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
D UNIT	Liquid pipe	ø6.35 mm
	Gas pipe	ø9.52 mm
E UNIT	Liquid pipe	ø6.35 mm
	Gas pipe	ø12.7 mm

\* 3-branch type is only for A, B, and C unit.

## Different-diameter joint (optional parts)

Type	Model name	Connected pipes diameter mm	Diameter A mm	Diameter B mm
Flare (Fig.7-1)	MAC-A454JP-E	ø9.52 → ø12.7	ø9.52	ø12.7
	MAC-A455JP-E	ø12.7 → ø9.52	ø12.7	ø9.52
	MAC-A456JP-E	ø12.7 → ø15.88	ø12.7	ø15.88
	PAC-493PI	ø6.35 → ø9.52	ø6.35	ø9.52
	PAC-SG76RJ-E	ø9.52 → ø15.88	ø9.52	ø15.88



**Fig.7-1**

### Conversion formula




1/4 inch	ø6.35 mm
3/8 inch	ø9.52 mm
1/2 inch	ø12.7 mm
5/8 inch	ø15.88 mm
3/4 inch	ø19.05 mm

## 7-5. SYSTEM CONTROL

### 7-5-1. Example for the System




- Example for wiring control cables, wiring method and address setting, permissible lengths, and the constraint items are listed in the standard system with detailed explanation.

A. Example of an M-NET remote controller system (address setting is necessary.)


Example of wiring control cables		Wiring Method and Address Setting																
<div>1. Standard operation</div>  <ul style="list-style-type: none"><li>• 1 M-NET remote controller for each CITY MULTI series indoor unit.</li><li>• There is no need for setting the 100 position on the M-NET remote controller.</li></ul>		<div>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each indoor unit (M-IC). Use non-polarized 2-core wire.</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) for each indoor unit with the terminal block (TB5) for the M-NET remote controller (M-NET RC).</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>CITY MULTI series indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit(OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor unit plus 50.</td></tr><tr><td>M-NET remote controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr></tbody></table>		Unit	Range	Setting Method	CITY MULTI series indoor unit (M-IC)	001 to 050	—	Outdoor unit(OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.	M-NET remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100			
Unit	Range	Setting Method																
CITY MULTI series indoor unit (M-IC)	001 to 050	—																
Outdoor unit(OC)	051 to 100	Use the smallest address of all the indoor unit plus 50.																
M-NET remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
<div>2. Operation using 2 M-NET remote controllers</div>  <ul style="list-style-type: none"><li>• Using 2 M-NET remote controllers for each CITY MULTI series indoor unit.</li></ul>		<div>a. Same as above 1.a</div> <div>b. Same as above 1.b</div> <div>c. Set address switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>CITY MULTI series indoor unit (M-IC)</td><td>001 to 050</td><td>—</td></tr><tr><td>Outdoor unit (OC)</td><td>051 to 100</td><td>Use the smallest address of all the indoor units plus 50.</td></tr><tr><td>Main M-NET remote controller (M-NET RC)</td><td>101 to 150</td><td>Indoor unit address plus 100</td></tr><tr><td>Sub M-NET remote controller (M-NET RC)</td><td>151 to 200</td><td>Indoor unit address plus 150</td></tr></tbody></table>		Unit	Range	Setting Method	CITY MULTI series indoor unit (M-IC)	001 to 050	—	Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.	Main M-NET remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100	Sub M-NET remote controller (M-NET RC)	151 to 200	Indoor unit address plus 150
Unit	Range	Setting Method																
CITY MULTI series indoor unit (M-IC)	001 to 050	—																
Outdoor unit (OC)	051 to 100	Use the smallest address of all the indoor units plus 50.																
Main M-NET remote controller (M-NET RC)	101 to 150	Indoor unit address plus 100																
Sub M-NET remote controller (M-NET RC)	151 to 200	Indoor unit address plus 150																
<div>3. Group operation</div>  <ul style="list-style-type: none"><li>• Multiple indoor units operated together by 1 remote controller</li></ul>		<div>a. Same as above 1.a</div> <div>b. Connect terminals M1 and M2 on transmission cable terminal block (TB5) of the M-IC main unit with the most recent address within the same indoor unit (M-IC) group to terminal block (TB5) on the remote controller.</div> <div>c. Set the address setting switch (on outdoor unit P.C.B) as shown below.</div> <table><thead><tr><th>Unit</th><th>Range</th><th>Setting Method</th></tr></thead><tbody><tr><td>M-IC (Main)</td><td>001 to 050</td><td>Use the smallest address within the same group of M-NET control indoor units.</td></tr><tr><td>M-IC (Sub)</td><td>001 to 050</td><td>Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).</td></tr><tr><td>Outdoor unit</td><td>051 to 100</td><td>Use the smallest address of all the M-NET control indoor units plus 50.</td></tr><tr><td>Main M-NET Remote Controller (M-NET RC)</td><td>101 to 150</td><td>Set at an M-IC (Main) address within the same group plus 100.</td></tr></tbody></table> <div>d. Use the CITY MULTI series indoor unit (M-IC) within the group with the most functions as the M-IC (Main) unit.</div>		Unit	Range	Setting Method	M-IC (Main)	001 to 050	Use the smallest address within the same group of M-NET control indoor units.	M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).	Outdoor unit	051 to 100	Use the smallest address of all the M-NET control indoor units plus 50.	Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.
Unit	Range	Setting Method																
M-IC (Main)	001 to 050	Use the smallest address within the same group of M-NET control indoor units.																
M-IC (Sub)	001 to 050	Use an address, other than that of the M-IC (Main) from among the units within the same group of indoor units. This must be in sequence with the M-IC (Main).																
Outdoor unit	051 to 100	Use the smallest address of all the M-NET control indoor units plus 50.																
Main M-NET Remote Controller (M-NET RC)	101 to 150	Set at an M-IC (Main) address within the same group plus 100.																
Combinations of 1 through 3 above are possible.																		

• Name, Symbol and the Maximum Remote controller Units for Connection

Name	Symbol	Maximum units for connection
Outdoor unit	OC	—
M-NET control Indoor unit	M-IC	Refer to "2-1. SYSTEM CONSTRUCTION"
M-NET remote controller	M-NET RC	Maximum 2 M-NET RC for 1 indoor unit, Maximum 12 M-NET RC for 1 OC


Permissible Lengths	Constraint items
<p>Longest transmission cable length (1.25 mm<sup>2</sup>)  <math>L_1 + L_2 \leq 200</math> m  M-NET Remote controller cable length</p> <ol style="list-style-type: none"> <li>If 0.5 to 1.25 mm<sup>2</sup>  <math>l_1, l_2 \leq 10</math> m</li> <li>If the length exceeds 10 m, use a 1.25 mm<sup>2</sup> shielded wire.  The section of the cable that exceeds 10 m must be included in the longest length via outdoor units and longest transmission cable length.</li> </ol>	<ul style="list-style-type: none"> <li>M-NET RC and MA remote controller (MA) cannot be used together.</li> <li>Do not connect anything with TB15 of indoor unit (M-IC).</li> </ul> 
Same as above	<ul style="list-style-type: none"> <li>Use the indoor unit (M-IC) address plus 150 as the sub remote controller address. In this case, it should be 152.</li> <li>3 or more remote controllers (RC) cannot be connected to 1 indoor unit.</li> </ul> 
Same as above	<ul style="list-style-type: none"> <li>The remote controller address is the indoor unit main address plus 100. In this case, it should be 101.</li> </ul> 

B. Example of a group operation system with 2 or more outdoor units and an M-NET remote controller.  
(Address settings are necessary.)











• Name, Symbol, and the Maximum Units for Connection

Permissible Length	<ul style="list-style-type: none"> <li>• Longest length via outdoor units : <math>L_1+L_2+L_3+L_4</math>, <math>L_3+L_4+L_5+L_6</math>, <math>L_1+L_2+L_5+L_6 \leq 500</math> m (1.25 mm<sup>2</sup>)</li> <li>• Longest transmission cable length : <math>L_1</math>, <math>L_3+L_4</math>, <math>L_2+L_5</math>, <math>L_6 \leq 200</math> m (1.25 mm<sup>2</sup>)</li> <li>• Remote controller cable length : <math>\ell_1</math>, <math>\ell_2+\ell_3 \leq 10</math> m (0.5 to 1.25 mm<sup>2</sup>)</li> </ul> <p>If the length exceeds 10 m, use a 1.25 mm<sup>2</sup> shielded wire.</p> <p>The section of the cable that exceeds 10 m must be included in the longest length via outdoor units and longest transmission cable length.</p>
Constraint items	 <p>(A) : Group          (B) : Group          (C) : Group          (D) : Shielded Wire          (E) : Sub M-NET Remote Controller          ( ) : Address example</p> <ul style="list-style-type: none"> <li>• Never connect together the terminal blocks (TB5) for transmission wires for M-NET control indoor units (M-IC) that have been connected to different outdoor units (OC).</li> <li>• Set all addresses to ensure that they are not overlapped.</li> <li>• M-NET remote controller and MA remote controller cannot be connected with the M-NET control indoor unit of the same group wiring together.</li> </ul>


C. Example of an MA remote controller system (address setting is not necessary.)

NOTE: In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit.


Example of wiring control cables	Wiring Method and Address Setting
<p>1. Standard operation</p>  <p>• 1 MA remote controller for each indoor unit</p>	<p>a. Use feed wiring to connect terminals M1 and M2 on transmission cable block (TB3) for the outdoor unit (OC) to terminals M1 and M2 on the transmission cable block (TB5) of each CITY MULTI series indoor unit (M-IC). Use non-polarized 2-core wire.</p> <p>b. Connect terminals 1 and 2 on transmission cable terminal block (TB15) for each CITY MULTI series indoor unit with the terminal block for the MA remote controller (MA-RC).</p>
<p>2. Operation using 2 remote controllers</p>  <p>• Using 2 MA remote controllers for each CITY MULTI series indoor unit</p>	<p>a. The same as above 1.a</p> <p>b. The same as above 1.b</p> <p>c. In the case of using 2 remote controllers, connect terminals 1 and 2 on transmission cable terminal block (TB15) for each indoor unit with the terminal block for 2 MA remote controllers.</p> <p>• Set either one of the MA remote controllers to "sub remote controller".</p> <p>Refer to the installation manual of MA remote controller.</p>
<p>3. Group operation</p>  <p>• Multiple indoor units operated together by 1 MA remote controller</p>	<p>a. The same as above 1.a</p> <p>b. The same as above 1.b</p> <p>c. Connect terminals 1 and 2 on transmission cable terminal block (TB15) of each CITY MULTI series indoor unit, which is doing group operation with the terminal block the MA remote controller. Use non-polarized 2-core wire.</p> <p>d. In the case of same group operation, need to set the address that is only main CITY MULTI series indoor unit. Please set the smallest address within number 01–50 of the CITY MULTI series indoor unit with the most functions in the same group.</p>
<p>Combinations of 1 through 3 above are possible.</p>	

Permissible Lengths	Constraint items
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 200 \text{ m}</math> (1.25 mm<sup>2</sup>)</p> <p>MA remote controller cable length:  <math>\ell_1, \ell_2 \leq 200 \text{ m}</math> (0.3 to 1.25 mm<sup>2</sup>)</p>	 <p>The MA remote controller and the M-NET remote controller cannot be used together with the CITY MULTI series indoor unit of the same group.</p>
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 200 \text{ m}</math> (1.25 mm<sup>2</sup>)</p> <p>MA remote controller cable length:  <math>\ell_3 + \ell_4, \ell_5 \leq 200 \text{ m}</math> (0.3 to 1.25 mm<sup>2</sup>)</p>	 <p>3 MA remote controllers or more cannot be connected with the CITY MULTI series indoor unit of the same group.</p>
<p>Longest transmission cable length:  <math>L_1 + L_2 \leq 200 \text{ m}</math> (1.25 mm<sup>2</sup>)</p> <p>MA remote controller cable length:  <math>\ell_7 + \ell_8 \leq 200 \text{ m}</math> (0.3 to 1.25 mm<sup>2</sup>)</p>	 <p>The second MA remote controller is connected with the terminal block (TB15) for the MA remote controller of the same CITY MULTI series indoor unit (M-IC) as the first MA remote control.</p>


D. Example of a group operation with 2 or more outdoor units and an MA remote controller.  
(Address settings are necessary.)



• Name, Symbol, and the Maximum Units for Connection

Permissible Length	<p>Longest length via outdoor unit (M-NET cable): <math>L_1+L_2+L_3+L_4</math>, <math>L_3+L_4+L_6+L_7</math> and <math>L_1+L_2+L_6+L_7 \leq 500</math> m (1.25 mm<sup>2</sup> or more)</p> <p>Longest transmission cable length (M-NET cable): <math>L_1</math> and <math>L_3+L_4</math> and <math>L_2+L_6</math> and <math>L_7 \leq 200</math> m (1.25 mm<sup>2</sup> or more)</p> <p>MA Remote controller cable length: <math>m_1</math> and <math>m_1+m_2+m_3</math> and <math>m_1+m_2+m_3+m_4 \leq 200</math> m (0.3 to 1.25 mm<sup>2</sup>)</p>
Constraint items	 <p>(A) : Group  (B) : Group  (C) : Group  (D) : Shielded Wire  (E) : Sub MA Remote Controller  ( ) : Address example</p> <ul style="list-style-type: none"> <li>• Never connect together the terminal blocks (TB5) for transmission wires for CITY MULTI series indoor units (M-IC) that have been connected to different outdoor units (OC).</li> <li>• M-NET remote controller and MA remote controller cannot be connected with the CITY MULTI series indoor unit of the same group wiring together.</li> </ul>


## E. Example of a system using Branch Box and A-Control indoor unit



# • Name, Symbol, and the Maximum Units for Connection

Permissible Length	<p>Longest length via outdoor unit (M-NET cable): <math>L_1+L_2+L_3+L_4+L_5 \leq 500</math> m (1.25 mm<sup>2</sup> or more)</p> <p>Longest transmission cable length (M-NET cable): <math>L_1+L_2, L_3+L_4, L_5 \leq 200</math> m (1.25 mm<sup>2</sup> or more)</p> <p>Longest transmission cable length (A-Control cable): <math>L_6 \leq 25</math> m (1.5 mm<sup>2</sup>)</p> <p>Remote controller cable length: <math>m_1 \leq 200</math> m (0.3 to 1.25 mm<sup>2</sup>)</p>
Constraint items	<p>①: Shielded wire ( ): Address example</p> <p>• Plural indoor units cannot be operated by a single remote controller.</p> <p>• Different refrigerant systems cannot be connected together.</p> <p>• M-NET remote controller cannot be connected.</p>

F. Example of a system using Branch Box, A-Control indoor unit, and CITY MULTI series indoor unit.





# • Name, Symbol, and the Maximum Units for Connection

Permissible Length	<p>Longest length via outdoor unit (M-NET cable): <math>L_1+L_2+L_3+L_4+L_5+L_6+L_7 \leq 500</math> m (1.25 mm<sup>2</sup> or more)</p> <p>Longest transmission cable length (M-NET cable): <math>L_1+L_2+L_3+L_4</math>, <math>L_5+L_6</math> and <math>L_7 \leq 200</math> m (1.25 mm<sup>2</sup> or more)</p> <p>Longest transmission cable length (A-Control cable): <math>L_8 \leq 25</math> m (1.5 mm<sup>2</sup>)</p> <p>Remote controller cable length: <math>m_1 \leq 200</math> m (0.3 to 1.25 mm<sup>2</sup>)</p>
Constraint items	<p>Ⓢ: Shielded wire ( ): Address example</p> <ul style="list-style-type: none"> <li>• Plural indoor units cannot be operated by a single remote controller.</li> <li>• Different refrigerant systems cannot be connected together.</li> <li>• M-NET remote controller cannot be connected.</li> </ul>


## 8-1. CHECK POINTS FOR TEST RUN

### 8-1-1. Procedures before test run

- (1) Before a test run, make sure that the following work is completed.
  - Installation related :  
Make sure that the panel of cassette type and electrical wiring are done.  
Otherwise electrical functions like auto vane will not operate normally.
  - Piping related :  
Perform leakage test of refrigerant and drain piping.  
Make sure that all joints are perfectly insulated.  
Check stop valves on both liquid and gas side for full open.
  - Electrical wiring related :  
Check ground wire, transmission cable, remote controller cable, and power supply cable for secure connection.  
Make sure that all switch settings of address or adjustments for special specification systems are correctly settled.
- (2) Safety check :  
With the insulation tester of 500V, inspect the insulation resistance.  
Do not touch the transmission cable and remote controller cable with the tester.  
The resistance should be over 1.0 MΩ. Do not proceed inspection if the resistance is less than 1.0 MΩ.  
Inspect between the outdoor unit power supply terminal block and ground first, metallic parts like refrigerant pipes or the electrical box next, then inspect all electrical wiring of outdoor unit, indoor unit, and all linked equipment .
- (3) Before operation :
  - a) Turn the power supply switch of the outdoor unit to on for compressor protection. For a test run, wait at least 12 hours from this point.
  - b) Register control systems into remote controller(s). Never touch the on/off switch of the remote controller(s). Refer to “7-2. Special Function Operation and Settings (for M-NET Remote Controller)” as for settings. In MA remote controller(s), this registration is unnecessary.
- (4) More than 12 hours later from power supply to the outdoor unit, turn all power switch to on for the test run. Perform test run according to the “Operation procedure” table of the bottom of this page. While test running, make test run reports .

#### 8-1-1-1. Test run for M-NET Remote controller

When you deliver the unit after the test run, instruct the end user for proper usage of the system using owners' manual and the test run report you made to certificate normal operation. If abnormalities are detected during test run, refer to “8-1-2 Countermeasures for Error During Test Run”. As for DIP switch setting of outdoor unit, refer to “8-3. INTERNAL SWITCH FUNCTION TABLE”.




- (a) Read the section about Test run in the indoor unit Installation Manual before performing a test run.
- (b) During the test run, indoor units will be forced to operate in the Thermo-ON status.  
Except the set temperature, normal operation functions are accessible during test run.
- (c) By selecting the address of another indoor unit, the liquid pipe temperature of the selected unit can be monitored.
- (d) The test run will automatically end in two hours.

\* When AHC is controlled from the controller

To monitor the operating status of AHC, touch the [<] button on the [Test run] screen and access the [General equipment] screen.

To set the humidity setting for the humidifier (when one is connected to the AHC), touch the [>] button on the [Indoor unit setting] screen.


## 8-1-1-2. Test run for wired remote controller <PAR-4xMAA, PAR-3xMAA ("x" represents 0 or later)>




- ① Select "Service" from the Main menu, and press the [ ✓ ] button.



Select "Test run" with the [ F1 ] or [ F2 ] button, and press the [ ✓ ] button.



- ② Select "Test run" with the [ F1 ] or [ F2 ] button, and press the [ ✓ ] button.



### Test run operation


Press the [ F1 ] button to go through the operation modes in the order of "Cool and Heat".

Cool mode: Check the cold air blows out.  
Heat mode: Check the heat blows out.

Check the operation of the outdoor unit's fan.



Press the [ ✓ ] button and open the Vane setting screen.



### Auto vane check


Check the auto vane with the [ F1 ] [ F2 ] buttons.



Press the [ ↺ ] button to return to "Test run operation".



Press the [ ⏻ ] button.



When the test run is completed, the "Test run menu" screen will appear.  
The test run will automatically stop after 2 hours.

\*The function is available only for the model with vanes.

## 8-1-2. Countermeasures for Error During Test Run

- If a problem occurs during test run, a code number will appear on the remote controller (or LED on the outdoor unit), and the air conditioning system will automatically cease operating.

Determine the nature of the abnormality and apply corrective measures.

Check code (2 digits)	Check code (4 digits)	Trouble	Detected Unit			Remarks
			Indoor	Outdoor	Remote Controller	
Ed	0403	Serial communication error		○		Outdoor unit outdoor multi controller circuit board – Power circuit board communication trouble
U2	1102	Compressor temperature trouble		○		Check delay code 1202
UE	1302	High pressure trouble		○		Check delay code 1402
U7	1500	Superheat due to low discharge temperature trouble		○		Check delay code 1600
U2	1501	Refrigerant shortage trouble		○		Check delay code 1601
		Closed valve in cooling mode		○		Check delay code 1501
P6	1503	Freeze protection of branch box or indoor unit	○			
EF	1508	4-way valve trouble in heating mode		○		Check delay code 1608
L6	2135	Circulation water freeze protection	○			
PA	2500	Water leakage	○			
P5	2502	Drain overflow protection	○			
P4	2503	Drain sensor abnormality	○			
UF	4100	Compressor current interruption (locked compressor)		○		Check delay code 4350
Pb	4114	Fan trouble (Indoor unit)	○			
UP	4210	Compressor overcurrent interruption		○		
U9	4220	Voltage shortage/overvoltage/PAM error/L1 open phase/primary current sensor error/power synchronization signal error		○		Check delay code 4320
U5	4230	Heat sink temperature trouble		○		Check delay code 4330
U6	4250	Power module trouble or Overcurrent trouble		○		Check delay code 4350
U8	4400	Fan trouble (Outdoor unit)		○		Check delay code 4500
U3	5101	Air inlet thermistor (TH21) open/short	○			
		Compressor temperature thermistor (TH4) open/short		○		Check delay code 1202
U4	5102	Liquid pipe temperature thermistor (TH22) open/short	○			
		Suction pipe temperature thermistor (TH6) open/short		○		Check delay code 1211
U4	5103	Gas pipe temperature thermistor (TH23) open/short	○			
U4	5105	Outdoor liquid pipe temperature thermistor (TH3) open/short		○		Check delay code 1205
U4	5106	Ambient temperature thermistor (TH7) open/short		○		Check delay code 1221
U4	5109	HIC pipe temperature thermistor (TH2) open/short		○		Check delay code 1222
U4	5110	Heat sink temperature thermistor (TH8) open/short		○		Check delay code 1214
F5	5201	High pressure sensor (63HS) trouble		○		Check delay code 1402
F3	5202	Low pressure sensor (63LS) trouble		○		Check delay code 1400
UH	5300	Primary current error		○		Check delay code 4310
P4	5701	Contact failure of drain float switch	○			
A0	6600	Duplex address error	○	○	○	Only M-NET Remote controller is detected.
A2	6602	Transmission processor hardware error	○	○	○	Only M-NET Remote controller is detected.
A3	6603	Transmission bus BUSY error	○	○	○	Only M-NET Remote controller is detected.
A6	6606	Signal communication error with transmission processor	○	○	○	Only M-NET Remote controller is detected.
A7	6607	No ACK error	○		○	Only M-NET Remote controller is detected.
A8	6608	No response frame error	○		○	Only M-NET Remote controller is detected.
E0/E4	6831	MA communication receive error	○		○	Only MA Remote controller is detected.
E3/E5	6832	MA communication send error	○		○	Only MA Remote controller is detected.
E3/E5	6833	MA communication send error	○		○	Only MA Remote controller is detected.
E0/E4	6834	MA communication receive error	○		○	Only MA Remote controller is detected.
EF	7100	Total capacity error		○		
EF	7101	Capacity code error	○	○		
EF	7102	Connecting excessive number of units and branch boxes		○		
EF	7105	Address setting error		○		
EF	7130	Incompatible unit combination		○		

### Notes:

- When the outdoor unit detects No ACK error/No response error, an object indoor unit is treated as a stop, and not assumed to be abnormal.
- The check codes displayed on the units may be different between the error source and others. In that case, please refer to the check code of error source by displayed attribute and address.
- Refer to the service manual of indoor unit or remote controller for the detail of error detected in indoor unit or remote controller.

#### Self-diagnosis function

The indoor and outdoor units can be diagnosed automatically using the self-diagnosis switch (SW1) and LED1, LED2 (LED indication) found on the multi-controller of the outdoor unit.  
LED indication: Set all contacts of SW1 to OFF.


#### During normal operation

The LED indicates the drive state of the controller in the outdoor unit.

Bit	1	2	3	4	5	6	7	8
Indication	Compressor operated	52C	21S4	SV1	(SV2)	—	—	Always lit

#### [Example]

When the compressor and SV1 are turned during cooling operation.



Check code

0403  
(Ed)

## Serial communication error

Abnormal points and detection methods	Causes and checkpoints
If serial communication between the outdoor multi controller circuit board and outdoor power circuit board is defective.	<ol style="list-style-type: none"> <li>1. Wire breakage or contact failure of connector CN2 or CN4</li> <li>2. Malfunction of communication circuit to power circuit board on outdoor multi controller circuit board</li> <li>3. Malfunction of communication circuit on outdoor power circuit board</li> </ol>

### ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check the connection of the communication line (CN2 and CN4) between the outdoor multi controller circuit board and power circuit board.</p> <p>Are they connected normally?</p> <p>No</p> <p>Yes</p>	<p>Connect the CN2 and CN4 properly. Replace them in the case of breakage.</p> <p>The communication circuit of either the outdoor multi controller circuit board or power circuit board is defective. If unable to identify the defective circuit; ①Replace the outdoor multi controller circuit board if it does not recover. ②Replace the outdoor power circuit board.</p>


## Compressor temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>(1) If TH4 falls into following temperature conditions;</p> <ul style="list-style-type: none"> <li>•exceeds 105°C [221°F] continuously for 5 minutes</li> <li>•exceeds 115°C [239°F]</li> </ul> <p>TH4: Thermistor &lt;Compressor&gt; LEV: Linear expansion valve</p>	<ol style="list-style-type: none"> <li>1. Malfunction of stop valve</li> <li>2. Over-heated compressor operation caused by shortage of refrigerant</li> <li>3. Defective thermistor</li> <li>4. Defective outdoor multi controller circuit board</li> <li>5. LEV performance failure</li> <li>6. Defective indoor controller board</li> <li>7. Clogged refrigerant system caused by foreign object</li> <li>8. Refrigerant shortage (Refrigerant liquid accumulation in compressor while indoor unit is OFF/thermo-OFF.)</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor temperature trouble

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## High pressure trouble

Chart 1 of 4

Abnormal points and detection methods	Causes and checkpoints
<p>(1) High pressure abnormality (63H operation) Abnormal if 63H operates(*) during compressor operation. (* 4.15 MPaG [602 PSIG])</p> <p>(2) High pressure abnormality (63HS detected) 1. Abnormal if a pressure detected by 63HS is 4.31 MPaG [625 PSIG] or more during compressor operation. 2. Abnormal if a pressure detected by 63HS is 4.14 MPaG [600 PSIG] or more for 3 minutes during compressor operation.</p> <p>63H : High pressure switch 63HS: High pressure sensor LEV : Linear expansion valve SV1 : Solenoid valve TH7 : Thermistor &lt;Ambient&gt;</p>	<ol style="list-style-type: none"> <li>1. Defective operation of stop valve (not fully open)</li> <li>2. Clogged or broken pipe</li> <li>3. Malfunction or locked outdoor fan motor</li> <li>4. Short-cycle of outdoor unit</li> <li>5. Dirt of outdoor heat exchanger</li> <li>6. Remote controller transmitting error caused by noise interference</li> <li>7. Contact failure of the outdoor multi controller circuit board connector</li> <li>8. Defective outdoor multi controller circuit board</li> <li>9. Short-cycle of indoor unit</li> <li>10. Decreased airflow, clogged filter, or dirt on indoor unit.</li> <li>11. Malfunction or locked indoor fan motor</li> <li>12. Decreased airflow caused by defective inspection of outdoor temperature thermistor (It detects lower temperature than actual temperature.)</li> <li>13. Indoor LEV performance failure</li> <li>14. Malfunction of fan driving circuit</li> <li>15. SV1 performance failure</li> <li>16. Defective High pressure sensor</li> <li>17. Defective High pressure sensor input circuit on outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Is 5201 displayed when restarted?</p> <p><b>Yes</b> (5201)</p> <p><b>No</b> (1302)</p>	<p>Refer to the diagnosis of check code 5201.</p>
<p>Is the outdoor stop valve (liquid/gas) fully open?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Open the stop valve (liquid/gas) fully.</p>
<p>Does the outdoor fan rotate while the operation?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Check the outdoor fan motor. Refer to "How to check the parts" on the outdoor unit service manual.</p>
<p>Does the indoor unit fan rotate while the operation?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Check the indoor unit fan motor. Refer to "How to check the parts" on the indoor unit service manual.</p>
<p>Is the indoor unit short-cycled?</p> <p><b>Yes</b> (short-cycled)</p> <p><b>No</b> (no short-cycle)</p> <p>Continue to the next page.</p>	<p>Resolve the short-cycle.</p>




## High pressure trouble

Chart 2 of 4

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## High pressure trouble

Chart 3 of 4

## •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## High pressure trouble

Chart 4 of 4

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Superheat due to low discharge temperature trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>If the discharge superheat is continuously detected <math>-15^{\circ}\text{C}</math> [<math>-27^{\circ}\text{F}</math>](*) or less for 5 minutes even though the indoor LEV has minimum open pulse after the compressor starts operating for 10 minutes.</p> <p>LEV : Linear expansion valve TH4 : Thermistor &lt;Compressor&gt; 63HS: High pressure sensor</p> <p>*At this temperature, conditions for the abnormality detection will not be satisfied if no abnormality is detected on either TH4 or 63HS.</p>	<ol style="list-style-type: none"> <li>1. Disconnection or loose connection of TH4</li> <li>2. Defective holder of TH4</li> <li>3. Disconnection of LEV coil</li> <li>4. Disconnection of LEV connector</li> <li>5. LEV performance failure</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Superheat due to low discharge temperature trouble

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Refrigerant shortage trouble

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>(1) When all of the following conditions have been satisfied for 15 consecutive minutes:</p> <ol style="list-style-type: none"> <li>1. The compressor is operating in HEAT mode.</li> <li>2. Discharge superheat is 80°C [144°F] or more.</li> <li>3. Difference between TH7 and TH3 applies to the formula of <math>(TH7 - TH3 &lt; 5^{\circ}\text{C}[9^{\circ}\text{F}])</math></li> <li>4. The saturation temperature converted from a high pressure sensor detects below 35°C [95°F].</li> </ol> <p>(2) When all of the following conditions have been satisfied:</p> <ol style="list-style-type: none"> <li>1. The compressor is in operation.</li> <li>2. When cooling, discharge superheat is 80°C [144°F] or more, and the saturation temperature converted from a high pressure sensor is over -40°C [-40°F].</li> <li>3. When heating, discharge superheat is 90°C [162°F] or more.</li> </ol>	<ol style="list-style-type: none"> <li>1. Defective operation of stop valve (not fully open)</li> <li>2. Defective thermistor</li> <li>3. Defective outdoor multi controller circuit board</li> <li>4. Indoor LEV performance failure</li> <li>5. Gas leakage or shortage</li> <li>6. Defective 63HS</li> </ol> <p>TH3 : Thermistor &lt;Outdoor liquid pipe&gt;  TH7 : Thermistor &lt;Ambient&gt;  LEV : Linear expansion valve  63HS: High pressure sensor</p>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Refrigerant shortage trouble

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Check code

1501  
(U2)

## Closed valve in cooling mode

Abnormal points and detection methods	Causes and checkpoints
<p>If stop valve is closed during cooling operation.</p> <p>When both of the following temperature conditions have been satisfied for 20 minutes or more during cooling operation.</p> <ol style="list-style-type: none"> <li>1. TH22j-TH21j <math>\geq -2^{\circ}\text{C}</math> [<math>-3.6^{\circ}\text{F}</math>]</li> <li>2. TH23j-TH21j <math>\geq -2^{\circ}\text{C}</math> [<math>-3.6^{\circ}\text{F}</math>]</li> </ol> <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<ol style="list-style-type: none"> <li>1. Outdoor liquid/gas valve is closed.</li> <li>2. Malfunction of outdoor LEV (LEV-A)(blockage)</li> </ol> <p>TH21: Indoor intake temperature thermistor (RT11 or TH1) TH22: Indoor liquid pipe temperature thermistor (RT13 or TH2) TH23: Indoor gas pipe temperature thermistor (TH-A to E) LEV: Linear expansion valve</p>

### ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<pre> graph TD     Q1{{Is the outdoor stop valve (liquid/gas) fully open?}}     Q1 -- No --&gt; R1[Open the outdoor stop valve (liquid/gas) fully.]     Q1 -- Yes --&gt; P1[Disconnect the outdoor LEV wiring to check the resistance.]     P1 --&gt; Q2{{Is the resistance detected?}}     Q2 -- No --&gt; R2[Replace the outdoor LEV.]     Q2 -- Yes --&gt; R3[Replace the outdoor multi controller circuit board.]           </pre>	



# Check code


1503  
(P6)

## Freeze protection of branch box or indoor unit

Abnormal points and detection methods	Causes and checkpoints
<p>The purpose of the check code is to prevent indoor unit from freezing or dew condensation which is caused when a refrigerant keeps flowing into the unit in STOP.</p> <p>When all of the following conditions are satisfied:</p> <ol style="list-style-type: none"> <li>1. The compressor is operating in COOL mode.</li> <li>2. 15 minutes have passed after the startup of the compressor, or the change in the number of operating indoor units is made (including a change by turning thermo-ON/OFF).</li> <li>3. After the condition 2 above is satisfied, the thermistor of indoor unit in STOP detects TH22j <math>\leq -5^{\circ}\text{C}</math> [<math>23^{\circ}\text{F}</math>] for 5 consecutive minutes.</li> </ol>	<ol style="list-style-type: none"> <li>1. Wrong piping connection between indoor unit and branch box</li> <li>2. Miswiring between indoor unit and branch box</li> <li>3. Miswiring of LEV in branch box or indoor unit</li> <li>4. Malfunction of LEV in branch box or indoor unit</li> </ol>

### •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## 4-way valve trouble in heating mode

Abnormal points and detection methods	Causes and checkpoints
<p>If 4-way valve does not operate during heating operation.</p> <p>When any of the following temperature conditions is satisfied for 3 min or more during heating operation</p> <ol style="list-style-type: none"> <li>1. TH22j-TH21j <math>\leq -10^{\circ}\text{C}</math> [<math>-18^{\circ}\text{F}</math>]</li> <li>2. TH23j-TH21j <math>\leq -10^{\circ}\text{C}</math> [<math>-18^{\circ}\text{F}</math>]</li> <li>3. TH22j <math>\leq 3^{\circ}\text{C}</math> [<math>37.4^{\circ}\text{F}</math>]</li> <li>4. TH23j <math>\leq 3^{\circ}\text{C}</math> [<math>37.4^{\circ}\text{F}</math>]</li> </ol> <p>Note: For indoor unit, the abnormality is detected if an operating unit satisfies the condition.</p>	<ol style="list-style-type: none"> <li>1. 4-way valve failure</li> <li>2. Disconnection or failure of 4-way valve coil</li> <li>3. Clogged drain pipe</li> <li>4. Disconnection or loose connection of connectors</li> <li>5. Malfunction of input circuit on outdoor multi controller circuit board</li> <li>6. Defective outdoor power circuit board</li> </ol> <p>TH21: Indoor intake temperature thermistor (RT11 or TH1) TH22: Indoor liquid pipe temperature thermistor (RT13 or TH2) TH23: Indoor gas pipe temperature thermistor (TH-A to E)</p>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor current interruption (Locked compressor)

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected before 30 seconds since the compressor starts operating.	<ol style="list-style-type: none"> <li>1. Closed stop valve</li> <li>2. Decrease of power supply voltage</li> <li>3. Looseness, disconnection, or wrong phase of compressor wiring connection</li> <li>4. Incorrect DIP-SW setting of model selection on the outdoor controller board</li> <li>5. Defective compressor</li> <li>6. Defective outdoor power circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor current interruption (Locked compressor)

Chart 2 of 2

## •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor overcurrent interruption

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
If overcurrent of DC bus or compressor is detected after 30 seconds since the compressor starts operating.	<ol style="list-style-type: none"> <li>1. Closed outdoor stop valve</li> <li>2. Decrease of power supply voltage</li> <li>3. Looseness, disconnection, or wrong phase of compressor wiring connection</li> <li>4. Model selection error on indoor controller board or outdoor multi controller circuit board</li> <li>5. Defective compressor</li> <li>6. Defective outdoor power circuit board</li> <li>7. Defective outdoor multi controller circuit board</li> <li>8. Malfunction of indoor/outdoor unit fan</li> <li>9. Short-cycle of indoor/outdoor unit</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.




## Compressor overcurrent interruption

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



# Voltage shortage /Overvoltage/PAM error/L1 open phase/ Primary current sensor error/Power synchronization signal error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>If any of following symptoms are detected;</p> <ul style="list-style-type: none"> <li>●Decrease of DC bus voltage to 200 V(Vmodel), 350 V (Y model)</li> <li>●Increase of DC bus voltage to 400 V (V model), 760 V (Y model)</li> <li>●DC bus voltage stays at 310V or less for consecutive 30 seconds when the operational frequency is over 20 Hz.</li> <li>●When any of following conditions is satisfied while the detections value of primary current is 0.1A or less. <ul style="list-style-type: none"> <li>1. The operational frequency is 40Hz or more.</li> <li>2. The compressor current is 6A or more.</li> </ul> </li> </ul>	<ul style="list-style-type: none"> <li>① Decrease/increase of power supply voltage</li> <li>② L1 open-phase (Y model only)</li> <li>③ Primary current sensor failure</li> <li>④ Disconnection of compressor wiring</li> <li>⑤ Malfunction of 52C relay</li> <li>⑥ Defective outdoor power circuit board</li> <li>⑦ Malfunction of 52C relay driving circuit on outdoor multi controller circuit board</li> <li>⑧ Disconnection of CN5 (Y model only)</li> <li>⑨ Disconnection of CN2</li> <li>⑩ Malfunction of primary current detecting circuit on outdoor power circuit board</li> <li>⑪ Malfunction of resistor connected to 52C relay on outdoor power circuit board (Y model only)</li> </ul>


## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

V model : single phase model

Y model : three phase four wire model


The black square (■) indicates a switch position.



## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.





## Check code


4230  
(U5)

## Heat sink temperature trouble

Abnormal points and detection methods	Causes and checkpoints
<p>If TH8 detects a temperature outside the specified range during compressor operation.</p> <p>TH8: Thermistor &lt;Heat sink&gt;</p>	<ol style="list-style-type: none"> <li>1. Blocked outdoor fan</li> <li>2. Malfunction of outdoor fan motor</li> <li>3. Blocked airflow path</li> <li>4. Rise of ambient temperature</li> <li>5. Characteristic defect of thermistor</li> <li>6. Malfunction of input circuit on outdoor power circuit board</li> <li>7. Malfunction of outdoor fan driving circuit</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## Power module trouble or Overcurrent trouble

Abnormal points and detection methods	Causes and checkpoints
<p>If both of the following conditions have been satisfied:</p> <ol style="list-style-type: none"> <li>1. Overcurrent of DC bus or compressor is detected during compressor operation.</li> <li>2. Inverter power module is determined to be defected.</li> </ol>	<ol style="list-style-type: none"> <li>1. Short-circuit caused by looseness or disconnection of compressor wiring</li> <li>2. Defective compressor</li> <li>3. Defective outdoor power circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.


Diagnosis	Remedy
<p>Turn the power OFF to check for looseness or disconnection of the compressor wiring.</p> <p>Are they connected properly?</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>1. Disconnect the compressor wiring (U-V-W phase). 2. Turn ON the SW7-1(*) on the outdoor multi controller circuit board. 3. Operate the unit.</p> <p>* SW7-1 ON: Ignore 5300(UH) error.</p> <p>Is the check code &lt;4250&gt; still displayed?</p> <p><b>No</b></p> <p><b>Yes</b></p>	
	<p>Connect the compressor wiring (U, V and W phase) properly, then turn the power back ON.</p> <p>Replace the compressor (Defective compressor).</p> <p>Replace the outdoor power circuit board or the outdoor multi controller circuit board (Defective outdoor power circuit board).</p>

## Fan trouble (Outdoor unit)

Abnormal points and detection methods	Causes and checkpoints
If no rotational frequency is detected, or detected a value outside the specified range during fan motor operation.	1. Malfunction of fan motor 2. Disconnection of CNF connector 3. Defective outdoor multi controller circuit board

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## Compressor temperature thermistor (TH4) open/short


&lt;Detected in outdoor unit&gt;

Abnormal points and detection methods	Causes and checkpoints
<p>If TH4 detects to be open/short. (The open/short detection is disabled for 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: 3°C [37°F] or less Short: 217°C [423°F] or more    TH4: Thermistor &lt;Compressor&gt;</p>	<ol style="list-style-type: none"> <li>1. Disconnection or contact failure of connectors</li> <li>2. Characteristic defect of thermistor</li> <li>3. Defective outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.



## Suction pipe temperature thermistor (TH6) open/short


&lt;Detected in outdoor unit&gt;

Abnormal points and detection methods	Causes and checkpoints
<p>If TH6 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°C [-40°F] or less Short: 90°C [194°F] or more TH6: Thermistor &lt;Suction pipe&gt;</p>	<ol style="list-style-type: none"> <li>1. Disconnection or contact failure of connectors</li> <li>2. Characteristic defect of thermistor</li> <li>3. Defective outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Outdoor liquid pipe temperature thermistor (TH3) open/short

Abnormal points and detection methods	Causes and checkpoints
<p>If TH3 detects to be open/short. (The open/short detection is disabled during 10 seconds to 10 minutes after compressor starts, during defrosting operation, or for 10 minutes after returning from the defrosting operation.) Open: -40°C [-40°F] or less Short: 90°C [194°F] or more      TH3: Thermistor &lt;Outdoor liquid pipe&gt;</p>	<ol style="list-style-type: none"> <li>1. Disconnection or contact failure of connectors</li> <li>2. Characteristic defect of thermistor</li> <li>3. Defective outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Ambient temperature thermistor (TH7) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH7 detects to be open/short Open: $-40^{\circ}\text{C}$ [ $-40^{\circ}\text{F}$ ] or less Short: $90^{\circ}\text{C}$ [ $194^{\circ}\text{F}$ ] or more TH7: Thermistor <Ambient>	1. Disconnection or contact failure of connectors 2. Characteristic defect of thermistor 3. Defective outdoor multi controller circuit board

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## HIC pipe temperature thermistor (TH2) open/short

Abnormal points and detection methods	Causes and checkpoints
If TH2 detects to be open/short. Open: $-40^{\circ}\text{C}$ [ $-40^{\circ}\text{F}$ ] or less Short: $90^{\circ}\text{C}$ [ $194^{\circ}\text{F}$ ] or more TH2: Thermistor <HIC pipe>	1. Disconnection or contact failure of connectors 2. Characteristic defect of thermistor 3. Defective outdoor multi controller circuit board

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.






## Heat sink temperature thermistor (TH8) open/short

1. Disconnection or contact failure of connectors
2. Characteristic defect of thermistor
3. Defective outdoor multi controller circuit board

The black square (■) indicates a switch position.




## High pressure sensor (63HS) trouble

Abnormal points and detection methods	Causes and checkpoints
<ol style="list-style-type: none"> <li>When the detected pressure in the High pressure sensor is 1kgf/cm<sup>2</sup> or less during operation, the compressor stops operation and enters into an anti-restart mode for 3 minutes.</li> <li>When the detected pressure is 1kgf/cm<sup>2</sup> or less immediately before restarting, the compressor falls into an abnormal stop with a check code &lt;5201&gt;.</li> <li>For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>Defective High pressure sensor</li> <li>Decrease of internal pressure caused by gas leakage</li> <li>Disconnection or contact failure of connector</li> <li>Malfuction of input circuit on outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Low pressure sensor (63LS) trouble

Abnormal points and detection methods	Causes and checkpoints
<ol style="list-style-type: none"> <li>When the detected pressure in the Low pressure sensor is <math>-2.3\text{kgf/cm}^2</math> or less, or <math>23.1\text{kgf/cm}^2</math> or more during operation, the compressor stops operation with a check code &lt;5202&gt;.</li> <li>For 3 minutes after compressor restarting, during defrosting operation, and for 3 minutes after returning from defrosting operation, above mentioned symptoms are not determined as abnormal.</li> </ol>	<ol style="list-style-type: none"> <li>Defective Low pressure sensor</li> <li>Decrease of internal pressure caused by gas leakage</li> <li>Disconnection or contact failure of connector</li> <li>Malfunction of input circuit on outdoor multi controller circuit board</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

The black square (■) indicates a switch position.




## Primary current error

Abnormal points and detection methods	Causes and checkpoints				
<p>If any of the following conditions is detected:</p> <p>1 Primary current sensor detects any of the following conditions (single phase unit only):</p> <table border="1"> <tr> <td>10 consecutive-second detection</td><td>One-time detection</td></tr> <tr> <td>34 A</td><td>38 A</td></tr> </table> <p>2 Secondary current sensor detects 25 A or more. 3 Secondary current sensor detects 1.0 A or less.</p>	10 consecutive-second detection	One-time detection	34 A	38 A	<ol style="list-style-type: none"> <li>1. Decrease/trouble of power supply voltage</li> <li>2. Disconnection of compressor wiring</li> <li>3. Current sensor trouble on outdoor power circuit board</li> <li>4. Wiring through current sensor (penetration type) is not done.</li> </ol>
10 consecutive-second detection	One-time detection				
34 A	38 A				

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



Check code

6600  
(A0)

## Duplex address error

Abnormal points and detection methods	Causes and checkpoints
If 2 or more units with the same address exist.	1. There are 2 units or more with the same address in their controller among outdoor unit, indoor unit, Fresh Master, Lossnay or remote controller 2. Noise interference on indoor/outdoor connectors

### •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Search for a unit with the same address as the source of abnormality.</p> <p>Is there any unit with the same address?</p> <p>Yes</p> <p>No</p> <p>Turn the power back ON.</p> <p>Does it operate normally?</p> <p>No</p> <p>Yes</p>	<p>Correct the address, and turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.</p> <p>Malfunction of sending/receiving circuit on indoor/outdoor unit is suspected.</p> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## Transmission processor hardware error

Abnormal points and detection methods	Causes and checkpoints
If the transmission line shows "1" although the transmission processor transmitted "0".	<ol style="list-style-type: none"> <li>1. A transmitting data collision occurred because of a wiring work or polarity change has performed while the power is ON on either of the indoor/outdoor unit, Fresh Master or Lossnay</li> <li>2. Malfunction of transmitting circuit on transmission processor</li> <li>3. Noise interference on indoor/outdoor connectors</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<pre> graph TD     A{{A wiring work was performed while the power OFF.}} -- No --&gt; B[If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.]     A -- Yes --&gt; C[Turn the power back ON.]     C --&gt; D{{Does it operate normally?}}     D -- No --&gt; E[Replace the indoor/outdoor controller board.]     D -- Yes --&gt; F[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<p>If the wiring work was performed while the power ON, turn the power OFF of indoor/outdoor unit, Fresh Master or Lossnay simultaneously for 2 minutes or more, then turn the power back ON.</p> <p>Replace the indoor/outdoor controller board.</p> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## Transmission bus BUSY error

Abnormal points and detection methods	Causes and checkpoints
<ol style="list-style-type: none"> <li>1. An abnormality when no transmission status caused by transmitting data collision continues for 8 to 10 minutes.</li> <li>2. An abnormality when data cannot be output on the transmission line consecutively because of noise etc. for 8 to 10 minutes.</li> </ol>	<ol style="list-style-type: none"> <li>1. The transmission processor is unable to transmit due to a short-cycle voltage such as noise is mixed on the transmission line.</li> <li>2. The transmission processor is unable to transmit due to an increase of transmission data amount caused by a miswiring of the terminal block (transmission line) (TB3) and the terminal block (centralized control line) (TB7) on the outdoor unit.</li> <li>3. The share on transmission line becomes high due to a mixed transmission caused by a malfunction of repeater on the outdoor unit, which is a function to connect/disconnect transmission from/to control system and centralized control system.</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check whether the transmission line to the indoor unit, Fresh Master, Lossnay or remote controller is miswired to the terminal block (TB7) on outdoor unit or not.</p> <p>Is the transmission line miswired?</p> <p><b>Yes</b> (miswired)</p> <p><b>No</b> (Not miswired)</p> <p>Check whether the transmission line with the other refrigerant system of the indoor unit, Fresh Master or Lossnay is miswired to the terminal block (TB3) on outdoor unit or not.</p> <p>Is the transmission line miswired?</p> <p><b>Yes</b> (miswired)</p> <p><b>No</b> (Not miswired)</p> <p>Turn the power back ON.</p> <p>Does it operate normally?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Correct the wiring, then turn the power back ON.</p> <p>Correct the wiring, then turn the power back ON.</p> <p>Replace the indoor/outdoor controller board.</p> <p>There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## Signal communication error with transmission processor

Abnormal points and detection methods	Causes and checkpoints
1. If the data of unit/transmission processor were not normally transmitted. 2. If the address transmission from the unit processor was not normally transmitted.	1. Accidental disturbance such as noise or lightning surge 2. Hardware malfunction of transmission processor

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 45%;"> <p>Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.</p> <pre> graph TD     A[Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.] --&gt; B{Does it operate normally?}     B -- No --&gt; C[Replace the controller (Defect of error source controller).]     B -- Yes --&gt; D[There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre> </div> <div style="width: 50%;"> <div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;">             Replace the controller (Defect of error source controller).           </div> <div style="border: 1px solid black; padding: 5px;">             There is no abnormality on the AC unit. It might be caused by an external noise, so check the transmission line to remove the factor(s).           </div> </div> </div>	



## No ACK error

Chart 1 of 4

Abnormal points and detection methods	Causes and checkpoints
<p>① Represents a common error detection An abnormality detected by the sending side controller when receiving no ACK from the receiving side, though signal was once sent. The sending side searches the error in 30 seconds interval for 6 times continuously.</p>	<ol style="list-style-type: none"> <li>1. The previous address unit does not exist since the address switch was changed while in electric continuity status.</li> <li>2. Decline of transmission voltage/signal caused by tolerance over on transmission line ·At the furthest end: 200 m ·On remote controller line: (12 m)</li> <li>3. Decline of transmission voltage/signal due to unmatched transmission line types ·Types for shield line: CVVS, CPEVS, or MVVS ·Line diameter: 1.25 mm<sup>2</sup> or more</li> <li>4. Decline of transmission voltage/signal due to excessive number of connected units</li> <li>5. Malfunction due to accidental disturbance such as noise or lightning surge</li> <li>6. Defect of error source controller</li> </ol>
<p>② The cause of displayed address and attribute is on the outdoor unit side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the outdoor unit.</p>	<ol style="list-style-type: none"> <li>1. Contact failure of indoor/outdoor unit transmission line</li> <li>2. Disconnection of transmission connector (CN2M) on indoor unit</li> <li>3. Malfunction of sending/receiving circuit on indoor/outdoor unit</li> <li>4. Disconnection of the connectors on the circuit board</li> </ol>
<p>③ The cause of displayed address and attribute is on the indoor unit side. An abnormality detected by the remote controller if receiving no ACK when sending data from the remote controller to the indoor unit.</p>	<ol style="list-style-type: none"> <li>1. While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON.</li> <li>2. Contact failure of indoor unit or remote controller transmission line</li> <li>3. Disconnection of transmission connector (CN2M) on indoor unit</li> <li>4. Malfunction of sending/receiving circuit on indoor unit or remote controller</li> </ol>
<p>④ The cause of the displayed address and attribute is on the remote controller side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the remote controller.</p>	<ol style="list-style-type: none"> <li>1. While operating with multi refrigerant system indoor units, an abnormality is detected when the indoor unit transmit signal to the remote controller during the other refrigerant-system outdoor unit is turned OFF, or within 2 minutes after it turned back ON.</li> <li>2. Contact failure of indoor unit or remote controller transmission line</li> <li>3. Disconnection of transmission connector (CN2M) on indoor unit</li> <li>4. Malfunction of sending/receiving circuit on indoor unit or remote controller</li> </ol>

## No ACK error

Chart 2 of 4

Abnormal points and detection methods	Causes and checkpoints
<p>⑤ The cause of displayed address and attribute is on the Fresh Master side. An abnormality detected by the indoor unit if receiving no ACK when transmitting signal from the indoor unit to the Fresh Master.</p>	<ol style="list-style-type: none"> <li>1. While the indoor unit is operating with multi refrigerant system Fresh Master, an abnormality is detected when the indoor unit transmits signal to the remote controller while the outdoor unit with the same refrigerant system as the Fresh Master is turned OFF, or within 2 minutes after it turned back ON.</li> <li>2. Contact failure of indoor unit or Fresh Master transmission line</li> <li>3. Disconnection of transmission connector (CN2M) on indoor unit or Fresh Master</li> <li>4. Malfunction of sending/receiving circuit on indoor unit or Fresh Master</li> </ol>
<p>⑥ The cause of displayed address and attribute is on Lossnay side. An abnormality detected by the indoor unit if receiving no ACK when the indoor unit transmit signal to the Lossnay.</p>	<ol style="list-style-type: none"> <li>1. An abnormality is detected when the indoor unit transmits signal to Lossnay while the Lossnay is turned OFF.</li> <li>2. While the indoor unit is operating with the other refrigerant Lossnay, an abnormality is detected when the indoor unit transmits signal to the Lossnay while the outdoor unit with the same refrigerant system as the Lossnay is turned OFF, or within 2 minutes after it turned back ON.</li> <li>3. Contact failure of indoor unit or Lossnay transmission line</li> <li>4. Disconnection of transmission connector (CN2M) on indoor unit</li> <li>5. Malfunction of sending/receiving circuit on indoor unit or Lossnay</li> </ol>
<p>⑦ The controller of displayed address and attribute is not recognized.</p>	<ol style="list-style-type: none"> <li>1. The previous address unit does not exist since the address switch was changed while in electric continuity status.</li> <li>2. An abnormality detected at transmitting from the indoor unit since the Fresh Master/Lossnay address are changed after synchronized setting of Fresh Master/Lossnay by the remote controller.</li> </ol>

## No ACK error


Chart 3 of 4

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Note:

When the address of the outdoor unit is displayed as abnormal, the outdoor circuit board may be faulty. If the unit is not restored after conducting the following procedure, check the outdoor circuit board.




## No ACK error

Chart 4 of 4

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## No response frame error

Abnormal points and detection methods	Causes and checkpoints
<p>If receiving no response command while already received ACK. The sending side searches the error in 30 seconds interval for 6 times continuously.</p>	<ol style="list-style-type: none"> <li>1. Continuous failure of transmission due to noise, etc</li> <li>2. Decline of transmission voltage/signal caused by tolerance over on transmission line <ul style="list-style-type: none"> <li>·At the furthest end: 200 m</li> <li>·On remote controller line: (12 m)</li> </ul> </li> <li>3. Decline of transmission voltage/signal due to unmatched transmission line types <ul style="list-style-type: none"> <li>·Types for shield line: CVVS, CPEVS, or MVVS</li> <li>·Line diameter: 1.25 mm<sup>2</sup> or more</li> </ul> </li> <li>4. Accidental malfunction of error source controller</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, then turn the power back ON.</p> <p>Does it operate normally?</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>Check the transmission line for disconnection and looseness (on the terminal board and connector).</p> <p>The transmission line is connected properly.</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>Check the transmission line whether it exceeds the tolerance or not.</p> <p>It is not exceeding the tolerance.</p> <p><b>No</b></p> <p><b>Yes</b></p> <p>Check whether the correct kind of transmission line is used or not.</p> <p>Is correct kind of transmission line used?</p> <p><b>No</b></p> <p><b>Yes</b></p>	<p>Replace the controller board (Defect of the controller which the displayed address/attribute belong to).</p> <p>Connect the transmission line properly.</p> <p>Correct it within the tolerance.</p> <p>Replace it with the correct kind of transmission line.</p> <p>There is no abnormality on the AC unit. Check the transmission line for transmission wave and noise.</p>


## MA communication receive error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
<p>Detected in remote controller or indoor unit:</p> <p>① When the main or sub remote controller cannot receive signal from indoor unit which has the "0" address.</p> <p>② When the sub remote controller cannot receive signal.</p> <p>③ When the indoor controller board cannot receive signal from remote controller or another indoor unit.</p> <p>④ When the indoor controller board cannot receive signal.</p>	<p>1. Contact failure of remote controller wirings</p> <p>2. Irregular Wiring (A wiring length, number of connecting remote controllers or indoor units, or a wiring thickness does not meet the conditions specified in the chapter "Electrical Work" in the indoor unit Installation Manual.)</p> <p>3. Malfunction of the remote controller sending/receiving circuit on indoor unit with the LED2 is blinking.</p> <p>4. Malfunction of the remote controller sending/receiving circuit</p> <p>5. Remote controller transmitting error caused by noise interference</p>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards




## MA communication receive error

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards

Diagnosis	Remedy
<p>Continued from the previous page.</p>  <pre> graph TD     Start([Continued from the previous page.]) --&gt; Refer[Refer to the chapter "Electrical Work".]     Refer --&gt; Decision{Is the wiring connected properly, meeting the condition?}     Decision -- No --&gt; Remedy1[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.]     Decision -- Yes --&gt; Remedy2[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<div>Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.</div> <div>No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).</div>


## MA communication send error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
Detected in remote controller or indoor unit.	<ol style="list-style-type: none"> <li>1. There are 2 remote controllers set as main.</li> <li>2. Malfunction of remote controller sending/receiving circuit</li> <li>3. Malfunction of sending/receiving circuit on indoor controller board</li> <li>4. Remote controller transmitting error caused by noise interference</li> </ol>

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards






## MA communication send error

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards

Diagnosis	Remedy
<p>Continued from the previous page.</p>  <pre> graph TD     Start[Continued from the previous page.] --&gt; Step1[Refer to the chapter "Electrical Work".]     Step1 --&gt; Decision{Is the wiring connected properly, meeting the condition?}     Decision -- No --&gt; Remedy1[Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.]     Decision -- Yes --&gt; Remedy2[No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).]           </pre>	<p>Connect the wiring properly as specified in the chapter "Electrical Work" in the indoor unit Installation Manual.</p> <p>No abnormality It might be caused by an external noise, so check the transmission line to remove the factor(s).</p>

## Check code

7100  
(EF)

## Total capacity error

## Abnormal points and detection methods

When the total capacity of connected indoor units exceeds the specified capacity (130% of the outdoor unit capacity), a check code <7100> is displayed.

## Causes and checkpoints

1. The total of number on connected indoor unit model names exceeds the specified capacity level.
2. The model name code of the outdoor unit is registered wrongly.

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

## Diagnosis

## Remedy

Check the total capacity of connected indoor units.

Is the total under 130% of outdoor unit capacity?

No

Correct it so that the total capacity of connected indoor units is under 130% of the outdoor unit capacity.

Yes

Check the capacity code switch (SW2 on the indoor controller board) on the connected indoor unit.

Is it set properly?

No

Set the switch properly.

Yes

Check the model selection switch (SW4 on the outdoor multi controller circuit board) of the outdoor unit.

Is it set properly?

No

Set the switch properly.

Yes

Complete.

# Check code

7101  
(EF)

## Capacity code error

### Abnormal points and detection methods

When a connected indoor unit is incompatible, a check code <7101> is displayed.

### Causes and checkpoints

The model name of connected indoor unit (model code) is read as incompatible.

The connectable indoor units are:

- SP112 to SP140 model: P10 to P140 model (code 2 to 28)
- When connecting via branch box: P15 to P100 model (code 3 to 20)

### ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

### Diagnosis

Check the model selection switch (SW4 on the indoor controller board) of the connected indoor unit.

Is it set properly?

No

Set the switch properly.

Yes

The model code of the connected indoor unit can be displayed by an operation of SW1 on the outdoor unit.

### Remedy

Check code

7102  
(EF)

## Connecting excessive number of units and branch boxes

Abnormal points and detection methods	Causes and checkpoints
When the connected indoor unit exceeds the limit, a check code <7102> is displayed.	<p>Connecting more indoor units and branch boxes than the limit.</p> <p>Abnormal if connecting status does not comply with the following limit;</p> <ol style="list-style-type: none"> <li>1. Connectable up to 12 indoor units</li> <li>2. Connect at least 1 indoor unit (Abnormal if connected none).</li> <li>3. Connectable up to 2 branch boxes</li> </ol>

### •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p>Check whether the connecting unit exceeds the limit or not.</p> <p>Does it exceed the limit?</p> <p>Yes</p> <p>No</p> <p>Check if at least 1 indoor unit is connected. Is an indoor unit connected?</p> <p>No</p> <p>Yes</p>	<p>Connect less number of units than the limit.</p> <p>Note: The model code of the connected indoor unit can be displayed by an operation of SW1 on the outdoor unit.</p> <p>Connect indoor unit.</p> <p>Check whether the M-NET line to the indoor unit is connected or not.</p>

## Address setting error

Chart 1 of 2

Abnormal points and detection methods	Causes and checkpoints
The address setting of connected unit is wrong.	There is a unit without correct address setting in the range specified in "7-5. SYSTEM CONTROL".

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p><b>&lt;Outdoor unit&gt;</b></p> <p>Check whether the outdoor unit address is set in 000, or in the range of 51 to 100.</p> <p>Is the address setting correct?</p> <p>No</p> <p>Yes</p>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the outdoor multi controller circuit board.</p>
<p><b>&lt;Indoor unit&gt;</b></p> <p>Check whether the indoor unit address is set in 00, or in the range of 01 to 50.</p> <p>Is the address setting correct?</p> <p>No</p> <p>Yes</p>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the indoor controller board.</p>
<p><b>&lt;Branch box&gt;</b></p> <p>Check whether the branch box address is set in 00, or in the range of 01 to 46.</p> <p>Is the address setting correct?</p> <p>No</p> <p>Yes</p>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the branch box controller board.</p>

## Address setting error

Chart 2 of 2

## ●Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.

Diagnosis	Remedy
<p><b>&lt;M-NET RC (main)&gt;</b></p> <p>Check whether the M-NET RC (main) address is set in 000, or in the range of 101 to 150.</p> <p>Is the address setting correct?</p> <p>No</p> <p>Yes</p>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the M-NET RC (main).</p>
<p><b>&lt;M-NET RC (sub)&gt;</b></p> <p>Check whether the M-NET RC (sub) address is set in 000, or in the range of 151 to 200.</p> <p>Is the address setting correct?</p> <p>No</p> <p>Yes</p>	<p>Set the address properly, then turn the power OFF of indoor/outdoor unit, Fresh Master, Lossnay and remote controller simultaneously for 2 minutes or more, and turn the power back ON.</p> <p>Replace the M-NET RC (sub).</p>

Check code

7130  
(EF)

## Incompatible unit combination error

### Abnormal points and detection methods


When the connected indoor unit is not compatible with the outdoor unit, the outdoor unit detects the error at startup.

### Causes and checkpoints



Connecting indoor unit(s) which is not authorized to connect to the outdoor unit.

#### •Diagnosis of defects

Make sure to turn the power OFF before connecting/disconnecting any connectors, or replacing boards.



## 8-2. THE FOLLOWING SYMPTOM DO NOT REPRESENT TROUBLE (EMERGENCY)

Symptom	Display of remote controller	CAUSE
Even the cooling (heating) operation selection button is pressed, the indoor unit cannot be operated.	"Cooling (Heating)" blinks	The indoor unit cannot cool (Heat) if other indoor units are heating (Cooling).
The auto vane runs freely.	Normal display	Because of the control operation of auto vane, it may change over to horizontal blow automatically from the downward blow in cooling because the downward blow operation has been continued for 1 hour. At defrosting in heating, hot adjusting and thermostat OFF, it automatically changes over to horizontal blow.
Fan setting changes during heating.	Normal display	Ultra-low speed operation is commenced at thermostat OFF. Light air automatically change over to set value by time or piping temperature at thermostat ON.
Fan stops during heating operation.	"Heat Defrost:  "	The fan stops during defrosting.
Fan does not stop while operation has been stopped.	Light out	Fan runs for 1 minute after stopping to exhaust residual heat (only in heating).
No setting of fan while start SW has been turned on.	"Heat Standby:  "	Ultra-low speed operation for 5 minutes after SW ON or until piping temperature reaches 35°C. Then low speed operates for 2 minutes and operates at the normal set air volume. (Hot adjust control)
Indoor unit remote controller shows "Please wait" indicator for about 2 minutes when turning ON power supply.	"Please wait" blinks	The system is in the process of startup. Operate remote controller again after "Please wait" disappears.
Drain pump does not stop while unit has been stopped.	Light out	After a stop of cooling operation, unit continues to operate drain pump for 3 minutes and then stops.
Drain pump continues to operate while unit has been stopped.	—	Unit continues to operate drain pump if drainage is generated, even during a stop.



### 8-3. INTERNAL SWITCH FUNCTION TABLE

PUMY-SP112VKMR1.TH

PUMY-SP112YKMR1.TH

PUMY-SP112VKMR1.TH-BS

PUMY-SP112YKMR1.TH-BS

PUMY-SP125VKMR1.TH

PUMY-SP125YKMR1.TH

PUMY-SP125VKMR1.TH-BS

PUMY-SP125YKMR1.TH-BS







PUMY-SP140VKMR1.TH

PUMY-SP140YKMR1.TH

PUMY-SP140VKMR1.TH-BS

PUMY-SP140YKMR1.TH-BS

The black square (■) indicates a switch position.

Switch	Step	Function	Operation in Each Switch Setting		Remarks	Purpose	Additional Information																																						
			ON	OFF																																									
SWU1 ones digit SWU2 tens digit	Rotary switch		Before turning the power ON	<Initial settings> 	—	—																																							
	1-8		Can be set either during operation or not.	<Initial settings> 	To display outdoor unit's information to the LED on outdoor multi controller circuit board. Refer to "8-8. OUTDOOR UNIT INFORMATION DISPLAY".	—																																							
SW2 Function Switch	1	Selects operating system startup	With centralized controller	Without centralized controller	<Initial settings> 	Turn ON when the centralized controller is connected to the outdoor unit.	• SW2-1 must be turned ON if a central controller is connected to the system. An example of this would be a TC-24, EB50A, AG150, AE50 or AE200. If SW2-1 is not turned on, while using a central controller, in rare circumstances problems may be encountered such as indoor units not responding to group commands. Therefore, turning SW2-1 ON is recommended if a central controller is used. • Group setting of 2 or more A-IC units which is connected to branch box via centralized controller is not allowed.																																						
	2	Connection Information Clear Switch	Clear	Do not clear		When relocating units or connecting additional units.	—																																						
	3	Abnormal data clear switch input	Clear abnormal data	Normal		To delete an error history.	—																																						
	4	Pump down	ON	OFF		To facilitate outdoor unit the pumping down operation. Frequency = Fixed to 65 Hz Indoor-Electronic expansion valve = Fully open Outdoor fan step = Fixed to 10	Please refer to a section referring to the pumping down on outdoor units Installation Manuals. It might not be possible to collect all the refrigerant if the amount is excessive.																																						
	5	—	—	—		—	—																																						
	6	—	—	—		—	—																																						
SW3 Trial operation	1	ON/OFF from outdoor unit	ON	OFF	<Initial settings> 	—	—																																						
	2	Mode setting	Heating	Cooling		—	—																																						
SW2/ SW4/ SW8/ SW9 Model Switch	1-6	<table><tr><th>MODELS</th><th>SW2</th><th>SW4</th><th>SW8</th><th>SW9</th></tr><tr><td>PUMY-SP112VKM</td><td></td><td></td><td></td><td></td></tr><tr><td>PUMY-SP125VKM</td><td></td><td></td><td></td><td></td></tr><tr><td>PUMY-SP140VKM</td><td></td><td></td><td></td><td></td></tr></table> <table><tr><th>MODELS</th><th>SW2</th><th>SW4</th><th>SW8</th><th>SW9</th></tr><tr><td>PUMY-SP112YKM</td><td></td><td></td><td></td><td></td></tr><tr><td>PUMY-SP125YKM</td><td></td><td></td><td></td><td></td></tr><tr><td>PUMY-SP140YKM</td><td></td><td></td><td></td><td></td></tr></table>	MODELS	SW2	SW4	SW8	SW9	PUMY-SP112VKM					PUMY-SP125VKM					PUMY-SP140VKM					MODELS	SW2	SW4	SW8	SW9	PUMY-SP112YKM					PUMY-SP125YKM					PUMY-SP140YKM					Before the power is turned ON.	<Initial settings> Set for each capacity.	—
MODELS	SW2	SW4	SW8	SW9																																									
PUMY-SP112VKM																																													
PUMY-SP125VKM																																													
PUMY-SP140VKM																																													
MODELS	SW2	SW4	SW8	SW9																																									
PUMY-SP112YKM																																													
PUMY-SP125YKM																																													
PUMY-SP140YKM																																													

Continue to the next page.



The black square (■) indicates a switch position.

Switch	Step	Function	Operation in Each Switch Setting		Remarks	Purpose	Additional Information
			ON	OFF			
SW5 Function Switch	1	Demand control setting for Australia	Australia setting	Normal*1	<Initial settings> ON ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ OFF 1 2 3 4 5 6 7 8	Turn ON to activate the demand control for Australia.	(Do not turn this ON if the unit is in outside Australia)
	2	Change the indoor unit's LEV opening at startup	Enable	Normal		To set the LEV opening at startup higher than usual. (+150 pulses) To improve the operation with the LEV almost clogged.	The refrigerant flow noise at startup become louder.
	3	—	—	—		—	—
	4	—	—	—		—	—
	5	Change the indoor unit's LEV opening at defrost	Enable	Normal	To decrease the target sub cool value. To reduce the discharge temperature decrease due to refrigerant liquid accumulation in the units. To additionally increase about 50 to 70 pulses of the LEV opening for units other than in HEAT operation. To avoid a refrigerant shortage (less capacity) due to refrigerant liquid accumulation in the units which is not in operation. To reduce the room temperature increase by setting the LEV opening lower for the indoor units in FAN or COOL.	The refrigerant flow noise during the defrosting operation become louder.	
	6	Switching the target sub cool (Heating mode)	Enable	Normal		A refrigerant flow noise might be generated if the sub cool value is too small.	
	7	While the outdoor unit is in HEAT operation, additionally increase about 50 to 70 pulses of the LEV opening on the indoor unit which is in FAN, STOP, COOL or thermo-OFF*2.	Active	Inactive		A refrigerant flow noise might be generated in units other than the one in operation.	
	8	While the outdoor unit is in HEAT operation, fully close the linear expansion valve on the indoor unit which is in FAN or COOL*3.	Enable	Normal		The refrigerant is more likely to collect in the indoor units in FAN or COOL, which can cause refrigerant shortage of units. (Results in less capacity and increase of discharge temperature.)	
SW6 Function Switch	1	—	—	—	<Initial settings> ON ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ OFF 1 2 3 4 5 6 7 8	—	—
	2	—	—	—		—	—
	3	—	—	—		—	—
	4	Change of defrosting control	Enable (For high humidity)	Normal		To shorten the defrosting prohibition time in high humidity (or heavy snow) region, in order to reduce malfunctions caused by frost.	The performance of the HEAT operation is somewhat reduced since the defrosting operation is frequently performed.
	5	External static pressure mode	Enable	Normal	To raise the fan rotation to raise the performance when an external static pressure is applied. To raise the performance by setting the Pdm higher during HEAT operation. To raise/reduce the performance by changing the target ETm during COOL operation. Switch to raise the performance: raises the performance Switch to reduce the performance: prevents dew condensation	It can support the external static pressure up to 30 Pa. The power input and the sound level become larger due to increasing the outdoor unit's fan rotation.	
	6	Switching the target discharge pressure (Pdm)	Enable	Normal		Power consumption is raised due to a higher frequency. (The performance would not be raised at the maximum operating frequency)	SW6-6 ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ Target Pdm (kg/cm <sup>2</sup> )   29.5   31.5
	7	Switching (1) the target evaporation temperature (ETm)	Enable	Normal		Switching it to raise the performance, it raises the power consumption, and produces more dew condensation. Switching it to reduce the performance, it makes the performance insufficient.	SW6-7 ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ SW6-8 ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ Target ETm (°C)   9   11   6   5 Note: The target ETm varies according to an intake temperature.
	8	Switching (2) the target evaporation temperature (ETm)	Enable	Normal			

\*1 Refer to "8-4. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR".

\*2 SW5-7 Opens the indoor-electronic expansion valve as a countermeasure against the indoor unit in FAN, COOL, STOP, or thermo-OFF operation with refrigerant-shortage status due to an accumulation of liquid refrigerant in the indoor unit.

\*3 SW5-8 Countermeasure against room temperature rise for indoor unit in FAN and COOL mode.

\*4 During heating operation and the ambient temperature is 4°C(39°F) or below, the freeze prevention heater is energized.

\*5 During heating mode is OFF (include thermo-OFF in cooling mode), and the ambient temperature is 4°C(39°F) or below, the freeze prevention heater is energized.

Continue to the next page.

Switch	Step	Function	Operation in Each Switch Setting			Remarks	Purpose	Additional Information
			ON	OFF	When to Set			
SW7 Function Switch	1	Ignore current sensor abnormality and rotational frequency abnormality of outdoor fan motor	Enable	Normal	After turning the power ON*6	<Initial settings> 	To perform a test run for electrical parts alone without running the compressor. Also, to perform the troubleshooting of electrical parts without operating the outdoor unit's fan.	Make sure to connect the connectors to the compressor after checking the electrical parts. Be careful not to get electrical shock while working on electrical parts.
	2	Setting to energize the freeze stat heater (optional part)	During heating operation only*4	Include when the heating operation is OFF.*5	Can be set when OFF or during operation		It reduces snow on the base, even it blows inside the unit, by setting the base heater ON while the HEAT operation is stopped.	Power consumption raises while the operation is stopped.
	3	—	—	—	—		—	—
	4	Maximum frequency down at 1 hour after COOL operation	Enable	Normal	Can be set when OFF or during operation		To reduce dew condensation on the indoor unit by lowering the frequency.	The performance might be insufficient.
	5	—	—	—	—		—	—
	6	Manual defrost	Manual defrost	Normal	During compressor running in HEAT mode.		Turn ON when it is necessary to perform the defrosting operation forcibly. (Effective only at startup, or 10 minutes after the last defrosting operation)	It performs the defrosting operation forcibly. (HEAT operation is stopped temporarily)
SW9 Function Switch	1	Auto change over from remote controller (IC with the minimum address)	Enable	Disable	Before turning the power ON	<Initial settings> 	Enables the indoor unit with the minimum address to select AUTO mode, and switches the operation mode of the other indoor units to the same mode.	Cannot be set when the centralized control is ON.
	2	Switching the Silent/Demand mode	Demand control	Silent mode	Can be set when OFF or during operation		—	About the Silent mode/Demand control setting, refer to "8-4. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR".
	3	—	—	—	—		—	—
	4	—	—	—	—		—	—


\*4 During heating operation and the ambient temperature is 4°C(39°F) or below, the freeze prevention heater is energized.

\*5 During heating mode is OFF (include thermo-OFF in cooling mode), and the ambient temperature is 4°C(39°F) or below, the freeze prevention heater is energized.

\*6 Make sure to wait for 5 minutes after turning the breaker ON.

## 8-4. OUTDOOR UNIT INPUT/OUTPUT CONNECTOR


### • State (CN51)



- Ⓐ Distant control board
- Ⓑ Relay circuit
- Ⓒ External output adapter (PAC-SA88HA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Lamp power supply
- Ⓕ Procure locally
- Ⓖ Max. 10m

L1: Error display lamp  
 L2: Compressor operation lamp  
 X, Y: Relay (coil rating: ≤ 0.9W, DC 12 VDC)

### • Auto changeover (CN3N)




- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10 m

	ON	OFF
SW1	Heating	Cooling
SW2	Validity of SW1	Invalidity of SW1

SW1: Switch  
 SW2: Switch  
 X, Y: Relay (contact rating: ≥ 0.1 A, 15 VDC)  
 (min. applicable load: ≤ 1 mA)

### • Silent Mode/Demand Control (CN3D)



- Ⓐ Remote control panel
- Ⓑ Relay circuit
- Ⓒ External input adapter (PAC-SC36NA-E)
- Ⓓ Outdoor unit control board
- Ⓔ Relay power supply
- Ⓕ Procure locally
- Ⓖ Max. 10 m

SW1: Switch  
 SW2: Switch  
 X, Y: Relay (contact rating: ≥ 0.1 A, 15 VDC)  
 (min. applicable load: ≤ 1 mA)

The silent mode and the demand control are selected by switching the DIP switch 9-2 on outdoor controller board. It is possible to set it to the following power consumption (compared with ratings) by setting SW1, 2.

	Outdoor controller board DIP SW9-2	SW1	SW2	Function
Silent mode (Cooling only)	OFF	OFF	OFF	Normal
		ON	OFF	Silent mode
		OFF	ON	Super silent mode 1
		ON	ON	Super silent mode 2
Demand control	ON	OFF	OFF	100% (Normal)
		ON	OFF	75%
		ON	ON	50%
		OFF	ON	0% (Stop)

## 8-5. HOW TO CHECK THE PARTS

PUMY-SP112VKM(R1).TH

PUMY-SP125VKM(R1).TH

PUMY-SP140VKM(R1).TH

PUMY-SP112YKM(R1).TH

PUMY-SP125YKM(R1).TH

PUMY-SP140YKM(R1).TH

PUMY-SP112VKM(R1).TH-BS





PUMY-SP125VKM(R1).TH-BS

PUMY-SP140VKM(R1).TH-BS

PUMY-SP112YKM(R1).TH-BS

PUMY-SP125YKM(R1).TH-BS

PUMY-SP140YKM(R1).TH-BS

Parts name	Checkpoints														
Thermistor (TH2) <HIC pipe> Thermistor (TH3) <Outdoor liquid pipe> Thermistor (TH4) <Compressor> Thermistor (TH6) <Suction pipe> Thermistor (TH7) <Ambient> Thermistor (TH8) <Heat sink>	Disconnect the connector then measure the resistance with a tester. (At the ambient temperature 10 to 30°C) <table><tr><td></td><td>Normal</td><td>Abnormal</td></tr><tr><td>TH4</td><td>160 to 410 kΩ</td><td rowspan="4">Open or short</td></tr><tr><td>TH2 TH3 TH6 TH7</td><td>4.3 to 9.6 kΩ</td></tr><tr><td>TH8</td><td>39 to 105 kΩ</td></tr><tr><td></td><td></td></tr></table>		Normal	Abnormal	TH4	160 to 410 kΩ	Open or short	TH2 TH3 TH6 TH7	4.3 to 9.6 kΩ	TH8	39 to 105 kΩ				
	Normal	Abnormal													
TH4	160 to 410 kΩ	Open or short													
TH2 TH3 TH6 TH7	4.3 to 9.6 kΩ														
TH8	39 to 105 kΩ														
Fan motor (MF1) 	Measure the resistance between the connector pins with a tester. (At the ambient temperature 20°C) <table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>Red - Blue</td><td>Brown - Blue</td><td>Orange - Blue</td><td>White - Blue</td><td rowspan="2">Open or short (Short, for White - Blue)</td></tr><tr><td>1.1 ± 0.05 MΩ</td><td>40 ± 4 kΩ</td><td>220 ± 22 kΩ</td><td>Open</td></tr></table>	Normal				Abnormal	Red - Blue	Brown - Blue	Orange - Blue	White - Blue	Open or short (Short, for White - Blue)	1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22 kΩ	Open
Normal				Abnormal											
Red - Blue	Brown - Blue	Orange - Blue	White - Blue	Open or short (Short, for White - Blue)											
1.1 ± 0.05 MΩ	40 ± 4 kΩ	220 ± 22 kΩ	Open												
Solenoid valve coil <4-way valve> (21S4)	Measure the resistance between the terminals with a tester. (At the ambient temperature 20°C) <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>1725 ± 172.5 Ω</td><td>Open or short</td></tr></table>	Normal	Abnormal	1725 ± 172.5 Ω	Open or short										
Normal	Abnormal														
1725 ± 172.5 Ω	Open or short														
Motor for compressor (MC) 	Measure the resistance between the terminals with a tester. (Winding temperature 20°C) <table><tr><td colspan="2">Normal</td><td rowspan="2">Abnormal</td></tr><tr><td>PUMY-SP•VKM</td><td>PUMY-SP•YKM</td></tr><tr><td>0.44 ± 0.022 Ω</td><td>0.88 ± 0.044 Ω</td><td>Open or short</td></tr></table>	Normal		Abnormal	PUMY-SP•VKM	PUMY-SP•YKM	0.44 ± 0.022 Ω	0.88 ± 0.044 Ω	Open or short						
Normal		Abnormal													
PUMY-SP•VKM	PUMY-SP•YKM														
0.44 ± 0.022 Ω	0.88 ± 0.044 Ω	Open or short													
Solenoid valve coil <Bypass valve> (SV1)	Measure the resistance between the terminals with a tester. (At the ambient temperature 20°C) <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>1182.5 ± 83 Ω</td><td>Open or short</td></tr></table>	Normal	Abnormal	1182.5 ± 83 Ω	Open or short										
Normal	Abnormal														
1182.5 ± 83 Ω	Open or short														
Linear expansion Valve (LEV-A) 	<table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>Gray - Black</td><td>Gray - Red</td><td>Gray - Yellow</td><td>Gray - Orange</td><td rowspan="2">Open or short</td></tr><tr><td colspan="4">46 ± 3 Ω</td></tr></table>	Normal				Abnormal	Gray - Black	Gray - Red	Gray - Yellow	Gray - Orange	Open or short	46 ± 3 Ω			
Normal				Abnormal											
Gray - Black	Gray - Red	Gray - Yellow	Gray - Orange	Open or short											
46 ± 3 Ω															
Linear expansion Valve (LEV-B) 	<table><tr><td colspan="4">Normal</td><td>Abnormal</td></tr><tr><td>Red - White</td><td>Red - Orange</td><td>Red - Yellow</td><td>Red - Blue</td><td rowspan="2">Open or short</td></tr><tr><td colspan="4">46 ± 4 Ω</td></tr></table>	Normal				Abnormal	Red - White	Red - Orange	Red - Yellow	Red - Blue	Open or short	46 ± 4 Ω			
Normal				Abnormal											
Red - White	Red - Orange	Red - Yellow	Red - Blue	Open or short											
46 ± 4 Ω															


## Check method of DC fan motor (fan motor/outdoor multi controller circuit board)

### 1. Notes:

- High voltage is applied to the connector (CNF1) for the fan motor. Pay attention to the service.
- Do not pull out the connector (CNF1) for the motor with the power supply on.  
(It causes trouble of the outdoor multi controller circuit board and fan motor.)

### 2. Self check

Symptom: The outdoor fan cannot rotate.



Note: Turn SW7-1 OFF after the troubleshooting completes.

The fan sometimes starts on-off cycle operation during low-load operation or cooling at low ambient temperature.  
It is not abnormal; the operation ensures reliability of the product.

## 8-6. HOW TO CHECK THE COMPONENTS

### <Thermistor feature chart>

#### Low temperature thermistors


- Thermistor <HIC pipe> (TH2)
- Thermistor <Outdoor liquid pipe> (TH3)
- Thermistor <Suction pipe> (TH6)
- Thermistor <Ambient> (TH7)

Thermistor R0 = 15 kΩ ± 3 %

B constant = 3480 ± 1 %

$$R_t = 15 \exp \left\{ 3480 \left( \frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C	15 kΩ	30°C	4.3 kΩ
10°C	9.6 kΩ	40°C	3.0 kΩ
20°C	6.3 kΩ		
25°C	5.2 kΩ		



#### Medium temperature thermistor


- Thermistor <Heat sink> (TH8)

Thermistor R50 = 17 kΩ ± 2 %

B constant = 4150 ± 3 %

$$R_t = 17 \exp \left\{ 4150 \left( \frac{1}{273+t} - \frac{1}{323} \right) \right\}$$

0°C	180 kΩ
25°C	50 kΩ
50°C	17 kΩ
70°C	8 kΩ
90°C	4 kΩ



#### High temperature thermistor


- Thermistor <Compressor> (TH4)

Thermistor R120 = 7.465 kΩ ± 2 %

B constant = 4057 ± 2 %

$$R_t = 7.465 \exp \left\{ 4057 \left( \frac{1}{273+t} - \frac{1}{393} \right) \right\}$$

20°C	250 kΩ	70°C	34 kΩ
30°C	160 kΩ	80°C	24 kΩ
40°C	104 kΩ	90°C	17.5 kΩ
50°C	70 kΩ	100°C	13.0 kΩ
60°C	48 kΩ	110°C	9.8 kΩ







## <HIGH PRESSURE SENSOR>

### • Comparing the High Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the high pressure sensor appears on the LED1 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

- (1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.
  - 1) When the gauge pressure is between 0 and 0.098 MPaG [14 PSIG], internal pressure is caused due to gas leak.
  - 2) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 0.098 MPaG [14 PSIG], the connector may be defective or be disconnected. Check the connector and go to (4).
  - 3) When the pressure displayed on self-diagnosis LED1, 2 exceeds 5.0 MPaG [725 PSIG], go to (3).
  - 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).
- (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1,2 after 15 minutes have passed since the start of operation. (Compare them by MPaG [PSIG] unit.)
  - 1) When the difference between both pressures is within 0.25 MPaG [36 PSIG], both the high pressure sensor and the control board are normal.
  - 2) When the difference between both pressures exceeds 0.25 MPaG [36 PSIG], the high pressure sensor has a problem. (performance deterioration)
  - 3) When the pressure displayed on self-diagnosis LED1, 2 does not change, the high pressure sensor has a problem.
- (3) Remove the high pressure sensor from the control board to check the pressure on the self-diagnosis LED1, 2.
  - 1) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 0.098 MPaG [14 PSIG], the high pressure sensor has a problem.
  - 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 5.0 MPaG [725 PSIG], the control board has a problem.
- (4) Remove the high pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63HS) to check the pressure with self-diagnosis LED1, 2.
  - 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 5.0 MPaG [725 PSIG], the high pressure sensor has a problem.
  - 2) If other than 1), the control board has a problem.



### • High Pressure Sensor Configuration (63HS)

The high pressure sensor consists of the circuit shown in the figure below. If 5 VDC is applied between the white and the black wires, voltage corresponding to the pressure between the blue and the black wires will be output, and the value of this voltage will be converted by the microprocessor. The output voltage is 0.078 V per 0.098 MPaG [14 PSIG].

Note:

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1






## <LOW PRESSURE SENSOR>

### • Comparing the Low Pressure Sensor Measurement and Gauge Pressure

By configuring the digital display setting switch (SW1) as shown in the figure below, the pressure as measured by the low pressure sensor appears on the LED1 on the control board.



The figure at left shows that the switches 1 through 4 are set to ON and 5 through 8 are set to OFF.

#### (1) While the outdoor unit is stopped, compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2.

- 1) When the gauge pressure is between 0 and 0.098 MPaG [14 PSIG], internal pressure is caused due to gas leak.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is between 0 and 0.098 MPaG [14 PSIG], the connector may be defective or be disconnected. Check the connector and go to (4).
- 3) When the outdoor temperature is 30°C [86°F] or less, and the pressure displayed on self-diagnosis LED1, 2 exceeds 1.7 MPaG [247 PSIG], go to (3).  
When the outdoor temperature exceeds 30°C [86°F], and the pressure displayed on self-diagnosis LED1, 2 exceeds 1.7 MPaG [247 PSIG], go to (5).
- 4) If other than 1), 2) or 3), compare the pressures while the sensor is running. Go to (2).

#### (2) Compare the gauge pressure and the pressure displayed on self-diagnosis LED1, 2 after 15 minutes have passed since the start of operation. (Compare them by MPaG [PSIG] unit.)

- 1) When the difference between both pressures is within 0.2 MPaG [29 PSIG], both the low pressure sensor and the control board are normal.
- 2) When the difference between both pressures exceeds 0.2 MPaG [29 PSIG], the low pressure sensor has a problem. (performance deterioration)
- 3) When the pressure displayed on the self-diagnosis LED1, 2 does not change, the low pressure sensor has a problem.

#### (3) Remove the low pressure sensor from the control board to check the pressure with the self-diagnosis LED1, 2 display.

- 1) When the pressure displayed on the self-diagnosis LED1,2 is between 0 and 0.098 MPaG [14 PSIG], the low pressure sensor has a problem.
- 2) When the pressure displayed on self-diagnosis LED1, 2 is approximately 1.7 MPaG [247 PSIG], the control board has a problem.

#### (4) Remove the low pressure sensor from the control board, and short-circuit between the pin 2 and pin 3 connectors (63LS) to check the pressure with the self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 1.7 MPaG [247 PSIG], the low pressure sensor has a problem.
- 2) If other than 1), the control board has a problem.

#### (5) Remove the high pressure sensor (63HS) from the control board, and insert it into the connector for the low pressure sensor (63LS) to check the pressure with the self-diagnosis LED1, 2.

- 1) When the pressure displayed on the self-diagnosis LED1, 2 exceeds 1.7 MPaG [247 PSIG], the control board has a problem.
- 2) If other than 1), go to (2).


### • Low Pressure Sensor Configuration (63LS)

The low pressure sensor consists of the circuit shown in the figure below. If 5 VDC is applied between the red and the black wires, voltage corresponding to the pressure between the white and the black wires will be output, and the value of this voltage will be converted by the microprocessor. The output voltage is 0.173 V per 0.098 MPaG [14 PSIG].


Note:

The pressure sensor on the body side is designed to connect to the connector. The connector pin number on the body side is different from that on the control board side.

	Body side	Control board side
Vcc	Pin 1	Pin 3
Vout	Pin 2	Pin 2
GND	Pin 3	Pin 1



Pressure: 0–1.7 MPaG [247 PSIG]  
Vout: 0.5–3.5 V  
0.173 V/0.098 MPaG [14 PSIG]




- ③—①: 5 V(DC)  
②—①: Output Vout (DC)

## 8-7. TEST POINT DIAGRAM

### Outdoor multi controller circuit board

PUMY-SP112VKM(R1).TH      PUMY-SP125VKM(R1).TH      PUMY-SP140VKM(R1).TH  
PUMY-SP112YKM(R1).TH      PUMY-SP125YKM(R1).TH      PUMY-SP140YKM(R1).TH  
PUMY-SP112VKM(R1).TH-BS      PUMY-SP125VKM(R1).TH-BS      PUMY-SP140VKM(R1).TH-BS  
PUMY-SP112YKM(R1).TH-BS      PUMY-SP125YKM(R1).TH-BS      PUMY-SP140YKM(R1).TH-BS

<CAUTION> TEST POINT ① is high voltage.



## Outdoor power circuit board

PUMY-SP112VKM(R1).TH

PUMY-SP125VKM(R1).TH

PUMY-SP140VKM(R1).TH

PUMY-SP112VKM(R1).TH-BS

PUMY-SP125VKM(R1).TH-BS

PUMY-SP140VKM(R1).TH-BS

### Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken.  
Measure the resistance in the following points (connectors, etc.).

#### 1. Check of POWER MODULE

##### ① Check of DIODE circuit

**R** - **P1** **S** - **P1** **R** - **N1** **S** - **N1**

##### ② Check of IGBT circuit

**P2** - **L1**, **P2** - **L2**, **P2** - **L3**, **N2** - **L1**, **N2** - **L2**, **N2** - **L3**

##### ③ Check of INVERTER circuit

**P3** - **U**, **P3** - **V**, **P3** - **W**, **N3** - **U**, **N3** - **V**, **N3** - **W**

Note: The marks **R**, **S**, **L1**, **L2**, **L3**, **P1**, **P2**, **P3**, **N1**, **N2**, **N3**, **U**, **V** and **W** shown in the diagram are not actually printed on the board.

CN2

Connect to the outdoor multi controller circuit board (CN2)

①-⑤: Transmitting signal to outdoor controller circuit board (0-5 VDC)

②-⑤: Zero cross signal (0-5 VDC)

③-④: 15 VDC

⑥-⑤: 15 VDC

⑦-⑤: 15 VDC

CN6  
Thermistor

CN4  
Connect to the outdoor multi controller circuit board (CN4)

U/V/W  
Connect to the compressor (MC)  
Voltage among phases: 10-180VAC

CNAC1  
230 VAC  
Connect to the M-NET power circuit board (CN1)

CNAC2  
230 VAC  
Connect to the outdoor multi controller circuit board (CNAC)

NI, LI  
Voltage of 230 VAC is input  
(Connect to the terminal block (TB1))

TB1A, TB2A, TB3A,  
TB1B, TB2B, TB3B  
Connect to DCL

CNDC  
280-380 VDC (①+, ③-)  
Connect to the outdoor controller circuit board (CNDC)

E1, E3, E4  
Connect to the electrical parts box

## Outdoor power circuit board

PUMY-SP112YKM(R1).TH

PUMY-SP125YKM(R1).TH

PUMY-SP140YKM(R1).TH

PUMY-SP112YKM(R1).TH-BS

PUMY-SP125YKM(R1).TH-BS

PUMY-SP140YKM(R1).TH-BS

### Brief Check of POWER MODULE

If they are short-circuited, it means that they are broken.  
Measure the resistance in the following points (connectors, etc.).


#### 1. Check of DIODE MODULE

L1 - P1, L2 - P1, L3 - P1, L1 - N1, L2 - N1, L3 - N1

#### 2. Check of DIP-IPM

P2 - U, P2 - V, P2 - W, N2 - U, N2 - V, N2 - W

Note: The marks L1, L2, L3, N1, N2, P1, P2, U, V and W shown in the diagram are not actually printed on the board.



## M-NET power circuit board

PUMY-SP112VKM(R1).TH

PUMY-SP112YKM(R1).TH

PUMY-SP112VKM(R1).TH-BS

PUMY-SP112YKM(R1).TH-BS

PUMY-SP125VKM(R1).TH

PUMY-SP125YKM(R1).TH

PUMY-SP125VKM(R1).TH-BS


PUMY-SP125YKM(R1).TH-BS

PUMY-SP140VKM(R1).TH

PUMY-SP140YKM(R1).TH

PUMY-SP140VKM(R1).TH-BS

PUMY-SP140YKM(R1).TH-BS





## Outdoor noise filter circuit board

PUMY-SP112YKM(R1).TH

PUMY-SP125YKM(R1).TH


PUMY-SP140YKM(R1).TH

PUMY-SP112YKM(R1).TH-BS

PUMY-SP125YKM(R1).TH-BS

PUMY-SP140YKM(R1).TH-BS

LI1, LI2, LI3, NI  
POWER SUPPLY  
LI1-LI2/LI2-LI3/LI3-LI1: 400 VAC input  
LI1-NI/LI2-NI/LI3-NI: 230 VAC input  
(Connect to the terminal block (TB1))



## 8-8. OUTDOOR UNIT INFORMATION DISPLAY

SW: setting  
0...OFF  
1...ON

No.	SW1 setting 12345678	Display on the LED1, 2 (display data)								Notes
		1	2	3	4	5	6	7	8	
0	00000000	Compressor operation	52C	21S4	SV1	(SV2)			Always lighting	ON: light on OFF: light off •When abnormality occurs, check display. Light on at time of abnormality
1	10000000	Relay output display	0000-9999 (Alternating display of addresses and check code)	No.3 unit check	No.4 unit check	No.5 unit check	No.6 unit check	No.7 unit check	No.8 unit check	
2	01000000	Check display	Superheat due to low discharge temperature	Compressor shell temperature abnormality	TH4 abnormality	TH3 abnormality	Outdoor fan rotation frequency abnormality	TH7 abnormality	TH8 abnormality	
3	11000000	Protection input	Compressor over current interception	Voltage abnormality	Insufficient refrigerant amount abnormality	Current sensor/primary current abnormality	63LS abnormality	63HS abnormality	start over current interception abnormality delay	Display detected microprocessor protection or abnormality
4	00100000	Protection input	Address double setting abnormality	Indoor unit capacity error	Over capacity	Indoor unit address error	Outdoor unit address error	Current sensor open/short	serial communication abnormality (outdoor unit)	
5	10100000	Abnormality delay display 1	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	Display all abnormalities remaining in abnormality delay
6	01100000	Abnormality delay display 2	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	
7	11100000	Abnormality delay display 3	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by closed valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
8	00010000	Abnormality delay history 1	Superheat due to low discharge temperature delay	Compressor shell temperature abnormality delay	TH4 abnormality delay	TH3 abnormality delay	Outdoor fan rotation frequency abnormality delay	TH7 abnormality delay	TH8 abnormality delay	
9	10010000	Abnormality delay history 2	Compressor over current interception delay	Voltage abnormality delay	Insufficient refrigerant amount abnormality delay	Current sensor/primary current abnormality delay	63LS abnormality delay	63HS abnormality delay	start over current interception abnormality delay	Display all abnormalities remaining in abnormality delay
10	01010000	Abnormality delay history 3	TH2 abnormality delay	4-way valve abnormality delay	Delay caused by closed valve in cooling mode	Power module abnormality delay	TH6 abnormality delay	Current sensor open/short delay		
11	11010000	Abnormality code history 1 (the latest)								
12	00110000	Abnormality code history 2								
13	10110000	Abnormality code history 3								
14	01110000	Abnormality code history 4								
15	11110000	Abnormality code history 5								
16	00001000	Abnormality code history 6								
17	10001000	Abnormality code history 7								
18	01001000	Abnormality code history 8								
19	11001000	Abnormality code history 9								
20	00101000	Abnormality code history 10 (the oldest)								
21	10101000	Cumulative time	0-9999 (unit: 1 hour)							
22	01101000	Cumulative time	0-9999 (unit: 10 hour)							
23	11101000	Outdoor unit operation display	Compressor energizing	Compressor operating prohibition	Abnormality detection					Display of cumulative compressor operating time
24	00011000	Indoor unit operation mode	No. 1 unit mode	No. 2 unit mode	No. 3 unit mode	No. 4 unit mode	No. 5 unit mode	No. 6 unit mode	No. 7 unit mode	Light ON/Light OFF Cooling: light on, Heating: light blinking Stop fan: light off
25	10011000	Indoor unit operation display	No. 1 unit operation	No. 2 unit operation	No. 3 unit operation	No. 4 unit operation	No. 5 unit operation	No. 6 unit operation	No. 7 unit operation	Thermo ON: light on Thermo OFF: light off

- Display abnormalities up to present (including abnormality terminals)
- History record in 1 is the latest; records become older in sequence; history record in 10 is the oldest.

No.		SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes																														
		12345678		1	2	3	4	5	6	7	8																															
26	01011000		Capacity code (No. 1 indoor unit)	0-255								•Display of indoor unit capacity code •The No. 1 unit will start from the M-NET address with the lowest number																														
27	11011000		Capacity code (No. 2 indoor unit)																																							
28	00111000		Capacity code (No. 3 indoor unit)																																							
29	10111000		Capacity code (No. 4 indoor unit)																																							
30	01111000		Capacity code (No. 5 indoor unit)																																							
31	11111000		IC1 operation mode	STOP	Fan	Cooling thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF	3-minutes delay/no	Light on/light off	•Display of indoor unit operating mode																														
32	00000100		IC2 operation mode																																							
33	10000100		IC3 operation mode																																							
34	01000100		IC4 operation mode																																							
35	11000100		IC5 operation mode																																							
36	00100100		OC operation mode	Compressor ON/OFF	Heating/Cooling	Abnormal/normal	DEFROST/NO	Refrigerant pull back/no	Excitation current/no	3-minutes delay/no	Light on/light off	•Display of indoor unit operating mode																														
37	10100100		External connection status																																							
38	01100100		Communication demand capacity																																							
39	11100100		Number of compressor ON/OFF																																							
40	00010100		Compressor operating current																																							
41	10010100		Input current of outdoor unit	0-999.9 (Arms)								Display a count of compressor operation/stop																														
42	01010100		Thermo-ON operating time	0000-9999 (unit: x10)								Display detected current																														
43	11010100		Total capacity of thermo-ON	0-255								Display cumulative time of thermo-ON operation																														
44	00110100		Number of indoor units	0-255								Display total capacity code of indoor units in thermo-ON																														
45	10110100		DC bus voltage	0-9999 (V)								Display number of connected indoor units																														
46	01110100		State of LEV control	Td over heat prevention	SHd decrease prevention	Minimum Sj correction depends on Td	Minimum Sj correction depends on SHd	LEV opening correction depends on Pd	LEV opening correction depends on Td	Correction of high compression ratio prevention	Freeze prevention control at the beginning of SHd	Display active LEV control																														
47	11110100		State of compressor frequency control 1	Condensing temperature limit control	Compressor temperature control		Discharge temp. (heating) backup control	Pd abnormality control (heating)	Pd Back up control(heating)			Display active compressor frequency control																														
48	00001100		State of compressor frequency control 2	Heat sink over heat prevention control	Secondary current control	Input current control		Frequency restrain of receipt voltage change	Low pressure decrease prevention	Hz-up inhibit control at the beginning of SHd																																
49	10001100		Protection input	63LS abnormality	HIC abnormality		Frozen protection	4-way valve disconnection abnormality	Delay caused by closed valve in cooling mode	TH6 abnormality	Power module abnormality																															
50	01001100		The second current value when microprocessor of POWER BOARD abnormality is detected	0-999.9[Arms]								Display data at time of abnormality																														
51	11001100		Heatsink temperature when microprocessor of POWER BOARD abnormality is detected	-99.9-999.9 (°C)																																						
<table><tr><th colspan="2">State of compressor frequency(Hz) control</th><th>Content</th></tr><tr><td colspan="2">Discharge pressure control</td><td>Hz control by pressure limitation</td></tr><tr><td colspan="2">Compressor temperature control</td><td>Hz control by discharge temperature limitation</td></tr><tr><td colspan="2">SV control</td><td>Hz control by bypass valve</td></tr><tr><td colspan="2">Abnormal rise of Pd control</td><td>Control that restrains abnormal rise of discharge pressure</td></tr><tr><td colspan="2">Heat sink over heat prevention control</td><td>Heat sink over heat prevention control</td></tr><tr><td colspan="2">Secondary current control</td><td>Secondary current control</td></tr><tr><td colspan="2">Input current control</td><td>Input current control</td></tr><tr><td colspan="2">Hz correction of receipt voltage decrease prevention</td><td>Max.Hz correction control due to voltage decrease</td></tr><tr><td colspan="2">Hz restrain of receipt voltage change</td><td>Max.Hz correction control due to receipt voltage change</td></tr></table>													State of compressor frequency(Hz) control		Content	Discharge pressure control		Hz control by pressure limitation	Compressor temperature control		Hz control by discharge temperature limitation	SV control		Hz control by bypass valve	Abnormal rise of Pd control		Control that restrains abnormal rise of discharge pressure	Heat sink over heat prevention control		Heat sink over heat prevention control	Secondary current control		Secondary current control	Input current control		Input current control	Hz correction of receipt voltage decrease prevention		Max.Hz correction control due to voltage decrease	Hz restrain of receipt voltage change		Max.Hz correction control due to receipt voltage change
State of compressor frequency(Hz) control		Content																																								
Discharge pressure control		Hz control by pressure limitation																																								
Compressor temperature control		Hz control by discharge temperature limitation																																								
SV control		Hz control by bypass valve																																								
Abnormal rise of Pd control		Control that restrains abnormal rise of discharge pressure																																								
Heat sink over heat prevention control		Heat sink over heat prevention control																																								
Secondary current control		Secondary current control																																								
Input current control		Input current control																																								
Hz correction of receipt voltage decrease prevention		Max.Hz correction control due to voltage decrease																																								
Hz restrain of receipt voltage change		Max.Hz correction control due to receipt voltage change																																								



No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
52	00101100	Outdoor LEV-A opening pulse	0-2000 (pulse)								Display of opening pulse of outdoor LEV
53	10101100	Outdoor LEV-A opening pulse abnormality delay									
54	01101100	Outdoor LEV-A opening pulse abnormality									
55	11101100	Outdoor LEV-B opening pulse									
56	00011100	Outdoor LEV-B opening pulse abnormality delay									
57	10011100	Outdoor LEV-B opening pulse abnormality									
58	01011100	63LS (Low pressure)	-99.9-999.9 (kgf/cm <sup>2</sup> )								Display of data from sensor and thermistor
59	11011100	63LS abnormality delay	-99.9-999.9 (kgf/cm <sup>2</sup> )								
60	00111100	63 LS abnormality	-99.9-999.9 (°C)								
61	10111100	TH2 (HIC pipe)	-99.9-999.9 (°C)								
62	01111100	TH2(HIC) abnormality delay	-99.9-999.9 (°C)								Display of actual operating frequency
63	11111100	TH2 (HIC) abnormality	0-255 (Hz)								
64	00000010	Operational frequency	0-255 (Hz)								
65	10000010	Target frequency	0-255 (Hz)								Display of target frequency
66	01000010	Outdoor fan control step number	0-15								Display of number of outdoor fan control steps (target)
69	10100010	IC1 LEV Opening pulse	0-2000 (pulse)								Display of opening pulse of indoor LEV
70	01100010	IC2 LEV Opening pulse									
71	11100010	IC3 LEV Opening pulse									
72	00010010	IC4 LEV Opening pulse									
73	10010010	IC5 LEV Opening pulse									
74	01010010	High pressure sensor (Pdt)	-99.9-999.9 (kgf/cm <sup>2</sup> )								Display detected data of outdoor unit sensors and thermistors
75	11010010	TH4(Compressor)Td data	-99.9-999.9 (°C)								
76	00110010	TH6(Suction pipe)ET data									
77	10110010	TH7(Ambient) data									
78	01110010	TH3(Outdoor liquid pipe) data									
80	00001010	TH8(Heat sink) data									Display detected data of indoor unit thermistor
81	10001010	IC1 TH23 (Gas)									
82	01001010	IC2 TH23 (Gas)									
83	11001010	IC3 TH23 (Gas)									
84	00101010	IC4 TH23 (Gas)									
85	10101010	IC5 TH23 (Gas)									

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
86	01101010	IC1 TH22 (Liquid)	-99.9~999.9 (°C) (When the indoor unit is not connected, it is displayed as 0.)								Display detected data of indoor unit thermistors
87	11101010	IC2 TH22 (Liquid)									
88	00011010	IC3 TH22 (Liquid)									
89	10011010	IC4 TH22 (Liquid)									
90	01011010	IC5 TH22 (Liquid)									
91	11011010	IC1 TH21 (Intake)									
92	00111010	IC2 TH21 (Intake)									
93	10111010	IC3 TH21 (Intake)									
94	01111010	IC4 TH21 (Intake)									
95	11111010	IC5 TH21 (Intake)									
96	00000110	Outdoor SC (cooling)	-99.9~999.9 (°C)								Display of outdoor subcool (SC) data
97	10000110	Target subcool step	-2~4								Display of target subcool step data
98	01000110	IC1 SC/SH	-99.9~999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
99	11000110	IC2 SC/SH									
100	00100110	IC3 SC/SH									
101	10100110	IC4 SC/SH									
102	01100110	IC5 SC/SH	-99.9~999.9 (°C) Pdm (0.0~30.0) (kgf/cm <sup>2</sup> ) ETm (-2.0~23.0) (°C) SCm (0.0~20.0) (°C)								Display of all control target data
103	11100110	Discharge superheat (SHd)									
105	10010110	Target Ptd display (heating) kgf/F									
106	01010110	Target ET display (cooling)									
107	11010110	Target outdoor SC (cooling)	SCm/SHm (0.0~20.0) (°C)								Light on at time of abnormality COOL/DRY: light on HEAT: light blinking FAN/STOP: light off Thermo-ON: light on Thermo-OFF: light off Display of indoor unit operation mode
108	00110110	Target indoor SC/SH (IC1)									
109	10110110	Target indoor SC/SH (IC2)									
110	01110110	Target indoor SC/SH (IC3)									
111	11110110	Target indoor SC/SH (IC4)									
112	00001110	Target indoor SC/SH (IC5)									
113	10001110	Indoor unit check status (IC9-12)		No.9 unit check	No.10 unit check	No.11 unit check	No.12 unit check				
114	01001110	Indoor unit operation mode (IC9-12)		No.9 unit mode	No.10 unit mode	No.11 unit mode	No.12 unit mode				
115	11001110	Indoor unit operation display (IC9-12)		No.9 unit operation	No.10 unit operation	No.11 unit operation	No.12 unit operation				
116	00101110	IC9 operation mode		STOP	Fan	Cooling Thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF		
117	10101110	IC10 operation mode									
118	01101110	IC11 operation mode									
119	11101110	IC12 operation mode									
120	00011110	Target indoor SC/SH (IC9)	SCm/SHm (0.0~20.0) (°C)								Display of all control target data
121	10011110	Target indoor SC/SH (IC10)									
122	01011110	Target indoor SC/SH (IC11)									
123	11011110	Target indoor SC/SH (IC12)									
124	00111110	IC9 LEV opening pulse abnormality delay	0~2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality delay
125	10111110	IC10 LEV opening pulse abnormality delay									
126	01111110	IC11 LEV opening pulse abnormality delay									
127	11111110	IC12 LEV opening pulse abnormality delay									



No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes	
			1	2	3	4	5	6	7	8		
128	00000001	Actual frequency of abnormality delay	0-255 (Hz)								Display of actual frequency at time of abnormality delay	
129	10110001	Fan step number at time of abnormality delay	0-15								Display of fan step number at time of abnormality delay	
131	11000001	IC1 LEV opening pulse abnormality delay	0-2000 (pulse)								Delay of opening pulse of indoor LEV at time of abnormality delay	
132	00100001	IC2 LEV opening pulse abnormality delay										
133	10100001	IC3 LEV opening pulse abnormality delay										
134	01100001	IC4 LEV opening pulse abnormality delay										
135	11100001	IC5 LEV opening pulse abnormality delay										
136	00010001	High pressure sensor data at time of abnormality delay kgf/cm2	-99.9-999.9 (kgf/cm²)								Display of data from High pressure sensor, all thermistors, and SC/SH at time of abnormality delay	
137	10010001	TH4 (Compressor) sensor data at time of abnormality delay	-99.9-999.9 (°C)									
138	01010001	TH6 (Suction pipe) sensor data at time of abnormality delay										
139	11010001	TH3 (Outdoor liquid pipe) sensor data at time of abnormality delay										
140	00110001	TH8 (Heat sink) sensor data at time of abnormality delay										
141	10110001	OC SC (cooling) at time of abnormality delay	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)									
142	01110001	IC1 SC/SH at time of abnormality delay										
143	11110001	IC2 SC/SH at time of abnormality delay										
144	00001001	IC3 SC/SH at time of abnormality delay										
145	10001001	IC4 SC/SH at time of abnormality delay										
146	01001001	IC5 SC/SH at time of abnormality delay										
147	11001001	IC9 SC/SH at time of abnormality delay										
148	00100001	IC10 SC/SH at time of abnormality delay										
149	10101001	IC11 SC/SH at time of abnormality delay										
150	01101001	IC12 SC/SH at time of abnormality delay										

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
151	11101001	IC9 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality
152	00011001	IC10 LEV opening pulse at time of abnormality									
153	10011001	IC11 LEV opening pulse at time of abnormality									
154	01011001	IC12 LEV opening pulse at time of abnormality									
155	11011001	IC9 SC/SH at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality
156	00111001	IC10 SC/SH at time of abnormality									
157	10111001	IC11 SC/SH at time of abnormality									
158	01111001	IC12 SC/SH at time of abnormality									
159	11111001	IC9 Capacity code	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number
160	00000101	IC10 Capacity code									
161	10000101	IC11 Capacity code									
162	01000101	IC12 Capacity code									
163	11000101	IC9 SC/SH	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data
164	00100101	IC10 SC/SH									
165	10100101	IC11 SC/SH									
166	01000101	IC12 SC/SH									
170	01010101	ROM version monitor	0.00-99.99 (ver)								Display of version data of ROM
171	11010101	ROM type									Display of ROM type
172	00110101	Check sum mode	0000-FFFF								Display of check sum code of ROM
173	10110101	IC9 TH23 (Gas)	-99.9-999.9 (°C)								Display detected data of indoor unit thermistors
174	01110101	IC10 TH23 (Gas)									
175	11110101	IC11 TH23 (Gas)									
176	00001101	IC12 TH23 (Gas)									
177	10001101	IC9 TH22 (Liquid)									
178	01001101	IC10 TH22 (Liquid)									
179	11001101	IC11 TH22 (Liquid)									
180	00101101	IC12 TH22 (Liquid)									
185	10011101	IC9 TH21 (Intake)									
186	01011101	IC10 TH21 (Intake)									
187	11011101	IC11 TH21 (Intake)									
188	00111101	IC12 TH21 (Intake)									
189	10111101	History of voltage error (U9/4220)	-	-	PAM error	Converter Fault	Power synchronization signal error	L1 open phase error	Under voltage error	Over voltage error	
190	01111101	External connection status at time of abnormality delay	CN3N 1-3 input	CN3N 1-2 input	CN3S 1-2 input	CN3D 1-3 input	CN3D 1-2 input	CN3D 1-2 input			
191	11111101	External connection status at time of abnormality	CN3N 1-3 input	CN3N 1-2 input	CN3S 1-2 input	CN3D 1-3 input	CN3D 1-2 input	CN3D 1-2 input			

No.	SW1 setting 12345678	Display mode	Display on the LED1, 2 (display data)								Notes						
			1	2	3	4	5	6	7	8							
192	00000011	Actual frequency of abnormality	0-255 (Hz)								Display of actual frequency at time of abnormality						
193	10000011	Fan step number at time of abnormality	0-15								Display of fan step number at time of abnormality						
195	11000011	IC1 LEV opening pulse at time of abnormality	0-2000 (pulse)								Display of opening pulse of indoor LEV at time of abnormality						
196	00100011	IC2 LEV opening pulse at time of abnormality															
197	10100011	IC3 LEV opening pulse at time of abnormality															
198	01100011	IC4 LEV opening pulse at time of abnormality															
199	11100011	IC5 LEV opening pulse at time of abnormality															
200	00010011	High pressure sensor data at time of abnormality	-99.9-999.9 (kgf/cm <sup>2</sup> )								Display of data from High pressure sensor; all thermistors, and SC/SH at time of abnormality.						
201	10010011	TH4 (Compressor) sensor data at time of abnormality															
202	01010011	TH6 (Suction pipe) sensor data at time of abnormality															
203	11010011	TH3 (Outdoor liquid pipe) sensor data at time of abnormality															
204	00110011	TH8 (Heat sink) sensor data at time of abnormality															
205	10110011	OC SC (cooling) at time of abnormality	-99.9-999.9(°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)								Display of indoor SC/SH data at time of abnormality						
206	01110011	IC1 SC/SH at time of abnormality															
207	11110011	IC2 SC/SH at time of abnormality															
208	00001011	IC3 SC/SH at time of abnormality															
209	10001011	IC4 SC/SH at time of abnormality															
210	01001011	IC5 SC/SH at time of abnormality	0-255								Display of indoor unit capacity code The No.1 unit will start from the M-NET address with the lowest number						
211	11001011	IC6 Capacity code															
212	00101011	IC7 Capacity code															
213	10101011	IC8 Capacity code															
214	01101011	IC6 operation mode	STOP	Fan	Cooling thermo-ON	Cooling thermo-OFF	Heating thermo-ON	Heating thermo-OFF		Display of indoor unit operation mode							
215	11101011	IC7 operation mode															
216	00011011	IC8 operation mode	0-2000 (pulse)								Display of opening pulse of indoor LEV						
217	10011011	IC6 LEV opening pulse															
218	01011001	IC7 LEV opening pulse															
219	11011001	IC8 LEV opening pulse															

No.	SW1 setting	Display mode	Display on the LED1, 2 (display data)								Notes
			1	2	3	4	5	6	7	8	
220	00111011	IC6 TH23 (Gas)	-99.9~999.9 (°C)							Display detected data of indoor unit thermistor	
221	10111011	IC7 TH23 (Gas)									
222	01111011	IC8 TH23 (Gas)									
223	11111011	IC6 TH22 (liquid)									
224	00000111	IC7 TH22 (liquid)									
225	10000111	IC8 TH22 (liquid)									
226	01000111	IC6 TH21 (intake)									
227	11000111	IC7 TH21 (intake)									
228	00100111	IC8 TH21 (intake)									
229	10100111	IC6 SC/SH	-99.9~999.9 (°C) during heating: subcool (SC)/during cooling: superheat (SH) (Fixed to "0" during cooling operation)						Display of indoor SC/SH data		
230	01100111	IC7 SC/SH									
231	11100111	IC8 SC/SH									
232	00010111	Target indoor SC/SH (IC6)	SCm/SHm (0.0~20.0) (°C)							Display of all control target data	
233	10010111	Target indoor SC/SH (IC7)									
234	01010111	Target indoor SC/SH (IC8)									
235	11010111	IC6 LEV opening pulse abnormality delay	0~2000 (pulse)							Display of opening pulse of indoor LEV at time of abnormality delay	
236	00110111	IC7 LEV opening pulse abnormality delay									
237	10110111	IC8 LEV opening pulse abnormality delay									
238	01110111	IC6 SC/SH at time of abnormality delay	-99.9~999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)							Display of indoor SC/SH data at time of abnormality delay	
239	11110111	IC7 SC/SH at time of abnormality delay									
240	00001111	IC8 SC/SH at time of abnormality delay									
241	10001111	IC6 LEV opening pulse at time of abnormality	0~2000 (pulse)							Display of opening pulse of indoor LEV at time of abnormality	
242	01001111	IC7EV opening pulse at time of abnormality									
243	11001111	IC8 LEV opening pulse at time of abnormality									
244	00101111	IC6 SC/SH at time of abnormality	-99.9~999.9 (°C) During heating: subcool (SC) During cooling: superheat (SH) (Fixed to "0" during cooling operation)							Display of indoor SC/SH data at time of abnormality delay	
245	10101111	IC7 SC/SH at time of abnormality									
246	01101111	IC8 SC/SH at time of abnormality									
250	01011111	IC9 LEV opening pulse	0~2000 (pulse)							Display of opening pulse of indoor LEV	
251	11011111	IC10 LEV opening pulse									
252	00111111	IC11 LEV opening pulse									
253	10111111	IC12 LEV opening pulse									

This chapter provides an introduction to electrical wiring for the CITY MULTI series, together with notes concerning power wiring, wiring for control (transmission wires and remote controller wires), and the frequency converter.

### 9-1. OVERVIEW OF POWER WIRING

- (1) Use a separate power supply for the outdoor unit and indoor unit.
- (2) Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.
- (3) The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops. Make sure the power-supply voltage does not drop more than 10 %.
- (4) Specific wiring requirements should adhere to the wiring regulations of the region.
- (5) Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.
- (6) Install an earth line longer than power cables.

#### ⚠ Warning:

- Be sure to use specified wires to connect so that no external force is imparted to terminal connections. If connections are not fixed firmly, it may cause heating or fire.
- Be sure to use the appropriate type of overcurrent protection switch. Note that generated overcurrent may include some amount of direct current.

#### ⚠ Caution:


- Some installation site may require attachment of an earth leakage breaker. If no earth leakage breaker is installed, it may cause an electric shock.
- Do not use anything other than breaker and fuse with correct capacity. Using fuse and wire or copper wire with too large capacity may cause a malfunction of unit or fire.
- Be sure to install N-Line. Without N-Line, it could cause damage to the unit.

### 9-2. WIRING OF MAIN POWER SUPPLY AND EQUIPMENT CAPACITY

#### 9-2-1. Wiring diagram for main power supply

##### ■ Schematic Drawing of Wiring: When NOT using a Branch Box (example)


PUMY-SP•VKM series



##### ■ Schematic Drawing of Wiring: When using a Branch Box (example)


<When power is supplied from the outdoor unit>

PUMY-SP•VKM series



<When power is supplied separately>


#### PUMY-SP•VKM series



#### ■ Schematic Drawing of Wiring: When using a Branch Box and M -NET control indoor unit (example)

<When power is supplied separately>

#### PUMY-SP•VKM series




#### PUMY-SP•YKM series



<When power is supplied from the outdoor unit>

#### PUMY-SP•VKM series





## 9-2-2. Cross section area of Wire for Main Power and ON/OFF capacities

PUMY-SP112VKM(R1).TH PUMY-SP125VKM(R1).TH PUMY-SP140VKM(R1).TH  
PUMY-SP112YKM(R1).TH PUMY-SP125YKM(R1).TH PUMY-SP140YKM(R1).TH  
PUMY-SP112VKM(R1).TH-BS PUMY-SP125VKM(R1).TH-BS PUMY-SP140VKM(R1).TH-BS  
PUMY-SP112YKM(R1).TH-BS PUMY-SP125YKM(R1).TH-BS PUMY-SP140YKM(R1).TH-BS

<Outdoor unit> <When power is supplied to outdoor unit and branch box separately>

Model		Power Supply	Minimum Wire Cross-sectional area (mm <sup>2</sup> )			Breaker for Wiring *1	Breaker for Current Leakage
			Main Cable	Branch	Ground		
Outdoor Unit	SP112-140V	~N 220-230-240V, 50 Hz ~N 220 V, 60 Hz	6	—	6	32 A	32 A 30 mA 0.1 seconds or less
	SP112-140Y	3N~380-400-415V, 50 Hz 3N~380 V, 60 Hz *2	1.5	—	1.5	16 A	16 A 30 mA 0.1 seconds or less

<Outdoor unit> <When power is supplied to branch box from the outdoor unit>

Model		Power Supply	Minimum Wire Cross-sectional area (mm <sup>2</sup> )			Breaker for Wiring *1	Breaker for Current Leakage
			Main Cable	Branch	Ground		
Outdoor Unit	SP112-140V	~N 220-230-240V, 50 Hz ~N 220 V, 60 Hz	6	—	6	40 A	40 A 30 mA 0.1 seconds or less
	SP112-140Y	3N~380-400-415V, 50 Hz 3N~380 V, 60 Hz *2	2.5	—	2.5	25 A	25 A 30 mA 0.1 seconds or less

\*1 A breaker with at least 3.0 mm contact separation in each poles shall be provided. Use non-fuse breaker (NF) or earth leakage breaker (NV).

\*2 In multi-phase appliances, the colour of the neutral conductor of the supply cord, if any, shall be blue.

<Indoor units> \*When power is supplied to indoor unit and outdoor unit separately

Total operating current of the indoor unit	Minimum wire thickness (mm <sup>2</sup> )			Ground-fault interrupter *3	Local switch (A)		Breaker for wiring (NFB)
	Main Cable	Branch	Ground		Capacity	Fuse	
F0 = 16 A or less *4	1.5	1.5	1.5	20 A current sensitivity *5	16	16	20
F0 = 25 A or less *4	2.5	2.5	2.5	30 A current sensitivity *5	25	25	30
F0 = 32 A or less *4	4.0	4.0	4.0	40 A current sensitivity *5	32	32	40

Apply to IEC61000-3-3 about max. permissive system impedance.

\*3 The Ground-fault interrupter should support inverter circuit.

The Ground-fault interrupter should combine using of local switch or wiring breaker.

\*4 Please take the larger of F1 or F2 as the value for F0.

F1 = Total operating maximum current of the indoor units × 1.2

F2 = F2 = {V1 × (Quantity of Type 1)/C} + {V1 × (Quantity of Type 2)/C} + {V1 × (Quantity of Type 3)/C} + ... + {V1 × (Quantity of Type 15)/C}

Connect to Branch box (PAC-MK-BC)

Indoor unit	V1	V2
Type 1 PEAD-RP-JAQ(L).UK, PEAD-M-JA(L)	26.9	2.4
Type 2 SEZ-KD-VA, SEZ-M-DA, PCA-RP-KAQ, PCA-M-KA, PLA-RP-EA(.UK), PLA-M-EA(.UK)	19.8	
Type 3 SLZ-KF-VA, SLZ-M-FA	17.1	
Type 4 MLZ-KA-VA, MLZ-KP-VF	9.9	
Type 5 MSZ-LN-VG, MSZ-AP-VF, MSZ-AP-VG, MFZ-KJ-VE	7.4	
Type 6 MSZ-FH-VE, MSZ-GF-VE, MSZ-SF-VE, MSZ-EF-VE, MSZ-SF-VA, MSZ-GE-VA, MSZ-EF-VG	6.8	
Type 7 Branch box (PAC-MK-BC(B))	5.1	3.0

Connect to Connection kit (PAC-LV11M)

Indoor unit	V1	V2
Type 8 MSZ-LN-VG, MSZ-AP-VF, MSZ-AP-VG	7.4	2.4
Type 9 MSZ-SF-VA, MSZ-SF-VE, MSZ-EF-VE, MSZ-FH-VE, MSZ-GE-VA, MSZ-EF-VG	6.8	
Type10 Connection kit (PAC-LV11M)	3.5	

Indoor unit	V1	V2
Type 11 PEFY-P-VMA(L)-E, PEFY-P-VMA3-E	38.0	1.6
Type 12 PMFY-P-VBM-E, PLFY-P-VBM-E, PLFY-P-VEM-E, PLFY-EP-VEM-E, PLFY-P-VFM-E, PEFY-P-VMS1(L)-E, PCFY-P-VKM-E, PKFY-P-VHM-E, PKFY-P-VKM-E, PFFY-P-VCM-E, PFFY-P-VKM-E, PFFY-P-VLRMM-E, PKFY-PVLM-E/ET	19.8	2.4
Type 13 PLFY-P-VCM-E	9.9	
Type 14 PKFY-P-VBM-E	3.5	
Type 15 PLFY-P-VLMD-E, PEFY-P-VMH-E, PEFY-P-VMR-E-L/R, PEFY-P-VMH-E-F, PFFY-P-VLEM-E, PFFY-P-VLRM-E, GUF*4-RD(H)4	0	0

C: Multiple of tripping current at tripping time 0.01 s

Please pick up "C" from the tripping characteristic of the breaker.

<Example of "F2" calculation>

Condition PLFY-P-VBM-E × 4 + PEFY-P-VMA-E × 1, C = 8 (refer to right sample chart)

F2 = 19.8 × 4/8 + 38 × 1/8

= 14.65

→ 16 A breaker (Tripping current = 8 × 16 A at 0.01 s)

\*5 Current sensitivity is calculated using the following formula.

G1 = V2 × (Quantity of Type1) + V2 × (Quantity of Type2) + V2 × (Quantity of Type3) + ... + V2 × (Quantity of Type15) + V3 × (Wire length[km])

<Example of "G1" calculation>


When connecting 3 units of the SEZ-KD respectively to a branch box with a wire that is 20 m long and 1.5 mm<sup>2</sup> in diameter, then connecting the branch box and PEFY-VMA to a single breaker with a wire that is 100 m long in total and 2.5 mm<sup>2</sup> in diameter.

G1 = 2.4 × 3 + 3 + 1.6 + 48 × 0.02 × 3 + 56 × 0.1

= 20.28

G1	Current sensitivity
30 or less	30 mA 0.1 seconds or less
100 or less	100 mA 0.1 seconds or less

Wire thickness	V3
1.5 mm <sup>2</sup>	48
2.5 mm <sup>2</sup>	56
4.0 mm <sup>2</sup>	66



1. Bear in mind ambient conditions (ambient temperature, direct sunlight, rain water, etc.) when proceeding with the wiring and connections.

2. The wire size is the minimum value for metal conduit wiring. The power cord size should be 1 rank thicker consideration of voltage drops.

Make sure the power-supply voltage does not drop more than 10%.

3. Specific wiring requirements should adhere to the wiring regulations of the region.

4. Power supply cords of parts of appliances for outdoor use shall not be lighter than polychloroprene sheathed flexible cord (design 60245 IEC57). For example, use wiring such as YZW.

5. Install an earth line longer than power cables.

## 9-3. DESIGN FOR CONTROL WIRING

Please note that the types and numbers of control wires needed by the CITY MULTI series depend on the remote controllers and whether they are linked with the system or not.

### 9-3-1. Selection number of control wires

Use		M-NET remote controller
Remote controller → indoor unit		Remote controller used in system control operations. • Group operation involving different refrigerant systems. • Linked operation with upper control system.
Transmission wires	Wires connecting → indoor units	2-core wire (non-polar)
	Wires connecting → indoor units with outdoor unit	
	Wires connecting → outdoor units	

## 9-4. WIRING TRANSMISSION CABLES

### 9-4-1. Types of control cables

#### 1. Wiring transmission cables

Types of transmission cables	Shielding wire CVVS, CPEVS, or MVVS
Cable diameter	More than 1.25 mm <sup>2</sup>
Maximum wiring length	Within 200 m

#### 2. M-NET Remote control cables

Types of remote control cables	Shielding wire (2-core) CVVS, CPEVS, or MVVS
Cable diameter	0.5 to 1.25 mm <sup>2</sup>
Remarks	When 10 m is exceeded, use a cable with the same specifications as transmission line wiring.

#### 3. MA Remote control cables

Type of remote control cable	Sheathed 2-core cable (unshielded) CVV
Cable diameter	0.3 to 1.25 mm <sup>2</sup> (0.75 to 1.25 mm <sup>2</sup> )*
Remarks	Within 200 m

\* Connected with simple remote controller.

### 9-4-2. Wiring examples

• Controller name, symbol and allowable number of controllers.

Name		Symbol	Allowable number of controllers	
Outdoor unit controller		OC	—	
Indoor unit controller	CITY MULTI Series	M-IC	PUMY-SP112	1 to 12 units per 1 OC* <sup>1</sup>
			PUMY-SP125	
			PUMY-SP140	
	M, S, P Series	A-IC	PUMY-SP112	2 to 8 units per 1 OC* <sup>1</sup>
			PUMY-SP125	
			PUMY-SP140	
Branch box		BC	0 to 2 units per 1 OC* <sup>1</sup>	
Remote controller	M-NET	M-NET RC* <sup>2</sup>	Maximum of 12 controllers for 1 OC* <sup>1</sup> (Cannot be connected if Branch box is used.)	
	MA	MA-RC	Maximum of 2 per group	
	Wireless	WL-RC		

\*<sup>1</sup> The number of connectable units may be limited by some conditions such as an indoor unit's capacity or each unit's equivalent power consumption.  
(Refer to DATA BOOK.)


\*<sup>2</sup> Do not use the Lossnay controller (PZ-61DR-E, PZ-43SMF-E, PZ-52SF-E, PZ-60DR-E).

## 9-5. SYSTEM SWITCH SETTING

In order to identify the destinations of signals to the outdoor units, indoor units, and remote controller of the CITY MULTI series, each microprocessor must be assigned an identification number (address). The addresses of outdoor units, indoor units, and remote controller must be set using their settings switches. Please consult the installation manual that comes with each unit for detailed information on setting procedures.


## 9-6. EXAMPLE EXTERNAL WIRING DIAGRAM FOR A BASIC SYSTEM (USING PUMY-SP·YKM)

### ■ Example of system when using an M-NET controller




### ■ Example of system when using a Branch Box

<When power is supplied separately>



<When power is supplied from outdoor unit>



## 9-7. METHOD FOR OBTAINING ELECTRICAL CHARACTERISTICS WHEN A CAPACITY AGREEMENT IS TO BE SIGNED WITH AN ELECTRIC POWER COMPANY

The electrical characteristics of connected indoor unit system for air conditioning systems, including the CITY MULTI series, depend on the arrangement of the indoor and outdoor units.

First read the data on the selected indoor and outdoor units and then use the following formulas to calculate the electrical characteristics before applying for a capacity agreement with the local electric power company.

### 9-7-1. Obtaining the electrical characteristics of the CITY MULTI series system

#### (1) Procedure for obtaining total power consumption

	Page numbers in this technical manual	Power consumption
Total power consumption of each indoor unit	See the technical manual of each indoor unit.	①
Power consumption of outdoor unit*	Standard capacity diagram— Refer to 4-3.	②
Total power consumption of system	See the technical manual of each indoor unit.	①+② <kW>

\*The power consumption of the outdoor unit will vary depending on the total capacity of the selected indoor units.

#### (2) Method of obtaining total current

	Page numbers in this technical manual	Subtotal
Total current through each indoor unit	See the technical manual of each indoor unit.	①
Current through outdoor unit*	Standard capacity diagram— Refer to 4-3.	②
Total current through system	See the technical manual of each indoor unit.	①+② <A>

\*The current through the outdoor unit will vary depending on the total capacity of the selected indoor units.

#### (3) Method of obtaining system power factor

Use the following formula and the total power and current obtained in parts ① and ② on the above tables to calculate the system power factor.

$$\text{System power factor} = \frac{(\text{Total system power consumption})}{(\text{Total system current} \times \text{voltage})} \times 100 \%$$


### 9-7-2. Applying to an electric power company for power and total current

Calculations should be performed separately for heating and cooling employing the same methods; use the largest resulting value in your application to the electric power company.

## 10-1. REFRIGERANT PIPING SYSTEM

**Line-Branch Method**

Connection Examples  
(Connecting to 4 Indoor Units)



Permissible Length	Total Piping Length	$A+B+C+a+b+c+d \leq 120 \text{ m}$
	Farthest Piping Length (L)	$A+B+C+d \leq 70 \text{ m}$
	Farthest Piping Length After First Branch (l)	$B+C+d \leq 50 \text{ m}$
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	50 meters or less (If the outdoor unit is lower, 30 meters or less)
	High/Low Difference in Indoor/Indoor Section (h)	15 meters or less

**■ Selecting the Refrigerant Branch Kit**

Use an optional branch piping kit (CMY-Y62-G-E).

**■ Select Each Section of Refrigerant Piping**

- (1) Section From Outdoor Unit to First Branch (A)  
(2) Section From Branch to Indoor Unit (a,b,c,d)  
(3) Section From Branch to Branch (B,C)
- Each Section of Piping

Select the size from the table to the right.

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)  
(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)

Model	Piping Diameter (mm)	
PUMY-SP112	Liquid Line	ø9.52
PUMY-SP125	Gas Line	ø15.88
PUMY-SP140		

Model number	Piping Diameter (mm)	
50 or lower	Liquid Line	$l \leq 30 \text{ m}$ ø6.35
	Gas Line	$l > 30 \text{ m}$ ø9.52
63 to 140	Liquid Line	ø9.52
	Gas Line	ø15.88

- (3) Refrigerant Piping Diameter In Section From Branch to Branch

Liquid Line (mm)	Gas Line (mm)
ø9.52	ø15.88

Note:  
When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT when selecting the pipe size and piping length.

**■ Additional refrigerant charge**

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

**Calculation of additional refrigerant charge**

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.1 kg, round up the calculated additional refrigerant charge.  
(For example, if the calculated charge is 6.01 kg, round up the charge to 6.1 kg.)

<Additional Charge>

**Calculation of refrigerant charge**

Pipe size	Pipe size		Pipe size
Liquid pipe		+	Liquid pipe
ø6.35 mm			ø9.52 mm
(m) × 19.0 (g/m)			(m) × 50.0 (g/m)

Total capacity of connected indoor units	Amount for the indoor units
up to 8.0 kW	1.5 kg
8.1 to 16.0 kW	2.5 kg
16.1 kW or above	3.0 kg

**Included refrigerant amount when shipped from the factory**

Included refrigerant amount
3.5 kg

<Example>

Outdoor model : SP125

Indoor 1 : P63 (7.1 kW)  
2 : P40 (4.5 kW)  
3 : P25 (2.8 kW)  
4 : P20 (2.2 kW)

A : ø9.52 mm 20 m  
B : ø9.52 mm 5 m  
C : ø9.52 mm 5 m  
a : ø9.52 mm 15 m  
b : ø6.35 mm 10 m  
c : ø6.35 mm 10 m  
d : ø6.35 mm 20 m

At the conditions below:

The total length of each liquid line is as follows:  
ø9.52 :  $A + B + C + a = 20 + 5 + 5 + 15 = 45 \text{ m}$   
ø6.35 :  $b + c + d = 10 + 10 + 20 = 40 \text{ m}$


The total capacity of connected indoor unit is as follows:  
 $7.1 + 4.5 + 2.8 + 2.2 = 16.6$

<Calculation example>

Additional refrigerant charge

$$40 \times \frac{19.0}{1000} + 45 \times \frac{50.0}{1000} + 3.0 = 6.1 \text{ kg (rounded up)}$$

**Header-Branch Method**  
Connection Examples  
(Connecting to 4 Indoor Units)




Permissible Length	Total Piping Length	A+a+b+c+d ≤ 120 m																									
	Farthest Piping Length (L)	A+d ≤ 70 m																									
	Farthest Piping Length After First Branch ( ℓ )	d is 50 meters or less																									
Permissible High/Low Difference	High/Low Difference in Indoor/Outdoor Section (H)	50 meters or less (If the outdoor unit is lower, 30 meters or less)																									
	High/Low Difference in Indoor/Indoor Section (h)	15 meters or less																									
<b>■ Selecting the Refrigerant Branch Kit</b>		Please select branching kit, which is sold separately, from the table below. (The kit comprises sets for use with liquid pipes and for use with gas pipes.)																									
		<table><tr><td>Branch header (4 branches)</td><td>Branch header (8 branches)</td></tr><tr><td>CMY-Y64-G-E</td><td>CMY-Y68-G-E</td></tr></table>			Branch header (4 branches)	Branch header (8 branches)	CMY-Y64-G-E	CMY-Y68-G-E																			
Branch header (4 branches)	Branch header (8 branches)																										
CMY-Y64-G-E	CMY-Y68-G-E																										
<b>■ Select Each Section of Refrigerant Piping</b>		<div><div><div>(1) Section From Outdoor Unit to First Branch (A)</div><div>(2) Section From Branch to Indoor Unit (a,b,c,d)</div><div>Each Section of Piping</div></div><div>Select the size from the table to the right.</div></div> <div><div>(1) Refrigerant Piping Diameter In Section From Outdoor Unit to First Branch (Outdoor Unit Piping Diameter)</div><table><tr><th>Model</th><th colspan="2">Piping Diameter (mm)</th></tr><tr><td>PUMY-SP112</td><td>Liquid Line</td><td>ø9.52</td></tr><tr><td>PUMY-SP125</td><td rowspan="2">Gas Line</td><td rowspan="2">ø15.88</td></tr><tr><td>PUMY-SP140</td></tr></table><div><div>Note:</div><div>When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT when selecting the pipe size and piping length.</div></div></div> <div><div>(2) Refrigerant Piping Diameter In Section From Branch to Indoor Unit (Indoor Unit Piping Diameter)</div><table><tr><th>Model number</th><th colspan="2">Piping Diameter (mm)</th></tr><tr><td rowspan="2">50 or lower</td><td>Liquid Line</td><td>ℓ ≤ 30 m ø6.35 ℓ &gt; 30 m ø9.52</td></tr><tr><td>Gas Line</td><td>ø12.7</td></tr><tr><td rowspan="2">63 to 140</td><td>Liquid Line</td><td>ø9.52</td></tr><tr><td>Gas Line</td><td>ø15.88</td></tr></table></div>			Model	Piping Diameter (mm)		PUMY-SP112	Liquid Line	ø9.52	PUMY-SP125	Gas Line	ø15.88	PUMY-SP140	Model number	Piping Diameter (mm)		50 or lower	Liquid Line	ℓ ≤ 30 m ø6.35 ℓ > 30 m ø9.52	Gas Line	ø12.7	63 to 140	Liquid Line	ø9.52	Gas Line	ø15.88
Model	Piping Diameter (mm)																										
PUMY-SP112	Liquid Line	ø9.52																									
PUMY-SP125	Gas Line	ø15.88																									
PUMY-SP140																											
Model number	Piping Diameter (mm)																										
50 or lower	Liquid Line	ℓ ≤ 30 m ø6.35 ℓ > 30 m ø9.52																									
	Gas Line	ø12.7																									
63 to 140	Liquid Line	ø9.52																									
	Gas Line	ø15.88																									
<b>■ Additional refrigerant charge</b>		Refer to the same section in the previous page.																									





## 10-2. REFRIGERANT PIPING SYSTEM (WHEN USING BRANCH BOX)

### Branch box Method Connection Examples (Connecting to 8 Indoor Units)



Permissible length (One-way)	Total piping length	$A + B + C + a + b + c + d + e + f + g + h \leq 120 \text{ m}$
	Farthest piping length (L)	$A + C + h \leq 80 \text{ m}$ ( $A + C \leq 55 \text{ m}$ , $h \leq 25 \text{ m}$ )
	Piping length between outdoor unit and branch boxes	$A + B + C \leq 55 \text{ m}$
	Farthest piping length after branch box (1)	$l \leq 25 \text{ m}$
	Total piping length between branch boxes and indoor units	$a + b + c + d + e + f + g + h \leq 95 \text{ m}$
Permissible height difference (One-way)	In indoor/outdoor section (H)*	$H \leq 50 \text{ m}$ (In the case of that outdoor unit is set higher than indoor unit) $H \leq 30 \text{ m}$ (In the case of that outdoor unit is set lower than indoor unit)
	In branch box/indoor unit section (h1)	$h1 + h2 \leq 15 \text{ m}$
	In each branch unit (h2)	$h2 \leq 15 \text{ m}$
	In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
Number of bends		$\leq 15$

\*Branch box should be placed within the level between the outdoor unit and indoor units.

### Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to Branch box (A, B, C)  
 (2) Section From Branch box to Indoor Unit (a to h)
- Each Section of Piping

Select the size from the table to the right.

#### (1) Refrigerant Piping Diameter In Section From Outdoor Unit to Branch box (Outdoor Unit Piping Diameter)

Model number	Piping Diameter (mm)
PUMY-SP112 PUMY-SP125 PUMY-SP140	Liquid Line Gas Line
	$\phi 9.52$ $\phi 15.88$

#### (2) Refrigerant Piping Diameter In Section From Branch box to Indoor Unit (Indoor Unit Piping Diameter)

Indoor unit series	Model number	A Liquid pipe	B Gas pipe	(mm)
M series or S series	15 to 42	$\phi 6.35$	$\phi 9.52$	
	50	$\phi 6.35$	$\phi 12.7$	
	60	$\phi 6.35$	$\phi 15.88$	
	71, 80	$\phi 9.52$	$\phi 15.88$	
P series	35, 50	$\phi 6.35$	$\phi 12.7$	
	60 to 100	$\phi 9.52$	$\phi 15.88$	

\* If the pipe size of indoor unit is different, use a different-diameter joint.

### Additional refrigerant charge

Refrigerant for the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

#### Calculation of additional refrigerant charge

- Calculate the additional charge using the liquid pipe size and length of the extended piping and total capacity of connected indoor units.
- Calculate the additional refrigerant charge using the procedure shown to the right, and charge with the additional refrigerant.
- For amounts less than 0.1 kg, round up the calculated additional refrigerant charge.  
(For example, if the calculated charge is 6.01 kg, round up the charge to 6.1 kg.)

#### <Additional Charge>

#### Calculation of refrigerant charge

Pipe size Liquid pipe $\phi 6.35 \text{ mm}$ (m) $\times 19.0 \text{ (g/m)}$	+	Pipe size Liquid pipe $\phi 9.52 \text{ mm}$ (m) $\times 50.0 \text{ (g/m)}$	+	Total capacity of connected indoor units	Amount for the indoor units
				up to 8.0 kW	1.5 kg
				8.1 to 16.0 kW	2.5 kg
				16.1 kW or above	3.0 kg

#### Included refrigerant amount when shipped from the factory

Included refrigerant amount
3.5 kg

#### <Example>

Outdoor model: SP125  
 Indoor 1: P63 (7.1 kW)  
 2: P40 (4.5 kW)  
 3: P25 (2.8 kW)  
 4: P20 (2.2 kW)

A:  $\phi 9.52 \text{ mm}$  30 m  
 a:  $\phi 9.52 \text{ mm}$  15 m  
 b:  $\phi 6.35 \text{ mm}$  10 m  
 c:  $\phi 6.35 \text{ mm}$  10 m  
 d:  $\phi 6.35 \text{ mm}$  20 m

At the conditions below:

The total length of each liquid line is as follows:

$$\phi 9.52 : A + a = 30 + 15 = 45 \text{ m}$$

$$\phi 6.35 : b + c + d = 10 + 10 + 20 = 40 \text{ m}$$

The total capacity of connected indoor unit is as follows:

$$7.1 + 4.5 + 2.8 + 2.2 = 16.6$$


#### <Calculation example>

Additional refrigerant charge

$$40 \times \frac{19.0}{1000} + 45 \times \frac{50.0}{1000} + 3.0 = 6.1 \text{ kg (rounded up)}$$



### Connection Examples (Connecting to 1 Branch box)



Permissible length (One-way)	Total piping length	$A+B+C+D+E+a+b+c+d+e+f+g+h+i+j \leq 120 \text{ m}$
	Farthest piping length (L1)	$A+E+a \text{ or } A+B+C+e \leq 70 \text{ m}$
	Farthest piping length. Via Branch box (L2)	$A+B+C+D+j \leq 80 \text{ m}$
	Piping length between outdoor unit and branch box	$A+B+C+D \leq 55 \text{ m}$
	Farthest piping length from the first joint	$B+C+D \text{ or } B+C+e \leq 50 \text{ m}$
	Farthest piping length after branch box	$j \leq 25 \text{ m}$
	Total piping length between branch boxes and indoor units	$f+g+h+i+j \leq 95 \text{ m}$
Permissible height difference (One-way)	In indoor/outdoor section (H)*	$H \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit)
		$H \leq 30 \text{ m}$ (In the case of outdoor unit is set lower than indoor unit)
	In branch box/indoor unit section (h1)	$h1 \leq 15 \text{ m}$
	In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
Number of bends		$\leq 15$

\*Branch box should be placed within the level between the outdoor unit and indoor units.

Please select branching kit, which is sold separately, from the table below.  
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

Branch header (4 branches)	Branch header (8 branches)
CMY-Y64-G-E	CMY-Y68-G-E

(1) Refrigerant Piping Diameter In Section From Outdoor Unit to Branch box or Branch header (Out-door Unit Piping Diameter)

- (1) Section From Outdoor Unit to Branch box or Branch header (A to E)
  - (2) Sections From Branch box or Branch header to Indoor Unit (a to j)
- } Each Section of Piping

Select the size from the table to the right.

Model	Piping Diameter (mm)
PUMY-SP112 PUMY-SP125 PUMY-SP140	Liquid Line Gas Line
	ø9.52 ø15.88

- (2) Refrigerant Piping Diameter In Section From Branch box or Branch header to Indoor Unit (Indoor Unit Piping Diameter)

Indoor unit series	Model number	A Liquid pipe		B Gas pipe	(mm)
CITY MULTI	50 or lower	$\ell \leq 30$ m	$\varnothing 6.35$	$\varnothing 12.7$	* If the unit is different
		$\ell > 30$ m	$\varnothing 9.52$		
	63 to 140	$\varnothing 9.52$	$\varnothing 15.88$		
M series or S series	22 to 42	$\varnothing 6.35$	$\varnothing 9.52$		
	50	$\varnothing 6.35$	$\varnothing 12.7$		
	60	$\varnothing 6.35$	$\varnothing 15.88$		
	71, 80	$\varnothing 9.52$	$\varnothing 15.88$		
P series	35,50	$\varnothing 6.35$	$\varnothing 12.7$		
	60 to 100	$\varnothing 9.52$	$\varnothing 15.88$		


\* If the pipe size of indoor unit is different, use a different-diameter joint.

**Note:**  
When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT when selecting the pipe size and piping length.

Refer to the same section in the previous page.

### Mixed Method

Connection Examples  
(Connecting to 2 Branch boxes)



Permissible length (One-way)	Total piping length	$A+B+C+D+E+a+b+c+d+e+f+g+h+i+j+k \leq 120 \text{ m}$
	Farthest piping length (L1)	$A+E+a \leq 70 \text{ m}$
	Farthest piping length. Via Branch box (L2)	$A+B+C+k \leq 80 \text{ m}$
	Piping length between outdoor unit and branch boxes	$A+B+C+D \leq 55 \text{ m}$
	Farthest piping length from the first joint	$B+C \text{ or } E+a \leq 50 \text{ m}$
	Farthest piping length after branch box	$k \leq 25 \text{ m}$
	Farthest branch box from outdoor unit	$A+B+C \leq 55 \text{ m}$
	Total piping length between branch boxes and indoor units	$d+e+f+g+h+i+j+k \leq 95 \text{ m}$
Permissible height difference (One-way)	In indoor/outdoor section (H)*	$H \leq 50 \text{ m}$ (In the case of outdoor unit is set higher than indoor unit) $H \leq 30 \text{ m}$ (In the case of outdoor unit is set lower than indoor unit)
	In branch box/indoor unit section (h1)	$h1+h2 \leq 15 \text{ m}$
	In each branch unit (h2)	$h2 \leq 15 \text{ m}$
	In each indoor unit (h3)	$h3 \leq 12 \text{ m}$
Number of bends		$\leq 15$

\*Branch box should be placed within the level between the outdoor unit and indoor units.

### ■ Selecting the Refrigerant Branch Kit

Please select branching kit, which is sold separately, from the table below.  
(The kit comprises sets for use with liquid pipes and for use with gas pipes.)

Branch header (4 branches)	Branch header (8 branches)
CMY-Y64-G-E	CMY-Y68-G-E

### ■ Select Each Section of Refrigerant Piping

- (1) Section From Outdoor Unit to Branch box or Branch header (A to E)
- (2) Sections From Branch box or Branch header to Indoor Unit (a to k)
- Each Section of Piping

Select the size from the table to the right.

- (1) Refrigerant Piping Diameter In Section From Outdoor Unit to Branch box or Branch header (Out-door Unit Piping Diameter)

Model	Piping Diameter (mm)	
PUMY-SP112 PUMY-SP125 PUMY-SP140	Liquid Line	ø9.52
	Gas Line	ø15.88

- (2) Refrigerant Piping Diameter In Section From Branch box or Branch header to Indoor Unit (Indoor Unit Piping Diameter)

Indoor unit series	Model number	A Liquid pipe		B Gas pipe	(mm)
CITY MULTI	50 or lower	$\ell \leq 30 \text{ m}$	ø6.35	ø12.7	
		$\ell > 30 \text{ m}$	ø9.52		
M series or S series	63 to 140		ø9.52	ø15.88	
	22 to 42		ø6.35	ø9.52	
	50		ø6.35	ø12.7	
	60		ø6.35	ø15.88	
P series	71, 80		ø9.52	ø15.88	
	35, 50		ø6.35	ø12.7	
	60 to 100		ø9.52	ø15.88	

\* If the pipe size of indoor unit is different, use a different-diameter joint.

Note:

When connecting the CONNECTION KIT (PAC-LV11M-J) and an M-series indoor unit, refer to the installation manual for the CONNECTION KIT when selecting the pipe size and piping length.

### ■ Additional refrigerant charge

Refer to the same section in the previous page.

## 10-3. PRECAUTIONS AGAINST REFRIGERANT LEAKAGE


### 10-3-1. Introduction

R410A refrigerant of this air conditioner is non-toxic and non-flammable but leaking of large amount from an indoor unit into the room where the unit is installed may be deleterious. To prevent possible injury, the rooms should be large enough to keep the R410A concentration specified by ISO 5149-1 as follows.

Maximum concentration  
Maximum refrigerant concentration of R410A of a room is  $0.44\text{kg/m}^3$  accordance with ISO 5149-1.  
To facilitate calculation, the maximum concentration is expressed in units of  $\text{kg/m}^3$  (kg of R410A per  $\text{m}^3$ )

**Maximum concentration of R410A:  $0.44\text{ kg/m}^3$**

(ISO 5149-1)



### 10-3-2. Confirming procedure of R410A concentration

Follow (1) to (3) to confirm the R410A concentration and take appropriate treatment, if necessary.

**(1) Calculate total refrigerant amount by each refrigerant system. Total refrigerant amount is precharged refrigerant at ex-factory plus additional charged amount at field installation.**


Note:

When the air conditioning system consists of several independent refrigerant system, figure out the total refrigerant amount by each independent refrigerant system.


**(2) Calculate room volumes ( $\text{m}^3$ ) and find the room with the smallest volume**

The part with    represents the room with the smallest volume.


**(a) Situation in which there are no partitions**



**(b) There are partitions, but there are openings that allow the effective mixing of air.**



**(c) If the smallest room has mechanical ventilation apparatus that is linked to a household gas detection and alarm device, the calculations should be performed for the second smallest room.**



**(3) Use the results of calculations (1) and (2) to calculate the refrigerant concentration:**

Total refrigerant in the refrigerating unit (kg)  $\leq$  Maximum concentration( $\text{kg/m}^3$ )

The smallest room in which an indoor unit has been installed ( $\text{m}^3$ )

Maximum concentration of R410A:  $0.44\text{kg/m}^3$

If the calculation results do not exceed the maximum concentration, perform the same calculations for the larger second and third room, etc., until it has been determined that nowhere the maximum concentration will be exceeded.

PUMY-SP112VKM(R1).TH

PUMY-SP112YKM(R1).TH

PUMY-SP112VKM(R1).TH-BS

PUMY-SP112YKM(R1).TH-BS

PUMY-SP125VKM(R1).TH

PUMY-SP125YKM(R1).TH

PUMY-SP125VKM(R1).TH-BS

PUMY-SP125YKM(R1).TH-BS

PUMY-SP140VKM(R1).TH

PUMY-SP140YKM(R1).TH

PUMY-SP140VKM(R1).TH-BS

PUMY-SP140YKM(R1).TH-BS

—————&gt; : Indicates the visible parts in the photos/figures.

-----&gt; : Indicates the invisible parts in the photos/figures.


## OPERATING PROCEDURE

## 1. Removing the service panel and the top panel

- (1) Remove 3 service panel fixing screws (5 × 12), and slide the hook on the right downward to remove the service panel.
- (2) Remove screws (2 for front, 3 for rear/5 × 12) of the top panel and remove it.

## PHOTOS/FIGURES

Photo 1



## 2. Removing the fan motor (MF1)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove 4 fan grille fixing screws (5 × 12) to detach the fan grille. (See Photo 1)
- (4) Remove a nut (for right handed screw of M6) to detach the propeller. (See Photo 2)
- (5) Disconnect the connector CNF1 on the multi controller circuit board in the electrical parts box. (See Photo 4)
- (6) Loosen a clamp on the side of the motor support. (See Photo 3)
- (7) Remove 4 fan motor fixing screws (5 × 20) to detach the fan motor. (See Photo 3)

Note: Tighten the propeller fan with a torque of  $5.7 \pm 0.3 \text{ N} \cdot \text{m}$ .

Photo 2 Front panel fixing screws






Photo 3



## 3. Removing the electrical parts box

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connecting wire from terminal block. (See Photo 5 for VKM type, or Photo 7 for YKM type)
- (4) Disconnect the connector CNF1, 4-way valve coil, LEV-A and LEV-B on the multi controller circuit board.
  - <Symbols on the board>
  - CNF1: Fan motor
  - LEV-A: LEV
  - LEV-B: LEV
  - 21S4: 4-way valve coil
  - 63HS: Pressure sensor
  - SV1: Solenoid valve coil
  - 63H: Pressure switch
  - 63LS: Pressure sensor
- (5) Disconnect the pipe-side connections of the following parts:
  - Thermistor <HIC> (TH2)
  - Thermistor <Compressor> (TH4)
  - Thermistor <Liquid> (TH3)
  - Thermistor <Suction> (TH6)
  - Thermistor <Ambient> (TH7)
- (6) Remove the comp felt (top).
- (7) Remove a nut from the terminal cover to remove the cover, and disconnect the compressor lead wire. (See Photo 11)
- (8) Remove 2 electrical parts box fixing screws (4 × 10), and detach the electrical parts box by pulling upward. The electrical parts box is fixed with 2 hooks on the left and 1 hook on the right.

Photo 4





## OPERATING PROCEDURE

### 4. Disassembling the electrical parts box (VKM type)

- (1) Disconnect all the connectors on the multi controller circuit board.
- (2) Remove 2 screws ① which fix the plate holding the multi controller circuit board and the electrical parts box. (See Photo 5)
- (3) Remove the multi controller circuit board. (See Photo 5)
- (4) Disconnect the M-NET power board connector on the back plate of the controller circuit board.
- (5) Disconnect the connectors of reactor on the back plate of the electrical parts box. (See Photo 6)
- (6) Remove screws ② on the back plate of the electrical parts box. (See Photo 6)
- (7) Remove the 3 reactors. (See Photo 6)

**Note 1: When reassembling the electrical parts box, make sure that the wirings are correct.**

**Note 2: When exchanging the reactor, make sure to exchange all the 3 reactors.**


### 5. Disassembling the electrical parts box (YKM type)

- (1) Disconnect all the connectors on the multi controller circuit board.
- (2) Remove 2 screws ① which fix the plate holding the multi controller circuit board and the electrical parts box. (See Photo 7.)
- (3) Remove the multi controller circuit board. (See Photo 7.)
- (4) Disconnect the M-NET power board connector on the back plate of the controller circuit board.
- (5) Disconnect all the connectors on the noise filter circuit board. (See Photo 8)
- (6) Remove 9 supports on the noise filter circuit board. (See Photo 8)
- (7) Remove the noise filter circuit board. (See Photo 8)
- (8) Remove the noise filter plate fixing screws. (See Photo 8)
- (9) Disconnect the connectors of reactor on the bottom plate of the electrical parts box. (See Photo 9)
- (10) Remove 4 screws ② on the bottom plate of the electrical parts box. (See Photo 9)
- (11) Remove the reactor. (See Photo 9)


**Note: When reassembling the electrical parts box, make sure that the wirings are correct.**

## PHOTOS/FIGURES

**Photo 5**




**Photo 6**




\* The M-NET power board is installed behind the multi controller circuit board.

**Photo 7**




\* The M-NET power board is installed behind the multi controller circuit board.



**Photo 8**



**Photo 9**





OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>6.Removing the thermistor &lt;HIC&gt; (TH2) and the thermistor &lt;Compressor&gt; (TH4)</b></p> <p>(1) Remove the service panel. (See Photo 1)</p> <p>(2) Remove the top panel. (See Photo 1)</p> <p>(3) Disconnect the following connectors on the controller circuit board in the electrical parts box.</p> <ul style="list-style-type: none"><li>• TH2: Black</li><li>• TH4:White</li></ul> <p>[Removing the thermistor &lt;HIC&gt; (TH2)]</p> <p>(4) Loosen the fastener fixing the connector to the electrical parts box. (See Photo 10)</p> <p>(5) Pull out the thermistor &lt;HIC&gt; (TH2) from the sensor holder. (See Photo 13)</p> <p>[Removing the thermistor &lt;Compressor&gt; (TH4)]</p> <p>(4) Loosen the fastener fixing the connector to the electrical parts box. (See Photo 10)</p> <p>(5) Remove the comp felt (top).</p> <p>(6) Pull out the thermistor &lt;Compressor&gt; (TH4) from the sensor holder. (See Photo 11)</p>	<p><b>Photo 10</b></p>  <p>Fastener</p>
<p><b>7. Removing the thermistor &lt;Liquid&gt; (TH3), the thermistor &lt;Suction&gt; (TH6), and thermistor &lt;Ambient&gt; (TH7)</b></p> <p>(1) Remove the service panel. (See Photo 1.)</p> <p>(2) Remove the top panel. (See Photo 1.)</p> <p>(3) Remove the side panel (R) by removing the following screws:</p> <ul style="list-style-type: none"><li>• Electrical parts box fixing screws (4 × 10): 2 pieces</li><li>• Valve bed fixing screws (5 × 12): 2 pieces</li><li>• Side panel fixing screw on the right side of the panel (5 × 12): 1 piece</li><li>• Side panel fixing screw in the rear of the panel (5 × 12): 3 pieces</li></ul> <p>(4) Disconnect the following connectors on the multi controller circuit board in the electrical parts box.</p> <ul style="list-style-type: none"><li>• TH3: White</li><li>• TH6/7: Red</li></ul> <p>(5) Loosen the fastener fixing the connector to the electrical parts box. (See Photo 10)</p> <p>(6) Pull out each thermistor from the sensor holder. (See Photo 12, 13)</p> <p><b>Note: When replacing thermistor &lt;Ambient&gt; (TH7), replace it together with thermistor &lt;Suction&gt; (TH6), since they are combined together.</b></p>	<p><b>Photo 11</b></p>  <p>Thermistor &lt;Compressor&gt; (TH4)</p> <p>Nut</p> <p>Compressor</p> <p>Terminal cover</p>

## OPERATING PROCEDURE

### 8. Removing LEV coil

[LEV-A]

- (1) Remove the service panel. (See Photo 1)
- (2) Disconnect the connector CNL VA (WH) on the multi controller circuit board in the electrical parts box.
- (3) Remove the LEV coil by sliding the coil upward. (See Photo 13)

[LEV-B]

- (1) Remove the service panel. (See Photo 1)
- (2) Disconnect the connector CNL VB (RD) on the multi controller circuit board in the electrical parts box.
- (3) Remove the LEV coil by sliding the coil upward. (See Photo 13)

### 9. Removing LEV

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box. (Refer to procedure 3)
- (4) Remove the LEV coil. (Refer to procedure 8)
- (5) Recover refrigerant.
- (6) Remove the welded part of LEV.

**Note 1:** Recover refrigerant without spreading it in the air.

**Note 2:** The welded part can be removed easily by removing the right side panel.

**Note 3:** When installing the LEV, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.

## PHOTOS/FIGURES

Photo 12

Thermistor <Ambient> (TH7)




Photo 13







Photo 14





OPERATING PROCEDURE	PHOTOS/FIGURES
<p><b>10. Removing the 4-way valve coil (21S4)</b></p> <p>(1) Remove the service panel. (See Photo 1)</p> <p><b>[Removing the 4-way valve coil]</b></p> <p>(2) Remove 4-way valve coil fixing screw (M5 × 7).</p> <p>(3) Remove the 4-way valve coil by sliding the coil toward you.</p> <p>(4) Disconnect the connector 21S4 (green) on the outdoor multi controller circuit board in the electrical parts box.</p>	<p><b>Photo 15</b></p>  <p>4-way valve coil (21S4)</p> <p>4-way valve</p> <p>4-way valve coil fixing screw</p>
<p><b>11. Removing the 4-way valve</b></p> <p>(1) Remove the service panel. (See Photo 1)</p> <p>(2) Remove the top panel. (See Photo 1)</p> <p>(3) Remove the electrical parts box (Refer to procedure 3)</p> <p>(4) Remove 3 valve bed fixing screws (5 × 12) and 4 stop valve fixing screws (5 × 16) and then remove the valve bed. (See Photo 4)</p> <p>(5) Remove 4 right side panel fixing screw (5 × 12) in the rear of the unit and then remove the right side panel.</p> <p>(6) Remove the 4-way valve coil. (See Photo 15)</p> <p>(7) Recover refrigerant.</p> <p>(8) Remove the welded part of 4-way valve.</p> <p><b>Note 1:</b> Recover refrigerant without spreading it in the air.</p> <p><b>Note 2:</b> The welded part can be removed easily by removing the right side panel.</p> <p><b>Note 3:</b> When installing the 4-way valve, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.</p>	



## OPERATING PROCEDURE

### 12. Removing the solenoid valve coil (SV1) and the solenoid valve

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Disconnect the connector SV1 (Gray) on the multi controller circuit board in the electrical parts box.
- (4) Remove the electrical parts box. (Refer to procedure 3)
- (5) Remove the solenoid valve coil fixing screw (M4 ×6).
- (6) Remove the solenoid valve coil by sliding the coil upward.
- (7) Recover refrigerant.
- (8) Remove the welded part of solenoid valve.

**Note 1:** Recover refrigerant without spreading it in the air.

**Note 2:** When installing the solenoid valve, cover it with a wet cloth to prevent it from heating (120°C or more), then braze the pipes so that the inside of pipes are not oxidized.

### 13. Removing the high pressure switch (63H)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the electrical parts box. (Refer to procedure 3)
- (4) Remove the side panel (R). (Refer to the procedure 7 (3))
- (5) Pull out the 2 lead wire of the high pressure switch.
- (6) Recover refrigerant.
- (7) Remove the welded part of high pressure switch.

**Note 1:** Recover refrigerant without spreading it in the air.

**Note 2:** The welded part can be removed easily by removing the right side panel.

**Note 3:** When installing the high pressure switch and high pressure sensor, cover them with a wet cloth to prevent them from heating (100°C or more), then braze the pipes so that the inside of pipes are not oxidized.

### 14. Removing the low pressure sensor (63LS) and the high pressure sensor (63HS)

- (1) Remove the service panel. (See Photo 1)
- (2) Remove the top panel. (See Photo 1)
- (3) Remove the side panel (R). (Refer to the procedure 7 (3))
- (4) Disconnect the connector 63LS (blue) and the 63HS (white) on the multi controller circuit board in the electrical parts box.
- (5) Loosen the clamps, which are fixing the low pressure sensor and high pressure sensor lead wire to the top of the electrical parts box. (See Photo 17)
- (6) Recover refrigerant.
- (7) Remove the welded part of low pressure sensor and high pressure sensor.

**Note 1:** Recover refrigerant without spreading it in the air.

**Note 2:** The welded part can be removed easily by removing the right side panel.

**Note 3:** When installing the low pressure sensor and high pressure sensor, cover it with a wet cloth to prevent it from heating (100°C or more), then braze the pipes so that the inside of pipes are not oxidized.

## PHOTOS/FIGURES

Photo 16





Photo 17



## OPERATING PROCEDURE

### 15. Removing the compressor (MC)

- (1) Remove the service panel. (See Photo 1.)
- (2) Remove the top panel. (See Photo 1.)
- (3) Remove the electrical parts box. (Refer to procedure 3)
- (4) Remove the valve bed by removing the following screws:
  - Valve bed fixing screws (5 × 12): 3 pieces
  - Stop valve fixing screws (5 × 16): 4 pieces
- (5) Remove 2 cover panel (front) fixing screws (5 × 12) to remove the cover panel (front).
- (6) Remove 5 cover panel (rear) fixing screws (5 × 12) to remove the cover panel (rear).
- (7) Remove 2 side panel (R) fixing screws in the rear of the panel (5 × 12) and remove the side panel (R).
- (8) Remove the comp felt (top) and (body).
- (9) Remove the nut on the terminal cover to remove the terminal cover, and remove the compressor lead wire. (See Photo18)
- (10) Remove the thermistor <Compressor> (TH4).
- (11) Recover refrigerant.
- (12) Remove the welded pipe of compressor inlet and outlet.
- (13) Remove 3 compressor fixing nuts.

**Note 1: Recover refrigerant without spreading it in the air.**

**Note 2: When reconnecting the compressor wirings, ensure that the connection is correct: Check the color of the wiring and the label on the terminal block, and connect properly.**


### 16. Removing the accumulator

- (1) Remove the service panel. (See Photo 1.)
- (2) Remove the top panel. (See Photo 1.)
- (3) Remove the electrical parts box. (Refer to procedure 3)
- (4) Remove the valve bed. (Refer to the procedure 15(4))
- (5) Remove the cover panel (front). (Refer to the procedure 15 (5))
- (6) Remove the cover panel (rear). (Refer to the procedure 15 (6))
- (7) Remove the side panel (R). (Refer to the procedure 15 (7))
- (8) Recover refrigerant.
- (9) Remove the welded pipe of accumulator inlet and outlet.
- (10) Remove 2 accumulator fixing screws. (See Photo18)

**Note: Recover refrigerant without spreading it in the air.**

## PHOTOS/FIGURES

Photo 18



# CITY MULTI

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO100-8310, JAPAN

©Copyright 2017 MITSUBISHI ELECTRIC CORPORATION  
Issued: Mar. 2020 No. OCH668 REVISED EDITION-E  
Issued: Jul. 2019 No. OCH668 REVISED EDITION-D  
Issued: Nov. 2018 No. OCH668 REVISED EDITION-C  
Issued: Apr. 2018 No. OCH668 REVISED EDITION-B  
Issued: Dec. 2017 No. OCH668 REVISED EDITION-A  
Published: Sep. 2017 No.OCH668  
Made in Japan

Specifications are subject to change without notice.