






Outlet/inlet extension AR35XTT10/15/20








AR35XTT - Inlet part 1






AR35XTT - Inlet part 2






AR35XTT - Outlet part 1

17




18



AR35XTT - Outlet part 2

19



20



130-210 mm



Main office

Frico AB
Box 102
SE-433 22 Partille
Sweden

Tel: +46 31 336 86 00
Fax: +46 31 26 28 25