


Model LGH-15RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	X50 039 710	Filter stopper	8			
3.	R50 541 383	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	8			
5.	R50 541 380	Hanger	4			
6.	R50 541 717	Cover	2			
7.	Y50 115 619	Flange	4			
8.	H00 000 487	PTT screw 4×8	46			
9.	R50 541 487	Maintenance cover	1			
10.	X50 039 717	Filter	4	▲		
11.	R50 541 718	Lossnay core	2	▲	With filter stopper	
12.	R50 541 384	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	1			



* shows accessory parts.


Model LGH-15RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 331 067	Special nut(8)	2		Left-handed	
22.	M34 398 077	Tab washer	2			
23.	R50 541 480	Centrifugal fan	2	▲	φ 180	
24.	R50 028 465	Special washer	2		φ 8.1	
25.	Y50 115 454	Motor	1	▲		
26.	R50 214 708	Motor plate	4			
27.	H00 000 332	PTT screw 4×10	13			
28.	R50 541 712	Motor fix plate	2			
29.	D43 008 223	Cord clamper	2			
30.	Y50 115 453	Motor	1	▲		
31.	H00 312 007	PTT screw 4×6	16			
32.	M45 649 226	Cord bush	2			
33.	Y50 115 709	Connector cover	1			
34.	D41 006 363	Cord band	1			
35.	Y50 115 710	Connector plate	1			
36.	R50 541 488	Separator	2			




Model LGH-15RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
41.	R50 533 693	Fix plate	1			
42.	Y50 115 708	Damper motor cover	1			
43.	Y50 115 225	Bush	1			
44.	R50 541 715	Damper support	1			
45.	M31 234 089	Special bush	2			
46.	R50 095 156	Pull spring	1			
47.	R50 213 713	Damper	1			
48.	R50 351 225	Cord bush	1			
49.	Y50 061 260	Damper motor	1	▲	AC220·240V	
50.	R50 054 225	Bush	1			
51.	Y50 115 150	Rod	1			
52.	Y50 115 705	Control cover	1			
53.	Y50 115 368	Wiring diagram	1			
54.	Y50 115 287	Capacitor	2	▲	1.5 μF·440VAC	
55.	H00 003 005	PPT screw 3×8	1			
56.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
57.	H00 013 076	Lock washer(4)	2			
58.	Y50 115 216	Transformer	1	▲	AC230V	
59.	H00 011 008	PT screw 4×8(BS)	1			
60.	M45 017 228	Cord band	1			
61.	K83 170 228	Cord band	2			
62.	R50 546 705	Circuit fix plate	1			
63.	R50 476 225	Bush	3			
64.	H00 000 003	PP screw 4×8	2			
65.	H00 154 005	PPT screw 4×12	1			
66.	M13 100 242	Terminal block	1	▲	3P	
67.	Y50 115 712	Terminal block fix plate	1			
68.	Y55 001 223	Cord clip	1			
69.	Y50 115 711	Side plate	1			
70.	K82 163 225	Bush	2			
71.	R50 546 167	Thermistor	1	▲		
72.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	



Model LGH-25RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	X50 039 710	Filter stopper	8			
3.	R50 541 383	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	8			
5.	R50 541 380	Hanger	4			
6.	R50 541 717	Cover	2			
7.	Y50 075 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	46			
9.	R50 541 487	Maintenance cover	1			
10.	X50 039 717	Filter	4	▲		
11.	R50 541 718	Lossnay core	2	▲	With filter stopper	
12.	R50 541 384	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	1			



* shows accessory parts.

Model LGH-25RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 331 067	Special nut(8)	2		Left-handed	
22.	M34 398 077	Tab washer	2			
23.	R50 541 480	Centrifugal fan	2	▲	φ 180	
24.	R50 028 465	Special washer	2		φ 8.1	
25.	Y50 115 456	Motor	1	▲		
26.	R50 214 708	Motor plate	4			
27.	H00 000 332	PTT screw 4×10	13			
28.	R50 541 712	Motor fix plate	2			
29.	D43 008 223	Cord clamper	2			
30.	Y50 115 455	Motor	1	▲		
31.	H00 312 007	PTT screw 4×6	14			
32.	M45 649 226	Cord bush	2			
33.	Y50 115 709	Connector cover	1			
34.	D41 006 363	Cord band	1			
35.	Y50 115 710	Connector plate	1			
36.	R50 541 488	Separator	2			




Model LGH-25RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
41.	R50 533 693	Fix plate	1			
42.	Y50 115 708	Damper motor cover	1			
43.	Y50 115 225	Bush	1			
44.	R50 541 715	Damper support	1			
45.	M31 234 089	Special bush	2			
46.	R50 095 156	Pull spring	1			
47.	R50 213 713	Damper	1			
48.	R50 351 225	Cord bush	1			
49.	Y50 061 260	Damper motor	1	▲	AC220·240V	
50.	R50 054 225	Bush	1			
51.	Y50 115 150	Rod	1			
52.	Y50 115 705	Control cover	1			
53.	Y50 115 368	Wiring diagram	1			
54.	Y50 115 288	Capacitor	2	▲	2.0 μ F·440VAC	
55.	H00 003 005	PPT screw 3×8	1			
56.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
57.	H00 013 076	Lock washer(4)	2			
58.	Y50 115 216	Transformer	1	▲	AC230V	
59.	H00 011 008	PT screw 4×8(BS)	1			
60.	M45 017 228	Cord band	1			
61.	K83 170 228	Cord band	2			
62.	R50 546 705	Circuit fix plate	1			
63.	R50 476 225	Bush	3			
64.	H00 000 003	PP screw 4×8	2			
65.	H00 154 005	PPT screw 4×12	1			
66.	M13 100 242	Terminal block	1	▲	3P	
67.	Y50 115 712	Terminal block fix plate	1			
68.	Y55 001 223	Cord clip	1			
69.	Y50 115 711	Side plate	1			
70.	K82 163 225	Bush	2			
71.	R50 546 167	Thermistor	1	▲		
72.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	

Model LGH-35RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	R50 521 710	Filter stopper	8			
3.	R50 542 381	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	8			
5.	R50 541 380	Hanger	4			
6.	R50 541 717	Cover	2			
7.	Y50 075 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	48			
9.	R50 542 486	Maintenance cover	1	▲		
10.	Y50 116 717	Filter	4	▲		
11.	R50 542 710	Lossnay core	2	▲	With filter stopper	
12.	R50 542 382	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	1			



* shows accessory parts.


Model LGH-35RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 331 067	Special nut(8)	2		Left-handed	
22.	M34 398 077	Tab washer	2			
23.	R50 542 480	Centrifugal fan	2	▲	φ 220	
24.	R50 542 707	Fan base	2			
25.	M34 706 465	Special washer	2		φ 10	
26.	Y50 116 453	Motor	2	▲		
27.	Y50 116 712	Motor fix plate	2			
28.	H00 189 007	PTT screw 5×10	8			
29.	D43 008 223	Cord clamber	2			
30.	M45 649 226	Cord bush	4			
31.	Y50 115 709	Connector cover	2			
32.	H00 312 007	PTT screw 4×6	15			
33.	Y50 115 710	Connector plate	2			
34.	M45 017 228	Cord band	2			
35.	R50 542 487	Separator	2			
36.	H00 194 008	PT screw 5×20	8			
37.	Y50 116 080	Special washer	8			
38.	H00 012 050	Nut(5)	8			



Model LGH-35RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
41.	R50 533 693	Fix plate	1			
42.	Y50 115 708	Damper motor cover	1			
43.	Y50 115 225	Bush	1			
44.	R50 351 225	Cord bush	1			
45.	Y50 061 260	Damper motor	1	▲	AC220·240V	
46.	R50 054 225	Bush	1			
47.	Y50 116 156	Rod	1			
48.	Y50 115 705	Control cover	1			
49.	Y50 115 368	Wiring diagram	1			
50.	H00 003 005	PPT screw 3×8	1			
51.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
52.	H00 013 076	Lock washer(4)	2			
53.	Y50 115 216	Transformer	1	▲	AC230V	
54.	H00 011 008	PT screw 4×8(BS)	1			
55.	Y50 115 712	Terminal block fix plate	1			
56.	K83 170 228	Cord band	2			
57.	R50 546 705	Circuit fix plate	1			
58.	R50 476 225	Bush	3			
59.	H00 000 003	PP screw 4×8	2			
60.	H00 154 005	PPT screw 4×12	1			
61.	M13 100 242	Terminal block	1	▲	3P	
62.	Y50 116 287	Capacitor	2	▲	3.0 μ F·440VAC	
63.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
64.	R50 547 167	Thermistor	1	▲		
65.	Y50 115 711	Side plate	1			
66.	K82 163 225	Bush	2			
67.	Y55 001 223	Cord clip	1			



* shows accessory parts.

Model LGH-50RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	R50 521 710	Filter stopper	8			
3.	R50 542 383	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	8			
5.	R50 541 380	Hanger	4			
6.	R50 542 706	Cover	2			
7.	R50 429 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	48			
9.	R50 542 486	Maintenance cover	1	▲		
10.	R50 521 717	Filter	4	▲		
11.	R50 542 711	Lossnay core	2	▲	With filter stopper	
12.	R50 542 384	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	1			



* shows accessory parts.


Model LGH-50RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 331 067	Special nut(8)	2		Left-handed	
22.	M34 398 077	Tab washer	2			
23.	R50 542 480	Centrifugal fan	2	▲	φ 220	
24.	R50 542 707	Fan base	2			
25.	M34 706 465	Special washer	2		φ 10	
26.	Y50 116 454	Motor	2	▲		
27.	Y50 116 712	Motor fix plate	2			
28.	H00 189 007	PTT screw 5×10	8			
29.	D43 008 223	Cord clamper	2			
30.	M45 649 226	Cord bush	4			
31.	Y50 115 709	Connector cover	2			
32.	H00 312 007	PTT screw 4×6	15			
33.	Y50 115 710	Connector plate	2			
34.	M45 017 228	Cord band	2			
35.	R50 542 487	Separator	2			
36.	H00 194 008	PT screw 5×20	8			
37.	Y50 116 080	Special washer	8			
38.	H00 012 050	Nut(5)	8			



Model LGH-50RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
41.	R50 533 693	Fix plate	1			
42.	Y50 115 708	Damper motor cover	1			
43.	Y50 115 225	Bush	1			
44.	R50 351 225	Cord bush	1			
45.	Y50 061 260	Damper motor	1	▲	AC220·240V	
46.	R50 054 225	Bush	1			
47.	Y50 116 156	Rod	1			
48.	Y50 115 705	Control cover	1			
49.	Y50 115 368	Wiring diagram	1			
50.	H00 003 005	PPT screw 3×8	1			
51.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
52.	H00 013 076	Lock washer(4)	2			
53.	Y50 115 216	Transformer	1	▲	AC230V	
54.	H00 011 008	PT screw 4×8(BS)	1			
55.	Y50 115 712	Terminal block fix plate	1			
56.	K83 170 228	Cord band	2			
57.	R50 546 705	Circuit fix plate	1			
58.	R50 476 225	Bush	1			
59.	H00 000 003	PP screw 4×8	2			
60.	H00 154 005	PPT screw 4×12	1			
61.	M13 100 242	Terminal block	1	▲	3P	
62.	Y50 116 288	Capacitor	2	▲	3.5 μ F·440VAC	
63.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
64.	R50 547 167	Thermistor	1	▲		
65.	Y50 115 711	Side plate	1			
66.	K82 163 225	Bush	2			
67.	Y55 001 223	Cord clip	1			



* shows accessory parts.

Model LGH-65RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	R50 524 710	Filter stopper	8			
3.	R50 543 381	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	8			
5.	R50 543 380	Hanger	4			
6.	R50 542 706	Cover	2			
7.	R50 429 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	55			
9.	R50 543 486	Maintenance cover	1			
10.	R50 524 717	Filter	4	▲		
11.	R50 543 710	Lossnay core	2	▲	With filter stopper	
12.	R50 543 382	Core guide(right)	1			
13.	R50 466 344	Hinge	2			
14.	Y50 029 712	Fix piece	1			



* shows accessory parts.

Model LGH-65RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 218 067	Special nut(12)	2		Left-handed	
22.	K83 466 113	Washer(12)	2			
23.	R50 543 480	Centrifugal fan	2	▲	φ 245	
24.	R50 543 707	Fan base	2			
25.	R50 543 708	Inlet ring	2			
26.	H00 157 008	PT screw 6×20	8			
27.	M34 043 080	Special washer(6)	8			
28.	Y50 033 104	Key	2		5×5×11.5	
29.	Y50 117 453	Motor	2	▲		
30.	R50 543 712	Motor fix plate	2			
31.	H00 189 007	PTT screw 5×10	16			
32.	H00 061 050	Nut(6)	8			
33.	M45 649 226	Cord bush	4			
34.	Y50 115 709	Connector cover	2			
35.	M45 017 228	Cord band	2			
36.	Y50 115 710	Connector plate	2			
37.	H00 312 007	PTT screw 4×6	2			
38.	R50 543 488	Separator	2			




Model LGH-65RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
51.	R50 533 693	Fix plate	1			
52.	Y50 115 708	Damper motor cover	1			
53.	Y50 115 225	Bush	1			
54.	R50 351 225	Cord bush	1			
55.	Y50 061 260	Damper motor	1	▲	AC220•240V	
56.	R50 054 225	Bush	1			
57.	Y50 117 150	Rod	1			
58.	Y50 115 705	Control cover	1			
59.	Y50 115 368	Wiring diagram	1			
60.	H00 003 005	PPT screw 3×8	1			
61.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
62.	H00 013 076	Lock washer(4)	2			
63.	Y50 115 216	Transformer	1	▲	AC230V	
64.	H00 011 008	PT screw 4×8(BS)	1			
65.	Y50 115 712	Terminal block fix plate	1			
66.	K83 170 228	Cord band	2			
67.	R50 546 705	Circuit fix plate	1			
68.	R50 476 225	Bush	1			
69.	H00 000 003	PP screw 4×8	2			
70.	H00 154 005	PPT screw 4×12	1			
71.	M13 100 242	Terminal block	1	▲	3P	
72.	Y50 117 287	Capacitor	2	▲	5.0 μ F•440VAC	
73.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
74.	R50 547 167	Thermistor	1	▲		
75.	Y50 115 711	Side plate	1			
76.	K82 163 225	Bush	2			
77.	Y55 001 223	Cord clip	1			

Model LGH-80RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	R50 522 710	Filter stopper	8			
3.	R50 543 383	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	16			
5.	R50 095 380	Hanger	4			
6.	R50 543 704	Cover	2			
7.	Y50 021 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	54			
9.	R50 543 487	Maintenance cover	1			
10.	R50 529 717	Filter	4	▲		
11.	R50 543 711	Lossnay core	2	▲	With filter stopper	
12.	R50 543 384	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	2			



* shows accessory parts.


Model LGH-80RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 218 067	Special nut(12)	2		Left-handed	
22.	K83 466 113	Washer(12)	2			
23.	R50 543 480	Centrifugal fan	2	▲	φ 245	
24.	R50 543 709	Fan base	2			
25.	R50 543 708	Inlet ring	2			
26.	H00 061 050	Nut(6)	8			
27.	Y50 033 104	Key	2		5×5×11.5	
28.	Y50 117 454	Motor	2	▲		
29.	Y50 117 712	Motor fix plate	2			
30.	H00 189 007	PTT screw 5×10	16			
31.	M34 043 080	Special washer(6)	8			
32.	H00 157 008	PT screw 6×20	8			
33.	M45 649 226	Cord bush	4			
34.	Y50 115 709	Connector cover	2			
35.	M45 017 228	Cord band	2			
36.	Y50 115 710	Connector plate	2			
37.	H00 312 007	PTT screw 4×6	2			
38.	R50 543 489	Separator	2			
39.	D41 123 223	Lead wire clip	1			



Model LGH-80RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
51.	R50 533 693	Fix plate	1			
52.	Y50 115 708	Damper motor cover	1			
53.	Y50 115 225	Bush	1			
54.	R50 351 225	Cord bush	1			
55.	Y50 061 260	Damper motor	1	▲	AC220·240V	
56.	R50 054 225	Bush	1			
57.	Y50 117 151	Rod	1			
58.	Y50 115 705	Control cover	1			
59.	Y50 115 368	Wiring diagram	1			
60.	H00 003 005	PPT screw 3×8	1			
61.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
62.	H00 013 076	Lock washer(4)	2			
63.	Y50 115 216	Transformer	1	▲	AC230V	
64.	H00 011 008	PT screw 4×8(BS)	1			
65.	Y50 115 712	Terminal block fix plate	1			
66.	K83 170 228	Cord band	2			
67.	R50 546 705	Circuit fix plate	1			
68.	R50 476 225	Bush	1			
69.	H00 000 003	PP screw 4×8	2			
70.	H00 154 005	PPT screw 4×12	1			
71.	M13 100 242	Terminal block	1	▲	3P	
72.	Y50 117 288	Capacitor	2	▲	7.0 μ F·440VAC	
73.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
74.	R50 548 167	Thermistor	1	▲		
75.	Y50 115 711	Side plate	1			
76.	K82 163 225	Bush	2			
77.	Y55 001 223	Cord clip	1			



* shows accessory parts.

Model LGH-100RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 541 045	Special screw	2			
2.	R50 522 710	Filter stopper	8			
3.	R50 544 381	Core guide(left)	1			
4.	H00 000 244	PT screw 6×12	16			
5.	R50 095 380	Hanger	4			
6.	R50 543 704	Cover	2			
7.	Y50 021 609	Flange	4			
8.	H00 000 487	PTT screw 4×8	54			
9.	R50 543 487	Maintenance cover	1			
10.	R50 522 717	Filter	4	▲		
11.	R50 544 710	Lossnay core	2	▲	With filter stopper	
12.	R50 544 382	Core guide(right)	1			
13.	R50 466 344	Hinge	1			
14.	Y50 029 712	Fix piece	2			



* shows accessory parts.


Model LGH-100RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 218 067	Special nut(12)	2		Left-handed	
22.	K83 466 113	Washer(12)	2			
23.	R50 543 480	Centrifugal fan	2	▲	φ 245	
24.	R50 543 709	Fan base	2			
25.	R50 543 708	Inlet ring	2			
26.	H00 061 050	Nut(6)	8			
27.	Y50 033 104	Key	2		5×5×11.5	
28.	Y50 118 451	Motor	2	▲		
29.	Y50 117 712	Motor fix plate	2			
30.	H00 189 007	PTT screw 5×10	16			
31.	M34 043 080	Special washer(6)	8			
32.	H00 157 008	PT screw 6×20	8			
33.	M45 649 226	Cord bush	4			
34.	Y50 115 709	Connector cover	2			
35.	M45 017 228	Cord band	2			
36.	Y50 115 710	Connector plate	2			
37.	H00 312 007	PTT screw 4×6	2			
38.	R50 543 489	Separator	2			
39.	D41 123 223	Lead wire clip	1			



Model LGH-100RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
51.	R50 533 693	Fix plate	1			
52.	Y50 115 708	Damper motor cover	1			
53.	Y50 115 225	Bush	1			
54.	R50 351 225	Cord bush	1			
55.	Y50 061 260	Damper motor	1	▲	AC220·240V	
56.	R50 054 225	Bush	1			
57.	Y50 117 151	Rod	1			
58.	Y50 115 705	Control cover	1			
59.	Y50 115 368	Wiring diagram	1			
60.	H00 003 005	PPT screw 3×8	1			
61.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
62.	H00 013 076	Lock washer(4)	2			
63.	Y50 115 216	Transformer	1	▲	AC230V	
64.	H00 011 008	PT screw 4×8(BS)	1			
65.	Y50 115 712	Terminal block fix plate	1			
66.	K83 170 228	Cord band	2			
67.	R50 546 705	Circuit fix plate	1			
68.	R50 476 225	Bush	1			
69.	H00 000 003	PP screw 4×8	2			
70.	H00 154 005	PPT screw 4×12	1			
71.	M13 100 242	Terminal block	1	▲	3P	
72.	Y50 118 287	Capacitor	2	▲	9.0 μ F·440VAC	
73.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
74.	R50 548 167	Thermistor	1	▲		
75.	Y50 115 711	Side plate	1			
76.	K82 163 225	Bush	2			
77.	Y55 001 223	Cord clip	1			



* shows accessory parts.

Model LGH-150RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 543 487	Maintenance cover	2			
2.	R50 541 045	Special screw	4			
3.	R50 522 710	Filter stopper	16			
4.	R50 543 383	Core guide(left)	2			
5.	H00 000 487	PTT screw 4×8	99			
6.	R50 545 704	Flange	2			
7.	R50 466 344	Hinge	2			
8.	R50 111 381	Hanger	8			
9.	H00 000 244	PT screw 6×12	40			
10.	R50 529 717	Filter	8	▲		
11.	R50 543 711	Lossnay core	4	▲	With filter stopper	
12.	R50 543 384	Core guide(right)	2			
13.	Y50 029 712	Fix piece	4			
14.	Y50 118 711	Fix plate	4			
15.	Y50 021 609	Flange	4			



* shows accessory parts.


Model LGH-150RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 218 067	Special nut(12)	4		Left-handed	
22.	K83 466 113	Washer(12)	4			
23.	R50 543 480	Centrifugal fan	4	▲	φ 245	
24.	R50 543 709	Fan base	4			
25.	R50 543 708	Inlet ring	4			
26.	H00 061 050	Nut(6)	16			
27.	Y50 033 104	Key	4		5×5×11.5	
28.	Y50 117 454	Motor	4	▲		
29.	Y50 117 712	Motor fix plate	4			
30.	H00 189 007	PTT screw 5×10	32			
31.	M34 043 080	Special washer(6)	16			
32.	H00 157 008	PT screw 6×20	16			
33.	M45 649 226	Cord bush	8			
34.	Y50 115 709	Connector cover	4			
35.	M45 017 228	Cord band	4			
36.	Y50 115 710	Connector plate	4			
37.	H00 312 007	PTT screw 4×6	4			
38.	R50 543 489	Separator	4			
39.	D41 123 223	Lead wire clip	2			



Model LGH-150RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
51.	R50 541 706	Damper motor cover	2			
52.	H00 013 076	Lock washer(4)	4			
53.	H00 000 349	PT screw 4×8	2			
54.	R50 541 225	Bush	2			
55.	R50 476 225	Bush	6			
56.	H00 000 007	PPT screw 4×25	4			
57.	Y50 123 260	Damper motor	2	▲	AC100V	
58.	R50 543 150	Rod	2			
59.	Y50 118 707	Control cover	1			
60.	Y50 118 368	Wiring diagram	1			
61.	X40 181 226	Cord clamber	1			
62.	D41 133 225	Cord clamber	3			
63.	D43 008 223	Cord clamber	1			
64.	Y50 118 288	Capacitor	4	▲	7.0 μ F·440VAC	
65.	Y50 118 710	Connector support	1			
66.	K83 170 228	Cord band	3			
67.	H00 000 384	PPT screw 3×6	12			
68.	Y50 009 268	Relay	6	▲		
69.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
70.	D40 169 382	Circuit fix plate	1			
71.	H00 000 003	PP screw 4×8	6			
72.	Y50 075 216	Transformer	2	▲	AC220·240V	
73.	Y50 118 708	Control base	1			
74.	H00 011 008	PT screw 4×8(BS)	2			
75.	R50 548 167	Thermistor	1	▲		
76.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
77.	H00 003 005	PPT screw 3×8	1			
78.	Y55 001 223	Cord clip	2			
79.	H00 000 488	PTT screw 4×12	1			
80.	M13 100 242	Terminal block	1	▲	3P	
81.	Y50 118 709	Core guide(cord)	1			
82.	K83 223 225	Bush	2			
83.	Y50 138 728	Control fix plate	1			
84.	D41 004 363	Cord band	1			
85.	Y50 115 216	Transformer	1	▲	AC230V	



* shows accessory parts.

Model LGH-200RX5-E


No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
1.	R50 543 487	Maintenance cover	2			
2.	R50 541 045	Special screw	4			
3.	R50 522 710	Filter stopper	16			
4.	R50 544 381	Core guide(left)	2			
5.	H00 000 487	PTT screw 4×8	99			
6.	R50 545 704	Flange	2			
7.	R50 466 344	Hinge	2			
8.	R50 111 381	Hanger	8			
9.	H00 000 244	PT screw 6×12	40			
10.	R50 522 717	Filter	8	▲		
11.	R50 544 710	Lossnay core	4	▲	With filter stopper	
12.	R50 544 382	Core guide(right)	2			
13.	Y50 029 712	Fix piece	4			
14.	Y50 118 711	Fix plate	4			
15.	Y50 021 609	Flange	4			



* shows accessory parts.


Model LGH-200RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
21.	R50 218 067	Special nut(12)	4		Left-handed	
22.	K83 466 113	Washer(12)	4			
23.	R50 543 480	Centrifugal fan	4	▲	φ 245	
24.	R50 543 709	Fan base	4			
25.	R50 543 708	Inlet ring	4			
26.	H00 061 050	Nut(6)	16			
27.	Y50 033 104	Key	4		5×5×11.5	
28.	Y50 118 451	Motor	4	▲		
29.	Y50 117 712	Motor fix plate	4			
30.	H00 189 007	PTT screw 5×10	32			
31.	M34 043 080	Special washer(6)	16			
32.	H00 157 008	PT screw 6×20	16			
33.	M45 649 226	Cord bush	8			
34.	Y50 115 709	Connector cover	4			
35.	M45 017 228	Cord band	4			
36.	Y50 115 710	Connector plate	4			
37.	H00 312 007	PTT screw 4×6	4			
38.	R50 543 489	Separator	4			
39.	D41 123 223	Lead wire clip	2			



Model LGH-200RX5-E

No.	Parts No.	Name of part	Q'ty pcs/unit	Critical for safety	Remarks	Price
51.	R50 541 706	Damper motor cover	2			
52.	H00 013 076	Lock washer(4)	4			
53.	H00 000 349	PT screw 4×8	2			
54.	R50 541 225	Bush	2			
55.	R50 476 225	Bush	6			
56.	H00 000 007	PPT screw 4×25	4			
57.	Y50 123 260	Damper motor	2	▲	AC100V	
58.	R50 543 150	Rod	2			
59.	Y50 118 707	Control cover	1			
60.	Y50 118 368	Wiring diagram	1			
61.	X40 181 226	Cord clamper	1			
62.	D41 133 225	Cord clamper	3			
63.	D43 008 223	Cord clamper	1			
64.	Y50 119 287	Capacitor	4	▲	9.0 μ F·440VAC	
65.	K83 170 228	Cord band	3			
66.	H00 000 384	PPT screw 3×6	12			
67.	Y50 009 268	Relay	6	▲		
68.	Y50 118 708	Control base	1			
69.	Y50 118 710	Connector support	1			
70.	Y50 115 171	Circuit board	1	▲	LG-X3-E	
71.	D40 169 382	Circuit fix plate	1			
72.	H00 000 003	PP screw 4×8	6			
73.	Y50 075 216	Transformer	2	▲	AC220·240V	
74.	H00 011 008	PT screw 4×8(BS)	2			
75.	Y50 119 167	Thermistor	1	▲		
76.	Y50 047 231	Connection cable	1		SLIM-LOSSNAY	
77.	H00 003 005	PPT screw 3×8	1			
78.	Y55 001 223	Cord clip	2			
79.	H00 000 488	PTT screw 4×12	1			
80.	M13 100 242	Terminal block	1	▲	3P	
81.	Y50 118 709	Core guide(cord)	1			
82.	K83 223 225	Bush	2			
83.	Y50 138 728	Control fix plate	1			
84.	D41 004 363	Cord band	1			
85.	Y50 115 216	Transformer	1	▲	AC230V	



* shows accessory parts.