

Revision B:

- MUZ-LN25VG2 - **E1**, **ET1**,
MUZ-LN35VG2 - **E1**, **ET1**, and
MUZ-LN50VG2 - **E1**, **ET1** have been added.
- Some descriptions have been modified.

OBB767 REVISED EDITION-A is void.

OUTDOOR UNIT

No. OBB767
REVISED EDITION-B

PARTS CATALOG

MUZ-LN25VG - **E1**, **ER1**, **ET1**

MUZ-LN35VG - **E1**, **ER1**, **ET1**


MUZ-LN50VG - **E1**, **ER1**, **ET1**

MUZ-LN60VG - **E1**, **ER1**, **ET1**

MUZ-LN25VG2 - **E1**, **ET1**

MUZ-LN35VG2 - **E1**, **ET1**

MUZ-LN50VG2 - **E1**, **ET1**



MUZ-LN25VG
MUZ-LN35VG

CONTENTS

1. SERVICE PARTS LIST 2

SERVICE MANUAL (OBH767)

Revision A:

- Part number for INVERTER P.C. BOARD has been changed.


Revision B:

- MUZ-LN25VG2 - [E1], [ET1], MUZ-LN35VG2 - [E1], [ET1], and MUZ-LN50VG2 - [E1], [ET1] have been added.
- Some descriptions have been modified.

1 SERVICE PARTS LIST

MUZ-LN25VG

1-1. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS



1-1. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS


Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit			Remarks
				MUZ-LN25			
				VG- E1	VG- ER1	VG- ET1	
1	E22 J63 232	CABINET		1	1	1	
2	E22 J63 531	ICE GUARD		1	1	1	
3	E22 Y84 521	GRILLE		1	1	1	
4	E22 927 501	PROPELLER FAN		1	1	1	
5	E22 Y84 290	BASE		1	1	1	
6	E22 065 506	COMPRESSOR RUBBER SET		3	3	3	3 RUBBERS/SET
7	E22 R81 900	COMPRESSOR	MC	1	1	1	KVB073FYXMC
8	E22 T66 661	STOP VALVE (GAS)		1	1	1	ø9.52
9	E22 T66 662	STOP VALVE (LIQUID)		1	1	1	ø6.35
10	E22 L59 245	SERVICE PANEL		1	1	1	
11	E22 G11 233	BACK PANEL		1	1	1	
12	E22 Y84 640	EXPANSION VALVE		1	1	1	
13	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	1	
14	E22 R81 961	4-WAY VALVE		1	1	1	
15	E22 930 079	THERMO HOLDER		1	1	1	
16	E22 930 525	CONDENSER WIRE NET		1	1	1	
17	E22 930 523	CONDENSER NET		1	1	1	
18	E22 G11 293	SEPARATOR		1	1	1	
19	E22 929 515	MOTOR SUPPORT		1	1	1	
20	E22 L85 297	TOP PANEL		1	1	1	
21	E22 Y84 630	OUTDOOR HEAT EXCHANGER		1	1	1	
22	E22 Y84 301	OUTDOOR FAN MOTOR	MF	1	1	1	RC0J50-□□
(23)	E22 J47 936	CAPILLARY TUBE		1	1	1	ø4.0×ø2.4×240
(24)	E22 838 704	DRAIN SOCKET		1	1	1	



MUZ-LN25VG

1-2. OUTDOOR UNIT ELECTRICAL PARTS






1-2. OUTDOOR UNIT ELECTRICAL PARTS

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit			Remarks
				MUZ-LN25			
				VG- ET1	VG- ER1	VG- ET1	
1	E22 G11 337	REACTOR	L61	1	1	1	
2	E22 R81 306	THERMISTOR SET	RT61, RT62	1	1	1	DEFROST, DISCHARGE
3	E22 927 308	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	1	
4	E22 P72 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	1	
5	E22 R81 490	R.V. COIL	21S4	1	1	1	
6	E22 T95 374	TERMINAL BLOCK	TB1	1	1	1	5 P
7	E22 59E 451	INVERTER P.C. BOARD		1	1	1	Includes heat sink and RT64


MUZ-LN25VG2
1-3. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS



1-3. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS


Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN25		
				VG2- 	VG2- 	
1	E22 J63 232	CABINET		1	1	
2	E22 J63 531	ICE GUARD		1	1	
3	E22 Y84 521	GRILLE		1	1	
4	E22 95B 501	PROPELLER FAN		1	1	
5	E22 Y84 290	BASE		1	1	
6	E22 065 506	COMPRESSOR RUBBER SET		3	3	3 RUBBERS/SET
7	E22 R81 900	COMPRESSOR	MC	1	1	KVB073FYXMC
8	E22 T66 661	STOP VALVE (GAS)		1	1	ø9.52
9	E22 T66 662	STOP VALVE (LIQUID)		1	1	ø6.35
10	E22 L59 245	SERVICE PANEL		1	1	
11	E22 G11 233	BACK PANEL		1	1	
12	E22 Y84 640	EXPANSION VALVE		1	1	
13	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	
14	E22 21G 645	EXPANSION VALVE ASSEMBLY		1	1	Includes LEV body and capillary tube
15	E22 R81 961	4-WAY VALVE		1	1	
16	E22 930 079	THERMO HOLDER		1	1	
17	E27 M71 078	THERMO HOLDER COVER		1	1	
18	E22 930 525	CONDENSER WIRE NET		1	1	
19	E22 930 523	CONDENSER NET		1	1	
20	E22 G11 293	SEPARATOR		1	1	
21	E22 14F 515	MOTOR SUPPORT		1	1	
22	E22 L85 297	TOP PANEL		1	1	
23	E22 Y84 630	OUTDOOR HEAT EXCHANGER		1	1	
24	E22 97B 301	OUTDOOR FAN MOTOR	MF	1	1	RC0J50-□□
25	E22 J47 936	CAPILLARY TUBE		1	1	ø4.0×ø2.4×240
26	E22 838 704	DRAIN SOCKET		1	1	



MUZ-LN25VG2

1-4. OUTDOOR UNIT ELECTRICAL PARTS






1-4. OUTDOOR UNIT ELECTRICAL PARTS

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN25		
				VG2- 	VG2- 	
1	E22 G10 337	REACTOR	L61	1	1	
2	E22 R81 306	THERMISTOR SET	RT61, RT62	1	1	DEFROST, DISCHARGE
3	E22 927 308	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	
4	E22 P72 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	
5	E22 R81 490	R.V. COIL	21S4	1	1	
6	E22 T95 374	TERMINAL BLOCK	TB1	1	1	5 P
7	E22 30J 451	INVERTER P.C. BOARD		1	1	Includes heat sink and RT64

MUZ-LN35VG


1-5. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS



1-5. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS


Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit			Remarks
				MUZ-LN35			
				VG- E1	VG- ER1	VG- ET1	
1	E22 J63 232	CABINET		1	1	1	
2	E22 J63 531	ICE GUARD		1	1	1	
3	E22 Y84 521	GRILLE		1	1	1	
4	E22 927 501	PROPELLER FAN		1	1	1	
5	E22 Y84 290	BASE		1	1	1	
6	E22 C34 506	COMPRESSOR RUBBER SET		3	3	3	3 RUBBERS/SET
7	E22 Y85 900	COMPRESSOR	MC	1	1	1	SVB092FBAMT
8	E22 T66 661	STOP VALVE (GAS)		1	1	1	ø9.52
9	E22 T66 662	STOP VALVE (LIQUID)		1	1	1	ø6.35
10	E22 L59 245	SERVICE PANEL		1	1	1	
11	E22 G15 233	BACK PANEL		1	1	1	
12	E22 Y84 640	EXPANSION VALVE		1	1	1	
13	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	1	
14	E22 R81 961	4-WAY VALVE		1	1	1	
15	E22 930 079	THERMO HOLDER		1	1	1	
16	E22 930 525	CONDENSER WIRE NET		1	1	1	
17	E22 930 523	CONDENSER NET		1	1	1	
18	E22 G11 293	SEPARATOR		1	1	1	
19	E22 929 515	MOTOR SUPPORT		1	1	1	
20	E22 L85 297	TOP PANEL		1	1	1	
21	E22 Y84 630	OUTDOOR HEAT EXCHANGER		1	1	1	
22	E22 Y84 301	OUTDOOR FAN MOTOR	MF	1	1	1	RC0J50-□□
②③	E22 J47 936	CAPILLARY TUBE		1	1	1	ø4.0×ø2.4×240
②④	E22 838 704	DRAIN SOCKET		1	1	1	



MUZ-LN35VG

1-6. OUTDOOR UNIT ELECTRICAL PARTS






1-6. OUTDOOR UNIT ELECTRICAL PARTS

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit			Remarks
				MUZ-LN35			
				VG- ET1	VG- ER1	VG- ET1	
1	E22 G11 337	REACTOR	L61	1	1	1	
2	E22 R81 306	THERMISTOR SET	RT61, RT62	1	1	1	DEFROST, DISCHARGE
3	E22 927 308	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	1	
4	E22 P72 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	1	
5	E22 R81 490	R.V. COIL	21S4	1	1	1	
6	E22 T95 374	TERMINAL BLOCK	TB1	1	1	1	5 P
7	E22 60E 451	INVERTER P.C. BOARD		1	1	1	Includes heat sink and RT64

MUZ-LN35VG2


1-7. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS




1-7. OUTDOOR UNIT STRUCTURAL PARTS AND FUNCTIONAL PARTS

Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN35		
				VG2- 	VG2- 	
1	E22 J63 232	CABINET		1	1	
2	E22 J63 531	ICE GUARD		1	1	
3	E22 Y84 521	GRILLE		1	1	
4	E22 95B 501	PROPELLER FAN		1	1	
5	E22 Y84 290	BASE		1	1	
6	E22 C34 506	COMPRESSOR RUBBER SET		3	3	3 RUBBERS/SET
7	E22 Y85 900	COMPRESSOR	MC	1	1	SVB092FBAMT
8	E22 T66 661	STOP VALVE (GAS)		1	1	ø9.52
9	E22 T66 662	STOP VALVE (LIQUID)		1	1	ø6.35
10	E22 L59 245	SERVICE PANEL		1	1	
11	E22 G15 233	BACK PANEL		1	1	
12	E22 Y84 640	EXPANSION VALVE		1	1	
13	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	
14	E22 21G 645	EXPANSION VALVE ASSEMBLY		1	1	Includes LEV body and capillary tube
15	E22 R81 961	4-WAY VALVE		1	1	
16	E22 930 079	THERMO HOLDER		1	1	
17	E27 M71 078	THERMO HOLDER COVER		1	1	
18	E22 930 525	CONDENSER WIRE NET		1	1	
19	E22 930 523	CONDENSER NET		1	1	
20	E22 G11 293	SEPARATOR		1	1	
21	E22 14F 515	MOTOR SUPPORT		1	1	
22	E22 L85 297	TOP PANEL		1	1	
23	E22 Y84 630	OUTDOOR HEAT EXCHANGER		1	1	
24	E22 97B 301	OUTDOOR FAN MOTOR	MF	1	1	RC0J50-□□
	E22 J47 936	CAPILLARY TUBE		1	1	ø4.0×ø2.4×240
	E22 838 704	DRAIN SOCKET		1	1	



MUZ-LN35VG2
1-8. OUTDOOR UNIT ELECTRICAL PARTS






1-8. OUTDOOR UNIT ELECTRICAL PARTS

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN35		
				VG2- 	VG2- 	
1	E22 20A 337	REACTOR	L61	1	1	
2	E22 R81 306	THERMISTOR SET	RT61, RT62	1	1	DEFROST, DISCHARGE
3	E22 927 308	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	
4	E22 P72 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	
5	E22 R81 490	R.V. COIL	21S4	1	1	
6	E22 T95 374	TERMINAL BLOCK	TB1	1	1	5 P
7	E22 31J 451	INVERTER P.C. BOARD		1	1	Includes heat sink and RT64

MUZ-LN50VG- **E1** MUZ-LN50VG- **ER1**

1-9. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS




1-9. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS

Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN50		
				VG- E1	VG- ER1	
1	E22 Y86 297	TOP PANEL		1	1	
2	E22 Y86 630	OUTDOOR HEAT EXCHANGER		1	1	
3	E22 Y86 301	OUTDOOR FAN MOTOR	MF	1	1	RC0J50-□□
4	E22 Y86 501	PROPELLER FAN		1	1	
5	E22 Y86 232	CABINET		1	1	
6	E22 Y86 531	ICE GUARD		1	1	
7	E22 Y86 521	GRILLE		1	1	
8	E22 Y84 290	BASE		1	1	
9	E22 Y86 293	SEPARATOR		1	1	
10	E22 C34 506	COMPRESSOR RUBBER SET		3	3	3 RUBBERS/SET
11	E22 R83 900	COMPRESSOR	MC	1	1	SVB130FBBMT
12	E22 Y86 661	STOP VALVE (GAS)		1	1	ø9.52
13	E22 838 704	DRAIN SOCKET		1	1	
14	E22 Y86 662	STOP VALVE (LIQUID)		1	1	ø6.35
15	E22 Y84 640	EXPANSION VALVE		1	1	
16	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	
17	E22 Y86 490	R.V. COIL	21S4	1	1	
18	E22 J44 961	4-WAY VALVE		1	1	
19	E22 Y86 650	VALVE COVER		1	1	
20	E22 Y86 245	SERVICE PANEL		1	1	
21	E22 Y86 233	BACK PANEL		1	1	
22	E22 Y86 309	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	
23	E22 C34 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	
24	E22 Y86 306	THERMISTOR SET	RT61, RT62	1	1	DEFROST, DISCHARGE
25	E22 H21 337	REACTOR	L61	1	1	
26	E22 T95 374	TERMINAL BLOCK	TB1	1	1	5 P
27	E22 61E 451	INVERTER P.C. BOARD		1	1	Includes heat sink and RT64
28	E22 Y86 525	CONDENSER WIRE NET		1	1	
29	E22 Y86 515	MOTOR SUPPORT		1	1	
30	E22 22A 079	THERMO HOLDER		1	1	
③①	E22 J47 936	CAPILLARY TUBE		1	1	ø4.0 × ø2.4 × 240
③②	E22 F35 936	CAPILLARY TUBE		2	2	ø3.0 × ø2.0 × 210

MUZ-LN50VG- ET1

1-10. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS




1-10. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS

Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit	Remarks
				MUZ-LN50	
				VG- ET1	
1	E12 Y86 297	TOP PANEL		1	
2	E12 Y86 630	OUTDOOR HEAT EXCHANGER		1	
3	E12 Y86 301	OUTDOOR FAN MOTOR	MF	1	RC0J50-□□
4	E12 Y86 501	PROPELLER FAN		1	
5	E12 Y86 232	CABINET		1	
6	E12 Y86 531	ICE GUARD		1	
7	E12 Y86 521	GRILLE		1	
8	E12 Y84 290	BASE		1	
9	E12 Y86 293	SEPARATOR		1	
10	E12 C34 506	COMPRESSOR RUBBER SET		3	3 RUBBERS/SET
11	E12 R83 900	COMPRESSOR	MC	1	SVB130FBBMT
12	E12 Y86 661	STOP VALVE (GAS)		1	ø9.52
13	E12 838 704	DRAIN SOCKET		1	
14	E12 Y86 662	STOP VALVE (LIQUID)		1	ø6.35
15	E12 Y84 640	EXPANSION VALVE		1	
16	E12 Y84 493	EXPANSION VALVE COIL	LEV	1	
17	E12 Y86 490	R.V. COIL	21S4	1	
18	E12 J44 961	4-WAY VALVE		1	
19	E12 Y86 650	VALVE COVER		1	
20	E12 Y86 245	SERVICE PANEL		1	
21	E12 Y86 233	BACK PANEL		1	
22	E12 Y86 309	AMBIENT TEMPERATURE THERMISTOR	RT65	1	
23	E12 C34 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	
24	E12 Y86 306	THERMISTOR SET	RT61, RT62	1	DEFROST, DISCHARGE
25	E12 H21 337	REACTOR	L61	1	
26	E12 T95 374	TERMINAL BLOCK	TB1	1	5 P
27	E12 61E 451	INVERTER P.C. BOARD		1	Includes heat sink and RT64
28	E12 Y86 525	CONDENSER WIRE NET		1	
29	E12 Y86 515	MOTOR SUPPORT		1	
30	E12 22A 079	THERMO HOLDER		1	
③①	E12 J47 936	CAPILLARY TUBE		1	ø4.0 × ø2.4 × 240
③②	E12 F35 936	CAPILLARY TUBE		2	ø3.0 × ø2.0 × 210

MUZ-LN50VG2

1-11. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS




1-11. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS

Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit		Remarks
				MUZ-LN50		
				VG2- E1	VG2- ET1	
1	E22 Y86 297	TOP PANEL		1	1	
2	E22 Y86 630	OUTDOOR HEAT EXCHANGER		1	1	
3	E22 Y86 301	OUTDOOR FAN MOTOR	MF	1	1	RC0J50-□□
4	E22 Y86 501	PROPELLER FAN		1	1	
5	E22 Y86 232	CABINET		1	1	
6	E22 Y86 531	ICE GUARD		1	1	
7	E22 Y86 521	GRILLE		1	1	
8	E22 Y84 290	BASE		1	1	
9	E22 Y86 293	SEPARATOR		1	1	
10	E22 C34 506	COMPRESSOR RUBBER SET		3	3	3 RUBBERS/SET
11	E22 R83 900	COMPRESSOR	MC	1	1	SVB130FBBMT
12	E22 Y86 661	STOP VALVE (GAS)		1	1	ø9.52
13	E22 838 704	DRAIN SOCKET		1	1	
14	E22 Y86 662	STOP VALVE (LIQUID)		1	1	ø6.35
15	E22 Y84 640	EXPANSION VALVE		1	1	
16	E22 41G 645	EXPANSION VALVE ASSEMBLY		1	1	Includes LEV body and capillary tube
17	E22 Y84 493	EXPANSION VALVE COIL	LEV	1	1	
18	E22 Y86 490	R.V. COIL	21S4	1	1	
19	E22 J44 961	4-WAY VALVE		1	1	
20	E22 Y86 650	VALVE COVER		1	1	
21	E22 Y86 245	SERVICE PANEL		1	1	
22	E22 Y86 233	BACK PANEL		1	1	
23	E22 Y86 309	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	
24	E22 C34 307	OUTDOOR HEAT EXCHANGER TEMPERATURE THERMISTOR	RT68	1	1	
25	E22 Y86 306	THERMISTOR SET	RT61, RT62	1	1	DEFROST, DISCHARGE
26	E22 N94 337	REACTOR	L61	1	1	
27	E22 T95 374	TERMINAL BLOCK	TB1	1	1	5 P
28	E22 61E 451	INVERTER P.C. BOARD		1	1	Includes heat sink and RT64
29	E22 Y86 525	CONDENSER WIRE NET		1	1	
30	E22 Y86 515	MOTOR SUPPORT		1	1	
③①	E22 J47 936	CAPILLARY TUBE		1	1	ø4.0 × ø2.4 × 240
③②	E22 F35 936	CAPILLARY TUBE		1	1	ø3.0 × ø2.0 × 210

MUZ-LN60VG

1-12. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS



1-12. OUTDOOR UNIT STRUCTURAL PARTS, ELECTRICAL PARTS AND FUNCTIONAL PARTS

Part numbers that are circled are not shown in the illustration.

No.	Part No.	Part Name	Symbol in Wiring Diagram	Q'ty/unit			Remarks
				MUZ-LN60			
				VG- <table border="1"><tr><td>E1</td></tr></table>	E1	VG- <table border="1"><tr><td>ER1</td></tr></table>	
E1							
ER1							
ET1							

1	E22 L87 297	TOP PANEL		1	1	1	
2	E22 Y87 630	OUTDOOR HEAT EXCHANGER		1	1	1	
3	E22 F28 301	OUTDOOR FAN MOTOR	MF	1	1	1	RC0J60-□□
4	E22 F28 501	PROPELLER FAN		1	1	1	
5	E22 817 009	HANDLE		1	1	1	
6	E22 R13 232	CABINET		1	1	1	
7	E22 Y87 521	FAN GUARD		1	1	1	Includes ice guard
8	E22 F28 290	BASE		1	1	1	
9	E22 C34 506	COMPRESSOR RUBBER SET		3	3	3	3 RUBBERS/SET
10	E22 R86 900	COMPRESSOR	MC	1	1	1	SVB172FCKMT
11	E22 G16 662	STOP VALVE (LIQUID)		1	1	1	ø6.35
12	E22 G16 661	STOP VALVE (GAS)		1	1	1	ø12.7
13	E22 Y84 640	EXPANSION VALVE		1	1	1	
14	E22 Y87 493	EXPANSION VALVE COIL	LEV	1	1	1	
15	E22 R84 490	R.V. COIL	21S4	1	1	1	
16	E22 J44 961	4-WAY VALVE		1	1	1	
17	E22 F28 650	VALVE COVER		1	1	1	
18	E22 Y87 245	SERVICE PANEL		1	1	1	
19	E22 J52 233	BACK PANEL		1	1	1	
20	E22 G16 309	AMBIENT TEMPERATURE THERMISTOR	RT65	1	1	1	
21	E22 R84 308	THERMISTOR SET	RT61, RT62, RT68	1	1	1	DEFROST, DISCHARGE, OUTDOOR HEAT EXCHANGER TEMPERATURE
22	E22 F29 374	TERMINAL BLOCK	TB1	1	1	1	3 P
23	E22 T16 374	TERMINAL BLOCK	TB2	1	1	1	3 P
24	E22 Y87 451	INVERTER P.C. BOARD		1	1	1	Includes heat sink and RT64
25	E22 R84 337	REACTOR	L	1	1	1	
26	E22 L87 523	CONDENSER NET		1	1	1	
27	E22 F28 079	THERMO HOLDER		1	1	1	
28	E22 F28 515	MOTOR SUPPORT		1	1	1	
29	E22 R86 293	SEPARATOR		1	1	1	
③⑩	E22 527 936	CAPILLARY TUBE		1	1	1	ø4.0 × ø2.4 × 100
③⑪	E22 F28 704	DRAIN SOCKET		1	1	1	

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2016 MITSUBISHI ELECTRIC CORPORATION

Issued: Dec. 2019. No. OBB767 REVISED EDITION-B

Issued: Jun. 2018. No. OBB767 REVISED EDITION-A

Published: Dec. 2016. No. OBB767

Made in Japan

Specifications are subject to change without notice.