Photo

Descriptions

TO BE CONFIRMED

Applicable Models

- MSC-GA20VB
- MSC-GA25VB
- MSC-GA35VB
- MSZ-CA25VB
- MSZ-CA35VB

Specifications

TO BE CONFIRMED

Dimensions

Unit : mm

How to Use / How to Install

## REPLACEMENT OF THE AIR CLEANING FILTER

When the capacity is lowered because of dirt, etc., it is necessary to replace the air cleaning filter.

### Air cleaning filter replacement (about once every 4 months)

1   **Remove the catechin air filter.**

Catechin air filter

2   **Remove the air cleaning filter (White bellows type).**

Air cleaning filter

`Air cleaning filter`

3   **Install a new air cleaning filter.**

4   **Install the catechin air filter and securely**

Install.

- If the air cleaning filter is clogged, it may lower the unit's capacity or cause condensation at the air outlet.
- The air cleaning filter is disposable. The standard usable term is about 4 months. However, if the colour of the filter turns to dark brown, replace the filter at once.

Air Cleaning Filter

Photo

## Descriptions

TO BE CONFIRMED

Applicable Models

- MS-GA50VB
- MS-GA60VB
- MS-GA80VB
- MSH-GA50VB
- MSH-GA60VB
- MSH-GA80VB
- MSH-CA50VB

Specifications

TO BE CONFIRMED

Dimensions

Unit : mm

FRONT

How to Use / How to Install

REPLACEMENT OF THE AIR CLEANING FILTER (OPTION)

When the capacity is lowered because of dirt, etc., it is necessary to replace the air cleaning filter.

**Air cleaning filter replacement**

1 Remove the catechin air filter.

Catechin air filter

2 Remove the air cleaning filter (White bellows type).


Air cleaning filter

About once every 4 months

1 Install a new air cleaning filter.

2 Install the catechin air filter and securely close the front panel.

Air cleaning filter

- · If the air cleaning filter is clogged, it may lower the unit's capacity or cause condensation at the air outlet.
- · The air cleaning filter is disposable. The standard usable term is about 4 months. However, if the colour of the filter turns to dark brown, replace the filter at once.