

Systemair TST

Operation and maintenance instruction



Cleaning

The diffuser Systemair TST can be cleaned using lukewarm water and a mild detergent.

It's easy to remove the lower plate, which is attached to the upper plate with springs.

Commissioning

See plenum box PER for k-factors and adjustment guide.