





NOTUS-R

Installation, maintenance and operation instructions







?

$q_v = 320 \text{ m}^3/\text{h}$

1.

Air flow settings $\Delta P = 50 \text{ Pa} \dots 1000 \text{ Pa}$							
Pos. No.	1	2	3	4	5	6	7
$q_v \text{ (m}^3/\text{h)}$	200	244	289	333	378	422	467
$q_v \text{ (l/s)}$	55,5	67,9	80,2	92,6	104,9	117,3	129,
$U_c \text{ (V)}$	0	1,2	2,3	3,5	5	??	??

$P = \frac{4 - 3}{333 - 289} \cdot (320 - 289) + 3$



$P = \underline{\underline{3,7}}$

2.

✓


$q_v = 320 \text{ m}^3/\text{h}$

NOTUS-R...M1



?

$$q_v = 320 \text{ m}^3/\text{h}$$



1.


Air flow settings $\Delta P = 50 \text{ Pa} \dots 1000 \text{ Pa}$

Pos. No.	1	2	3	4	5	6	7	8
q_v (m ³ /h)	200	244	289	333	378	422	467	511
q_v (l/s)	55,5	67,9	80,2	92,6	104,9	117,3	129,6	142,0
U_c (V)	0	1	2,3	3,5	5	??	??	??

$$U_c = \frac{3,5 - 2,3}{333 - 289} \cdot (320 - 289) + 2,3$$

$$U_c = 3,15 \text{ V}$$

2.



✓

$$q_v = 320 \text{ m}^3/\text{h}$$

