

# **Technical data sheet**

Modulating linear actuator for operating air control dampers and slide valves in ventilation and air-conditioning systems

- For air control dampers up to approx. 1 m<sup>2</sup>
- Actuating force 150 N
- Nominal voltage AC/DC 24 V
- Control: modulating DC 0 ... 10 V, position feedback DC 2 ... 10 V
- Lenght of stroke 100 or 200 mm, fixed



## **Overview of types**

Туре	Stroke	Operating range	Weight	
LH24A-SR100	100 mm, fixed	DC 2 10 V ≃ 0 100 mm	475 g	
LH24A-SR200	200 mm, fixed	DC 2 10 V ≃ 0 200 mm	510 g	

#### **Technical data**

Electrical data	Nominal voltage	AC 24 V, 50/60 Hz DC 24 V	
	Power supply range	AC/DC 19.2 28.8 V	
	Power consumption In operation At rest	1.5 W @ nominal force 0.5 W	
	For wire sizing	3 VA	
		Cable 1 m, 3 x 0.75 mm <sup>2</sup>	
Functional data	Actuating force	150 N @ nominal voltage	
	Control Control signal Y Operating range	DC 0 10 V, typical input impedance 100 kΩ See «Overview of types»	
	Position feedback (Measuring voltage U)	DC 2 10 V, max. 1 mA	
	Position accuracy	±5%	
	Stroke	See «Overview of types»	
	Direction of stroke at Y = 0 V	Reversible with switch 1  ₹ resp. 0  ±	
	Running time	150 s / 100 mm	
	Sound power level	<35 dB (A)	
Safety	Protection class	III Safety extra-low voltage	
	Degree of protection	IP54 in any mounting position	
	EMC	CE according to 89/336/EEC	
	Mode of operation	Type 1 (to EN 60730-1)	
	Rated impulse voltage Supply	0.8 kV (to EN 60730-1)	
	Control	0.8 kV (to EN 60730-1)	
	Control pollution degree	3 (to EN 60730-1)	
	Ambient temperature range	–30 +50 °C	
	Non-operating temperature	−40 +80°C	
	Ambient humidity range	95% r.H., non-condensating (to EN 60730-1)	
	Maintenance	Maintenance-free	
<b>Dimensions / Weight</b>	Dimensions	See «Dimensions» on page 3	
	Weight	See «Overview of types»	



Safety notes		
	<ul> <li>The actuator is not allowed to be used outside the specified field not in aircraft or any other form of air transport.</li> <li>Assembly must be carried out by trained personnel. Any legal reissued by authorities must be observed during assembly.</li> <li>The device may only be opened at the manufacturer's site. It doe that can be replaced or repaired by the user.</li> <li>The rotary supports and coupling pieces available as accessorie lateral forces are likely. In addition, the actuator must not be tightly bolted to the applicat movable via the rotary support (refer to «Assembly notes»).</li> <li>If the linear actuator is exposed to severely contaminated atmost precautions must be taken on the system side. Excessive depost prevent the gear rack from being extended and retracted correct.</li> <li>If not installed horizontally, the gear disengagement pushbutton there is no pressure on the gear rod.</li> <li>When calculating the required actuating force, the specifications or slide valve manufacturers (cross section, design, installation sconditions must be observed.</li> <li>If a rotary support and/or coupling piece is used, losses in the ad expected.</li> <li>The device contains electrical and electronic components and is of as household refuse. All locally valid regulations and required</li> </ul>	gulations or regulations s not contain any parts s must always be used if tion. It must remain ohere, appropriate its of dust, soot etc. can y. may only be actuated when supplied by the damper site), and the air flow ctuation force are to be not allowed to be disposed
Product features		
Mode of operation	The actuator is controlled by means of a standard control signal DC 0 10 V. It opens to the position dictated by this signal. The measuring voltage U allows the damper position (0 100%) to be electrically indicated and serves as a follow-up control signal for other actuators.	
Manual override	Manual operation is possible with the pushbutton (the gearing latch remains disengaged as long as the pushbutton is pressed or detented).	
High functional reliability	The actuator is overload-proof, requires no limit switches and automatically stops when the end stop is reached.	
Accessories		
	Description	Data sheet
Electrical accessories	Positioner, types SGA24, SGF24 und SGE24	T2 - SG24
	Range controller, type SBG24	T2 - SBG24
	Digital position indication, type ZAD24	T2 - ZAD24
Mechanical accessories	Rotary support to compensate lateral forces, type Z-DS1	T2 - Z-LHA
	Coupling piece, type Z-KS2	T2 - Z-LHA
	Mechanical limiter set, type Z-AS2	T2 - Z-LHA


## **Electrical installation**

## Wiring diagram

- Notes
   Connection via safety isolating transformer!
- Other actuators can be connected in parallel.


Direction of stroke

Please note the performance data!





## **Dimensions** [mm]



#### Assembly notes

## Application without lateral forces

#### Application with lateral forces

Caution If a rotary support and/or coupling piece is used, losses in the actuation force are to be expected.



The linear actuator is screwed directly to the housing at three points. Afterwards, the head of the gear rod is fastened to the moving part of the ventilation application (e.g. damper or slide valve).

The coupling piece with the internal thread (Z-KS2) is connected to the head of the gear rod. The rotary support (Z-DS1) is screwed to the ventilation application.

Afterwards, the linear actuator is screwed to the previously mounted rotary support with the enclosed screw. Afterwards, the coupling piece, which is mounted to the head of the gear rod, is attached to the moving part of the ventilation application (e.g. damper or slide valve). The transverse forces can be compensated for to a certain limit with the rotary support and/or coupling piece. The maximum permissible swivel angle of the rotary support and coupling piece is  $10^{\circ}$ , laterally and upwards.



